

HR1846

HR1847

HR1848

EN

User manual

DA

Brugervejledning

DE

Benutzerhandbuch

EL

Εγχειρίδιο χρήσης

ES

Manual del usuario

FI

Käyttöohje

FR

Mode d'emploi

IT

Manuale utente

NL

Gebruiksaanwijzing

NO

Brukerhåndbok

PT

Manual do utilizador

SV

Användarhandbok

TR

Kullanım kılavuzu

دليل المستخدم

AR

راهنمای کاربر

FA

PHILIPS

Specifications are subject to change without notice
© 2012 Koninklijke Philips Electronics N.V.
All rights reserved.

3140 035 30732

English

Congratulations on your purchase, and welcome to Philips!
To fully benefit from the support that Philips offers, register your product at www.Philips.com/welcome.

1 Important

Safety

Read this user manual carefully before you use this 4-in-1 juicer and save it for future reference.

⚡ Danger

- Don't immerse the motor unit of the juicer in water, any other fluid, nor rinse it under the tap. Use only a moist cloth to clean.

⚠ Warning

- Check if the voltage indicated on the juicer corresponds to the local power voltage before you connect it.
- Only connect the juicer to a grounded power outlet. Always make sure that the plug is inserted firmly into the power outlet.
- Do not use the appliance if the plug, the power cord, or other components are damaged.
- Assemble the juicer properly before plugging it into the power outlet.
- Make sure that the damaged power cord is replaced by Philips, a service center authorized by Philips or similarly qualified persons in order to avoid a hazard.
- If you detect cracks in the filter / rotating sieve or if the filter / rotating sieve is damaged in anyway, do not use the appliance anymore and contact the nearest Philips service center.
- Avoid touching the sharp blades, especially when you clean them and when the juicer is still connected to power outlet.
- The appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to make sure that they do not play with the juicer.
- Keep the power cord out of the reach of children. Do not let the power cord hang over the edge of the table or worktop on which the juicer stands.
- Do not plug in the juicer or press any of the buttons on the control panel with wet hands.
- Never use the accessories to turn the juicer on and off.
- Never let the juicer operate unattended.
- Make sure the blade unit is securely fastened to the accessories before you assemble them onto the motor unit.

⚠ Caution

- Never use any accessories or parts from other manufacturers or that Philips does not specifically recommend. If you use such accessories or parts, your guarantee becomes invalid.
- Do not remove accessories from the motor unit when the juicer is working.
- Never reach into the jar or bowl with your fingers or an object while the juicer is running.
- Do not exceed the quantities and processing times indicated in the recipe section.
- Unplug the juicer immediately after use, e.g. before unscrewing the jar.
- Avoid touching the sharp blades, especially when the juicer is still connected to power outlet. If the blades get stuck, unplug the appliance before removing the ingredients that are blocking the blades by using a spatula.
- Place the juicer on a stable, horizontal, and level surface.
- Switch off and unplug the juicer from the power supply before you take out and insert any accessories from the main unit.
- Always let the juicer cool down before you clean or move it.
- Always clean the juicer after use. You can clean the juicer in the dishwasher.
- Always unplug the juicer if not used for a longer period.
- This appliance is intended for household use only.
- Make sure all parts are correctly mounted before you switch on the appliance.
- Only use the appliance when both clamps are locked. Unlock the clamps after you have switched off the appliance and the sieve has stopped rotating.
- Food coloring can discolor components. This is normal and has no impact on use.

Electromagnetic fields (EMF)

This Philips appliance complies with all standards regarding electromagnetic fields (EMF). If handled properly and according to the instructions in this user manual, the appliance is safe to use based on scientific evidence available today.

Built-in safety lock

This feature ensures that you can only switch on the appliance if the blender jar and lid, the mill beaker or the chopper bowl and blade unit (specific types only) are assembled on the motor unit properly. If the blender jar and lid, the mill beaker or the chopper bowl and blade unit are correctly assembled, the built-in safety lock will be unlocked.

2 Overview

①	Measuring cup	⑭	Chopper blade unit (HR1846, HR1847, and HR1848 only)
②	Blender jar lid	⑮	Chopper rubber ring (HR1846, HR1847, and HR1848 only)
③	Filter	⑯	Chopper beaker (HR1846, HR1847, and HR1848 only)
④	Blender jar	⑰	Pusher
⑤	Blender rubber ring	⑱	Feeding tube
⑥	Blender blade unit	⑲	Lid
⑦	Central base	⑳	Sieve
⑧	Juice container	㉑	Juice collector
⑨	Juice container cover Spout	㉒	Locking clips
⑩	Spout	㉓	Driving shaft
⑪	Mill blade unit (HR1847, and HR1848 only)	㉔	Pulp container
⑫	Mill rubber ring (HR1847 and HR1848 only)	㉕	Switch
⑬	Mill beaker (HR1847 and HR1848 only)	㉖	Motor unit

3 Before first use

- Take out all the accessories.
- Clean the parts of the juicer thoroughly before using the juicer for the first time (see chapter "Cleaning").
- Make sure all parts are completely dry before you start using the juicer.

4 Using the juicer

Extracting Juice

The juicer can be used for preparing fresh fruit juices. Pulp, pips and skins will be separated. Make sure the control switch is off. Then, connect to the power socket.

- Clean and cut large ingredients into pieces that fit into the feeding tube.
- Turn the control switch to the suggested speed.
- Put your ingredients through the feeding tube.
- Push the ingredients gently down with the pusher.

✿ Tips

- Remove stones from cherries, plums, peaches, etc. You do not have to remove cores or seeds from fruits like melons, apples and grapes.
- Use fresh fruit and vegetables; they contain more juice. Particularly suitable for processing in the juicer extractor are pineapples, beetroots, celery stalks, apples, cucumbers, carrots, spinach, melons, tomatoes, oranges and grapes.
- You do not have to remove thin peels or skins. Only remove thick peels, e.g. those of oranges, pineapples and uncooked beetroots. Also remove the white pith of citrus fruits because it has a bitter taste.
- When you prepare apple juice, remember that the thickness of the apple juice depends on the apple you are using. The juicer the apple the thinner the juice. Choose an apple that produces the type of juice you prefer.
- Apple juice turns brown very quickly. You can slow down this process by adding a few drops of lemon juice.
- Fruits that contain starch, such as bananas, papayas, avocados, figs and mangoes are not suitable for processing in the juicer extractor. Use a food processor, blender or bar blender to process these fruits.
- Leaves and leafstalks of e.g. lettuce can also be processed in the juicer extractor.
- Drink the juice immediately after you have extracted it. If it is exposed to air for some time, the juice will lose its taste and nutritional value.
- You can get more juice output if you use softer force to push the fruit and vegetables down.

≡ Notes

- Do not exert too much pressure on the pusher, since this would affect the quality of the end result and it could even cause the sieve to come to a halt.
- Do not run the juicer continuously for more than 2 minutes. If you have not finished extracting juice, switch the juicer off, and allow it to cool down to room temperature before you continue processing.
- Do not reach into the sieve through the pulp outlet of the pulp collector.

⚠ Cautions

- Be careful not to exert too much pressure on the handle of the jar.
- Never fill the jar with ingredients that have a temperature of over 60°C.
- Never overfill the blender jar above the maximum level indication (1.0 liters) to avoid spillage.
- Always insert the measuring cup into the lid before you start processing.
- Do not run the blender for more than 3 minutes at a time. If you have not finished blending after 3 minutes, switch the blender off and let it cool down to room temperature before you continue processing.
- Never put your hand or any object in the jar while the blender is running.
- Always set the control knob to 0 before you open the lid.

Grinding

The mill attachment can be used for grinding dry ingredients only. Follow the assembling steps for grinding dry ingredients. Remember to install the mill rubber ring before use.

Put the ingredients in the beaker.

- Screw the blade unit onto the beaker. Fix it by turning it in the direction of the arrow.
- Turn the assembled mill upside down, place and lock it on the motor unit.
- Turn the control switch to the suggested speed.
- Once complete, switch off, unlock, and remove the mill from the motor unit.
- Unscrew the blade unit from the beaker.

≡ Notes

- The mill is not suitable for ice crushing. Use the blender.
- Do not fill the beaker beyond the maximum indication. See the table for the advised quantities.
- Never use the mill for more than 30 seconds without interruption.

✿ Chopping

The chopper attachment can be used for chopping ingredients such as nuts, meat, hard cheese, dried fruits, chocolate, garlic, herbs, dry bread etc.

Follow the assembling steps for chopping. Remember to install the chopper rubber ring before use.

- Put the ingredients in the beaker.
- Screw the blade unit onto the beaker. Fix it by turning it in the direction of the arrow.
- Turn the assembled chopper upside down, place and lock it on the motor unit.
- Switch the chopper on.
- When you have finished chopping, switch the chopper off.
- Unlock and remove the assembled chopper from the motor unit.
- Unscrew the blade unit from the beaker.

✿ Tips

- Cut large ingredients into pieces approximately 2 cm before processing.
- If the ingredients are not evenly distributed, turn the appliance off. Open the lid and distribute the ingredients evenly on the surface of the chopper. Turn the appliance on again.

≡ Notes

- The chopper is not suitable for chopping hard ingredients like coffee beans, dry beans, nutmeg and uncooked rice. Use the mill.
- Do not use the chopper for mixing liquids. Use the blender.
- The cutting edge of the blades are very sharp, avoid touching them.
- Never exceed the maximum quantity. See the table for the advised quantities.
- Never use the chopper for more than 30 seconds without interruption.

5 Cleaning

It is easiest to clean the juicer, its parts and accessories immediately after use.

≡ Notes

- Unplug the juicer before you started cleaning it.
- Wait until the juicer has cooled down sufficiently before cleaning it.
- All detachable accessories can be cleaned in dishwasher.
- Clean the motor unit with a moist cloth.
- Do not use scouring pads, abrasive cleaning agents or aggressive liquids such as petrol, alcohol or acetone to clean the appliance.

- After you unplug the juicer, detach the used accessories, rubber rings, and parts and clean them in lukewarm washing up liquid.
- Rinse all accessories and parts under a tap.
- To clean the blender jar, pour lukewarm water and some detergent into it.
- Turn and lock the blender jar onto the motor unit until it locks into position, and for a few seconds.
- Detach the blender jar, knife unit, and remove the lid and measuring cup. Clean and rinse them as well.
- For better cleaning, you can use the brush to clean.

6 Storage

- Keep it in dry places to avoid the sieve, blades get rusty.
- Plug could be inserted into the main unit for storage.

7 Recipes

With 4-in-1 juicer, you can experiment endlessly and try out all kind of recipes. You can make delicious juices, shakes, soups, and sauces in no time at all. To give you an idea of the possibilities, you can go to www.kitchen.philips.com.

For Juicing

Ingredients	Weight	Speed
Cucumbers/ Spinach/ Melons/ Tomatoes/ Oranges/ Lemon/ Grapes/ Berries	500g	1
Apples/ Carrots/ Pineapples/ Beetroots/ Celery/ Pear	500g	2

For blending, milling, and chopping

Features	Ingredients	Weight Speed - 2	Time
Blending	Smoothies	1000ml	60 sec.
	Shakes & mixed drinks	1000ml	60 sec.
	Fruits & vegetables	1000ml	60 sec.
	Soups	500ml	60 sec.
	Batters	1000ml	60 sec.
	Sauces	1000ml	60 sec.
	Baby food	500ml	60 sec.
Milling	Ice	6 pieces (approx. 38x30x23mm)	15 x 1sec.
	Coffee	50g	30 sec.
	Nuts	50-100g	30 sec.
	Cheese	50-100g	30 sec.
Chopping	Sesame seeds	50-100g	30 sec.
	Dry beans	50-100g	30 sec.
	Chili paste	50g	30 sec.
	Garlics	100g	5 x 1 sec.
	Cooked eggs	100g	5 x 1 sec.
	Meat & fish	100g	5 sec.
	Herbs	20g	5 x 1 sec.
	Cheese	100g	3 x 5 sec.
	Nuts	100g	2 x 10 sec.

✿ Tip

- For crushing ice in blender jar and chopping in chopper, it is suggested to use the pulse to have a better result. That is to turn the appliance on and off to simulate the pulse effect.

8 Environment

Do not throw away the appliance with normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you can help to preserve the environment.

9 Troubleshooting

If you encounter problems when using this juicer, check the following points before requesting service. If you cannot solve the problem, contact the Philips Consumer Care Center in your country.

Problem	Solution
The juicer does not work.	The juicer is equipped with a safety system. If the accessories are not properly connected with the motor unit, the juicer does not work. Check whether the accessories have been connected in the right way (see the various sections). Turn off the juicer first!
The knife unit/ motor unit is blocked.	Turn off the juicer and process a smaller quantity.
The motor unit gives an unpleasant smell during the first few times of use.	This is normal for the first few applications. If the smelling continues, check the quantity you are processing, the application time, or used speed.
The blender shows leakage.	Turn off the juicer. Release the knife unit by turning it anti-clockwise. Check whether the rubber ring is properly assembled on the knife unit (rest on flat position).
The lid and/or measuring cup of the blender show leakage.	Make sure the lid is attached properly, and the measuring cup fits well.
The sieve of the juicer makes contact with the feeding tube or shows a high vibration during processing.	Turn off the juicer. Check if the sieve is properly connected. The ribs on the bottom of the sieve should fit properly on the motor coupling opening. Check if the sieve is not damaged. Cracks, fissures, loose grater disc or any other irregularity may cause malfunction.
The mill / blender / chopper shows a high vibration, produces a lot of noise or the blade unit is out of alignment.	Check whether the knife is properly and firmly attached to the beaker.
The mill or chopper leaks.	Check whether the rubber ring is assembled in a correct way.
	Small amount of leakage is normal. Make sure the rubber ring is assembled properly. The ring should rest around all interface, in a flat position.
The fruit juice or soy milk contains a lot of pulp or skins after filtering from the filter accessory in the blender.	Make sure that the filter is placed properly in the blender jar, the lid is closed and the measuring cup is inserted in the lid.

1/4

