

ENGLISH
 General description (Fig. 1) 1 Spray nozzle 2 Cap of filling opening 3 Steam control ☞ = steam ironing ☹ = dry ironing - CALC CLEAN = Calc-Clean function - Steam boost button (Specific types only) 5 Spray button 6 Temperature dial 7 Temperature light (specific types only: with safety-auto off indication) 8 Mains cord 9 Type plate 10 Water tank with MAX water level indication 11 Soleplate Using the appliance Filling the water tank

Note: Your appliance has been designed to be used with tap water. If you live in an area with hard water, fast scale build-up may occur. Therefore, it is recommended to use 100% distilled or demineralized water to prolong the lifetime of your appliance.

Note: Do not put perfume, vinegar, starch, descaling agents, ironing aids, chemically descaled water or other chemicals in the water tank.

- 1 Set the steam control to position ☹ (dry ironing). (Fig. 2)

2 Fill the water tank up to the MAX indication (Fig. 3).

3 Close the cap of the filling opening.

Selecting temperature and steam setting				
Table 1				
Fabric type	Temperature setting	Steam setting	Steam boost (specific types only)	Spray
Linen	MAX	☞	Yes	Yes
Cotton	●●●	☞	Yes	Yes
Wool	●●	☞	No	Yes
Silk	●●	☞	No	Yes
Synthetic fabrics (e.g. acrylic, nylon, polyamide, polyester).	●	☹	No	No

Note: As indicated in the table above, do not use steam or steam boost at a low temperature, otherwise hot water may leak from the iron.

- 1 Consult table 1 to set the temperature dial to the appropriate setting for your garment (Fig. 4).

2 Put the iron on its heel and plug it in. The temperature light goes on to indicate that the iron is heating up (Fig. 5).

3 When the temperature light goes out, the iron has reached the correct temperature.

4 Consult table 1 to select a steam setting that corresponds to the temperature you have set (Fig. 6).

Features
 Dry ironing Set the steam control to ☹ (dry ironing) to iron without steam. (Fig. 2) Spray function Press the spray button to moisten the article to be ironed. This helps remove stubborn creases (Fig. 7). Steam boost function (specific types only) Press and release the steam boost button for a powerful boost of steam to remove stubborn creases (Fig. 8). Vertical steam (specific types only) You can use the steam boost function when you hold the iron in vertical position for removing creases from hanging clothes, curtains etc (Fig. 9). Safety auto-off function (specific types only) The iron switches off automatically if it has not been moved for 30 seconds in horizontal position or 8 minutes in vertical position. The auto-off light starts flashing (Fig. 10).

- To let the iron heat up again, pick up the iron or move it slightly until the auto-off light goes out.

Cleaning and maintenance

Cleaning

1

Set the steam control to ☹ (dry ironing), unplug the iron and let it cool down. (Fig. 2)

2

Pour any remaining water out of the water tank.

3

Wipe flakes and any other deposits off the soleplate with a damp cloth and a non-abrasive (liquid) cleaning agent.

Caution: To keep the soleplate smooth, avoid hard contact with metal objects. Never use a scouring pad, vinegar or other chemicals to clean the soleplate.

Note: Regularly rinse the water tank with tap water. Empty the water tank after rinsing it.

Calc-Clean function