

English

1 Your multicooker

Congratulations on your purchase, and welcome to Philips!
To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

2 Important

Read this safety leaflet carefully before you use the multicooker and save it for future reference.

Danger

- The appliance must not be immersed.


Warning

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Cooking appliances should be positioned in a stable situation with the handles (if any) positioned to avoid spillage of the hot liquids.
- This appliance is intended to be used in household and similar applications such as:
 - staff kitchen areas in shops, offices and other working environments;
 - farm houses;
 - by clients in hotels, motels and other residential type environments;
 - bed and breakfast type environments.
- Make sure that the damaged power cord is replaced by Philips, a service center authorized by Philips or similarly qualified persons in order to avoid a hazard.
- Make sure to avoid spillage on the power connector to avoid a potential hazard.
- Always follow the instructions and use the appliance properly to avoid potential injury.
- Caution: Surface of the heating element is subject to residual heat after use.
- The appliance is not intended to be operated by means of an external timer or a separate remote-control system.
- Check if the voltage indicated on the rice cooker corresponds to the local power voltage before you connect it.
- Only connect the rice cooker to a grounded power outlet. Always make sure that the plug is inserted firmly into the power outlet.
- Do not use the appliance if the plug, the power cord, the inner pot, the sealing ring, or the main body is damaged.


- Do not let the power cord hang over the edge of the table or worktop on which the rice cooker stands.
- Make sure the heating element, the temperature sensor, and the outside of the inner pot are clean and dry before you put the plug in the power outlet.
- Do not plug in the rice cooker or press any of the buttons on the control panel with wet hands.

Caution

- Never use any accessories or parts from other manufacturers or that Philips does not specifically recommend. If you use such accessories or parts, your guarantee becomes invalid.
- Do not expose the rice cooker to high temperatures, nor place it on a working or still hot stove or cooker.
- Do not expose the rice cooker to direct sunlight.
- Place the rice cooker on a stable, horizontal, and level surface.
- Always put the inner pot in the rice cooker before you put the plug in the power outlet and switch it on.
- Do not place the inner pot directly over an open fire to cook rice.



- Do not use the inner pot if it is deformed.
- The accessible surfaces may become hot when the rice cooker is operating. Take extra caution when touching the rice cooker.
- Beware of hot steam coming out of the steam vent during cooking or out of the rice cooker when you open the lid. Keep hands and face away from the rice cooker to avoid the steam.
- The inner pot and steamer during and after cooking process, may be hot and heavy.
- Do not lift and move the rice cooker while it is operating.
- Do not exceed the maximum water level indicated in the inner pot to prevent overflow which might cause potential hazard.
- Do not place the cooking utensils inside the pot while cooking, keeping warm or reheating rice.
- Only use the cooking utensils provided. Avoid using sharp utensils.
- To avoid scratches, it is not recommended to cook ingredients with crustaceans and shellfish. Remove the hard shells before cooking.



- Do not insert metallic objects or alien substances into the steam vent.
- Do not place a magnetic substance on the lid. Do not use the rice cooker near a magnetic substance.
- Always let the rice cooker cool down before you clean or move it.
- Always clean the rice cooker after use. Do not clean the rice cooker in dishwasher.
- Always unplug the rice cooker if not used for a longer period.
- If the rice cooker is used improperly or for professional or semiprofessional purposes, or if it is not used according to the instructions in this user manual, the guarantee becomes invalid and Philips refuses liability for any damage caused.


Power failure backup function

This appliance has a backup function that remembers the status before a power failure.

- If the power failure occurs during a cooking process, and the power supply is resumed within two hours, the countdown of the cooking time continues where it left off.
- If the power failure occurs when the appliance is at preset mode, and the power supply is resumed within two hours, the countdown of the preset time continues where it left off.
- If the power supply is resumed after two hours, the appliance will not resume the previous work, but be in standby mode.

Electromagnetic fields (EMF)

This Philips appliance complies with all applicable standards and regulations regarding exposure to electromagnetic fields.



3 What's in the box (fig. 1)

① Multicooker main unit	⑤ Measuring cup
② Power cord	⑥ Steam tray
③ Rice scoop	⑦ Warranty card
④ Soup ladle	⑧ User manual

4 Overview (fig. 2)

① Top lid	⑩ Main body
② Detachable inner lid	⑪ Rice scoop holder
③ Detachable steam vent cap	⑫ Power socket
④ Inner pot	⑬ Heating element
⑤ Lid release button	⑭ Cooker handle
⑥ Control panel	⑮ Water level indications

Controls overview (fig. 3)


⑰ Warm/off button	⑳ Preset button
⑱ Hour button	㉑ Child lock button
㉒ Minute button	㉒ Menu button
㉓ Cooking time button	㉓ Cook button
㉔ Display screen	

Cooking time regulating range

Program	Default cooking time	Time regulation	Preset time
Standard rice cooking	Around 45 minutes	N/A	1-24 hours
Ultra quick rice cooking	Around 40 minutes	N/A	1-24 hours
Small portion rice cooking	Around 35 minutes	N/A	1-24 hours
Reheat	Around 25 minutes	25 - 59 minutes	N/A
Brown rice	Around 80 minutes	N/A	1-24 hours
Congee	1 hour	1 - 4 hours	1-24 hours
Soup	1 hour	1 - 4 hours	1-24 hours
Claypot rice	80 minutes	N/A	1-24 hours
Cake	45 minutes	N/A	N/A
Steam	20 minutes	10 - 40 minutes	N/A
Warm	N/A	Activated automatically after cooking functions are finished.	

Note

- The cooking time is counted from start of cooking till the keep warm process. The actual cooking time may vary depending on the voltage, room temperature, season, and the amount of water used.



5 Using the multicooker

Tip

- To cancel an ongoing cooking process, press the warm/off button (⏻), and the multicooker will be in standby mode.
- To switch off, you need to unplug the multicooker.

Before first use

- Take out all the accessories from the inner pot, and remove the packaging of the inner pot.
- Clean the parts of the multicooker thoroughly before using the multicooker for the first time (see chapter 'Cleaning and Maintenance').

Note

- Make sure all parts are completely dry before you start using the multicooker.

Cooking rice (fig. 4 & 5)

There are three rice cooking functions: standard rice cooking, ultra-quick rice cooking and small portion rice cooking.

- Measure the rice using the measuring cup provided.
- Wash away the dusts and bran of the rice with tap water.
- Put the pre-washed rice in the inner pot.
- Add water to the level indicated on the scale inside the inner pot that corresponds to the number of cups of rice used. Then smooth the rice surface.
 - For instance, if you cook 4 cups of rice, add water up to the 4-cup level indicated on the scale.

Note

- The level marked inside the inner pot is just an indication; you can always adjust the water level for different types of rice and your own preference.
- Besides following the water level indications, you may also add rice and water at 1:1-1:2 ratio for rice cooking.
- Do not exceed the volume indicated nor exceed the maximum water level indicated in the inner pot, as this may cause the multicooker to overflow and cause potential hazard.

- Press the lid release button to open the lid.
- Wipe the outside of the inner pot dry, then put it in the multicooker. Check if the inner pot is in proper contact with the heating element.

Note

- Make sure that the outside of the inner pot is dry and clean, and that there is no foreign residue on the heating element.

- Close the lid of the multicooker, and put the plug in the power socket.
- Press the menu button (⏻) until the desired rice cooking function is selected.

- Press and hold the cook button (⏻) for 3 seconds to start cooking.
- When the cooking is finished, you will hear 4 beeps and the selected cooking function light will be off.
- The multicooker will be in keep warm mode automatically.
 - The keep-warm cursor (⏻) will be indicated.

Note

- After the cooking is finished, stir the rice and loosen it immediately to release excessive moisture for fluffy rice.
- Depending on the cooking conditions, the bottom portion of the rice may become slightly browned.

Reheating (fig. 6)

- Loosen the cooled rice and evenly distribute it in the inner pot.
- Pour some water onto the rice to prevent it from becoming too dry. The quantity of the water depends on the amount of rice.
- Follow steps 6 and 7 in "Cooking rice".
- Press the menu button (⏻) until the reheating function (⏻) is selected.
 - To set a different cooking time, refer to chapter "Adjusting the cooking time".
- Press and hold the cook button (⏻) for 3 seconds to start cooking.
- When the cooking is finished, you will hear 4 beeps and the selected cooking function light will be off.
- The multicooker will be in keep warm mode automatically.
 - The keep-warm cursor (⏻) will be indicated.

Cooking brown rice (fig. 7)

- Follow steps 1 to 7 in "Cooking rice".
- Press the menu button (⏻) until the brown rice cooking function (⏻) is selected.
- Press and hold the cook button (⏻) for 3 seconds to start cooking.
- When the cooking is finished, you will hear 4 beeps and the selected cooking function light will be off.
- The multicooker will be in keep warm mode automatically.
 - The keep-warm cursor (⏻) will be indicated.

Steaming (fig. 8)

- Pour some water into the inner pot.
- Put the food to be steamed on a plate or in the steam tray.
- Put the steam tray into the inner pot.
- If you are using a separate plate, put it into the steam tray.
- Close the lid of the multicooker, and put the plug in the power socket.
- Press the menu button (⏻) until the steaming function (⏻) is selected.
 - To set a different cooking time, refer to chapter "Adjusting the cooking time".
- Press and hold the cook button (⏻) for 3 seconds to start cooking.
- When the cooking is finished, you will hear 4 beeps and the selected cooking function light will be off.
- The multicooker will be in keep warm mode automatically.
 - The keep-warm cursor (⏻) will be indicated.
- Open the lid and carefully take out the steamed food from the plate or steam basket.

Note

- Use a kitchen glove or a cloth, as the plate and steam tray will be very hot.
- You can adjust the water level as needed. Do not exceed the 4-cup level indicated on the inside of the inner pot.

Baking cake (fig. 9)

- Whisk the ingredients for cake well.
- Coat the inner pot with some butter or cooking oil, and then pour the cake mixture into it.
- Follow steps 6 and 7 in "Cooking rice".

Note

- Keep the top lid closed when baking cake.

- Press the menu button (⏻) until the cake function (⏻) is selected.
- Press and hold the cook button (⏻) for 3 seconds to start cooking.
- When the cooking is finished, you will hear 4 beeps and the selected cooking function light will be off.
- The multicooker will be in keep warm mode automatically.
 - The keep-warm cursor (⏻) will be indicated.
- Open the lid and carefully take out the inner pot to cool down.
- After the inner pot has cooled down, put a plate or cake rack on top of the pot, and then flip over to take the cake out.

Note

- When you remove the inner pot from the multicooker, use a kitchen glove or a cloth, as the inner pot will be very hot.

Cooking congee (fig. 10)

- Follow steps 1 to 7 in "Cooking rice".

Note

- Do not exceed the water level indication for congee cooking, as this may cause the rice cooker to overflow and cause potential hazard.

- Press the menu button (⏻) until the congee function (⏻) is selected.
 - To set a different cooking time, refer to chapter "Adjusting the cooking time".
- Press and hold the cook button (⏻) for 3 seconds to start cooking.
- When the cooking is finished, you will hear 4 beeps and the selected cooking function light will be off.
- The multicooker will be in keep warm mode automatically.
 - The keep-warm cursor (⏻) will be indicated.

 Note
<ul style="list-style-type: none">It is normal to find the congee stickler if it is left in keep warm mode for too long.

Making soup (fig. 10)

- Put the ingredients and water for the soup in the inner pot.

 Note
<ul style="list-style-type: none">Do not exceed the maximum water level indicated inside the inner pot on the scale for congee cooking.

- Follow steps 6 and 7 in “Cooking rice”.
- Press the menu button until the soup function is selected.
- To set a different cooking time, refer to chapter “Adjusting the cooking time”.
- Press and hold the cook button for 3 seconds to start cooking.
- When the cooking is finished, you will hear 4 beeps and the selected cooking function light will be off.
- The multicooker will be in keep warm mode automatically.
 - The keep-warm cursor (保溫) will be indicated.

Cooking clay pot rice (fig. 11)

- Follow steps 1 to 7 in “Cooking rice”.
- Press the menu button until the claypot rice function is selected.
- Press and hold the cook button for 3 seconds to start cooking.
- When the rice is ready, the multicooker beeps for a while.
- Add the ingredients for the claypot rice by placing them on top of the rice. Close the lid to resume the cooking process.
- When the cooking is finished, you will hear 4 beeps and the selected cooking function light will be off.
- The multicooker will be in keep warm mode automatically.
 - The keep-warm cursor (保溫) will be indicated.

Adjusting the cooking time (fig. 12)

You can adjust the cooking time for reheat, congee, soup and steam. Refer to the “Functions overview” table for the time regulation of each function.

After you have selected the desired cooking function using the menu button, the default cooking time will be displayed on the screen.

- Press the cooking time button , and the cooking time starts flashing on the display screen.
- Press the minute and/or hour buttons to set the desired cooking time.

 Tip
<ul style="list-style-type: none">Press the minute button once to adjust the cooking time by 1 minute; press the hour button once to adjust the cooking time by 1 hour; press and hold the minute or hour button to fast forward in adjusting the cooking time.

Preset time for delayed cooking (fig. 13)

You can preset the delayed cooking time for different cooking functions except steam, reheat and cake. The preset timer is available up to 24 hours.

- Press the menu button until your preferred cooking function is selected.
- Press the preset time button , and the preset time starts flashing on the display screen.
- Press the minute and/or hour buttons to set the preset time.
- After the preset time is set, press and hold the cook button for 3 seconds to confirm the preset time.

 Note
<ul style="list-style-type: none">The cooking will be finished when the preset time has elapsed. If the preset time is shorter than the cooking time, the multicooker will start the cooking process immediately.

 Tip
<ul style="list-style-type: none">Press the minute button once to adjust the cooking time by 10 minutes; press the hour button once to adjust the cooking time by 1 hour; press and hold the minute or hour button to fast forward in adjusting the preset time.

Setting up child lock (fig. 14)

To protect your child from starting the multicooker, you may set up the child lock function.

- Press and hold the child lock button for 3 seconds to enter the child lock mode.
- The child lock icon appears on the display.
- To unlock, press and hold the child lock button for 3 seconds again.
- The child lock icon disappears from the display.

6 Cleaning and Maintenance

 Note
<ul style="list-style-type: none">Unplug the multicooker before starting to clean it. Wait until the multicooker has cooled down sufficiently before cleaning it. Make sure to clean the detachable inner lid after cooking, otherwise it will discolour and develop a foul odor.

Interior

- Soak the detachable inner lid in warm or cold water and wash with a sponge.
- Wipe the heating element with wrung out cloth.
- Remove all the food residues stuck to the multicooker with a bamboo stick or a chopstick.

 Exterior
<ul style="list-style-type: none">Wipe with a cloth damped with soap water. Only use soft and dry cloth to wipe the control panel. Make sure to remove all the food residues around the control buttons.

Accessories and inner pot

Rice scoop, soup ladle, inner pot, steam tray, and steam vent cap.

- Soak in hot water and clean with sponge.

 Note
<ul style="list-style-type: none">Do not place spoons, bowls or any other object in the inner pot that may damage the nonstick coating. Clean the inner pot immediately after using seasonings in it.

7 Recycling

Do not throw away the product with the normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you help to preserve the environment. Follow your country’s rules for the separate collection of electrical and electronic products. Correct disposal helps prevent negative consequences for the environment and human health.

8 Guarantee and service

If you need service or information, or if you have a problem, visit the Philips website at www.philips.com.tw or contact the Philips Customer Care Center in your country. You can find its phone number in the worldwide guarantee leaflet. If there is no Customer Care Center in your country, go to your local Philips dealer.

9 Troubleshooting

If you encounter problems when using this multicooker, check the following points before requesting service. If you cannot solve the problem, contact the Philips Consumer Care Center in your country.

Problem	Solution
	<ul style="list-style-type: none">If the multicooker is positioned on an uneven or tilted surface, the texture of the cooked rice may be too hard or too soft as the amount of water becomes inconsistent. The texture of rice varies depending on the brand of rice, where it was harvested, and how long it was stored (new crop or old crop). The texture of rice varies depending on the water and temperatures. Using the preset function may result in softer rice. This is normal. Using the ultra quick rice cooking menu setting may result in harder rice. This is normal. Check if the inner pot is deformed. There is not enough water. Add water according to the scale on the inside of the inner pot. You did not press and hold the cook button for 3 seconds to start cooking. Make sure that there is no foreign residue on the heating element and the outside of the inner pot before switching the multicooker on.
The rice is too soft, too hard, or not well cooked.	<ul style="list-style-type: none">Check if there are food residue on the heating plate or outside of the inner pot. Remove the food residue with a bamboo stick or a chopstick. You have not rinse the rice properly. Rinse the rice until the water runs clear. Check if the inner pot is deformed.
Water spills out of the multicooker during cooking.	<ul style="list-style-type: none">Make sure that you add water to the level indicated on the scale inside the inner pot that corresponds to the number of cups of rice used. Make sure the water does not exceed the maximum level on the scale, as this may cause the appliance to overflow during cooking.
The cake result is too hard.	Please use cake mix and follow the instructions provided in the user manual.
I cannot get to the desired cooking function.	<ul style="list-style-type: none">Press the menu button repeatedly to select the desired cooking function as shown by the display screen. Check if the keep-warm indicator is on. Deactivate keep-warm and try again. Check if the power cord is connected to the cooker properly and if the plug is inserted firmly into the power outlet.
Rice smells bad after cooking	<ul style="list-style-type: none">After cooking, make sure the steam vent cap, inner lid and inner pot are cleaned thoroughly. Clean the inner pot with some washing detergent and warm water.
The light on the button does not go on or the display does not function.	<ul style="list-style-type: none">There is a connection problem. Check if the power cord is connected to the cooker properly and if the plug is inserted firmly into the power outlet.
Error	Solution
Error message (E1, E2, E3, or E4) appears on the display.	<ul style="list-style-type: none">There has been a power failure during cooking. Take the appliance to your Philips dealer or a service center authorized by Philips.
The cooker does not switch to keep warm mode automatically.	<ul style="list-style-type: none">The temperature control is defective. Take the appliance to your Philips dealer or a service center authorized by Philips.

10 Specifications

Model Number	HD3075	HD3077
Rated power output	980W	980W
Rated capacity	4.0L	5.0L
Rice volume	2-8 cups	2-10 cups
Dimension(LxWxH)	404mm x 304mm x 233mm	
Net Weight	3.8 kg	

繁體中文

1 您的微電腦灶燒電子鍋

感謝您購買本產品。歡迎來到飛利浦的世界！請至 www.Philips.com/welcome 登錄您的產品，以獲得飛利浦提供的完整支援。

2 重要事項

使用微電腦灶燒電子鍋前，請先仔細閱讀此安全手冊，並保留說明以供日後參考。

危險

- 請勿浸泡本產品。

警告

- 本產品不適合供下列人士 (包括小孩) 使用：身體官能或心智能力退化者，或是經驗與使用知識缺乏者。他們需要有負責其安全的人員在旁監督，或指示產品的使用方法，方可使用。
- 請看管孩童，避免他們將本產品當成玩具。
- 請平穩放置烹煮電器，並注意把手 (如果有) 的位置，避免熱燙液體溢漏。
- 本產品為居家用途設計，而類似的應用包含：
 - 店家的員工廚房、辦公室與其他工作場所；
 - 農舍；
 - 供住宿的飯店、汽車旅館與其他居住場所；
 - 擺設床位與供應早餐的空間。
- 務請將損壞的電線交由飛利浦、飛利浦授權之服務中心，或是具備同資格之技師進行更換，以免發生危險。
- 務必遵循使用說明正確使用設備，避免潛在傷害。
- 注意：使用后，加熱元件表面仍有餘熱。

本產品並非為透過外部定時器或獨立遙控系統進行操作而設計。

- 在您連接電源之前，請檢查本地的電源電壓是否與微電腦迷你電子鍋所示的電壓相符。
- 微電腦迷你電子鍋僅可與已接地的電源插座連接。務必確保插頭穩固插到電源插座中。
- 如果插頭、電源線、內鍋、密封環或主體有損壞，請勿使用產品。
- 請勿讓電源線懸掛在微電腦迷你電子鍋所在的餐桌或流理台邊緣。
- 請先確定加熱板、溫度感應器與內鍋外側是否清潔、乾燥，再將插頭插入電源插座。
- 連接微電腦迷你電子鍋電源或按壓控制面板上的按鈕時，請確保雙手乾燥。

- 請勿使用其他製造商的任何配件或零件，或非由飛利浦建議之配件或零件。如果您使用此類配件或零件，保固即會失效。
- 請勿將微電腦迷你電子鍋暴露在高溫下，也請勿放置於正在使用 (或尚有餘溫) 的爐子或廚具上。

- 請勿將微電腦迷你電子鍋直接曝曬在陽光下。
- 請將微電腦迷你電子鍋放置在平穩的水平表面上。
- 請先將內鍋放在微電腦迷你電子鍋中，再將插頭插入插座，並開啟電源。
- 請勿直接將內鍋置於爐火上炊飯。
- 內鍋若變形請勿使用。
- 使用微電腦迷你電子鍋時，暴露在外的表面可能會變熱。觸碰微電腦迷你電子鍋時，請格外謹慎。

- 在烹煮過程中，熱氣可能會從蒸氣通氣孔冒出；若您掀開鍋蓋，熱氣可能會從微電腦迷你電子鍋冒出。手和臉必須遠離微電腦迷你電子鍋以避免蒸氣。
- 在烹煮期間與結束後，內鍋及蒸爐可能溫度很高且重量很重。
- 請勿將微電腦迷你電子鍋運作期間加以抬起或移動。
- 請勿超過內鍋所指示的最高水位，以免水溢出，造成潛在危險。
- 烹調、保溫或熱飯時，請勿在內鍋中放廚具。
- 請僅使用隨附廚具。避免使用鋒利的廚具。
- 為避免刮痕，不建議直接烹調含有甲殼類食材的食物。烹飪前請先移除其硬殼。
- 請勿將金屬製品或其他異物插入蒸氣通氣孔內。
- 請勿將磁性物質放到蓋子上。請勿將微電腦迷你電子鍋放在磁性物質附近使用。
- 清潔或移動微電腦迷你電子鍋之前，請務必先待其冷卻。
- 使用微電腦迷你電子鍋後，請務必加以清潔。請勿將微電腦迷你電子鍋放入洗碗機內清洗。

- 如果有較長時間不使用微電腦迷你電子鍋，請務必拔下其插頭。
- 如果不當使用微電腦迷你電子鍋、作為 (半) 專業用途，或未依照使用手冊操作，保固將無效，且飛利浦將不擔負任何損壞賠償責任。

- 烹調、保溫或熱飯時，請勿在內鍋中放廚具。
- 請僅使用隨附廚具。避免使用鋒利的廚具。
- 為避免刮痕，不建議直接烹調含有甲殼類食材的食物。烹飪前請先移除其硬殼。
- 請勿將金屬製品或其他異物插入蒸氣通氣孔內。
- 請勿將磁性物質放到蓋子上。請勿將微電腦迷你電子鍋放在磁性物質附近使用。
- 清潔或移動微電腦迷你電子鍋之前，請務必先待其冷卻。
- 使用微電腦迷你電子鍋後，請務必加以清潔。請勿將微電腦迷你電子鍋放入洗碗機內清洗。

- 如果有較長時間不使用微電腦迷你電子鍋，請務必拔下其插頭。
- 如果不當使用微電腦迷你電子鍋、作為 (半) 專業用途，或未依照使用手冊操作，保固將無效，且飛利浦將不擔負任何損壞賠償責任。

- 共有三種煮飯功能：標準煮、超快煮、少量米。
 - 使用所附的量杯來量米。
 - 用清水將米粒中的灰塵及米糠等雜物洗乾淨。
 - 將洗好的米倒入內鍋中。
 - 視所使用的米杯數，將內鍋中的水位加至相應的刻度，然後讓米均勻攤平。
 - 例如：如果您要煮 4 杯米，請將水加到 4 杯的水位刻度。
- 按下開蓋按鈕，打開鍋蓋。
- 將內鍋外部擦乾，然後將其放入微電腦灶燒電子鍋內。檢查內鍋是否與發熱盤良好接觸。

 備註
<ul style="list-style-type: none">內鍋內側所標示的水位僅供參考；您可以隨時針對不同的米以及自己的偏好來調整水位。 除了依照水位刻度標示，您也可以將米和水用 1:1-2 的比例煮飯。 請勿超過指示的量或超過內鍋所標示的最高水位，否則可能使水溢出微電腦灶燒電子鍋造成危險。

- 若電源供應於兩個小時後恢復，本產品將不會繼續先前的工作，並會進入待機模式。

電磁場 (EMF)

本飛利浦產品符合所有電磁波暴露的相關通用標準和法規。

3 內容物 (圖 1)

 微電腦灶燒電子鍋主機體	 量杯
 電源線	 蒸籠
 飯匙	 保證卡
 湯杓	 使用手冊

4 概覽 (圖 2)

 上蓋	 主裝置
 可拆卸蓋板組件	 飯勺架
 可拆卸式蒸氣閘	 電源插座
 內鍋	 發熱盤
 開蓋按鈕	 電子鍋把手
 控制面板	 水位刻度標示

控制項概覽 (圖 3)

 保溫/取消按鈕	 預約時間按鈕
 小時調整按鈕	 兒童鎖按鈕
 分鐘調整按鈕	 功能選擇按鈕
 烹調時間按鈕	 烹調按鈕
 液晶屏	

編程	預設烹調時間	時間控制	預約時間
標準煮	約 45 分鐘	N/A	1 至 24 小時
超快煮	約 40 分鐘	N/A	1 至 24 小時
少量米	約 35 分鐘	N/A	1 至 24 小時
再加熱	約 25 分鐘	25 至 59 分鐘	N/A
糙米飯	約 80 分鐘	N/A	1 至 24 小時
煮粥	1 小時	1 至 4 小時	1 至 24 小時
煲湯	1 小時	1 至 4 小時	1 至 24 小時
鍋巴飯	80 分鐘	N/A	1 至 24 小時
蛋糕	45 分鐘	N/A	N/A
清蒸	20 分鐘	10 至 40 分鐘	N/A
保溫	N/A	烹調功能結束後自動啟動。	

 備註
<ul style="list-style-type: none">時間為從炊飯開始到進入保溫狀態所需的時間。另因電壓、室溫、季節、水量等而異。

 備註
<ul style="list-style-type: none">由於內鍋會變得很快，將內鍋從微電腦灶燒電子鍋內取出時，請使用廚房手套或布。

 秘訣
<ul style="list-style-type: none">如欲取消進行中的烹調程序，按下保溫/取消按鈕 ，微電腦灶燒電子鍋將進入待機模式。 如欲關閉電源，您必須將電源線拔離插座。

第一次使用

- 從內鍋拿出所有配件，除去內鍋的包裝。
- 第一次使用微電腦灶燒電子鍋前，請先徹底清潔各部件 (請參閱「清潔與維護」單元)。

 備註
<ul style="list-style-type: none">開始使用微電腦灶燒電子鍋前，請確認所有零件都已經完全乾燥。

 備註
<ul style="list-style-type: none">內鍋內側所標示的水位僅供參考；您可以隨時針對不同的米以及自己的偏好來調整水位。 除了依照水位刻度標示，您也可以將米和水用 1:1-2 的比例煮飯。 請勿超過指示的量或超過內鍋所標示的最高水位，否則可能使水溢出微電腦灶燒電子鍋造成危險。

 備註
<ul style="list-style-type: none">內鍋內側所標示的水位僅供參考；您可以隨時針對不同的米以及自己的偏好來調整水位。 除了依照水位刻度標示，您也可以將米和水用 1:1-2 的比例煮飯。 請勿超過指示的量或超過內鍋所標示的最高水位，否則可能使水溢出微電腦灶燒電子鍋造成危險。

 備註
<ul style="list-style-type: none">請確定內鍋外部乾燥、乾淨，且發熱盤上没有異物殘留。

 備註
<ul style="list-style-type: none">蓋上微電腦灶燒電子鍋鍋蓋，並將插頭插入電源插座。 按下功能選擇按鈕 ，直到選擇想要的煮飯功能為止。 按住烹調按鈕 3 秒以開始烹調。 烹調完成後，您將聽到 4 聲響聲，所選的烹調功能燈將熄滅。 微電腦灶燒電子鍋將自動進入保溫模式。 <ul style="list-style-type: none">保溫指示燈 (保溫) 將亮起。

 備註
<ul style="list-style-type: none">炊飯結束後請立即攪拌米飯，使多餘的水分蒸發，以防米飯結塊或發粘。 因炊飯條件不同，有時煮好的米飯底部可能有淺黃色的鍋巴。

 再加熱 (圖 6)
<ol style="list-style-type: none">將放涼的米飯翻鬆，均勻地舖在內鍋中。 在米飯上倒一些水，避免飯變得太乾。水量取決於米飯量。 照「煮飯」中的步驟 6 和 7 操作。 按下功能選擇按鈕 ，直到選擇再加熱功能 (區區區)。 如欲設定不同的烹調時間，請參考「調整烹調時間」單元 按住烹調按鈕 3 秒以開始烹調。 微電腦灶燒電子鍋將自動進入保溫模式。 <ul style="list-style-type: none">保溫指示燈 (保溫) 將亮起。

 再加熱 (圖 6)
<ol style="list-style-type: none">照「煮飯」中的步驟 1 至 7 操作。 按下功能選擇按鈕 ，直到選擇煮糙米飯功能 (區區區)。 按住烹調按鈕 3 秒以開始烹調。 烹調完成後，您將聽到 4 聲響聲，所選的烹調功能燈將熄滅。 微電腦灶燒電子鍋將自動進入保溫模式。 <ul style="list-style-type: none">保溫指示燈 (保溫) 將亮起。

 再加熱 (圖 6)
<ol style="list-style-type: none">照「煮飯」中的步驟 1 至 7 操作。 按下功能選擇按鈕 ，直到選擇煮糙米飯功能 (區區區)。 按住烹調按鈕 3 秒以開始烹調。 烹調完成後，您將聽到 4 聲響聲，所選的烹調功能燈將熄滅。 微電腦灶燒電子鍋將自動進入保溫模式。 <ul style="list-style-type: none">保溫指示燈 (保溫) 將亮起。

 清蒸 (圖 8)
<ol style="list-style-type: none">在內鍋內倒入一些水。 將要蒸煮的食物放在一個盤子裡或蒸籠裡。 將蒸籠放入內鍋中。 如果您使用的是盤子，請將它放入蒸籠內。 蓋上微電腦灶燒電子鍋鍋蓋，並將插頭插入電源插座。 按下微選擇按鈕 ，直到選擇清蒸功能 (區區區)。 如欲設定不同的烹調時間，請參考「調整烹調時間」單元。 按住烹調按鈕 3 秒以開始烹調。 烹調完成後，您將聽到 4 聲響聲，所選的烹調功能燈將熄滅。 <ul style="list-style-type: none">保溫指示燈 (保溫) 將亮起。 打開蓋子，小心地將蒸好的食物從盤子或蒸籠內取出。

 備註
<ul style="list-style-type: none">由於盤子和蒸籠會變得很快，請使用廚房手套或布。 您可以依需求調整水位。請勿超過內鍋內部所標示的 4 杯水位。

 烤蛋糕 (圖 9)
<ol style="list-style-type: none">充分攪拌蛋糕材料。 在內鍋塗上一層薄薄的奶油或食用油，然後將攪拌好的蛋糕材料倒入。 照「煮飯」中的步驟 6 和 7 操作。

 備註
<ul style="list-style-type: none">烤蛋糕時請蓋好頂蓋。

 備註
<ul style="list-style-type: none">開始清潔微電腦灶燒電子鍋前，請先拔除插頭。 請先等到微電腦灶燒電子鍋充分冷卻後再行清潔。 每次使用後，請務必清洗可拆卸蓋板元件，如果放置不予清洗，會造成變色及異味的產生。

 備註
<ul style="list-style-type: none">可拆卸內蓋板件用熱水或者冷水浸泡後，用海綿塊清洗擦拭。 發熱盤內用擲軟水分分的抹布擦拭。 如果有飯粒等異物沾附時，請用竹籤或牙籤將米粒清除乾淨。

 備註
<ul style="list-style-type: none">請勿超過煮粥的水位刻度標示，否則可能使水溢出電子鍋造成危險。

 備註
<ul style="list-style-type: none">按下功能選擇按鈕 ，直到選擇煮粥功能 (區區區)。 如欲設定不同的烹調時間，請參考「調整烹調時間」單元。 按住烹調按鈕 3 秒以開始烹調。 烹調完成後，您將聽到 4 聲響聲，所選的烹調功能燈將熄滅。 微電腦灶燒電子鍋將自動進入保溫模式。 <ul style="list-style-type: none">保溫指示燈 (保溫) 將亮起。

 備註
<ul style="list-style-type: none">如果粥熬放在保溫模式過久，粥變得稠是正常的情形。

 備註
<ul style="list-style-type: none">照「煮飯」中的步驟 6 和 7 操作。 按下功能選擇按鈕 ，直到選擇煲湯功能 (區區區)。 如欲設定不同的烹調時間，請參考「調整烹調時間」單元。 按住烹調按鈕 3 秒以開始烹調。 烹調完成後，您將聽到 4 聲響聲，所選的烹調功能燈將熄滅。 微電腦灶燒電子鍋將自動進入保溫模式。 <ul style="list-style-type: none">保溫指示燈 (保溫) 將亮起。

 備註</
--