

## Storage

Never wind the mains cord round the appliance.

- 1 Switch off the appliance and unplug it.
- 2 Let the appliance cool down completely on a heat-resistant surface.
- 3 Store the appliance in a safe and dry place.

## Environment

- Do not throw away the appliance with the normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you help to preserve the environment (Fig. 5).

## Guarantee & service

If you need service or information or if you have a problem, please visit the Philips website at [www.philips.com](http://www.philips.com) or contact the Philips Consumer Care Centre in your country (you find its phone number in the worldwide guarantee leaflet). If there is no Consumer Care Centre in your country, go to your local Philips dealer.

## Troubleshooting

This chapter summarises the most common problems you could encounter with the appliance. If you are unable to solve the problem with the information below, contact the Philips Consumer Care Centre in your country.

Problem	Possible cause	Solution
The appliance does not work.	There is a power failure or the socket to which the appliance is connected is not live.	Check if the power supply works. If it does, plug in another appliance to check whether the socket is live.
	The mains cord is damaged	If the mains cord is damaged, you must have it replaced by Philips, a service centre authorised by Philips or similarly qualified persons in order to avoid a hazard.

TRESemmé.  
USED BY PROFESSIONALS

HP4687/07



PHILIPS



[www.philips.com](http://www.philips.com)

100% recycled paper  
100% papier recyclé

4222.002.7067.2


## Introduction

Congratulations on your purchase and welcome to Philips! To fully benefit from the support that Philips offers, register your product at [www.philips.com/welcome](http://www.philips.com/welcome).

This TRESemmé Philips appliance is designed and created to give you the salon styles you want, in a quick and easy way. We hope you enjoy using this TRESemmé Philips styler.

## General description (Fig. 1)

- A** Anodised titanium plates
- B** Temperature wheel
- C** Power-on light
- D** On/off switch
- E** Hanging loop



## Important

Read this user manual carefully before you use the appliance and save it for future reference.

### Danger

- Keep the appliance away from water. Do not use it near or over water contained in baths, washbasins, sinks etc. When you use the appliance in a bathroom, unplug it after use. The proximity of water presents a risk, even when the appliance is switched off.

### Warning


- Check if the voltage indicated on the appliance corresponds to the local mains voltage before you connect the appliance.
- Check the condition of the mains cord regularly. Do not use the appliance if the plug, the mains cord or the appliance itself is damaged.
- If the mains cord is damaged, you must have it replaced by Philips, a service centre authorised by Philips or similarly qualified persons in order to avoid a hazard.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Keep the appliance away from non-heat-resistant surfaces and never cover the appliance with anything (e.g. a towel or clothing) when it is hot.
- Keep the appliance away from flammable items.
- Never leave the appliance unattended when it is connected to the mains.

### Caution

- For additional protection, we advise you to install a residual current device (RCD) in the electrical circuit that supplies the bathroom. This RCD must have a rated residual operating current not higher than 30mA. Ask your installer for advice.
- The straightening plates and the plastic parts near the plates reach a high temperature quickly. Prevent the hot surfaces of the appliance from coming into contact with your skin.
- The maximum temperature occurs just after heating up. The actual temperature during use may be lower.
- Always unplug the appliance after use.
- Wait until the appliance has cooled down before you store it.
- Always switch off the appliance before you put it down, even if it is only for a moment.
- Do not wind the mains cord round the appliance.
- Only use the appliance on dry hair.
- Do not use the appliance on artificial hair.
- Do not use the appliance for any other purpose than described in this manual.
- Do not leave the plates in your hair for more than a few seconds at a time as this may cause damage to your hair.
- Keep the straightening plates clean and free of dust, dirt and styling products such as mousse, spray and gel. Dust, dirt and styling products may cause damage to the anodised titanium plates.
- If you use the appliance on colour-treated hair, the straightening plates may stain.

### Electromagnetic fields (EMF)

This Philips appliance complies with all standards regarding electromagnetic fields (EMF). If handled properly and according to the instructions in this user manual, the appliance is safe to use based on scientific evidence available today.



## Using the appliance

Straighteners are powerful styling tools and must always be used with care. As with all straighteners that reach salon-high temperatures, do not use the appliance frequently to avoid damage to the hair. If you use the straightener incorrectly or if you use it at the wrong temperature setting, you could overheat your hair or even burn it. Always make sure you select a temperature setting that is suitable for your hair type.

### Straightening

- 1** Put the plug in the wall socket.
- 2** Set the on/off switch to 'I'.
  - ▶ The blue power-on light goes on.

**Never leave the appliance unattended when it is plugged in. Always put the appliance on a heat-resistant surface when it is heating up and when it is hot.**

- 3** Turn the temperature wheel to select the required temperature setting. Select a temperature setting that is suitable for your hair. (Fig. 2)
  - Always select a low setting when you use the straightener for the first time.
  - For coarse, curly or hard-to-straighten hair, select a medium to high setting.
  - For fine, medium-textured or softly waved hair, select a medium to low setting.

**Take extra care with pale, blonde, bleached or colour-treated hair, since it is susceptible to damage at high temperatures.**

- 4** Turn the temperature wheel to set the temperature.
- 5** Let the appliance heat up for at least 30 seconds.

- 6** Comb or brush your hair so that it is disentangled and smooth. (Fig. 3)

Use a comb to divide the hair into sections. Do not put too much hair in one section.

*Note: It is better to section off the crown area and to straighten the hair underneath first, followed by the top area.*

- 7** Take a section that is not wider than 5cm. Place it between the straightening plates and press the handles of the appliance firmly together.
- 8** Slide the straightener down the length of the hair in 5 seconds, from root to hair end, without stopping to prevent overheating (Fig. 4).
- 9** Repeat this process after 20 seconds until you have achieved the desired look.
- 10** Let your hair cool down. Do not comb or brush it before it has cooled down, as this would ruin the hairstyle you have just created.

### Cleaning

**Never immerse the appliance in water or any other liquid, nor rinse it under the tap.**

- 1** Switch off the appliance and unplug it.
- 2** Let the appliance cool down completely on a heat-resistant surface.
- 3** Clean the appliance with a damp cloth.