

About this User Manual

This manual contains all information you will need to initially install and operate your new TV.
Also read the help texts which are being displayed at the bottom of the screen.

If this instruction manual does not give an answer or if 'Troubleshooting' does not solve your TV problem, you can call your Local Philips Customer or Service Centre. See the supplied Worldwide guarantee booklet. Please, have the Model and Product number which you can find at the back or the bottom of your television set or on the packaging, ready, before calling the Philips customer support service.

Model: 32PF9431/93

Product No:

English

中文

Contents

Safety warnings	2	To make video and audio connections	34
Getting started	3	Side panel overview	35
Use of the remote control RC4350	5	Rear panel overview	36
Use of the option key	7	Connect	
Keys at the right side of the TV	8	a VCR or DVD recorder	37
Switch the TV on	8	two VCRs or VCR and DVD recorder	38
First time installation	9	a DVD player, a satellite receiver	
How to navigate through the menus	11	or Cable box	39
Use of the TV menu settings	12	a DVD player or Cable box	41
Adjust picture menu settings	14	a DVD player, Cable box, game console ..	41
Adjust sound menu settings	17	a PC	42
Adjust feature menu settings	19	a Home Cinema amplifier	43
How to search for and store TV channels ..	22	Select connected equipment	44
Rearrange the channel number list	24	Record with your recorder	44
Set your preferences	25	Audio- and video equipment keys	45
Select your connections	26	Troubleshooting	46
Reset the Factory settings	27	Annex 1 - Philips TV software upgrade	
How to upgrade the TV software	27	with portable memory	48
Create your favourite list	28	Annex 2 - Philips TV-Slideshow Format	
Multimedia browser	29	with background music	51
Teletext	32	Annex 3 - Philips TV - Digital camera	
		and USB issues	52
		Annex 4 - Issues referring to connected	
		peripherals with a HDMI connector	53
		Index	54
		Recycling	55
		Product information	55


310431525641



General

Do not insert the power plug in a wall socket or hang the TV to the wall before all connections are made.

- Place or hang the TV wherever you want, but make sure that air can circulate freely through the ventilation slots.



- Do not install the TV in a confined space such as a book case or a similar unit.
- To prevent any unsafe situations, no naked flame sources, such as lighted candles, should be placed in the vicinity.
- Avoid heat, direct sunlight and exposure to rain or water.
- The equipment shall not be exposed to dripping or splashing.

Care of the screen

Do not touch, push or rub or strike the screen with anything hard as this may scratch, mar or damage the screen permanently.

And please do not rub with dust clothes with chemical treatment.

Do not touch the surface with bare hands or greasy cloth (some cosmetics are detrimental to the screen). Unplug the TV before cleaning the screen.

When the surface becomes dusty, please wipe gently with absorbent cotton or other soft materials like chamois soaks. Do not use acetone, toluene and alcohol because they cause chemical damage. Do not use liquid cleaners or aerosol cleaners. Wipe off saliva or water drops as soon as possible. Their long time contact with the screen causes deformations and colour fading.

Stationary images on the TV screen

A characteristic of LCD and Plasma Display Panels is that displaying the same image for a long time can cause a permanent after-image to remain on the screen. This is called phosphor burn in. Normal use of the TV should involve the showing of pictures that contain constantly moving and changing images that fill the screen.

Examples of stationary images (this is not an all-inclusive list, you may encounter others in your viewing):

- TV and DVD menus: listings of DVD disk content;
- Black bars: when black bars appear at the left and right side of the screen, it is recommended to change to a picture format so that the picture fills the entire screen;
- TV channel logo: present a problem if they are bright and stationary. Moving or low-contrast graphics are less likely to cause uneven aging of the screen;
- Stock market stickers: presented at the bottom of the TV screen;
- Shopping channel logos and pricing displays: bright and shown constantly or repeatedly in the same location on the TV screen.

Examples of still pictures also include logos, computer images, time display, teletext and images displayed in 4:3 mode, static images or characters, etc.

Getting started

EN


Before you start

Warning: do not insert the mains cord into the mains at the bottom of the TV and in a wall socket or hang the TV on the wall before all connections are made.

Before you switch on your TV, connect all your peripheral equipment. See To make video and audio connections, p. 34.

Overview of the rear connector panel

There is a wide range of audio and video equipment that can be connected to your TV. See To make audio and video connections, p. 34.




AV1 can handle YPbPr, S-VIDEO, RGB+HB or CVBS and Audio L/R;

AV2 can handle CVBS, S-VIDEO and Audio L/R;

AV3 can handle YPbPr and Digital Audio;
HDMI 1 and 2.

Supported video formats: 480i, 480p, 576i, 576p, 720p, 1080i.


Warning: disconnect all power sources before making any connections.




Overview of the side connector panel

- To connect a camera, camcorder or game, see To make video and audio connections, p. 34.
- To connect a headphone, see To make video and audio connections, p. 34.
- To connect a USB device, see Multimedia browser, p. 29.

Connect the antenna

- Insert the aerial plug firmly into the aerial socket  at the bottom of the TV.


Tip: for best quality use the suppressor cable supplied.



Connect the mains

- Insert the mains cord supplied into the mains at the bottom of the TV and in the wall socket.

Warning: verify that the mains supply voltage corresponds to the voltage printed on the sticker at the rear of the TV.



Remote control

- Insert the 2 batteries supplied (Type R6-1,5V). Be sure the (+) and (-) ends of the batteries line up correctly (inside of case is marked.)

For most keys pressing a key once will activate the function. Pressing a second time will de-activate it.

Use of the remote control RC4350

EN



Standby

Press to switch the TV from or to standby mode. When switched to standby, a red indicator on the TV lights up.

Attention: the TV is never powered off completely unless it is physically unplugged.

DVD/R SAT TV VCR AUX


Press the **SELECT** key repeatedly to select one of the system modes in which the remote control can be used. If no action is being undertaken within 60 seconds, the remote control returns to TV mode.

After an action in the selected system mode the remote control will remain in this mode for 60 seconds and will then return to TV mode.

On screen information

Press to display (when available) information about the selected TV channel and programme.

Dual screen

Press the  key to show teletext on the right of the screen.


DEMO Press to switch the Demo menu on or off.

Colour keys

- When functions are attached to the colour keys, the colour keys are shown on screen.
- To select a page in Teletext mode.

OPTION

- To open and close the Quick access menu which contains a few frequently used options, like Picture format.
- When in teletext, press repeatedly to enlarge the teletext page display. See Teletext, p. 33.

 no function

Cursor keys

Press the cursor keys up/down, left/right to navigate through the menus.

OK - To activate a setting.

- Starts playing content in the Multimedia Browser application.

BROWSE/MENU:

To open and close the main menu. See How to navigate through the menus, p. 11.



Teletext On/Off

Volume

Press + or - to adjust the volume.

Mute key: interrupt the sound or restore it.

+P- Channel selection

- to browse through the TV channels and sources stored and marked in the Favourite channels lists;
- to select a page in Teletext mode;
- to quickly browse through the lists in the menus;
- to switch the TV on from standby mode.

0/9 Digit keys

To select a TV channel between 0 and 999.

AV Select your peripherals

See Installation menu, Select your connections, p. 26.

P+P Previous channel

Press to alternate between the currently viewed and the previously viewed TV channel.

Audio and Video equipment keys

See Audio and Video equipment keys, p. 45.

See Multimedia browser functional keys, p. 29.

CANCEL: no function

no function


FAV To display the channels list.

You can create up to four favourite lists.

Note: to set the remote control to work peripheral equipment, see p. 47.

Use of the OPTION key

EN



Quick access
Subtitles
Picture format
Equalizer
Clock

The **OPTION** key allows you to display the Quick access menu which will give you direct access to some features and menu options.

1. Press the **OPTION** key.
 - The Quick access menu appears.
2. Press the cursor up/down to select a menu item.
3. Press the **OK** key to jump to the selected menu item in the TV menu. (Except for the Clock option).
4. Use the cursor keys to make a selection.
5. Press the **OPTION** key to exit.

Subtitles:

See Adjust feature menu settings, p. 19.

Picture format:

See Use of the TV menu settings, Adjust picture menu settings, p. 16.

Equalizer:


See Use of the TV menu settings, Adjust sound menu settings, p. 17.

Clock:

- Select to activate/deactivate the clock display on the screen.

EN

Keys at the right side of the TV



In case your remote is lost or broken, apart from channel selection and volume adjustment, you can still change some of the basic settings with the keys at the right side of your TV.



- Press the power switch  to switch the TV on or off.

The **MENU** key can be used to summon the TV menu without the remote control.

- Use:
 - the **VOLUME** - and + keys and the **PROGRAM/CHANNEL** - and + keys to select menu items;
 - the **MENU** key to confirm your selection.

Note: when activated via the **MENU** key at the right side of the TV, only **Exit** lets you dismiss the menu. Navigate to **Exit**, press the cursor right and then press the **MENU** key.

Switch the TV on

- Press the power switch  at the right side of the TV.
 - ▷ An indicator on the front of the TV lights up and the screen comes on.
- If the TV is in standby mode, press the **-P+** keys or the  key on the remote control.

Note: the first time (and only the first time) you switch on your TV, you see a Welcome screen followed by the installation procedure. See First time installation, p. 9.

First time installation

EN



The first time (and only the first time) you switch on your TV, you see a Welcome screen followed by the installation procedure.



The installation procedure consists of a series of screens that will guide you through the installation of your TV. Follow the instructions on screen.

Note: if the TV has already been installed before and/or you want to change the First time installation settings, proceed with Use of the TV menu settings, p. 12.

Step 1: select your on-screen language

After the Welcome screen you are asked to select a language of the TV's on-screen menus. The text of the header and the info on screen continuously change language.

1. Press the cursor up/down to highlight your language.
2. Press the **OK** key on the remote control.
3. Follow the instructions on screen to proceed.





Step 2: complete the initial TV installation procedure

1. Press the green colour key on your remote control when **Television** is highlighted.
2. Press the green colour key on your remote control to start the Automatic channel installation.
 - ▷ All available TV channels are searched for and stored automatically. This will take a few minutes.

Note: if you choose to install the channels at a later time, select the Automatic installation in the TV menu, Installation, Channels, p. 22, to scan available channels.

3. Press the red colour key when the search is completed.

Step 3: Settings assistant: select your TV settings

By means of several split screens/full screens you are prompted to select your preferred picture and sound settings, to finally arrive at a complete setting which satisfies you.

1. Press the green colour key on your remote control to enter the **Settings assistant** menu.
2. Select your Location with the cursor up/down.
 - ▷ If you choose **Shop** it will skip the Settings assistant. The TV parameters for Picture and Sound will then be set to predefined fixed settings. Press the green colour key again to proceed.
 - ▷ If you choose **Home** it will display the Settings assistant.
3. Use the cursor left/right to each time select your preferred screen.
4. Press the green colour key to each time confirm your selection and to jump to the following screen.
 - ▷ The following items will be presented sequentially. In the header it is mentioned how many screens have been completed and how many screens there are in total.
5. Press the green colour key again to store all the settings and to return to the TV installation menu.

Note: when you skip or stop the Settings Assistant, then the standard settings Philips selected for you will be chosen.

6. Press the green colour key again to finish the First time installation procedure and to display the first stored TV channel.

Note: any time you can change or reset your settings or adjust individual settings for Picture and Sound in the TV settings menu. See p. 12, Use of the TV menu settings. To control the settings of special TV functions, features and accessory equipment, see p. 19, Adjust feature menu settings.

How to navigate through the menus

EN


Introduction

A lot of guiding instructions, help texts and messages will be displayed on your TV when you use the menus or when you try to execute an action.

Read the help texts which are being displayed on the specific item highlighted.

The colour keys at the bottom of the screen refer to the different actions which may be executed.

Press the corresponding colour key on the remote control to perform the required or desired action.



TV menu	TV settings
TV settings	Settings assistant
Features	Reset to standard
Installation	Picture
Exit	Sound
Info	

- Press the **MENU/BROWSE** key on the remote control.
 - The main menu appears on the screen.
 - TV menu** allows you to access the TV menu. See below.
 - TV channels** allows you to access the TV channel list and to create up to four favourite lists with your preferred TV channels. See Create your favourite channel list, p. 28.
 - Multimedia** allows you to access the Multimedia browser application. It lets you display your personal multimedia files. Multimedia is only present when a USB device is connected. See Multimedia browser, p. 29.
- Use the cursor up/down to highlight and select a menu item.
- Use the cursor right to enter the highlighted menu item.
 - The right panel shows the content of the highlighted menu item.
- Use the cursor up/down to select a menu item.
 - TV settings** allows you to adjust your preferred picture and sound settings
 - Features** allows you to control the settings of special TV features
 - Installation** allows you
 - to select your menu language;
 - to search for and store your TV channels;
 - to set or adjust various special functions;
 - to select connected peripheral equipment;
 - to reset your picture and sound settings to the factory standard settings;
 - to upgrade your TV software.

TV menu	TV settings
TV settings	Settings assistant
Features	Reset to standard
Installation	Picture
Exit	Sound
Info	

5. Press the cursor right to enter the highlighted menu item.
 - ▷ The content of the right panel is moved to the left panel and the right panel now shows the content of the newly highlighted item in the left panel.

Note: in some cases it is important that the picture can be watched while you adjust the settings. This means that when the highlight is on the right side panel, the other menu items hide away. When cursor left is pressed again, the hidden menu items reappear and the highlight moves to the left panel.

6. Press the **MENU/BROWSE** key to exit the main menu.

Use of the TV menu settings

Television	TV menu TV channels
Multimedia	

The TV menu allows you to access and change settings and preferences in case you want to change the First time installation settings and/or you want to control the settings of special TV functions, features and peripheral equipment.

Adjust viewing and listening settings

TV menu	TV settings
TV settings	Settings assistant
Features	Reset to standard
Installation	Picture
Exit	Sound
Info	

1. Press the **MENU/BROWSE** key on the remote control.
 - ▷ The main menu appears on the screen.
2. Select **TV menu** and press the cursor right.
 - ▷ The TV menu is displayed.
3. Select **TV settings** and press the cursor right.
 - ▷ The TV settings menu is moved to the left.
4. Press the **MENU/BROWSE** key to exit the menu.

To make it easier to change the settings of the TV, there are 3 ways of doing it.

Use of the TV menu settings (continued)

EN

TV menu	TV settings
TV settings	Settings assistant
Features	Reset to standard
Installation	Picture
Exit	Sound
Info	

A. Change settings in an easy-to-use manner with the Settings assistant.

Each time you've made a selection, press the green key to confirm your selection.

1. Select **Settings assistant** and press the cursor right.
 - ▷ By means of several split screens/full screens you are prompted to select your preferred picture and sound - settings to finally arrive at a complete setting which satisfies you.
See First time installation, Step 3: Settings assistant: select your TV settings, p. 10.
2. Press the green colour key to return to the TV menu again.

B. Use of the Standards settings (if present)

This allows you to reset your settings for viewing and listening to predefined factory settings.

TV menu	TV settings	Reset to standard
	Settings assistant	Current
	Reset to standard	Natural
	Picture	Vivid
	Sound	Subtle
Info		

1. Select **Reset to standard** and press the cursor right.
 - ▷ A menu appears which allows you to select one of the standard settings for viewing and listening.
 - ▷ **Current** shows your current settings for viewing and listening.
 - ▷ If you select **Natural**, it allows you to set your picture and sound settings to the recommended standard values. In most cases this will give the best balanced viewing experience.
 - ▷ If you select **Vivid**, it allows you to set your picture and sound settings to rich values, making use of the TV capabilities to its full extend.
 - ▷ If you select **Subtle**, it allows you to set your picture and sound settings to the purest representation of the original source content.
2. Press the green colour key to store the selected setting.

Note: storing a standard setting will overwrite your current settings for viewing and listening.

C. Individual settings for picture and sound

- Select **Picture** or **Sound** and press the cursor right.
 - ▷ A menu appears which allows you to fine tune the picture and sound settings.
 - ▷ To adjust the Picture settings, see Adjust picture menu settings, p. 14.
 - ▷ To adjust the Sound settings, see Adjust sound menu settings, p. 17.

TV menu	TV settings
TV settings	Settings assistant
Features	Reset to standard
Installation	Picture
Exit	Sound
Info	

The picture menu contains the settings that affect the quality of the picture.

1. Press the **MENU/BROWSE** key on the remote control.
 - ▷ The main menu appears.
2. Select **TV menu** and press the cursor right.
 - ▷ The TV menu is moved to the left.
3. Select **TV settings** and press the cursor right.
 - ▷ The TV settings menu is moved to the left panel.
4. Select **Picture** and press the cursor right.
 - ▷ The Picture menu is moved to the left panel.
5. Use the cursor up/down to select the Picture menu items.
6. Press the cursor right to enter the selected Picture menu item.
7. Use the cursor keys to adjust the settings.
8. Press the cursor left to return to the Picture menu.

TV menu	Picture
TV settings	
Settings assistant	Contrast
Reset to standard	Brightness
Picture	Colour
Sound	Hue
	Sharpness
	Tint

Info	

Contrast

Adjusts the intensity of bright parts in the picture but keep the dark parts unchanged.

Brightness

Adjusts the light output of the complete picture, which will mainly affect the darker areas of the picture.

Colour

Adjusts the saturation level of the colours to suit your personal preference.

Hue

Compensates for the colour variations in NTSC encoded transmissions.

Sharpness

Adjusts the sharpness of fine details in the picture.

Tint

Increases or decreases **Warm** (red) and **Cool** (blue) colours to suit personal preferences.

- Select **Cool** to give the white colours a blue, **Normal** to give the white colours a neutral, **Warm** to give the white colours a red tint.
- Select **Custom** to make a customised setting in the Custom tint menu item.

Adjust picture menu settings (Continued)

EN

TV menu	
TV settings	Picture
Settings assistant
Reset to standard	Custom tint
Picture	Pixel Plus
Sound	Dig. natural motion
	Dynamic contrast
	DNR

Info	

Custom tint (only when Tint is set to Custom)

Fine tunes the white point (WP) and black level (BL) of the picture.

1. Select **Custom tint** and press the cursor right.
 ▷ The right panel will move to the left to reveal the Custom sliders in the right panel.
2. Use the cursor keys to select and adjust the settings of:
R-WP: allows you to customise the colour tint by adjusting the red whitepoint of the picture.
G-WP: allows you to customise the colour tint by adjusting the green whitepoint of the picture.
B-WP: allows you to customise the colour tint by adjusting the blue whitepoint of the picture.
R-BL: allows you to customise the colour tint by adjusting the red blacklevel of the picture.
G-BL: allows you to customise the colour tint by adjusting the green blacklevel of the picture.
3. Use the colour keys to reset to the predefined settings.
4. Press the cursor left to return to the Picture menu.

Pixel Plus

Pixel Plus is the most ideal setting, as it fully processes the image to make every single pixel the best it can be, improving contrast, sharpness, picture depth, and colour reproduction and brilliance from every source, including High Definition.

- Select **On** or **Off** in order to activate/de-activate Pixel plus.

Digital natural motion

Reduces the field and line flicker and reproduces smooth movement especially in movies.

- Select **Off**, **Minimum** or **Maximum** in order to really see the difference in picture quality.

Dynamic contrast

Automatically makes the contrast in the darker and the brighter picture areas more noticeable as the image on the screen changes.

- Normally select **Medium**. It may be preferred to select **Minimum**, **Maximum** or **Off**.

DNR

dnr automatically filters out and reduces the image noise. This improves picture quality when receiving weak signals.

- Select **Off**, **Minimum**, **Medium** or **Maximum** according to the image noise in the picture.

TV menu	
TV settings	Picture
Settings assistant
Reset to standard	DNR
Picture	MPEG artefact red...
Sound	Colour enhancem..
	Active control
	Light sensor
	Picture format
Info	

MPEG artefact reduction

MPEG reduction On smoothens the transitions on digital content.

- Select **On** or **Off**

Colour enhancement

Automatically controls green enhancement and blue stretch. It makes the colours more vivid.

- Select **Off**, **Minimum**, **Medium** or **Maximum**.

Active control

The TV continuously measures and corrects all incoming signals in order to provide the best picture possible.

- Select **On** or **Off** to activate/de-activate Active control.

Light sensor

Light sensor On automatically adjusts the picture settings for best viewing depending on the lighting conditions in the room.

- Select **On** or **Off**.

Picture format

This allows you to adjust the size of the picture dependant on the broadcasted format and your preferred setting. How to navigate through the TV settings menu, see p. 12, Use of the TV menu settings.

Tip: this function is also accessible via the **OPTION** key on the remote control.

- Choose among the following picture formats: Auto format, Super zoom, 4:3, Movie Expand 14:9, Movie Expand 16:9 or Wide screen.

Auto format makes the picture fill the screen as much as possible.


In case of subtitles in the bottom black bar, Auto format makes the subtitles visible.

In case of a broadcaster logo in the corner of the top black bar, the logo disappears from the screen.

Super zoom removes the black bars on the sides of 4:3 programmes with minimal distortion.

When in Movie Expand 14:9, Movie Expand 16:9 or Super zoom screen format, you can make subtitles visible with the cursor up/down.

Note: with HD sources not all picture formats will be available.



Adjust sound menu settings

EN

TV menu	
TV settings	Sound
Settings assistant	Equalizer
Reset to standard	Volume
Picture	Balance
Sound	Dual I/II
	Mono/Stereo
	Surround mode

Info	

The sound menu contains the settings that affect the quality of the sound.

1. Press the **MENU/BROWSE** key on the remote control.
 - ▷ The main menu appears.
2. Select **TV menu** and press the cursor right.
 - ▷ The TV Menu is moved to the left.
3. Select **TV settings** and press the cursor right.
 - ▷ The TV settings menu is moved to the left panel.
4. Select **Sound** and press the cursor right.
 - ▷ The Sound menu is moved to the left panel.
5. Use the cursor up/down to select the Sound menu items.
6. Press the cursor right to enter the selected Sound menu item.

Note: dependent on the input signal, one or more menu items may not be selectable.

7. Use the cursor keys to adjust the settings.
8. Press the cursor left to return to the Sound menu.

Equalizer

Allows you to change the frequency response of the sound to match your personal taste.

Tip: this function is also accessible via the **OPTION** key on the remote control.

Volume

Allows you to adjust the sound output level.

Balance

Allows you to adjust the output of the right and left speakers to obtain the best stereo reproduction for your listening position.

Dual I/II

Allows you to select, per channel, **Dual I** or **Dual II**, when dual sound transmission is available.

Mono/Stereo

Allows you to select, per TV channel, **Mono** or **Stereo** sound when stereo broadcasts are available.

Surround mode

Allows you to select the modes for more spatial or surround sound reproduction dependent on the broadcasted signals or signals from external inputs received.

TV menu	
TV settings	Sound
Settings assistant
Reset to standard	Headphone volume
Picture	AVL
Sound	Delta volume
	Auto surround
Info	

Headphone volume

Allows you to control the level of sound through the headphones.

AVL (Automatic Volume Leveler)

Automatically reduces the volume differences between channels and programmes, providing a more constant overall level. This will also reduce the dynamics of sound.

Delta volume

Allows you to correct for any permanent volume differences between TV channels or external sources.

Auto surround

When switched **On**, this allows the TV to automatically switch to the best surround sound mode the broadcaster transmits.

Adjust feature menu settings

EN

TV menu	Features
TV settings	Subtitle
Features	Sleeptimer
Installation	Childlock
Exit	Set/Change code
	On timer
	Demo
Info	

The Features menu allows you to control the settings of special TV functions, features and accessory equipment.

1. Press the **MENU/BROWSE** key on the remote control.
 - The main menu appears.
2. Select **TV menu** and press the cursor right.
 - The TV Menu is moved to the left.
3. Select **Features** and press the cursor right.
 - The Features menu is moved to the left panel.
4. Use the cursor up/down to select the Features menu items.
5. Press the cursor right to enter the selected Features menu item.
6. Use the cursor keys to adjust the settings.
7. Press the cursor left to return to the Features menu.

Subtitle

This displays Teletext subtitles from the selected TV channel. These can be permanently displayed, or only when mute is active. The teletext subtitle page must be stored for each TV channel.

1. Switch on teletext and select the proper subtitle page from the index.
2. Switch off teletext.
3. Select
 - **Subtitle On** to display the subtitles on the selected TV channels. A symbol will indicate that the mode is on.
 - **On during mute** to automatically display the subtitles only when the sound has been muted with the **M** key on the remote control.

Tip: this function is also accessible via the **OPTION** key on the remote control.

Sleeptimer

This sets a time period after which the TV automatically switches to standby.

1. Select **Sleeptimer**.
2. Press the cursor right.
3. Select a value with the cursor up/down.
 - The list will have values from 0 to 180 minutes. When 0 is selected, the sleeptimer is switched off.

Note: you can always switch off your TV earlier or select another time set.

TV menu	Features
TV settings	Subtitle
Features	Sleeptimer
Installation	Childlock
Exit	Set/Change code
	On timer
	Demo
Info	

Childlock

With a 4-digit code, you are able to lock TV channels and external sources to prevent children from watching certain programmes.

1. Select **Childlock**.
2. Press the cursor right to enter the Childlock menu.
3. Enter your 4-digit code.

Note: you have to re-enter your code each time you enter the Childlock menu.

4. Select one of the menu items of the Childlock menu and press the cursor right:
 - **Lock** to lock all channels and externals;
 - **Custom lock** to lock a certain programme or to lock all the channels from a certain time.
 - Select:
 - **Channel lock** to lock a certain TV channel or external. Press the **OK** key to activate;
 - **Lock after** to lock all programmes from a certain time onwards.
 - Press the cursor right.
 - Select **On** with the cursor right to set the lock.
 - Enter the time with the cursor up/down and right.
 - Select **Unlock** to disable all locks you have set.

Important: you have forgotten your code !

1. Select **Change code** and press the cursor right.
2. Enter the overriding code 8-8-8-8.
3. Enter a new personal 4-digit code.
4. Confirm your new entered code.
 - ▷ The previous code is erased and the new code is stored.

Set code/Change code

This allows you to set or change the personal 4-digit access code that is used in the different lock functions of the TV.

- Select **Set** or **Change code**.
 - ▷ If no PIN-code exists yet, the menu item is set to **Set code**. Follow the instructions on screen.
 - ▷ If a PIN-code has previously been entered, the menu item is set to **Change code**. Follow the instructions on screen.
- Enter your code with the digit keys. All number combinations from 0000 to 9999 are valid numbers.
 - ▷ The Features menu reappears with a message confirming that your PIN-code has been created or changed.

Adjust feature menu settings (Continued)

EN

On timer

TV menu	Features
TV settings	Subtitle
Features	Sleeptimer
Installation	Childlock
Exit	Set/Change code
	On timer
	Demo
Info	

Notes:

- only when Teletext is present;
- only one On timer can be set.

From standby, this automatically switches the TV to the specified channel number, at a specified time.

1. Select **On timer**.
2. Press the cursor right to enter the On timer menu.
3. Select **Timer** and press the cursor right.
4. Select **On**.
5. Select **Channel** and then the TV channel you want your TV to switch to on a selected time and day
6. Select **Day** and then a day of the week or select **Daily**.
7. Select **Time** and enter the time with the digit keys or with the cursor up/down.
8. Press the **OK** key to activate.
9. Press the cursor left to return to the Features menu or press the **MENU/BROWSE** key to switch off the menu.

Note: From now on, **every week**, your TV will automatically switch to the selected channel, on the selected day, at the selected time, until the On timer function is switched off again.

TV menu	Features	Demo
	Subtitle	Pixel Plus
	Sleeptimer	Settings assistant
	Childlock	Active control
	Set/Change code	
	On timer	
	Demo	
Info		

Demo

This allows you to get an idea of the features that are part of the television.

1. Select **Demo**.
2. Press the cursor right.
3. Select a desired demo.
4. Press the **OK** key to start the demo.
 - The selected demo is played once.
5. Press the red colour key to stop the demo and to return to the demo menu.
6. Press the red colour key to exit the demo menu.

How to search for and store TV channels

Tip: you will need this chapter only if you want to change the installation settings.

Television	TV menu
	TV channels
Multimedia	

TV menu	Installation
TV settings	Language
Features	Channels
Installation	Preferences
Exit	Connections
	Factory settings
	Software upgrade
Info	

TV menu	
Installation	Language
Language	Language
Channels	
Preferences	
Connections	
Factory settings	
Software upgrade	
Info	

TV menu	
Installation	Channels
Language	Autom. installation
Channels	Manual installation
Preferences	Rearrange
Connections	
Factory settings	
Software upgrade	
Info	

Installation menu

This menu will adjust settings related to the initial installation of your TV.

1. Press the **MENU/BROWSE** key on the remote control.
 - ▷ The main menu appears.
2. Select **TV menu** and press the cursor right.
 - ▷ The TV Menu is moved to the left.
3. Select **Installation** and press the cursor right.
 - ▷ The Installation menu is moved to the left panel.
4. Use the cursor up/down to select the Installation menu items.
5. Press the cursor right to enter the selected Installation menu item.
6. Use the cursor keys to make a selection.
7. Press the **OK** key to activate or to confirm.
8. Press the cursor left to return to the Installation menu or press the **MENU/BROWSE** key to switch off the menu.

Select your menu language

This allows you to select your preferred menu language.

1. Select the language menu item and enter the list of available languages with the cursor right.
2. Select your language with the cursor up/down.
3. Press the **OK** key to confirm your selection.

Store TV channels

After language is set correctly, you can now search for and store the TV channels.

- Select **Channels** in the TV, Installation menu.

Automatic installation

The TV will scan the entire frequency spectrum.

- ▷ All available TV channels are searched for and stored automatically. This will take a few minutes.
- ▷ When the search is complete, the menu will indicate the number of channels found.

How to search for and store TV channels (Continued)

EN

TV menu/Installation	
Channels	Manual installation
Autom. installation	System
Manual installation	Search
Rearrange	Fine tune
	Store current chan.
	Store as new chan.
Info	

Manual installation

This gives you the possibility to manually install (tuning-in channel by channel) TV channels.

1. Select **Manual installation** and press the cursor right.
2. Select **System**.
3. Select **Search** and press the cursor right.
4. Select the red or green colour key to proceed.

Tip: if you know the frequency, enter the 3 digits of the frequency with the digit keys 0 to 9 (For example, 049).

5. Press the cursor left to store the channel found or to search for another channel.
6. Select **Fine tune** and press the cursor right.
Fine tuning can be useful when the frequency has shifted a bit or when interference of another frequency occurs. Adjust the frequency with the cursor up/down in case of poor reception of the channel found.
7. Select **Store current channel** if you want to store the (fine tuned) frequency under the current channel number. Press the cursor right and confirm with the **OK** key.
8. Select **Store as new channel** if you want to store the (fine tuned) frequency under a new channel number. Press the cursor right and confirm with the **OK** key.
9. Use the rearrange menu to rename or reshuffle the channels. See next page.

Note: select **System (PAL BG, PAL I, PAL DK or NTSC M)**

TV menu	
Installation	Channels
Language	Autom. installation
Channels	Manual installation
Preferences	Rearrange
Connections	
Factory settings	
Software upgrade	
Info	

This allows you to rename, to reshuffle and to uninstall or reinstall the stored channels.

- Press the corresponding colour keys and follow the on screen instructions.

Reshuffle

This allows you to change the order of the stored TV channels.

- Select the channel you want to change place.
- Press the yellow colour key to move up a single position in the list.
- Press the blue colour key to move down a single position in the list.
- Repeat to reshuffle other TV channels.

Rename

This allows you to change the name stored in the memory or to assign a name to a channel or external for which a name has not yet been entered.

- Select the channel you want to rename.
- Press the red colour key on your remote control.
- Select the characters with the cursor up/down. Select the following position with the cursor right.
- Press the green colour key or the **OK** key when finished.

Notes:

- press the yellow colour key to delete all characters. The cursor is positioned at the beginning again;
- press the blue colour key to delete the character the cursor is positioned. Enter a new character with the cursor up/down;
- a name can be given to the channel numbers 0 to 999;
- space, numbers and other special characters are located between Z and A.

- Select another channel number and repeat steps 2 to 5.

Uninstall - reinstall

This allows you to uninstall a stored channel or external so that it is no longer possible to tune to. This also allows you to reinstall an earlier uninstalled channel.

- Select the channel you want to uninstall.
- Press the green colour key to uninstall the selected channel.
 - The uninstalled channel is indicated in the list by an icon in front of the uninstalled channel.
- Press the green colour key again to reinstall the uninstalled channel.

TV menu/Installation	
Channels	Rearrange
Automatic instal...	0
Manual installation	1
Rearrange	2
	3
	4
	5
	6
	7
Info	

Rearrange
0
1
2
3
4
5
6
7

☐ Rename
 ☐ Uninstall
 ☐ Move up
 ☐ Move down

Set your preferences

EN

TV menu	
Installation	Preferences
Language	Location
Channels	Teletext 2.5
Preferences	OSD
Connections	Programme title
Factory settings	Colour
Software upgrade	PLL
Info	

This menu contains items that can set or adjust various special TV functions and that will typically be accessed only occasionally.

Select your location

This allows you to select the location of your TV.

If you choose for **Shop** it will result in fixed settings of picture and sound.

The location **Home** will give full flexibility to change any predefined settings for picture and sound.

Select Teletext 2.5

Some broadcasters offer the opportunity to see more colours, other background colours and nicer pictures in the teletext pages.

- Select **Teletext 2.5 On** to take advantage of this feature.
- Select **Teletext Off** if you like the more neutral teletext layout.
 - ▷ The selection made is valid for all the channels which broadcast Teletext 2.5.

Note: it may take a few seconds before teletext broadcast switches over to Teletext 2.5.

Select the On Screen Display (OSD)

This allows you to select the display of the volume bar and a reduced or extended on screen display of programme and channel information.

- Select **Minimum** to activate the display of reduced channel information.
- Select **Normal** to activate the display of extended channel and programme information. For example, information on the programme, input signal quality of connected peripheral equipment, the screen format and sound mode, ratings, remaining time of the sleep timer setting,...

Display a Programme title

This allows you, to display the programme title according to the transmitted information.

- ▷ When selected **Yes**, after the selection of a TV programme or after you press the **i+** key on the remote control, a programme title will be displayed if transmitted.

Colour

This allows you to manually select the correct colour system.

PLL

This enables you to select a different setting for the picture decoding.

TV menu	
Installation	Connections
Language	AV1
Channels	AV2
Preferences	AV3
Connections	HDMI 1
Factory settings	HDMI 2
Software upgrade	Side
	Digital Audio IN
Info	

This allows you to select the peripheral equipment you have connected to the audio and video connectors.

1. Select **Connections**.
2. Press the cursor right.
3. Select the input to which the peripheral equipment is connected.
 - ▷ When you select **AV1, AV2, AV3, HDMI 1, HDMI 2, Side** or **Digital Audio In**, a list appears which allows you to identify which type of peripheral equipment is attached to this input.
4. Press the cursor right again to enter the list of types of peripherals connected to the selected input.
5. Select the peripheral equipment with the cursor up/down.

Digital Audio In

- If a peripheral equipment has a digital audio output, you can connect this with a single cable to the TV's **Digital Audio In** connector.
- In the Connections menu, assign the **Digital Audio In** to the corresponding external input to which your peripheral equipment is connected..

In addition to accepting audio input via Digital Audio In, the TV can output encoded Dolby Digital audio via the **DIGITAL AUDIO OUT** connector to an external amplifier or receiver. If your amplifier or receiver has a matching connector for Digital Audio In, you can connect it with a single cable to the TV's **DIGITAL AUDIO OUT**. See To make video and audio connections, Connect a Home Cinema amplifier; p. 43.

Reset the Factory settings

EN

TV menu	
Installation	Factory settings
Language	
Channels	Reset
Preferences	
Connections	
Factory settings	
Software upgrade	
Info	

This allows you to reset most of the predefined factory states.

1. Select and press the cursor right.
2. Press the **OK** key to erase settings and reset them to their default values.

How to upgrade the TV software

TV menu	
Installation	Software upgrade
Language	Current softw. info
Channels	Local upgrades
Preferences	Announcement
Connections	
Factory settings	
Software upgrade	
Info	

This allows you to upgrade your TV software using a USB device.

USB device upgrade

It is possible to initiate an upgrade procedure from a USB device before you start up the TV. The memory device must be filled with the appropriate upgrade image (and structure) which can be found on the www.philips.com/software website.


How to upload a new software version on your memory device, see Annex 1, Philips TV software upgrade with portable memory, p. 48.

Automatic software announcement

When you switch on your TV a message may appear that a new software upgrade is available.

- Press the red colour key on your remote control if you want to be reminded later on.
 - Press the green colour key on your remote control to confirm you have read the message.
 - ▷ Once you have confirmed, the message will not pop up again.
- If however, you want to see the last broadcasted announcement again, select **Announcement** in the Software upgrade menu.

Note: as long as the software upgrade has not been executed, the message will be available.



All channels	
	EXT1
	EXT2
	HDMI
	1 Analogue channel 1
	2 Digital channel 1
	3 Digital channel 2
	4 Radio channel 1
	5 Data channel 1
	Change list
Tune to a channel by pressing OK. Use -P+ for page up/down.	

All channels	
	All
	TV channels
	Radio channels
	Analogue
	Favourites 1
	Favourites 2
	Favourites 3
	Favourites 4
	Change list
Use cursor up/down to select and OK to confirm.	

Favourites 1	
	EXT1
	EXT2
	HDMI
	1 Analogue channel 1
	2 Digital channel 1
	3 Digital channel 2
	4 Radio channel 1
	5 Data channel 1
	Exit
	Leave edit
Press the OK key to mark / unmark.	

This allows you to select up to four favourite channels lists with your preferred TV channels and radio stations. For example, each member of your family can create his/her own favourite list. In addition to the favourite channel lists you may also select a list with only digital TV channels or a list with only the radio channels or a list with only the analogue channels.

Note: when this key is pressed the first time after you have finished the installation, it will bring up the full channel list. In other situations it will bring up the last selected channel list.

To select a channel from the displayed favourite list

1. Press the **FAV** key (or the **OK** key).
 - The last selected channel list appears.
2. Use the cursor up/down to select a channel.
3. Press the **OK** key to display the selected channel.

To select another favourite channel list

1. Press the **FAV** key.
 - The last selected channel list appears.
2. Press the red colour key to bring up the list of possible favourite channel lists.
3. Use the cursor up/down to select a list.
4. Press the **OK** key.
5. Press the **FAV** key again to exit.

To create a favourite list or to modify the list

1. Press the **FAV** key.
 - The last selected channel list appears.
2. Press the red colour key.
 - A list with all possible favourite channel lists appears.
3. Use the cursor up/down to select a Favourites (1 to 4) channel list.
4. Press the **OK** key.
5. Press the green colour key to enter the Edit mode.
 - The selected Favourite list will bring up a full channel list.
6. Use the cursor up/down to select a channel.
7. Press the **OK** key to check or uncheck the highlighted channel and to add it to or remove it from your selected favourite list.
- 8a.
 - Press the green colour key again to leave the Edit mode.
 - The modified favourite channel list appears.
 - Press the **FAV** key again to exit.
 - With the **-P+** key you will be able to browse through the TV channels of the selected list.
- 8b. Press the red colour key to remove the channel list.

Note: with the digit keys you can still select channels which are not marked as favourite.

Multimedia Browser

EN



The Multimedia browser lets you display pictures or play audio files stored on a USB device. The Multimedia browser application is invoked from the main menu.

- Following file formats can be reproduced:
 - for pictures: JPEG
 - for audio: MP3, MP3 Pro
 - for video: MPEG2
- Only FAT/DOS-formatted memory devices are supported.
- Philips can not be held responsible if your USB device is not supported.

To view content from a USB device

Tip: if your USB device does not fit into the USB connector at the side, use an USB extend cable to connect the USB device to the USB port. Ask your dealer for more information.


To insert a USB device

Note: USB devices are not supplied with this TV.

In case of a USB-memory stick or a digital camera, connect it to the USB connector at the side. See To make video and audio connections, Side panel overview, p. 35.
When a USB device is inserted, the Multimedia browser menu is displayed automatically. See further.





To remove the USB device


1. Press the **MENU/BROWSE** key on the remote control to switch off the main menu.
2. Remove the USB device.

**Multimedia Browser menu**

1. Insert a USB device.
2. Select the USB device under Multimedia with the cursor up/down.
 - ▷ The Multimedia browser allows you to browse content stored on the inserted USB device.
 - ▷ The 2-panel browser will be shown with the left panel containing the content types (Music, Pictures, Video).
 - ▷ The right panel will display the content that is available of the selected content type.
3. Press the cursor up/down to select a content.
4. Press the cursor right to enter the content.
5. Press the cursor up/down to select a file or a directory.

Note: press the green colour key to display all the image files in the current directory as thumbnails when browsing pictures. Press the green key again to display the image files in a list.








6. In case a **file** is selected, press the **OK** key to display a picture file or to play an audio file.
In case a **directory**, **album** or **playlist** is selected, press the cursor right to enter the content or press the **OK** key to start a slide show or a loop playback of the files present.
7. Press the cursor left to keep music playing and switch back to the Multimedia menu.
8. Press one of the colour keys on the remote control to perform the corresponding function mentioned at the bottom of the screen.
9. To stop playing content, press the  key on the remote control.

Tip: the blue colour key can, if necessary, be used to let the colour keys reappear.

Notes:

- your TV supports slide shows with background music. See Annex 2, Philips TV-slideshow format with background music, p. 48;
- the playback will continue to play even if temporarily switched to browser screens. The audio will be stopped when another song starts playing, or when the end has been reached;
- more technical remarks can be found in Annex 3, Philips TV-Digital camera and USB issues, p. 52.

Following icons may appear:

- | | |
|--|---|
|  folder |  music |
|  pictures |  self made playlist/album |
|  video | |


Multimedia Browser (Continued)

EN

Function keys at the bottom of the screen

Details	to display a description of the selected file or directory
Transitions	to select if you like to apply a transition during a slide show
Slide time	to select the duration a picture will be displayed in a slide show
Rotate	to rotate a picture
Repeat one/all	to repeat the playback of a music file
Shuffle	to shuffle music collections in a random way
Zoom	to select one of the zoom magnifications (x1, x2, x4) with the cursor up/down. Additionally you can shift the selected zoom window over the screen with the cursor keys.
Full/small screen	to toggle between a full or a small screen

Note: to rotate a picture or to select one of the zoom magnifications, first stop the slide show with the **OK** key or the blue colour key.



Multimedia function keys on the remote control


- ◀◀ to fast rewind displaying content
- to stop playing content
- ▶ - to play a single file, start a slide show, playback of a folder or other collection
- to pause playing content
- ▶▶ to fast forward displaying content



Note: only English Teletext supported.

Note: Teletext will not be available via equipment connected to a HDMI connector.

Most TV channels broadcast information via teletext. This TV has a 1200 pages memory that will store most broadcasted pages and subpages to reduce waiting time. After each programme change, the memory is refreshed.

- Press  to switch the teletext on.
- ▷ The main index page appears on the screen.


Select a Teletext page

- Enter the desired page number with the digit keys or with the **-P+** key.
- Select the options at the bottom of the screen with the colour keys.

Previous selected teletext page

- Press the **P+P** key.

Select T.O.P. teletext broadcasts





- Press .
- ▷ A T.O.P. overview of the teletext subjects available is displayed.
- Select with the cursor up/down, left/right the desired subject and press the **OK** key.

Note: not all TV channels broadcast T.O.P. teletext.

Select subpages


When a selected teletext page consists of different subpages, a list of available subpages appears on the screen. Press the cursor left or right to select the next or previous subpage.

Picture/Teletext

1. Press the  key.
2. Press the  key to show Teletext on the right of the screen.
3. Press the  key to return to a full teletext picture.
4. Press the  key to return to a full screen picture.

Teletext (Continued)

EN



Hypertext

With hypertext you can quickly jump to a pagenumber or search for a specific word shown on the current teletext page.

1. Press the **OK** key to highlight the first word or a number on the page.
2. Use the cursor up/down, left/right to select any other word or number you want to search for.
3. Press the **OK** key to confirm. The search starts.
 - ▷ A message appears at the bottom of the screen to indicate the searching, or that the word or page is not found.
4. Use the cursor up until the top of the page to exit hypertext.

Enlarge a Teletext page

- Press the **OPTION** key on the remote control repeatedly to display the upper teletext part, the lower teletext part and then to return to the normal teletext page size.

Teletext menu

The Teletext menu offers various functions to control teletext.

1. Switch teletext on and press the **MENU/BROWSE** key to activate the menu.
2. Press the cursor up/down to select the menu items.
3. Press the **OK** key to activate.
4. Press the **MENU/BROWSE** key to leave the teletext menu.

Menu	
Reveal	Off
Cycle subpages	Off
Language	Gr. II

Reveal

Reveals/conceals hidden information on a page, such as solutions to riddles and puzzles.

Cycle subpages (if subpages are available)

Makes the subpages cycle automatically.

- Press the **OK** key to activate and to deactivate again.

Language

If the displayed characters on screen do not correspond with the characters used by the teletext broadcaster, you can change the language group here.

- Select **Gr. I** or **G. II** with the **OK** key.


















EN

To make video and audio connections

Tip: use the inputs that are available on your equipment that provide the best video or audio performance, as below.

Note: your TV comes with all types of connectors with the exception of the DVI connector but some of your equipment may be equipped with this type. In this case you'll need a DVI to HDMI adapter or a HDMI to DVI cable and separate audio cables, all available at your local dealer.


Warning: be sure to connect the DVI output connector first, then connect to the HDMI input on your TV.

	Connector cable	Audio connection required
 HDMI	HDMI (High-definition Multimedia Interface) 	No
	Component video (480p/576p/720p/480i/576i/1080i) - Analogue audio (AV1)  - Digital audio (AV1 or AV3) 	 AUDIO L / R DIGITAL AUDIO IN
	RGB H/V 	 AUDIO L / R
 S-VIDEO	S-Video 	AUDIO L / R : L AV1 AV2 SIDE R 
 VIDEO	Video 	AUDIO L / R : L AV1 AV2 SIDE R 
 75 Ω	RF/Coaxial 	No

Note: cables are often colour-coded to connectors. Connect red to red, white to white....

To make video and audio connections - Side panel overview

EN



Camera, Camcorder, Game


1. Connect your camera, camcorder or game as shown.
2. Connect to **VIDEO** ② and **AUDIO L** ③ for mono equipment. For stereo equipment also connect **AUDIO R** ③.
S-VHS quality with an S-VHS camcorder is obtained by connecting the S-VHS cables with the **S-VIDEO** input ① and **AUDIO** inputs ③.

Warning: do not connect cable ① and ② at the same time. This may cause picture distortion !

Headphone

1. Insert the plug into the headphone socket as shown.
2. The headphone impedance must be between 8 and 4000 Ohm. The headphone socket has a 3.5 mm jack.

In the Sound menu select **Headphone volume** to adjust the headphone volume.


Tip: Press  on the remote control to switch off the internal loudspeakers of the TV.

USB

See Multimedia browser, p. 29.

EN


To make video and audio connections - Rear panel overview



Connect a VCR or DVD recorder

EN

Warning: do not place your recorder too close to the screen as some recorders may be susceptible for signals from the display. Keep a minimum distance of 0,5 m from the screen.



1. Connect the RF Antenna cable ① to the **RF IN** socket of your recorder.
2. Connect another RF cable ② from the output **OUT** of your recorder to the TV's input **CABLE/ANTENNA 75 Ω** jack.
3. Better playback quality can be obtained if you also connect the Video, Audio Left and Right (only for stereo devices) AV cables ③ to the **VIDEO, AUDIO L** and **R** input jacks of **AV2**.

If your recorder has an S-VHS video jack:


For improved picture quality, connect an S-video cable with the s-video input instead of connecting the recorder to the **VIDEO** jack of **AV2**.

S-Video does not provide audio, so audio cables must still be connected to provide sound.

Note:

- When using the **S-VIDEO** connector do not connect any device to the **AV2 VIDEO** or **AV1 VIDEO** input.


Note: you can not record signals from equipment connected to the **YPbPr** input.



1. Connect the RF antenna cable ① of the **RF IN** socket of your other AV device.
2. Connect the RF output of the AV device to the RF input of the recorder ②.
3. Connect another RF cable ④ from the output **OUT** of your recorder to the TV's input 75 Ω jack.
4. To obtain better picture quality, also connect the Video or S-Video, Audio left and Audio right cables of both devices to **AV1 (VIDEO or S-VIDEO, AUDIO L and R.)** ③ and to **AV2 (VIDEO or S-VIDEO, AUDIO L and R)** ⑤.

Notes:

- In case of mono equipment, only the left loudspeaker reproduces sound. Use a mono to stereo adaptor (not supplied) for sound reproduction via all internal loudspeakers.
- When using the **S-VIDEO** connector do not connect any device to the **AV2 VIDEO** or **AV1 VIDEO** input.




The **MONITOR OUT** connector can be used for a daisy chaining or to record programs from your TV ⑥. Only when a recorder is connected to **MONITOR OUT** it is possible to record an analog program from your TV. See Record with your recorder, p. 44.

Connect a DVD player, a satellite receiver or Cable box

EN

Tip: if necessary, you can adjust the picture position to the centre of the screen with the cursor keys.




With an S-Video connector

1. Connect an S-Video cable to the **AV1** or **AV2** **S-VIDEO** input ①.

Note: when using the **S-VIDEO** connector do not connect any device to the **AV2 VIDEO** or **AV1 VIDEO** input that you are using.


2. Connect the audio cables to the device's audio **L** and **R** jacks and to the **L** and **R AUDIO AV1** or **AV2** jacks ② on the TV accordingly to where you connected the S-Video cable.



With Component Video Connectors

- with digital audio :

1. Connect the three separate component video cables ① to the YPbPr jacks on the DVD player and to the **Y**, **Pb** and **Pr** jacks of **AV1** or **AV3** on the TV.
2. Connect the audio cable ② to the digital out of the equipment and to the **DIGITAL AUDIO IN** connector of the TV.
3. Select the equipment you have connected in the Installation menu, Select your connections, p. 26, and link it to **AV1** or **AV3**. Also select **Digital audio in** in the same Connections menu and link it to **AV1** or **AV3**.



- with analogue audio :

1. In case of a DVD player with analogue audio, connect the three separate component video cables ① to the YPbPr jacks on the DVD player and to the **Y**, **Pb** and **Pr** jacks of **AV1** on the TV. Connect the audio cable to the DVD's audio **L** and **R** jacks and to the **L/R AUDIO** jack of **AV1** ③.
2. In case of a cable box and/or a satellite receiver also connect the cable TV cable and/or the satellite antenna cable ④ and the aerial cable ⑤.

Notes:

- cables are often colour coded. Connect red to red, white to white, etc..;
- the labels for the component video sockets may differ depending on the DVD player connected. Although the abbreviations may vary, the letters B and R stand for the blue and red component signals, respectively, and Y indicates the luminance signal. Refer to the DVD player's instructions for use for definitions and connection details;
- to get an optimal viewing, it is advised to switch your equipment to the highest possible supported display modes.

Warning: in case you notice scrolling images, wrong colours or no colour, no picture, or even combinations of these on your screen, verify if the connections are done in the correct way and if the resolution and the signal standard of the connected equipment are set in the right way. See the handbook for your equipment.


Note:

- This television is designed to accept high definition signal standards 480p, 576p, 720p and 1080i as specified by the Electronic Industries Association standard EIA770.3. Digital devices from different manufacturers have the possibility of differing output standards which may cause difficulties for the television to properly display.

Connect a DVD player, Cable box or game console

EN

Tip: if necessary, you can adjust the picture position to the centre of the screen with the cursor keys.



With a HDMI connector


HDMI is the leading new standard for Digital video and audio interconnection.

1. Connect your equipment with the **HDMI** connector.
2. Select the equipment you have connected in the Installation menu, Select your connections, p. 26, and link it to **HDMI 1** or **2**.

Note: in case of any problems, see Annex 4: Issues referring to connected peripherals with a HDMI connector, p. 53.

Connect a DVD player or Cable box

Tip: if necessary, you can adjust the picture position to the centre of the screen with the cursor keys.




With a DVI connector

Note: only a DVD player with DVI with digital sound can be connected to the **HDMI** connector.


1. Connect the DVI to HDMI cable to one of the HDMI connectors of your TV ①.
2. Connect the audio cable ② to the **DIGITAL AUDIO IN** connector of the TV.
3. Select the equipment you have connected in the Installation menu, Select your connections, p. 26, and link it to **HDMI 1** or **2**.
4. Also select **Digital audio in** in the same Connections menu.

Notes:

- only a PC with digital sound can be connected to the **HDMI** connection;
- before connecting your PC to the TV, select your PC monitor settings to a refresh frequency of 60 Hz;
- supported PC monitor modes:
 VGA 640 x 480
 SVGA 800 x 600
 XGA 1024 x 768

**PC equipped with a DVI connector:**

1. Use a DVI to HDMI cable to connect to one of the **HDMI** connectors of your TV ①.
2. Connect the audio cable ② to the **DIGITAL AUDIO IN** connector of the TV.
3. Select the equipment you have connected in the Installation menu, Select your connections, p. 26, and link it to **HDMI 1** or **2**.
4. Also select **Digital audio in** in the same Connections menu.


**PC equipped with a VGA connector:**

1. Use a VGA to RGB H/V cable ① to connect to the **RGB H/V** connectors of your TV.
2. Connect the audio cable ② to the **AUDIO R** (right) and **L** (left) inputs of the TV.
3. Select the equipment you have connected in the Installation menu, Select your connections, p. 26.

Connect a Home Cinema amplifier


EN

Tip: to avoid visible delay between picture and sound, use the **DIGITAL AUDIO OUT** connector to connect your Home Cinema amplifier.



Digital Home Cinema amplifier

- Connect a digital Home Cinema amplifier to the **DIGITAL AUDIO OUT** connector ① at the bottom of the TV.




Analogue Home Cinema amplifier

- Connect your Home Cinema amplifier to the **AUDIO OUT L and R** connectors ② at the bottom of the TV.

EN

Select connected equipment



Before operating your connected equipment you have to make a selection in the Installation, Select your connections menu, p. 44.

1. Press the **MENU/BROWSE** key.
2. Select **TV Menu** and press the cursor right.
3. Select **Installation**.
4. Press the cursor right.
5. Select **Connections**.
6. Press the cursor right.
7. Select the input to which the peripheral equipment is connected.
8. Press the cursor right again to enter the list of types of peripherals connected to the selected input
9. Select the peripheral equipment with the cursor up/down.

Record with your recorder

Record a TV programme

You can record a TV programme using your recorders tuner without affecting your TV.

1. Select the channel number on your recorder.
2. Set your recorder to record.
See the handbook for your recorder.

Note: switching channel numbers on your TV does not disturb recording !

Record a programme from **MONITOR OUT**

You can record a programme on your recorder from the TV tuner via **MONITOR OUT**.

1. Switch on the device.
2. Select the channel or wanted device on your TV and the correct input on your recorder.
3. Select your recorder to record.
You record the tuner channel of the TV or selected device.

Note: do not switch channels or turn off your TV when you are recording through **MONITOR OUT**.










Audio- and video equipment keys

EN




Most of the audio and video equipment from our range of products can be operated with the remote control of your TV.

Press one of the keys after you pressed the **SELECT** key repeatedly according to the equipment you want to operate with this remote control. See Use of the remote control, p. 4.

-  to switch to standby
-  for pause,
-  for record,
-  for rewind (**VCR, CD**);
search down (**DVD**)
-  for stop,
-  for play,
-  for fast forward (**VCR, CD**);
search up (**DVD**)
-  to display information
- MENU** to switch the menu on or off
- **P +** for chapter, channel, track selection
0 to 9 digit entry,
- cursor up/down
to select the next or the previous disc (**CD**)
- cursor left/right
to select the previous or following track (**CD**)
- P+P** to select a DVD title/chapter;
index (**AUX**)
-  to select your choice of
subtitle language (**DVD**)

Notes:

- If no action is being undertaken within 60 seconds, the remote control returns to TV mode.
- After an action in the selected system mode, the remote control will remain in this mode for 60 seconds and will then return to TV mode or press the Select key to return to TV mode immediately.

Symptom	Possible cause/Remedy
No picture	<ul style="list-style-type: none"> Verify if the supplied cables are connected properly. (The aerial cable to the TV, the other aerial to your recorder, the power cables, ..) Verify if you selected the correct source. Verify if the child lock has been switched off.
Poor picture	<ul style="list-style-type: none"> Verify in the Manual installation menu if you have selected the correct TV system. Verify if your TV or house aerial isn't located too close to loudspeakers, non-earthed audio equipment or neon lights, etc. Mountains or high buildings can cause double pictures or ghost images. Sometimes you can improve the picture quality by changing the direction of the aerial. Is the picture or teletext unrecognisable. Verify if you have entered the correct frequency. See Installation, Manual installation, p. 23.
Poor colour	<ul style="list-style-type: none"> Select Factory settings in the Installation menu. Verify the connections between the optional equipment and the TV.
No sound	<ul style="list-style-type: none"> Verify if the volume isn't at minimum. Verify if the sound hasn't been muted with the  key. Verify the connections between the optional equipment and the TV.
The remote does not function	<ul style="list-style-type: none"> Verify if the remote is set correctly for the equipment you are using. Verify if the batteries are not dead. Replace the batteries. You can still use the keys at the right side of the TV. Select TV mode on your remote control. When pressing a key and some key leds are blinking with a higher speed and lower intensity than in a normal working condition, and your TV does not react on the key press, remove the batteries out of the remote control and put them back again.
The remote of connected equipment does not function well	<ul style="list-style-type: none"> The infrared signals of the screen may influence the reception sensibility of other peripherals. Solution: replace the batteries of the remote of other peripheral equipment.
No photo or music play or in poor quality	<ul style="list-style-type: none"> Verify if the source complies with a supported code.
No stable or not synchronised VGA picture	<ul style="list-style-type: none"> Verify if you have selected the correct VGA mode in your PC. See Connect a PC, p. 42. Verify the connections between the PC and the TV.
No solution found for your picture or sound problem	<ul style="list-style-type: none"> Switch off your TV off and then on again once. Never attempt to repair a defective TV yourself. Verify with your dealer or call a TV technician.
Red blinking led	<ul style="list-style-type: none"> Unplug the mains cord for 10 seconds and insert it in again.

Annex 1 - Philips TV software upgrade with portable memory

EN

Introduction

Philips offers software upgrade capability for your TV using portable memory. After you have completed a software upgrade, your TV will typically perform better.

What improvements are made depends on the upgrade software you are using as well as the software your TV contained before the upgrade.

You can execute the software upgrade procedure yourself.

Be aware that the content of this document is addressing technical or software skilled users.

To prepare a portable memory for software upgrade

For the procedure you will require:

- a personal computer with web browsing capability;
- an archive utility that supports the ZIP-format (e.g. WinZip for Windows or Stuffit for Mac OS);
- a preferably empty USB memory stick.

Note: only FAT/DOS-formatted portable memory is supported.

New software can be obtained from your dealer or can be downloaded from the www.philips.com/support website:

1. Go to **www.philips.com/support** using the web browser on your PC.
2. Follow the procedure to find the information and the software related to your TV.
3. Select the latest software upgrade file and download it to your PC.
4. Decompress the ZIP-file and copy the file "autorun.upg" to the root directory of the USB portable memory.


Note: only use software upgrades that can be found on the www.philips.com/support web site.


TV menu	
Installation	Software upgrade
Languages	Current softw. info
Channels	Local upgrades
Preferences	Announcement
Connections	
Factory settings	
Software upgrade	
Info	

To verify the version of the TV software

Before you start the software upgrade procedure, it is advised to check what the current TV software is.


1. Select **Software Upgrade** in the TV menu, Installation, Software upgrade.
2. Press the cursor right.
 - ▷ The Software Upgrade menu moves to the left panel.
3. Select **Current Software Info** to observe the version and the description of the current software.

Automatic software upgrade procedure

1. Switch off your TV and remove all memory devices.
2. Insert the USB portable memory that contains the downloaded software upgrade.
3. Switch on your TV with the power key  at the side of the TV.
4. At startup the TV will scan the USB portable memory until it finds the update content. The TV will automatically go to the upgrade mode. After a few seconds it will display the status of the upgrade procedure.

Warning:

- you are not allowed to remove the USB portable memory during the software upgrade procedure;
- in case of a power drop during the upgrade procedure, don't remove the USB portable memory from the TV. The TV will continue the upgrade as soon as the power comes back;
- if you try to upgrade to a software version lower than the current version, a confirmation will be asked. Downgrading to older software should only be done in case of real necessity;
- if an error occurs during the upgrade you should retry the procedure or contact your dealer;
- the automatic software upgrade procedure will only start if the version on the USB portable memory is different from the one in the TV.

5. When the software upgrade was successful, remove the USB portable memory and restart your TV with the power switch  at the side of the TV. Your TV will start up with the new software.

Note: once the upgrade is finished use your PC to remove the TV software from your USB portable memory.

Annex 1 (Continued)

EN


Manual software upgrade procedure

TV menu	
Installation	Software upgrade
Languages	Current softw. info
Channels	Local upgrades
Preferences	Announcement
Connections	
Factory settings	
Software upgrade	
Info	

For a manual software upgrade copy the "autorun.upg" file in a directory called "Upgrades" located in the root of the USB portable memory. You can rename the file if you like but keep the .upg extension.

1. Insert the portable memory that contains the downloaded software upgrade.
2. Select **Software Upgrade** in the Installation menu. Go to Local upgrades.
The TV will list all compatible software available on the USB portable memory and display the data for each selected upgrade version.
3. Select the correct upgrade version and press the red colour key to start the upgrade.
Your TV will restart and will automatically go to the upgrade mode. After a few seconds it will display the status of the upgrade procedure.

Warning: if you try to upgrade to a software version equal or lower than the current version, a confirmation will be asked. Downgrading to older software should only be done in case of real necessity.

4. When the software upgrade was successful, remove the USB portable memory and restart your TV with the power switch  at the side of the TV. Your TV will start up with the new software.

Notes:

- the latest version of this document can be found on the Philips support website (www.philips.com/support).
- Use the type number of your TV to find this documentation and other related files.
- Philips can't be held responsible for any problems that may occur as a result of the content in this document. Errors reported to Philips will be adapted and published on the Philips support website as soon as possible.

Introduction

This document explains how to make a Philips slideshow file with background audio. Be aware that the content of this document is addressing technical or software skilled users. To start the slideshow open the slideshow file in the Multimedia browser of your TV.

1. Press the **MENU/BROWSE** key on the remote control after having inserted a USB device and switched on the TV.
2. Go to where you stored the slideshow file (.alb) on your portable memory.
3. Select the slideshow file and press the ok key to start the slide show.
4. To stop a slide show, press the **■** key.

General Rules

- The slideshow will use plain ASCII XML syntax to allow the creation and editing of the slideshow files using simple tools.
- All references to network content must be based on the global address of the content.
- Content on a Portable Memory (PM) doesn't have a global address; as a result content from a PM can never be referenced from a slideshow not stored on the PM itself.
- To maintain portability, a slideshow stored on a PM should **ONLY** reference content on the same PM. Referencing global addresses can result in inconsistencies if the PM is used on a non-networked CE device. The latter is however not forbidden, it is only a recommendation.
- It is preferable that URL's referencing PM content are based on a relative path starting from the directory where the slideshow is stored. This path includes the device or drive name of the PM. An absolute path to content will also be supported.
 - relative path: pictures\test1.jpg, tamper.jpg, ..\new\bird.jpg, ...
 - absolute path: USB1:\pictures1\foo_bar.jpg, C:\f1.jpg, \organization.jpg, ...

General Format

The format and syntax below will be used to create the slideshow file (simple ascii text) with the extension .alb (.ALB). Examples: slshow1.alb, summer_holiday_2004.ALB, test.alb, ...

The following syntax should be used to create the text file:

```
<?xml version="1.0" encoding="ISO-885h9-1" ?>
<philips-slideshow version="1.0" >
  <title>Title of the slideshow</title>
  <audio>audio_url</audio>
  <slide-duration>30</slide-duration>
  <slides>
    <slide>slide_1_url</slide>
    <slide>slide_2_url</slide>
    <slide>slide_3_url</slide>
    <slide>slide_4_url</slide>
    <slide>slide_5_url</slide>
    <slide>slide_6_url</slide>
    ...
    <slide>slide_N-1_url</slide>
    <slide>slide_N_url</slide>
  </slides>
</philips-slideshow>
```

Annex 2 (Continued)**EN****Supported XML-tags**

The following table gives a description of the XML syntax.

Tag Name	Use	Description
philips-slideshow	mandatory	Philips slideshow signature including the version.
title	optional	The title of the playlist.
audio	optional	The audio-URL following this tag will define the music playing in the background during the slideshow. A single song or playlist (.m3u & .pls) are the only valid audio references. Other reference will not result in any audio playback. If a single song is referenced the song will be repeated forever. If a playlist is referenced the playlist will be played in sequence with a repeat at the end of the playlist.
slide-duration	optional	The default display time (in 0,1 second) of a slide. The TV application isn't obliged to support this tag. The TV application can force the use of one or multiple predefined display times.
slides	mandatory	Identifies the slides to show.
slide	optional	Identifies the URL of the individual slide.

Notes:

- the latest version of this document can be found on the Philips support website (www.philips.com/support);
- the software of your TV is upgradeable. If you have problems first check if you have the latest software installed on your TV. The latest software, together with instructions, can be found on the Philips support website. Use the type number of your TV to find this documentation and other related files.
- Philips can't be held responsible neither for any errors in the content of this document nor for any problems as a result of the content in this document. Errors reported to Philips will be adapted and published on the Philips support website as soon as possible.

Digital Camera Issues

If a USB connection between your digital camera and the TV isn't working, you can try the solutions below to resolve your problem.

- Make sure your digital camera is switched on and verify if the configuration of your digital camera is correct (see the manual of your digital camera for more information).
- Some digital cameras allow you to switch off the USB interface. Make sure that the USB interface is switched on before connecting to the TV.
- If you have a digital camera with only internal memory (no removable memory) you can try to copy the content manually to a USB memory device using a personal computer.
- Some digital cameras allow you to switch between PTP (Picture Transfer Protocol) or "PC Link" and USB Mass Storage. Make sure that you select USB Mass Storage or "PC Drive" on your digital camera.
- If your camera supports different interface settings be sure to try them one by one or contact the reseller of your camera to find out the correct setting.

USB Memory Device Issues

- Devices connected to the USB port of your TV must be "Mass Storage Class" compliant. If your device (digital camera, MP3 player, portable harddisk, ...) is not "Mass Storage Class" compliant it will not be detected by the content browser of the TV.
- The following subsets of the Mass Storage Class specification are supported:
 The implementation of the TV is based on the "Universal Serial Bus Mass Storage Class Specification Overview" (v1.2, June 23, 2003) including all documents referenced by the document. The document can be found on the USB standardisation website (www.usb.org).
 Full support of the USB Mass Storage Class Bulk-Only Transport (bInterfaceProtocol = 50h).
 Full support of SubClass Code = 05h; SFF-8070i spec.
 Full support of SubClass Code = 06h; SCSI transparent command set.
- For large USB memory devices, when you are in the Content Browser, it may take a long time before you can access your files.
- When using a USB portable harddisk: Due to the high power consumption of the harddisk, it is advised to use the external power supply of the portable harddisk to guarantee proper working under all conditions.

Annex 4: Issues referring to connected peripherals with a HDMI conector

EN

The **HDMI IN** connector allows the following TV and monitor display modes:

HD	Standard Definition TV (SDTV)	640x480i
		720x480i
		720x576i
	Enhanced Definition TV (EDTV)	640x480p
		720x480p
		720x576p
	High Definition TV (HDTV)	1920x1080i
		1280x720p
PC	VGA	640x480
	SVGA	800x600
	XGA	1024x768

- If necessary, you can adjust the picture position to the centre of the screen with the cursor keys.
- Due to legal requirements, it is possible that with certain copy protected PCM audio qualities from a peripheral equipment connected to the **HDMI** input, the Digital audio output signal is muted.
- Your TV supports HDCP (High-bandwidth Digital Content Protection). This is a system for protecting DVD content outputted via HDMI from being copied. It provides a secure digital link between a video source (DVD, PC, etc.) and your TV. Content is encrypted at the source peripheral equipment to prevent unauthorised copies from being made.
- Proper working is only guaranteed with HDMI compliant consumer products. Limit the cable length to max. 5 m.
- Digital peripheral equipment from different manufacturers have the possibility of differing output standards which may cause difficulties for the television to properly display.
- In case no signal is detected from your HDMI equipment, switch off the HDMI equipment and then on again.

To get an optimal viewing, it is advised to switch your DVD player, Blu-Ray or HD settop box to the highest possible supported display modes.

- active control 16
- antenna..... 4
- audio receiver 43
- audio equipment keys..... 45
- auto format..... 16
- automatic installation..... 22
- auto search mode..... 47
- auto surround mode..... 18
- avl (audio volume leveller)..... 18

- balance 17
- batteries 4, 55
- brightness 14

- cable box..... 39
- camera 35
- camcorder..... 35
- care of the screen 2
- change code 20
- channel list..... 11, 28
- child lock..... 20
- clock 7
- colour..... 14
- colour enhancement..... 16
- colour keys..... 5
- comp. video connectors..... 39
- connections..... 34
- contrast 14
- cursor keys..... 5
- custom tint..... 15

- delta volume 18
- demo 21
- digital audio in..... 26
- digital natural motion 15
- DNR 15
- dual I/II 17
- DVD player 39
- DVD recorder..... 38
- DVI connector 41, 42
- dynamic contrast 15

- equalizer 17

- factory settings..... 27
- favourite key 28
- favourite channel list..... 28
- features adjustment menu 19
- fine tune..... 23
- first time installation 9
- game..... 35, 41

- HDMI connector..... 41, 53
- headphone..... 35
- headphone volume..... 18
- Home Cinema amplifier 43
- hue 14
- hypertext..... 33

- installation menu..... 22

- location 25

- manual installation..... 23
- menu key 11
- menu language..... 22
- mono/stereo 17
- MPEG reduction 16
- multimedia browser 29
- mute key..... 5

- navigate through the menus.. 11

- on screen language..... 9
- on screen information 6
- on timer..... 21
- option key 7
- OK key..... 5
- OSD..... 25

- PC 42
- picture adjustment menu 14
- picture format 16
- PIN code 20
- pixel plus..... 15
- preferences menu..... 25
- previous channel 6
- programme title..... 25

- quick access menu 7

- rear panel overview 36
- rearrange channel list 24
- record a TV programme 44
- recycling..... 55
- reinstall 24
- remote control..... 5
- reset factory settings..... 27
- rename..... 24
- reset to standard..... 13
- reshuffle 24


- safety warnings 2

- satellite receiver 39
- search for channels 22
- select your connections..... 26
- select connected equipment. 44
- set code..... 20
- settings assistant 10
- side panel overview 35
- sharpness..... 14
- sleeptimer 19
- slideshow format..... 51
- software upgrade 27, 48
- sound adjustment menu..... 17
- standby key..... 5
- store channels 22
- subtitles..... 19
- surround mode 17
- switch the TV on..... 8

- teletext 32
- teletext menu..... 33
- teletext 2.5..... 25
- tint 14
- T.O.P. teletext pages..... 32
- troubleshooting..... 46
- tv menu settings 12

- uninstall..... 24
- usb connector 35
- usb device..... 29


- video equipment keys..... 45
- volume..... 5, 17
- VCR 37



Recycling

EN

Recycling

 The packaging of this product is intended to be recycled. Apply to the local authorities for correct disposal.

Disposal of your old product

Your product is designed and manufactured with highly quality material and components, which can be recycled and reused.



When this crossed-out wheeled bin symbol is attached to a product, it means the product is covered by the European Directive 2002/96/EC.

Please inform yourself about the local separate collection system for electrical and electronic products. Please act according to your local rules and do not dispose of your old products with your normal household waste.

The correct disposal of your old product will help prevent potential negative consequences for the environment and human health.

Disposal of batteries

The batteries supplied do not contain the heavy metals mercury and cadmium. Please check on how to dispose of exhausted batteries according to local regulations.

Product information

- Your TV consumes energy in standby mode. Energy consumption contributes to air and water pollution. Very low standby power consumption.
- Specifications: see the product leaflet on www.philips.com/support.
- If you need further assistance, please call the customer support service in your country.
- The corresponding telephone numbers and addresses are given in the supplied Worldwide guarantee booklet.

