

Register your product and get support at
www.philips.com/welcome

DS8500



EN **User manual**

FR **Mode d'emploi**

DA **Brugervejledning**

IT **Manuale utente**

DE **Benutzerhandbuch**

NL **Gebruiksaanwijzing**

ES **Manual del usuario**

SV **Användarhandbok**

PHILIPS

Contents

1	Important	4
	Safety	4
	Notice	6
<hr/>		
2	Your Docking Speaker	8
	Introduction	8
	What's in the box	8
	Overview of the main unit	8
	Overview of the remote control	10
<hr/>		
3	Get started	12
	Prepare the remote control	12
	Connect power	13
	Turn on	14
<hr/>		
4	Play	16
	Play from iPod/iPhone	16
	Play from an external device	17
	Adjust volume level	18
	Mute sound	18
<hr/>		
5	Product information	19
	Specifications	19
<hr/>		
6	Troubleshooting	20

1 Important

Safety

Important Safety Instructions

- ① Read these instructions.
- ② Keep these instructions.
- ③ Heed all warnings.
- ④ Follow all instructions.
- ⑤ Do not use this apparatus near water.
- ⑥ Clean only with dry cloth.
- ⑦ Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- ⑧ Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- ⑨ Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- ⑩ Only use attachments/accessories specified by the manufacturer.
- ⑪ Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.



- ⑫ Unplug this apparatus during lightning storms or when unused for long periods of time.
- ⑬ Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- ⑭ **Battery usage CAUTION** – To prevent battery leakage which may result in bodily injury, property damage, or damage to the unit:
 - Install all batteries correctly, + and - as marked on the unit.
 - Do not mix batteries (old and new or carbon and alkaline, etc.).
 - Remove batteries when the unit is not used for a long time.
 - The batteries shall not be exposed to excessive heat such as sunshine, fire or the like.
- ⑮ Apparatus shall not be exposed to dripping or splashing.
- ⑯ Do not place any sources of danger on the apparatus (e.g. liquid filled objects, lighted candles).
- ⑰ This product may contain lead and mercury. Disposal of these materials may be regulated due to environmental considerations. For disposal or recycling information, please contact your local authorities or the Electronic Industries Alliance: www.eiae.org.
- ⑱ Where the MAINS plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.



Warning

- Never remove the casing of this apparatus.
- Never lubricate any part of this apparatus.
- Never place this apparatus on other electrical equipment.
- Keep this apparatus away from direct sunlight, naked flames or heat.
- Ensure that you always have easy access to the power cord, plug or adaptor to disconnect the apparatus from the power.

Notice

Any changes or modifications made to this device that are not expressly approved by Philips Consumer Lifestyle may void the user's authority to operate the equipment.



This product complies with the radio interference requirements of the European Community.

Recycling



Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.

When you see the crossed-out wheel bin symbol attached to a product, it means the product is covered by the European Directive 2002/96/EC:



Never dispose of your product with other household waste. Please inform yourself about the local rules on the separate collection of electrical and electronic products. The correct disposal of your old product helps prevent potentially negative consequences on the environment and human health.

Your product contains batteries covered by the European Directive 2006/66/EC, which cannot be disposed of with normal household waste.



Please inform yourself about the local rules on separate collection of batteries. The correct disposal of batteries helps prevent potentially negative consequences on the environment and human health.

Norge

Typeskilt finnes på apparatens underside.

Observer: Nettbryteren er sekundært innkoplet. Den innebygde nettdelen er derfor ikke frakoplet nettet så lenge apparatet er tilsluttet nettkontakten.

For å redusere faren for brann eller elektrisk støt, skal apparatet ikke utsettes for regn eller fuktighet.

Environmental information

All unnecessary packaging has been omitted. We have tried to make the packaging easy to separate into three materials: cardboard (box), polystyrene foam (buffer) and polyethylene (bags, protective foam sheet.) Your system consists of materials which can be recycled and reused if disassembled by a specialized company. Please observe the local regulations regarding the disposal of packaging materials, exhausted batteries and old equipment.



Note

- The type plate is located on the bottom of the apparatus.

2 Your Docking Speaker

Congratulations on your purchase, and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

Introduction

With this unit, you can enjoy audio from the iPod/iPhone and other audio devices.


What's in the box

Check and identify the contents of your package:

- Main unit
 - Remote control
 - 1 x AC adaptor
 - 1 x AC power cord
 - 1 x Aux-in cable
 - User manual
-


Overview of the main unit

Front View




- ① - VOLUME +
 - Adjust volume.
- ② iPod/iPhone dock



Back View



- ③ Power supply socket
- ④ AUX IN
 - Jack for an external audio device.

Overview of the remote control



- 1 
 - Mute volume.
- 2 
 - Select Aux-in mode.
- 3 Up/down keys
 - Navigate through the iPod/iPhone menu.

- 4** **Fast forward/backward keys**
- Fast reverse or fast forward within a track or iPhone/iPod.
 - Skip to the previous/next track.
- 5** **▶||**
- Start or pause play.
- 6** **VOL +/-**
- Adjust volume.
- 7** **MENU**
- Access the iPod menu.
- 8** **OK**
- Confirm a selection.
- 9** **📱**
- Select iPod/iPhone dock mode.

3 Get started



Caution

- Use of controls or adjustments or performance of procedures other than herein may result in hazardous radiation exposure or other unsafe operation.

Always follow the instructions in this chapter in sequence.

If you contact Philips, you will be asked for the model and serial number of this apparatus. The model number and serial number are on the bottom of the apparatus. Write the numbers here:

Model No. _____

Serial No. _____

Prepare the remote control



Caution


- Risk of explosion! Keep batteries away from heat, sunshine or fire. Never discard batteries in fire.

For first-time use:

- 1** Remove the protective tab to activate the remote control battery.

To replace the remote control battery:

- 1** Open the battery compartment.
- 2** Insert one CR2032 battery with correct polarity (+/-) as indicated.
- 3** Close the battery compartment.



Note

- Before pressing any function button on the remote control, first select the correct source with the remote control instead of the main unit.
- If you are not going to use the remote control for a long time, remove the battery.


Connect power




Caution

- Risk of product damage! Ensure that the power supply voltage corresponds to the voltage printed on the bottom of the unit.
- Risk of electric shock! When you unplug the AC adaptor, always pull the plug from the socket. Never pull the cord.
- Before connecting the AC adaptor, ensure you have completed all other connections.


- 1 Insert the plug from the AC adaptor to the **DC IN** socket on the back of the main unit.



- 2 Connect one end of the AC power cord to the AC adaptor.



- 3 Connect the other end of the AC power cord to the wall outlet.



Turn on

The unit turns on automatically when connected to power.

- ↳ When user approaches the unit, light LED under volume button on the main unit turns on automatically.

Switch to standby

- In DOCK mode: disconnect the iPod/iPhone from the unit over 15 minutes.
 - ↳ The unit switches to Standby mode automatically.
- In Aux-in mode: the device no longer play music over 15 minutes.
 - ↳ The unit switches to Standby mode automatically.

4 Play

Play from iPod/iPhone

You can enjoy audio from iPod/iPhone through this unit.


Compatible iPod/iPhone

Apple iPod and iPhone models with a 30-pin dock connector. Made for :

- iPod nano (2nd generation)
 - iPod nano (3rd generation)
 - iPod nano (4th generation)
 - iPod nano (5th generation)
 - iPod classic
 - iPod touch (1st generation)
 - iPod touch (2nd generation)
 - iPod touch (3rd generation)
 - iPhone
 - iPhone 3G
 - iPhone 3GS.
-

Load the iPod/iPhone




- 1** Place the iPod/iPhone in the dock.



Remove the iPod/iPhone

- 1 Pull the iPod out of the dock.

Listen to the iPod/iPhone


- 1 Ensure that the iPod/iPhone is loaded correctly.
- 2 Press  to select DOCK mode.
- 3 Press .
 - ↳ The connected iPod/iPhone starts play.
 - To pause/resume play, press .
 - To skip to a track, press fast forward/backward keys.
 - To search during play, press and hold fast forward/backward keys, then release to resume normal play.
 - To navigate the menu, press **MENU**, then press up/down keys to select, and press **OK** to confirm.

Charge the iPod/iPhone

When the unit is connected to power, the docked iPod/iPhone begins to charge.

Play from an external device

You can also listen to an external audio device through this unit.

- 1 Press  to select Aux-in mode.
- 2 Connect the supplied Aux-in cable to:
 - the **AUX IN** jack (3.5mm) on the back of the unit.
 - the headphone jack on an external device.
- 3 Start to play the device (see the device user manual).

Adjust volume level

- 1 During play, press **VOL +/-** to increase/decrease the volume level.

Mute sound

- 1 During play, press **MUTE** to mute/unmute sound.

5 Product information



Note

- Product information is subject to change without prior notice.

Specifications

Amplifier

Rated Output Power	2X15 W RMS
Signal to Noise Ratio	85 dB
AUX IN	0.6 V RMS 10 kohm

General information

AC power (power adaptor)	OH-1048A1802500U-u Input: 100-240V~, 50/60Hz, 1.5A MAX; Output: 18V === 2.5A;
Operation Power Consumption	40W
Standby Power Consumption	<1W
Dimensions	
- Main Unit (W x H x D)	158 x 420 x 139 mm
Weight	
- Main Unit	3.32 kg

6 Troubleshooting



Warning

- Never remove the casing of this apparatus.

To keep the warranty valid, never try to repair the system yourself.

If you encounter problems when using this apparatus, check the following points before requesting service. If the problem remains unsolved, go to the Philips web site (www.philips.com/welcome). When you contact Philips, ensure that the apparatus is nearby and the model number and serial number are available.

No power

- Ensure that the AC power plug of the unit is connected properly.
- Ensure that there is power at the AC outlet.

No sound

- Adjust the volume.

No response from the unit

- Disconnect and reconnect the AC power plug, then turn on the unit again.



© 2010 Koninklijke Philips Electronics N.V.

All rights reserved.

Document order number: DS8500_12_UM_V1.2

