

Register your product and get support at
www.philips.com/welcome



SE650

SE655

Quick start guide


- 1 Connect
- 2 Install
- 3 Enjoy

PHILIPS


What's in the box



Handset for SE650/SE655



Base station for SE650
OR



SE655 with bracket




Battery door



2 AAA rechargeable
batteries



Power supply



Line cord*



User manual



Guarantee



Quick Start Guide

*You may find in the box the line adaptor delivered separately from the line cord. **In this case, you have to connect the line adaptor to the line cord first before plugging the line cord to the line socket.**

In multihandset packs, you will find one or more additional handsets, battery doors, chargers with power supply units and additional rechargeable batteries.



WARNING: Always use the line cord, power supply and batteries that came with your phone.

1

Connect

Connect the base station

1. Place the base station in a central location near the telephone line socket and electricity socket.



2. Connect the line cord and the power cable to their corresponding connectors at the back of the base station.
3. Connect the other end of the line cord and power cable to their respective sockets.


2

Install

Insert rechargeable batteries and charge


A

Insert batteries



B

Charge handset for 24 hours



Configure your phone (if necessary)

1. Press **OK** to display a list of countries.
2. Scroll up and down to find your country.
3. Press **OK** to confirm your selection.
(**Waiting...** will be displayed while the default line settings and menu language for the selected country are automatically configured.)
4. The product now goes to the **Date/Time** selection menu. Enter the current time and current date (HH:MM DD/MM/YY). Press to move the cursor left, or press to move it right.
If using the 12 hour format, just after setting the minutes, use to switch between AM and PM.
5. Press **OK** to confirm.



3

Enjoy



Make a call

Dial the number (maximum 24 digits) and press  or .

OR

Press  or  to take the line, and dial the number.


Answer a call

When the phone rings, press  or .

End a call










To end a conversation, press .

Adjust earpiece or speaker volume

During a call, scroll  to select from level 1 to level 5.






Set the ring tone

There are 15 ring tones available on your handset.

1. Press , scroll  to **Personal Set**, and press  **Select**.
2. Scroll  to **Handset Tones** and press  **Select**, then scroll  to **Ring Tones** and press  **Select**.
3. Scroll  to your desired melody. The melodies will play as you scroll to them.
4. Press  **Select** to set the ring tone.




A validation tone is emitted and the screen returns to the previous menu.

Store a contact in the phonebook




1. Press , **Phonebook** is highlighted; press  **Select**.
2. **New Entry** is highlighted; press  **Select**.
3. **Enter Name** is displayed. Enter the name of the contact (maximum 14 characters) and press  **OK**.
4. **Enter Number** is displayed. Enter the number (maximum 24 digits) and press  **OK**.

A validation tone is emitted.


Access phonebook


1. Press  and scroll  to browse the phonebook.
2. To view the details, press  **View**.


Call from the phonebook


1. Press  in idle mode.
2. Scroll  to a phonebook entry.
3. Press .
 - The call is initiated.


Listen to messages recorded on the answering machine (for SE655 only)


Press  on the base station to turn on the answering machine (the LED is turned on). The outgoing message is played.


Press  on the base station to play phone messages (the first recorded message will be played first).

Press  to skip the current message and play the next message.


Press  to go back to the previous message (if pressed within 1 second of current message playback).

Press  to replay current message (if pressed after 1 second of current message playback).

Press  to adjust speaker volume during message playback.

Press  to delete the current message.

Long press  to delete all old messages.

Press  again to turn off the answering machine (the LED is turned off).

Refer to your SE655 User Manual for details about the answering machine functions.

Troubleshooting

For more information, please refer to the User Manual that came with your phone.

Problem

- There's no dialling tone!
- Caller does not hear me clearly!
- **Searching...** is displayed on handset and '📶' icon is blinking!
- Caller number is not displayed!

Solution

- No power: Check the connections.
- Batteries are empty: Charge the batteries.
- Move closer to the base station.
- Wrong line cord used: Use the line cord provided.
- Line adaptor may be required: If applicable, connect the line adaptor to the line cord.
- Move closer to the base station.
- Move the base station at least one metre away from any electronic appliances.
- Move closer to the base station.
- Make sure that your base station is on.
- Reset your unit and restart handset registration.
- Service is not activated: Check your subscription with your network operator.

Welcome to Philips!

Register your product and get support at
www.philips.com/welcome

Need help?

User Manual

Refer to the User Manual that came with your SE650/655.

Online Help

www.philips.com/support

©2008 Koninklijke Philips Electronics N.V.
All rights reserved

Reproduction in whole or in part is prohibited without
the written consent of the copyright owner

CE 0168 
Printed in China

3111 285 47041 (GB)
UCZZ69937AZ(I)