

Micro Hi-Fi System

MCM158

Register your product and get support at
www.philips.com/welcome

User Manual



PHILIPS

México



Es necesario que lea cuidadosamente su instructivo de manejo.

	PRECAUCIÓN - ADVERTENCIA No abrir, riesgo de choque eléctrico	
	ATENCIÓN Verifique que el voltaje de alimentación sea el requerido para su aparato	
Para evitar el riesgo de choque eléctrico, no quite la tapa. En caso de requerir servicio, dirijase al personal calificado.		

Descripción: **Minisistema de Audio**
Modelo : **MCM158/55**
Alimentación: **110-127 / 220-240V~; 50 / 60 Hz**
Consumo: **15W**
Importador: **Philips Mexicana, S.A. de C.V.**
Domicilio: **Av. La Palma No.6**
Col. San Fernando La Herradura
Huixquilucan
Localidad y Tel: **Edo. de México C.P. 52784**
Tel.52 69 90 00
Exportador: **Philips Electronics HK, Ltd.**
País de Origen: **China**
N° de Serie: _____

**LEA CUIDADOSAMENTE ESTE INSTRUCTIVO
ANTES DE USAR SU APARATO.**




AVISO IMPORTANTE

Philips Mexicana, S.A. de C.V. no se hace responsable por daños o desperfectos causados por:

- Maltrato, descuido o mal uso, presencia de insectos o roedores (cucarachas, ratones etc.).*
- Cuando el aparato no haya sido operado de acuerdo con el instructivo del uso, fuera de los valores nominales y tolerancias de las tensiones (voltaje), frecuencia (ciclaje) de alimentación eléctrica y las características que deben reunir las instalaciones auxiliares.*
- Por fenómenos naturales tales como: temblores, inundaciones, incendios, descargas eléctricas, rayos etc. o delitos causados por terceros (choques asaltos, riñas, etc.).*

CAUTION

Use of controls or adjustments or performance of procedures other than herein may result in hazardous radiation exposure or other unsafe operation.



Contents

General Information

Supplied accessories	5
Environmental Information	5
Safety Information	5
Hearing Safety	6

Preparations

Rear connections	7
Inserting batteries into the Remote Control	8
Using the Remote Control to operate the system	8

Controls

Controls on the system and remote control	9
Controls available on the remote control only	9

Basic Functions

Plug and Play (for tuner installation)	10
Switching the system on	10
Power-saving automatic standby	10
Adjusting volume and sound	10

CD/MP3 Operation

Loading a disc	11
Basic playback controls	11
Playing an MP3 disc	11
Different play modes: SHUFFLE and REPEAT	12
Programming track numbers	12
Reviewing the programme	12
Erasing the programme	12

Radio Reception

Tuning to radio stations	13
Programming radio stations	13
Automatic programming	13
Manual programming	13
Tuning to preset radio stations	13

Other Connection

Listening to an external source	14
---------------------------------------	----

Maintenance

Clock/Timer

Setting the clock	15
Setting the timer	15
Activating and deactivating TIMER	15
Activating and deactivating SLEEP	15

Specifications

Troubleshooting

Congratulations on your purchase and welcome to Philips!

To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

IMPORTANT!

PLEASE NOTE THAT THE VOLTAGE SELECTOR LOCATED AT THE REAR OF THIS SYSTEM IS PRESET AT 220V FROM THE FACTORY. FOR COUNTRIES THAT OPERATE AT 110V-127V, PLEASE ADJUST TO 110V-127V BEFORE YOU SWITCH ON THE SYSTEM.

Supplied accessories

- 2 speaker boxes
- remote control

Environmental Information

All unnecessary packaging has been omitted. We have tried to make the packaging easy to separate into three materials: cardboard (box), polystyrene foam (buffer) and polyethylene (bags, protective foam sheet).

Your system consists of materials which can be recycled and reused if disassembled by a specialized company. Please observe the local regulations regarding the disposal of packaging materials, exhausted batteries and old equipment.

Safety Information

- Before operating the system, check that the operating voltage indicated on the typeplate (or the voltage indication beside the voltage selector) of your system is identical with the voltage of your local power supply. If not, please consult your dealer.
- Place the system on a flat, hard and stable surface.
- Where the MAINS plug or an appliance coupler is used as the disconnet device, the disconnet device shall remain readily operable.
- The apparatus shall not be exposed to dripping or splashing.
- Install the unit near the AC outlet and where the AC power plug can be easily reached.
- Place the system in a location with adequate ventilation to prevent internal heat build-up in your system. Allow at least 10 cm (4 inches) clearance from the rear and the top of the unit and 5 cm (2 inches) from each side.
- The ventilation should not be impeded by covering the ventilation openings with items, such as newspapers, table-cloths, curtains, etc.
- Do not expose the system, batteries or discs to excessive moisture, rain, sand or heat sources caused by heating equipment or direct sunlight.
- No naked flame sources, such as lighted candles, should be placed on the apparatus.
- No objects filled with liquids, such as vases, shall be placed on the apparatus.
- If the system is brought directly from a cold to a warm location, or is placed in a very damp room, moisture may condense on the lens of the disc unit inside the system. Should this occur, the CD player would not operate normally. Leave the power on for about one hour with no disc in the system until normal playback is possible.
- The mechanical parts of the set contain self-lubricating bearings and must not be oiled or lubricated.
- Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.
- **When the system is switched to Standby mode, it is still consuming some power. To disconnect the system from the power supply completely, remove the AC power plug from the wall socket.**

General Information

Hearing Safety

Listen at a moderate volume.

- Using headphones at a high volume can impair your hearing. This product can produce sounds in decibel ranges that may cause hearing loss for a normal person, even for exposure less than a minute. The higher decibel ranges are offered for those that may have already experienced some hearing loss.
- Sound can be deceiving. Over time your hearing "comfort level" adapts to higher volumes of sound. So after prolonged listening, what sounds "normal" can actually be loud and harmful to your hearing. To guard against this, set your volume to a safe level before your hearing adapts and leave it there.

To establish a safe volume level:


- Set your volume control at a low setting.
- Slowly increase the sound until you can hear it comfortably and clearly, without distortion.

Listen for reasonable periods of time:

- Prolonged exposure to sound, even at normally "safe" levels, can also cause hearing loss.
- Be sure to use your equipment reasonably and take appropriate breaks.

Be sure to observe the following guidelines when using your headphones.

- Listen at reasonable volumes for reasonable periods of time.
- Be careful not to adjust the volume as your hearing adapts.
- Do not turn up the volume so high that you can't hear what's around you.
- You should use caution or temporarily discontinue use in potentially hazardous situations.
- Do not use headphones while operating a motorized vehicle, cycling, skateboarding, etc.; it may create a traffic hazard and is illegal in many areas.



Rear connections

The type plate is located at the rear of the system.

A Power

- Before connecting the AC power cord to the wall outlet, ensure that all other connections have been made.
- If your system is equipped with a Voltage Selector; set the VOLTAGE SELECTOR to the local power line voltage.

WARNING!


- For optimal performance, use only the original power cable.
- Never make or change any connections with the power switched on.

To avoid overheating of the system, a safety circuit has been built in. Therefore, your system may switch to Standby mode automatically under extreme conditions. If this happens, let the system cool down before reusing it (not available for all versions).

B Speakers Connection

Front Speakers

Connect the speaker wires to the SPEAKERS terminals, right speaker to "RIGHT" and left speaker to "LEFT", coloured (marked) wire to "+" and black (unmarked) wire to "-".



- Fully insert the stripped portion of the speaker wire into the terminal as shown.


Notes:

- For optimal sound performance, use the supplied speakers.
- Do not connect more than one speaker to any one pair of + / - speaker terminals.
- Do not connect speakers with an impedance lower than the speakers supplied. Please refer to the SPECIFICATIONS section of this manual.

Preparations

Inserting batteries into the Remote Control

- 1 Open the battery compartment.
- 2 Insert two R03 or AAA batteries following the indications (+/-) inside the compartment.
- 3 Close the cover.



Using the Remote Control to operate the system

- 1 Aim the Remote Control directly at the remote sensor (IR) on the front panel.
- 2 Do not put any objects between the Remote Control and the system while operating the system.




CAUTION!

- Remove batteries if they are exhausted or if the Remote Control is not being used for a long time.
- Do not use old and new or different types of batteries in combination.
- Batteries contain chemical substances, so they should be disposed of properly.





Notes for the remote control:

- First, select the source you wish to control by pressing one of the source select keys on the remote control (DISC or AUX, for example).
- Then select the desired function (▶||, ◀, ▶| for example).


Controls on the system and remote control

- ① **STANDBY ON (PWR )**
 - switches the system to standby or on.
- ② **iR SENSOR**
 - infrared sensor for remote control.
- ③ **SOURCE**
 - selects the respective sound source for CD/TUNER/AUX.
 - switches on the system.
- ④ **ALBUM/PRESET +/-**
 - for radio selects a preset radio station.
 - for MP3 disc selects an album.
- ⑤ **DBB (Dynamic Bass Boost)**
 - enhances the bass.
- ⑥ **TUNING  **
 - for Tuner tunes to radio stations.
 - for CD skips to the beginning of the current/previous/subsequent track.
 - fast searches back and forward within a track/CD.
 - for clock/timer adjusts the hours and minutes for the clock/timer function
- VOL +/-**
 - adjusts the volume level.
- ⑦ **⏮**
 - starts or interrupts CD playback.
- ⑧ **MODE**
 - selects Repeat One, Repeat All or Shuffle play mode
- ⑨ **PROG**
 - for CD programmes tracks and reviews the programme.
 - for Tuner programmes tuner stations manually or automatically.
- ⑩ **■**
 - stops CD playback or erases a CD programme.
- ⑪ **PULL TO OPEN**
 - opens/closes the CD door.
- AUX jack (located on the back panel)**
 - connects an external source (3.5 mm socket)
- HEADPHONE (located on the back panel)**
 - connects headphones

Controls available on the remote control only

- ⑫ **TAPE**
 - No function on this set.
- ⑬ **REPEAT ALL**
 - selects Repeat All play mode.
- ⑭ **SHUF**
 - plays CD/MP3 tracks in random order.
- ⑮ **REP**
 - plays a track repeatedly.
- ⑯ **SLEEP**
 - activates/deactivates or selects the sleeper time.
- ⑰ **TIMER ON/OFF**
 - Turns on or off timer
- ⑱ **TIMER**
 - sets the timer function.
- ⑲ **⏮**
 - starts or interrupts CD playback.
 -  
 - for Tuner tunes to radio stations.
 - for clock/timer adjusts the hours and minutes for the clock/timer function
 -  
 - for CD skips to the beginning of the current/previous/subsequent track.
 - fast searches back and forward within a track/CD.
- ⑳ **DSC**
 - (Digital Sound Control) selects sound characteristics: JAZZ/POP/CLASSIC/ROCK.
- ㉑ **VOL +/-**
 - adjusts the volume level.
- ㉒ **MUTE**
 - interrupts and resumes sound reproduction
- ㉓ **Numeric keypad (0-9)**
 - selects track or station number
- ㉔ **CLOCK/DISPLAY**
 - for CD displays the current track number and total remaining time (or current album and track numbers for MP3 disc) during playback.
 - for clock sets the clock function

Basic Functions



IMPORTANT:
Before you operate the system, complete the preparation procedures.

Plug and Play (for tuner installation)

Plug and Play allows you to store all available radio stations automatically.

First time setup/power up

- 1 When you turn on the main supply, "AUTO INSTALL - PRESS PLAY" is displayed.
- 2 Press ► || on the system to start installation.
→ "PLUG AND PLAY" ... "INSTALL" is displayed, followed by "TUNER" and "AUTO".
→ PROG starts flashing.
→ The system will automatically store the radio stations with sufficient signal strength, starting from FM, and followed by AM band.
→ When all the available radio stations are stored or the memory for 20 presets are used, the first preset radio station will be played.

To reinstall Plug and Play

- 1 In standby mode, press and hold ► || on the system until "AUTO INSTALL - PRESS PLAY" is displayed.
- 2 Press ► || again to start installation.
→ All previously stored radio stations will be replaced.

To exit without storing the Plug and Play

- Press ■ on the system.
→ If you do not complete the Plug and Play installation, the function will be restarted when you next turn on the main supply again.

Notes:

- If no stereo frequency is detected during Plug and Play, "CHECK ANTENNA" will be displayed.
- During Plug and Play, if no button is pressed within 15 seconds, the system will exit Plug and Play mode.

Switching the system on

- Press **STANDBY-ON** (power symbol) or **SOURCE** (POWER, DISC, TUN, or AUX on the remote control).
→ The system will switch to the last selected source.
- Press **DISC, TUN, or AUX** on the remote control.
→ The system will switch to the selected source.

To switch the system to standby mode


- Press **STANDBY-ON** (power symbol) on the system (or **POWER** on the remote control).

Power-saving automatic standby


The power-saving feature automatically switches to standby 90 minutes after a CD playback has ended and no control is operated.

Adjusting volume and sound

- 1 Press **VOL + / -** to adjust volume.
→ Display shows the volume level VOL and a number from 0-32.
- 2 Press **DSC** repeatedly to select the desired sound effect: JAZZ / POP / CLASSIC / ROCK.
- 3 Press **DBB** to switch bass enhancement on or off.
→ Display shows: **DBB** if the DBB is activated.
- 4 Press **MUTE** on the remote control to interrupt sound reproduction instantly.
→ Playback will continue without sound.




- To activate sound reproduction you can:
 - press **MUTE** again;
 - adjust the volume controls;
 - change source.



IMPORTANT:

The lens of the CD player should never be touched.




Loading a disc

This CD player plays Audio Discs including CD-Recordables, CD-Rewritables and MP3 CD.

- CD-ROM, CD-I, CDV, VCD, DVD or computer CDs, however, are not possible.
- DRM-protected WMA file is not supported.

- 1 Select **CD** source.
- 2 Lift the CD door on the top of the system to open the CD compartment.
→ **OPEN** is displayed when you open the CD compartment.



- 3 Insert a disc with the printed side facing up and press down on **PULL TO OPEN** to close the CD door.
→ **READING** is displayed as the CD player scans the contents of a disc, and then the total number of tracks and playing time (or the total number of albums and tracks for MP3 disc) are shown.

Basic playback controls

To play a disc

- Press **▶||** to start playback.
→ The current track number and elapsed playing time of the track are displayed during disc playback.

To select a different track

- Press **TUNING ◀◀ ▶▶** (on the remote control ◀ / ▶) once or repeatedly until the desired track number appears in the display.

To find a passage within a track

- 1 Press and hold down on **TUNING ◀◀ ▶▶** (on the remote control ◀ / ▶).
→ The disc is played at high speed and low volume.
- 2 When you recognise the passage you want, release **TUNING ◀◀ ▶▶** (on the remote control ◀ / ▶).
→ Normal playback continues.

To interrupt playback

- Press **▶||** during playback.
→ The display freezes and the elapsed playing time flashes when playback is interrupted.
→ To resume, press **▶||** again.

To stop playback

- Press **■**.

Notes: CD play will also stop when;

- the CD door is opened.
- the disc has reached the end.
- you select another source: **TUNER** or **AUX**.
- you select standby.

Playing an MP3 disc

- 1 Load an MP3 disc.
→ The disc reading time may exceed 10 seconds due to the large number of songs compiled into one disc.
→ "**XXXX TXXXX**" is displayed. **XXXX** is the total album number and **TXXXX** is the total track number.
- 2 Press **ALBUM/PRESET + / -** to select a desired album.

CD/MP3 Operation

- 3 Press **TUNING** **I◀◀ ▶▶I** (on the remote control **◀ / ▶**) to select a desired track.
 - 4 Press **▶II** to start playback.
- During playback, press **CLOCK/DISPLAY** on the remote control to show the album and track numbers.

Supported MP3 disc formats:

- ISO9660, Joliet, UDF 1.5
- Maximum title number: 999 (depending on filename length)
- Maximum album number: 99
- Supported sampling frequencies: 32 kHz, 44.1 kHz, 48 kHz
- Supported Bit-rates: 32~256 (kbps), variable bitrates

Different play modes: SHUFFLE and REPEAT

You can select and change the various play modes before or during playback. The play modes can also be combined with PROGRAMME.

SHUF tracks of the entire disc are played in random order

REP ALL repeats the entire disc/ programme

REP plays the current track continuously

REP ALB repeats all tracks in the current (for MP3 only) album

- 1 To select your play mode, press **REP**, **REP ALL** or **SHUF** button before or during playback until the display shows the desired function.
 - 2 Press **▶II** to start playback if in the STOP position.
 - If you have selected SHUFFLE, playback starts automatically.
 - 3 To return to normal playback, press the respective **REP**, **REP ALL** or **SHUF** button until the various SHUFFLE/ REPEAT modes are no longer displayed.
- You can also press **■** to cancel your play mode.
- Note:**
- The **SHUFFLE** and **REPEAT** functions cannot be used simultaneously.

Programming track numbers

Programme in the STOP position to select and store your disc tracks in the desired sequence. If you like, store any track more than once. Up to 20 tracks can be stored in the memory.

- 1 In the stop position, use the **TUNING I◀◀ ▶▶I** (on the remote control **◀ / ▶**) to select your desired track number.
- For MP3, you may press **ALBUM/PRESET + / -** to select a desired album, then press **TUNING I◀◀ ▶▶I** (on the remote control **◀ / ▶**) to select your desired track.
- 2 Press **PROG.** to store.
 - Display: **PROG** flashes, and **PR** **□ I** is displayed briefly, then the selected track number (and the selected album number for MP3).
- 3 Repeat **steps 1-2** to select and store all desired tracks.
- 4 To start playback of your disc programme, press **▶II**.

Reviewing the programme


- Stop playback and press **PROG** repeatedly.
- To exit review mode, press **■**.

Erasing the programme

You can erase the programme by:

- pressing **■** once in the STOP mode;
- pressing **■** twice during playback;
- opening the CD compartment;
 - **PROG** disappears from the display.

Radio Reception



Tuning to radio stations

- 1 Press **SOURCE** on the set repeatedly or press **TUN** on the remote control repeatedly until the desired waveband (FM or AM) is displayed.
- 2 Press down on **TUNING** (◀◀ ▶▶) (◀◀ / ▶▶ on the remote control) and release the button. → The radio automatically tunes to a station with sufficient reception. Display indication during automatic tuning: *S E R C H*.
- 3 Repeat step 2 if necessary until you find the desired station.
- To tune to a weak station, press **TUNING** (◀◀ ▶▶) (◀◀ / ▶▶ on the remote control) briefly and repeatedly until you have found optimal reception.

Programming radio stations

You can store up to a total of 20 radio stations in the memory.

Automatic programming

Automatic programming will start with a chosen preset number. From this preset number upwards, former programmed radio stations will be overridden. The system will only programme stations which are not in the memory already.

- 1 Press **ALBUM/PRESET** + / - to select the preset number where programming should start.

Note:

– If no preset number is selected, default is preset (1) and all your presets will be overridden.

- 2 Press **PROG.** for more than 2 seconds to activate programming. → **AUTO** is displayed and available stations are programmed in order of waveband reception strength. The first preset automatically stored will then be played.

Manual programming

- 1 Tune to your desired station (see Tuning to radio stations).
- 2 Press **PROG.** to activate programming. → **PROG** flashes in the display.
- 3 Press **ALBUM/PRESET** + / - to allocate a number from 1 to 20 to this station.
- 4 Press **PROG** again to confirm the setting. → **PROG** disappears, the preset number and the frequency of the preset station are shown.
- 5 Repeat the above four steps to store other stations.
- You can override a preset station by storing another frequency in its place.

Tuning to preset radio stations

- Press **ALBUM/PRESET** + / - until the desired preset station is displayed.

Other Connection

Listening to an external source

You can listen to the sound of the connected external device through your system's speakers.

- 1 Select **AUX** source by pressing **AUX** button.
- 2 Use a cinch cable (not supplied) to connect MCM 158's AUX jack (3.5 mm, located on the back panel) to an AUDIO OUT or headphone jack on an external equipment (such as CD player, or VCR).

Maintenance

Cleaning the Cabinet

- Use a soft cloth slightly moistened with a mild detergent solution. Do not use a solution containing alcohol, spirits, ammonia or abrasives.


Cleaning Discs

- When a disc becomes dirty, clean it with a cleaning cloth. Wipe the disc from the centre out.
- Do not use solvents such as benzene, thinner, commercially available cleaners, or antistatic spray intended for analogue records.



Cleaning the disc lens

- After prolonged use, dirt or dust may accumulate at the disc lens. To ensure good playback quality, clean the disc lens with Philips CD Lens Cleaner or any commercially available cleaner. Follow the instructions supplied with cleaner.



Setting the clock

- 1 In standby mode, press and hold **CLOCK/DISPLAY** on the remote control set for 2 seconds.
- 2 Press **PROG.** to select 12-hour or 24-hour display.
- 3 Press **CLOCK/DISPLAY** to confirm.
→ The clock digits for the hours flash.
- 4 Press **TUNING** |◀◀ ▶▶| (◀◀/▶▶) on the remote control) to set the hours.
- 5 Press **CLOCK/DISPLAY** again.
→ The clock digits for the minutes flash.
- 6 Press **TUNING** |◀◀ ▶▶| (◀◀/▶▶) on the remote control) to set the minutes.
- 7 Press **CLOCK/DISPLAY** to confirm the time.

Note:

– The backlight for clock display is off in standby.

Setting the timer

- The system can be used as an alarm clock, whereby the CD or TUNER is switched on at a set time. The clock time needs to be set first before the timer can be used.
- 1 In standby mode, press and hold **TIMER** about 2 seconds on the remote control.
 - 2 Press **SOURCE** (or **DISC/TUN** on the remote control) to select sound source.
 - 3 Press **TIMER** to confirm your desired mode.
→ The clock digits for the hours flash.
 - 4 Press **TUNING** |◀◀ ▶▶| (◀◀/▶▶) on the remote control) to set the hours.

- 5 Press **TIMER** again.
→ The clock digits for the minutes flash.
- 6 Press **TUNING** |◀◀ ▶▶| (◀◀/▶▶) on the remote control) to set the minutes.
- 7 Press **TIMER** to confirm the time.
→ The timer is now set and activated.

Notes:

– If CD source is selected and no disc is in the CD tray or the disc has an error, TUNER will be selected automatically.


Activating and deactivating TIMER

- In standby or during playback, press **TIMER ON/OFF** once.
→ Display shows if activated, and disappears if deactivated.

Activating and deactivating SLEEP

The sleep timer enables the system to switch off by itself after a set period of time.

- Press **SLEEP** on the remote control once or more.
→ Display shows **zZ** and one of the sleep time options in sequence: 60, 45, 30, 15, 0, 60... if you have selected a time.
- To deactivate, press **SLEEP** on the remote control once or more until "0" is shown, or press **STANDBY ON** on the system (or **POWER** on the remote control).
→ **zZ** disappears from the display.



Specifications

AMPLIFIER

Output power 2 x 2W RMS
Signal-to-noise ratio \geq 60 dBA (IEC)
Frequency response 125 – 16000 Hz
Impedance loudspeakers 8 Ω

CD PLAYER

Frequency range 125 – 16000 Hz
Signal-to-noise ratio 65 dBA

TUNER

FM wave range 87.5 – 108 MHz
AM wave range 530 – 1700 kHz
Sensitivity
– FM 26 dB sensitivity 20 μ V
– AM 26 dB sensitivity 5 mV/m
Total harmonic distortion \leq 5%

SPEAKERS

Bass reflex system
Dimensions (w x h x d) . 134 x 230 x 152 (mm)

GENERAL INFORMATION

AC Power 110 – 127 / 220 – 240V
..... 50/60 Hz, switchable
Dimensions (w x h x d) .. 148 x 233 x 216 (mm)
Weight (with/without speakers)
..... approx. 3.65 / 1.53 kg
Power consumption
Active 15 W
Standby < 4 W

Specifications and external appearance are subject to change without notice.

WARNING

Under no circumstances should you try to repair the system yourself, as this will invalidate the warranty. Do not open the system as there is a risk of electric shock.

If a fault occurs, first check the points listed below before taking the system for repair. If you are unable to remedy a problem by following these hints, consult your dealer or Philips for help.

Problem	Solution
“NO DISC” is displayed.	<ul style="list-style-type: none"> ✓ Insert a disc. ✓ Check if the disc is inserted upside down. ✓ Wait until the moisture condensation at the lens has cleared. ✓ Replace or clean the disc, see “Maintenance”. ✓ Use a finalized CD-RW or a correct MP3-CD format disc.
Radio reception is poor.	<ul style="list-style-type: none"> ✓ If the signal is too weak, adjust the antenna for better reception. ✓ Increase the distance between the Mini HiFi System and your TV or VCR.
Recording or playback cannot be made.	<ul style="list-style-type: none"> ✓ Clean deck parts, see “Maintenance”. ✓ Use only NORMAL (IEC I) tape. ✓ Apply a piece of adhesive tape over the missing tab space.
The system does not react when buttons are pressed.	<ul style="list-style-type: none"> ✓ Remove and reconnect the AC power plug and switch on the system again.
Sound cannot be heard or is of poor quality.	<ul style="list-style-type: none"> ✓ Adjust the volume. ✓ Disconnect the headphones. ✓ Check that the speakers are connected correctly. ✓ Check if the stripped speaker wire is clamped. ✓ Make sure the MP3-CD was recorded within 32-256 kbps bit rate with sampling frequencies at 48 kHz, 44.1 kHz or 32 kHz.
The left and right sound outputs are reversed.	<ul style="list-style-type: none"> ✓ Check the speaker connections and location.

Troubleshooting

Problem	Solution
The remote control does not function properly.	<ul style="list-style-type: none">✓ Select the source (CD or TUNER, for example) before pressing the function button (▶, ◀, ▶).✓ Reduce the distance between the remote control and the system.✓ Insert the batteries with their polarities (+/- signs) aligned as indicated.✓ Replace the batteries.✓ Point the remote control directly towards the IR sensor.
The time is not working.	<ul style="list-style-type: none">✓ Set the clock correctly.✓ Press TIMER ON/OFF to switch on the timer.
The Clock/Timer setting is erased.	<ul style="list-style-type: none">✓ Power has been interrupted or the power cord has been disconnected. Reset the clock/timer.

Validez de la garantía

Todos los productos de la línea de audio y video Philips, se registrarán por un año de garantía internacional (365 días), salvo para Chile donde los productos de las líneas CD Portable y RCR CD, los cuales se rigen por 6 meses de garantía (182 días)

Condiciones de la garantía

Esta garantía perderá su validez si:

- El defecto es causado por uso incorrecto o en desacuerdo con el manual de instrucciones
- El aparato sea modificado, violado por una persona no autorizada por Philips
- El producto esté funcionando con un suministro de energía (red eléctrica, batería, etc.) de características diferentes a las recomendadas en el manual de instrucciones
- El número de serie que identifica el producto se encuentre de forma adulterada.

Están excluidos de garantía,

- Los defectos que se generen debido al incumplimiento del manual de instrucciones del producto
- Los casos fortuitos o de la fuerza mayor, como aquellos causados por agentes de la naturaleza y accidentes, descargas eléctricas, señales de transmisión débiles.
- Los defectos que se generen debido al uso de los productos en servicios no doméstico/residencial regulares o en desacuerdo con el uso recomendado
- Daños ocasionados por fluctuaciones de voltajes, voltaje fuera de norma o por causas fuera de Philips, como cortocircuitos en los bafles o parlantes.
- En las ciudades en donde no existe el taller autorizado del servicio de Philips, los costos del transporte del aparato y/o el técnico autorizado, corren por cuenta del cliente.
- La garantía no será válida si el producto necesita modificaciones o adaptaciones para que funcione en otro país que no es aquél para el cual fue mercadeado.

El único documento válido para hacer efectiva la garantía de los productos, es la Factura o Boleta de compra del consumidor final.

Aquellos productos que hayan sido adquiridos en otros países y que no estén en el rango normal del país donde se efectuará la reparación, dicha prestación de servicio tomará mas tiempo de lo normal ya que es necesario pedir las partes/piezas al centro de producción correspondiente.

Centros de información

Líneas de atención al consumidor

Chile: 600-7445477

Colombia: 01-800-700-7445

Costa Rica: 0800-506-7445

Ecuador: 1-800-10-1045

El Salvador: 800-6024

Guatemala: 1-800-299-0007

Panamá: 800-8300

Peru: 0800-00100

Rep. Dominicana: 1-800-751-2673

Venezuela: 0800-100-4888

POLIZA DE GARANTIA PARA MEXICO

ESTA POLIZA ES GRATUITA

Este aparato ha sido cuidadosamente diseñado y se ha fabricado con los mejores materiales bajo un estricto control de calidad, garantizando su buen funcionamiento por los periodos establecidos según el aparato (ver lista en la parte inferior) **a partir de la entrega del aparato al consumidor.**

Esta póliza incluye la reparación o reposición gratuita de cualquier parte o componente que eventualmente fallase y la mano de obra necesaria para su reparación, así como los gastos de transportación razonablemente erogados dentro de nuestros centros de servicio, misma que se hará efectiva en cualquiera de nuestros centros de servicio autorizados en el país.

Si su aparato llegase a requerir de nuestro servicio de garantía, acuda al centro de servicio más cercano a su domicilio, de tener alguna duda por favor llame a nuestro **CENTRO DE INFORMACIÓN AL CLIENTE LADA** sin costo en toda la republica al **01 800 504 62 00** en donde con gusto le indicaremos el centro de servicio autorizado más cercano a su domicilio.

PHILIPS MEXICANA S.A. de C.V. a través de sus centros de servicio autorizados **reparará y devolverá a usted su aparato en un plazo no mayor a 20 días hábiles,** contados a partir de la fecha de ingreso, impresa en la orden de servicio de cualquiera de nuestros centros de servicio autorizados.

La garantía de esta póliza cubre cualquier desperfecto o daño eventualmente ocasionado por los trabajos de reparación y/o traslado del aparato en el interior de nuestros centros de servicio autorizados.

Esta póliza sólo tendrá validez, si está debidamente requisitada, sellada por la casa vendedora, en caso de extravío de esta póliza, podrá hacer efectiva su garantía con la presentación de su factura de compra.

ESTA POLIZA NO SE HARA EFECTIVA EN LOS SIGUIENTES CASOS:

-Cuando el aparato sea utilizado en condiciones distintas a las normales.

-Cuando el aparato no haya sido operado de acuerdo con el instructivo de uso que se le acompaña.

-Cuando la causa de la falla o mal funcionamiento sea consecuencia de una reparación inadecuada o alteración producida por personas no autorizadas por PHILIPS MEXICANA S.A. de C.V.

PERIODOS DE GARANTIA

36 MESES.- Monitores para computadora.

12 MESES.- Televisores con y sin reproductor de video digital DVD, videocassetteras, reproductores de discos de video digital DVD, reproductores de disco de video digital con pantalla incluida, grabadores reproductores de disco de video digital DVD, grabadores reproductores de disco compacto, video proyectores (excepto la lámpara) , cámaras de video, radiograbadoras con y sin reproductor de disco compacto, reproductores de cassette portátil, reproductores de disco compacto portátil, reproductores de audio digital MP3 (Internet), decodificadores de señal (IRD), televisores para hotel, sistemas de observación, televisores de proyección, teléfonos celulares, pagers, minisistemas de audio, minisistemas de audio con reproductor de disco de video digital integrado, microsistemas de audio, sistemas de cine en casa, equipos modulares, sintonizadores, facsimils, LNB, antenas de recepción de satélite, DVD ROM, CDR ROM y CDRW ROM para computadora.

6 MESES.- radio relojes, radios A.M./F.M., auto estéreos, teléfonos inalámbricos, cámaras digitales.

3 MESES.- Accesorios, controles remotos, bocinas, cintas para fax y para cámaras de videoconferencia, audifonos.

PHILIPS

MC - 719 - ARCO

Philips Mexicana, S.A. de C.V.

Producto Importado por:
Philips Mexicana, S.A. de C.V.

Av. La Palma No.6
Col. San Fernando La Herradura
Huixquilucan, Edo. de México, C.P. 52784
Tel. 52 69 90 00

Centro de Información al Cliente
Información General

LADA SIN COSTO PARA TODA LA REPUBLICA
01 800 504 62 00
CORREO ELECTRONICO
philips@merkafon.com

MODELO _____ No. DE SERIE _____
La presente garantía contará a partir de: DIA _____ MES _____ AÑO _____

En caso que en su producto presente alguna falla, acuda al centro de servicio más cercano a su domicilio (según listado de talleres anexo) y en caso de tener alguna duda o pregunta por favor llame a nuestro Centro de información al Cliente, en donde con gusto le atenderemos en todo lo relativo a:

- * Servicio de sus aparatos Philips
- * Información de productos y Talleres Autorizados Philips;
- * Asesoría en el manejo e instalación de su producto Philips
- * Información en donde puede adquirir productos y accesorios Philips

Para hacer efectiva la garantía de su producto, es necesario presentar esta póliza debidamente requisitada o de lo contrario, presentar su factura de compra.

CENTROS DE SERVICIO AUTORIZADOS PHILIPS EN LAS PRINCIPALES CIUDADES

NOTA: Los Centros que tengan (S) solo proporcionan Servicio y los que tengan (SR) venden refacciones, accesorios y proporcionan Servicio

CIUDAD	LADA	TELEFONO	CORREO ELECTRONICO		CIUDAD	LADA	TELEFONO	CORREO ELECTRONICO	
ACAPULCO, GRO	744	483-32-96	serproa@yahoo.com.mx	S	MEXICO, D. F. ZONA NORTE	55	55-67-19-92 55-67-22-56	chyr_electronica@yahoo.com.mx	S
AGUASCALIENTES, AGS	449	915-51-81	jimsaele@hotmail.com	S	MEXICO, D. F. ZONA ORIENTE	55	57-88-89-37	cnoguedam@terra.com.mx	S
CAMPECHE, CAMP.	981	816 28 75	oreza@hotmail.com	S	MEXICO, D. F. ZONA PONIENTE	55	58 12 44 12	raumltrm@avante.net	S
CANCLUN, Q. ROO	998	984 18 74	gammacancun@webtelmex.net.mx	S	MONTERREY, N.L.	818	375-16-17 400-54-03	mcesa@prodigy.net.mx	S
CD. JUAREZ, CHIH	656	618-21-28 623-46-20	teloservicio@prodigy.net.mx	S	MORELIA, MCH	443	312-03-17	multiservicios_profesionales_de_zamorara@msn.co	S
CD. OBREGON, SON	644	412-41-51 419-20-93	mena747@prodigy.net.mx	S	NEZAHUALCOYOTL EDO.MEX	55	57-33-34-98	vicentegutierrez@prodigy.net.mx	S
CD. VICTORIA, TAMPS	834	315-68-03 312-51-93	eeil_smiller@yahoo.com.mx	S	OAXACA, OAX	951	516-47-37	efrancisor@prodigy.net.mx	S
COLIMA, COL	312	314-03-03	tv_antenas@hotmail.com	S	ORIZABA, VER	272	724 38 53	barreda_electronics@hotmail.com	S
CUERNAVACA, MOR	777	313-30-49 313-90-92	centroserviciohertz@hotmail.com	S	PACHUCA, HGO	771	714-15-81	zarateelo@hotmail.com	S
CULIACAN, SIN	687	716-15-10	stereovox@dn.megared.net.mx	S	POZA RICA, VER	782	824 47 82	sonydigital@prodigy.net.mx	S
CHIHUAHUA, CHIH	614	421-59-30 421-63-61	comercialfomestica@hotmail.com	S	PUEBLA, PUE	222	248-77-84 231-63-77	rascon12@prodigy.net.mx	S
CHILPANCIINGO, GRO.	747	471 72 73	ingitec_gro@hotmail.com	S	QUERETARO, QRO	442	216-10-09		S
DURANGO, DGO	618	825-00-05	evsurdigo@yahoo.com	S	SAN TILLO, COAH	844	415 35 80	etronicadigital_07@hotmail.com	S
GUADALAJARA, JAL	33	36-15-72-62 36-16-83-27	www. Leeocom.com.mx	S	SAN LUIS POTOSI, S.L.P.	444	815-34-07	centro_servicioslp@prodigy.net.mx	S
HERMOSILLO, SON	662	210-54-95 210-05-86	manuelw@prodigy.net.mx	S	SATELITE, EDO. MEX	55	55 62 59 73	missus_satelite@hotmail.com	S
IRAPUATO, GTO	462	628-51-10	tv_gase@hotmail.com	S	TAMPICO, TAMPS	833	214 13 60	electromovie@prodigy.net.mx	S
LA PAZ, B.C.S	612	122-95-89	cenalpa@prodigy.net.mx	S	TEPIC, NAY	311	212-66-93	spe_tn@hotmail.co	S
LEON, GTO	477	770-26-69	lceespecializados@hotmail.com	S	TUJANA, B.C.N	684	621-22-15	www.eg1@telhor.net	S
MATAMOROS, TAMPS	868	813-50-13	digitalelectronica@comunicable.net	S	TOLUCA, EDO. MEX	722	214-83-09		S
MAZATLAN, SIN	689	982-42-21	e_santel@hotmail.com	S	TOLUCA, EDO. MEX	722	213 62 94		S
MERIDA, YUC	999	928-59-05	evia2@prodigy.net.mx	S	TORREON, COAH	871	732-49-49	jomar02@prodigy.net.mx	S
MEXICALI, B.C.N	686	561-98-08 561-98-18	bajatelectronics@aol.com	S	TUXTLA GUERRERIZ, CHIS	961	618-19-08	kcvidao@prodigy.net.mx	S
MEXICO D.F. ZONA ARAGON	55	57 94 06 34	philipservicio@hotmail.com	S	URUAPAN, MICH	452	524-06-38 524-37-78	rossalao@nichi.telmex.net.mx	S
MEXICO D.F. ZONA CENTRO	55	55 21 60 07	unitelmex@yahoo.com.mx	SR	VERACRUZ, VER	229	932-78-23 932-44-44	antza@ver.megared.net.mx	S
MEXICO, D. F. ZONA SUR	55	55-36-71-03 55-36-25-75	centrosdeservicioelectronico@hotmail.com	S	VILLAHERMOSA, TAB	993	314-31-36 314-61-67	villalec@intaras.net.mx	S
MEXICO, D. F. ZONA NORTE	55	53 68 30 21	tissasser@prodigy.net.mx	S	ZACATECAS, ZAC.	492	922 31 63	sernacur@hotmail.com	S

Para mayor referencia de Talleres de Servicio Autorizados en otras ciudades comunicarse al 01 800 504 62 00 (lada sin costo)

LISTA DE SERVIÇO AUTORIZADO - BRASIL

ACRE									
CRUIZEIRO DO SUL	68-33224432	BARRA S FRANCISCO	27-37562345	BELO HORIZONTE	31-32257262	PORTO TROMBETAS	93-35491606		
RIO BRANCO	68-33217642	CASTELO	28-35420482	BELO HORIZONTE	31-32254066	SANTAREM	93-35232522		
RIO BRANCO	68-33249116	COLATINA	27-37222288	BELO HORIZONTE	31-34420944				
ALAGOAS		GUARAPARI	27-33614355	BELO HORIZONTE	31-34181919	PARNABA			
ARAPIRACA	82-5222367	LINHARES	27-33710148	BELO HORIZONTE	31-32957700	CAMPINA GRANDE	83-3212128		
MACEIO	82-32417237	S GABRIEL DA PALHA	27-37271153	BELO HORIZONTE	31-34491000	ESPERANCA	83-3612273		
PALMEIRA DOS INDIOS	82-4313452	SAO MATEUS	27-37638906	BELO HORIZONTE	31-21027373	GUARABIRA	83-2711159		
UNIAO DOS PALMARES	82-32811305	VILA VELHA	27-32289133	BELO HORIZONTE	31-35212300	JOAO PESSOA	83-3246689		
		VITORIA	27-32233899	BOM DESPACHO	37-35212906	JOAO PESSOA	83-3246604		
				BOM DESPACHO	37-35222511	NOVA FLORESTA	83-32210460		
		GOIAS		CARANGOLA	32-37421017	SAFE	83-3741014		
AMAPA		ANAPOLIS	62-3243562	CASSIA	35-35412293	SOLANEA	83-2832479		
MACAPA	96-2175934	CACU	64-6561811	CONGONHAS	31-37311638				
SANTANA	96-2811080	CALDAS NOVAS	64-6452878	CONS LAFAIETE	31-37637784				
		CATALAO	64-4413786	CONTAGEM	31-33912594				
AMAZONAS		FORMOSA	61-6318166	CONTAGEM	31-33953461				
MANAUS	92-36333035	GOIANIA	62-32919095	KORONEL FABRICIANO	31-38411804	AMPERE	46-5471605		
MANAUS	92-36633366	GOIANIA	62-32292908	CURVELO	38-37213009	ANTONINA	41-34321782		
MANAUS	92-33242252	GOIATUBA	94-34952272	DIVINOPOLIS	37-3212353	APUCARANA	43-34223506		
		INHUMAS	62-5111840	FORMIGA	37-33214177	ARAPONGAS	43-2753723		
BAHIA		IPAPERI	62-4511894	FRUTAL	34-34235274	ASSIS CHATEAUBRIAND	44-5285181		
ALAGONHAS	75-4211128	ITAPURANGA	62-3354484	GOV. VALADARES	32-32716650	BANDERANTES	44-5422711		
BARREIRAS	77-36117592	ITUBERAIA	64-34310837	GUAXUPE	35-35513891	CASCAVEL	43-3254005		
BOM JESUS DA LAPA	77-4814335	JUSSARA	62-3731806	GUAXUPE	35-35514174	CIANORTE	44-6292842		
BRUMADO	77-4412381	LUZIANIA	61-6228519	IPATINGA	31-38222332	CURITIBA	41-33334764		
CAETITE	77-34541183	MINEROS	64-6618259	ITABIRA	31-38316218	CURITIBA	41-32648791		
CAMACARI	71-36218288	PIRES DO RIO	64-4611133	ITAJUBA	35-36213153	CURITIBA	41-32534391		
CICERO DANTAS	75-32782767	RJUALMA	62-3971320	ITAPERICIBA	37-33411176	FOZ DO IGUAU	45-3233029		
CRUZ DAS ALMAS	75-4212839	RIO VERDE	64-36210173	ITAPERICIBA	37-33411326	FOZ DO IGUAU	45-32324115		
ESPLANADA	75-4271454	TRINDADE	62-5051505	ITAUNA	37-32414268	FRANCISCO BELTRAO	46-3523230		
EUNAPOLIS	73-2815181	URUCU	62-3571285	ITUATUBA	34-32682131	GUARAPARANA	42-36235325		
FEIRA DE SANTANA	75-32232882			JOAO MONLEVADE	31-38512909	IBAITI	43-5461162		
FEIRA DE SANTANA	75-2131427	MARANHAO		JOAO MONLEVADE	31-38521112	IBIPORA	43-2581863		
GANDU	73-32541664	ACALANDIA	99-35381889	JOAO PINHEIRO	38-35611327	IBATI	42-34221337		
ILHEUS	73-3215995	BACABAL	99-36212794	JUIZ DE FORA	32-30842524	LAPA	41-36222410		
IRECE	74-36401002	BALSAS	99-5401113	GOV. VALADARES	32-32151514	LOANDA	44-4232053		
ITABERABA	75-32512358	CAROLINA	98-7311335	LAGOA DA PRATA	37-32643493	LONDRINA	43-33241002		
ITABUNA	73-36137778	CAXIAS	99-35212377	LAVRAS	35-38219198	MADRUGARA	44-2331335		
ITAPETINGA	74-2613003	CHAPADINHA	98-4711364	MANHUAU	33-33314735	MARINGA	44-32264260		
JACOBINA	73-36211323	CODO	99-36611277	MONTI CARMELO	34-38422082	MEDIANEIRA	45-3264580		
JEQUIE	73-35254141	CODO	99-36612942	MONTI SANTO DE MINAS	35-35911868	PARANAIUA	42-2323006		
JUAZEIRO	74-36114546	COELHO NETO	98-34713511	MONTES CLAROS	38-32218935	PARANAGUA	41-34238084		
JUAZEIRO	74-36111002	IMPERATRIZ	99-35244969	MURIAE	32-37224334	PATO BRANCO	46-32242786		
LAURO DE FREITAS	71-3784021	PEDREIRAS	99-36423142	MUZAMBINHO	35-5712419	PONTA GROSSA	42-32226590		
MURITIBA	74-4219108	PRESIDENTE DUTRA	99-36631815	NANUQUE	33-36212165	RIO NEGRO	47-36450251		
PAULO AFONSO	75-32811349	SANTA INES	98-36357553	NOVA LIMA	31-35412026	ROLANDIA	43-2561947		
POCOES	77-4311890	SAO JOSE DE RIBAMAR	98-22241581	OLIVEIRA	37-33314444	S J DOS PINHAIS	46-32251529		
RIBESIDA DO POMBAL	75-2761853	SAO LUIS	98-32232326	PARA DE MINAS	37-32116369	S MIGUEL DO IGUAU	45-5651429		
SALVADOR	71-32472659	SAO LUIS	98-32315276	PARA DE MINAS	37-32219375	SANTA FE	44-2471147		
SALVADOR	71-2675000			PARACATU	38-36711250	SAO JORGE D OESTE	46-3413105		
SALVADOR	71-32072070	MATO GROSSO		PASSOS	35-35214342	STO ANTONIO PLATINA	43-3534809		
SALVADOR	71-33356233	ALTA FLORESTA	66-35212460	PASSOS DE MINAS	34-38222388	TELEMACO BORBA	42-32726044		
SANTO AMARO	75-32413171	ALTO ARAGUAJA	66-4811726	PATROCINIO	34-3811531	TOLEDO	45-32524471		
SENHOR DO BONFIM	74-5413143	BARRA DO GARGAS	66-4011394	PITANGUI	37-32716232	UMUARAMA	44-36231233		
SERININHA	75-32611794	CUJABA	65-36230421	PIURHI	37-33714632				
STO ANTONIO JESUS	75-36314470	LUÇAS DO RIO VERDE	65-5491333	POCOS DE CALDAS	35-37121866	PERNAMBUCO			
TEIXEIRA DE FREITAS	73-30111600	PONTES E LACERDA	65-2662326	POCOS DE CALDAS	35-37224448	BELO JARDIM	81-37261918		
VALENCA	75-6431710	PRIMAVERA DO LESTE	66-4981682	PONTE NOVA	31-38172486	CABO STO AGOSTINHO	81-3521183		
VITORIA DA CONQUISTA	77-34214183	RONDONOPOLIS	66-4233888	POUSO ALEGRE	34-34212120	CAMARAGIBE	81-34581264		
		SINOP	66-5314592	S SEBASTIAO PARAISO	35-35313094	CARUARU	81-37220235		
CEARA		TANGARA DA SERRA	65-3261431	SANTOS DUMONT	35-35210254	FLORESTA	81-8771274		
EREO SANTO	88-5310133	VARZEA GRANDE	65-6826502	SAO JOAO DEL REI	32-32516369	GARANHUNS	87-37611090		
CRATEUS	88-4910019	MATO GROSSO DO SUL		STO ANTONIO MONTE	32-33718306	GARANHUNS	87-37610085		
CRATO	88-5212501	AMAMBAI	67-4811543	TEOFILO OTONI	33-35225831	PAULISTA	81-34331142		
FORTALEZA	85-32875506	CAMPO GRANDE	67-33242804	TIMOTEO	31-38482728	RECIFE	81-21262111		
FORTALEZA	85-40088555	CAMPO GRANDE	67-3831540	UBA	32-35323626	RECIFE	81-34656042		
IBIAPINA	88-36531223	CAMPO GRANDE	67-3213898	UBERABA	34-33323220	RECIFE	81-34629090		
IGUATU	88-35810512	COURAÇOS	67-4211717	UBERLANDIA	34-32122636	SALGUEIRO	87-38740209		
ITAIPOCA	88-6312030	IVINHEMA	67-4421244	UBERLANDIA	32-32360764	SERRA TALHADA	87-38311401		
JUAZEIRO DO NORTE	88-35112667	NAVIRAÍ	67-4612486	VARGINHA	35-32227888				
LIQMOEIRO DO NORTE	88-4231938	NOVA ANDRADINA	67-4413851	VARZEA DA PALMA	38-37315148				
OROS	88-5841271	PONTE PORÁ	67-4314313	VAZANTE	34-38131420	PIAUÍ			
SOBRAL	88-36110605	RIO BRILHANTE	67-4522750	VICOSA	31-38918000	CAMPO MAIOR	86-32521376		
TIANGUA	88-36713336	TRES LAGOAS	67-5212007			FLORIANO	89-5221154		
UBAJARA	88-6341233			PARÁ		CERES	89-4621066		
		MINAS GERAIS		ABATETUBA	91-37512272	PARNAIBA	86-3222877		
DISTRITO FEDERAL		ALFENAS	35-32927104	BELEM	91-32690400	PICOS	89-4212444		
BRASILIA	61-32269898	ALMENARA	33-7211234	BELEM	91-34241090	PICOS	89-34155135		
BRASILIA	61-33016666	ANDRADAS	35-37312970	CAPANEMA	91-34621100	TERESINA	86-32213535		
GAMA	61-5564890	ARAXA	34-36611132	CASTANHAL	91-37215052	TERESINA	86-32214618		
ESPIRITO SANTO		ARAXA	34-3661869	ITAITUBA	93-5181545				
ALLEGRE	28-3526349	ARCOS	37-33513455	MARABA	94-3211891	RIO DE JANEIRO			
ARACRUZ	27-32561251	BAMBUI	37-34311473	OBIDOS	93-5427116	B JESUS TABAPONANA	22-38312216		
BAIXO GUAUNDU	27-37321142	BARBACENA	32-33310283	PARAGOMINAS	91-30110778	BELOF RORO	21-27616060		

LISTA DE SERVIÇO AUTORIZADO - BRASIL

CABO FRIO	22-26451819	SAO BORJA	55-34311850	BOTUCATU	14-38821081	SAO PAULO	11-32223211
CAMPOS GOYTACAZES	22-27221499	SAO FCO DE PAULA	54-2441466	BOTUCATU	14-38155044	SAO RAO	11-47842509
CANTAGALO	22-25553303	SAO GABRIEL	55-2325833	CAMPINAS	19-32369199	SAO VICENTE	13-34628031
DUQUE DE CAXIAS	21-27711508	SAO JOSE DO OURO	54-3521216	CAMPINAS	19-32544819	SORCOCABA	15-32241170
ITACARA	22-38612740	SAO LUIZ GONZAGA	55-33521365	CAMPINAS	19-32336498	SORCOCABA	15-32241170
ITAPERUNA	22-38226065	SAO MARCOS	54-2911462	CAMPINAS	19-37372500	STA BARBARA D'OESTE	19-34631211
MACAE	22-27628235	SOBRADINHO	51-37421409	CAMPO LIMPO PAULISTA	11-40329200	TABOAO DA SERRA	11-47871480
MACAE	22-27591358	STA CRUZ DO SUL	55-37155456	CANPOS DO JORDAO	12-36622142	TACQUARITINGA	16-32534039
MAGE	21-26330405	STA CRUZ DO SUL	51-37153048	CATANDUVA	15-32535224	TUAIBATE	12-36219000
NITEROI	21-26220157	TAFELARA	54-3442033	CERQUELHO	15-32482121	TUPIA	14-34962596
NOVA FRIBURGO	22-25227692	TAFERA	54-3851160	CRUZEIRO	12-31433859	VINHEDO	19-38765310
NOVA IGUAÇU	21-26675663	TAGUARI	51-6531291	DIADEMA	11-40430669	VOTUPORANGA	17-34215726
PETROPOLIS	24-22312737	TORRES	51-6641940	DRACENA	18-38212479		
RESENDE	24-33550101	TRES DE MAIO	55-3352101	FERNANDOPOLIS	17-34423921	SERGIPE	
RIO DE JANEIRO	21-25094622	TRES DE MAIO	55-3359727	FRANCA	16-37223898	ARACAJU	79-32119764
RIO DE JANEIRO	21-25892030	URUGUAIANA	55-34121991	FRANCO DA ROCHA	11-44692608	ARACAJU	79-32176080
RIO DE JANEIRO	21-25097316	VACARIA	54-2311396	GUARJUA	13-33582942	ESTANCIA	79-5223235
RIO DE JANEIRO	21-24315426	VENANCIO AIRES	51-37411443	GUARULHOS	11-64513576	ITABAIANA	79-4313023
RIO DE JANEIRO	21-31579290	VERA CRUZ	51-37181350	GUARULHOS	11-64431153	LAGATO	79-6312656
RIO DE JANEIRO	21-33916353			IGARAPAVA	16-31724600		
RIO DE JANEIRO	21-22367814	RONDÔNIA		INDAIAUBA	19-38753831	TOCANTINS	
RIO DE JANEIRO	21-31592187	ARIQUEMES	69-35353491	ITAPETNINGA	15-32710936	ARAUAJANA	63-4212857
RIO DE JANEIRO	21-30673252	CAJAL	66-4231415	ITAPICOLA	11-45862182	ARAUAJANA	63-4111818
RIO DE JANEIRO	21-25714999	CEREJIRAS	69-34022251	ITARARE	15-35322743	GUARAJA	63-34641590
RIO DE JANEIRO	21-24451123	GUAJARA-MIRIM	69-35414430	ITU	11-40230188	GURUPI	63-33511038
SAO GONÇALO	21-27013214	JI- PARANA	69-34211891	ITUVERAVA	16-7293365	GURUPI	63-3311038
TERESOPOLIS	21-27439467	PORTO VELHO	69-32273377	JABOTICABAL	16-32021580		
TRES RIOS	24-22556887	ROLIM DE MOURA	69-4421178	JALES	17-36324479		
TRES RIOS	24-22521388	VILHENA	69-33223321	JAU	14-36222117		
				JUNDIAI	11-45862182		
RIO GRANDE DO NORTE		ROIMHA		LEME	19-33713528		
CAICO	84-4171844	BOA VISTA	95-32249405	LIMEIRA	19-34413179		
MOSSORO	84-33147809	BOA VISTA	95-6233456	MARILIA	14-34547437		
NATAL	84-32231249			MATAO	16-33821046		
NATAL	84-32132345	SANTA CATARINA		MAJUA	11-45145233		
PAU DOS FERROS	84-3512334	BLUMENAU	47-3227242	MOGI DAS CRUZES	11-47941814		
		CANONHAS	47-6223615	MOGI-GUAÇU	19-38181171		
RIO GRANDE DO SUL		CANONHAS	47-6223615	MORI-MIRIM	19-38624401		
AGUDO	55-2651036	CAPINZAL	49-35552246	OLIMPIA	17-28121284		
ALEGRETE	55-34021969	CHAPECO	49-33223304	OSASCO	11-36837343		
BAGE	53-32411295	CHAPECO	49-33221144	OURINHOS	13-32325457		
BENTO GONÇALVES	54-4526825	CONCORDIA	49-34423704	PIRACICABA	19-34340454		
CAMAQUA	51-36711686	CRICUMA	48-34375155	PIRASSUNUNGA	19-35614091		
CAMPINAS DO SUL	54-3661300	CUNHA PORA	49-6460043	PORTO FERREIRA	19-35812441		
CANELA	54-32821551	CURITIBANOS	49-32410851	PRES PRUDENTE	18-2225168		
CAPOE DA CANOA	54-32521388	DESCANSO	49-36230245	PRES. EPTACIO	18-2814168		
CARAZINHO	54-3302292	FLORIANOPOLIS	48-32254149	PRES.PRUDENTE	18-2217943		
CAXIAS DO SUL	54-32153107	INDAIAL	47-33333275	PROMISSAO	14-35411646		
CAXIAS DO SUL	54-2268020	IPORA DO OESTE	49-36341289	RIBEIRAO PRETO	16-36106899		
CERRO LARGO	55-33591973	ITAIOPOLES	47-5622282	RIBEIRAO PRETO	16-36368156		
CORONEL BICACO	55-35571397	ITAJAI	47-33444777	RIBEIRAO PRETO	16-36107553		
ERECHIM	54-3211933	JARAGUA DO SUL	47-33722050	RIO CLARO	19-35348543		
ESTANCIA VELHA	51-35612142	JOACABA	49-35220418	S BERNARDO CAMPO	11-41257000		
FARROUPILHA	54-32683603	JORNILLE	47-54331146	S BERNARDO CAMPO	11-42687898		
FAXINAL DO SOTURNO	55-26231150	LAGES	49-2232335	S CAETANO DO SUL	11-42214334		
FLORES DA CUNHA	54-2922625	LAGES	49-32244414	S JOAO BOA VISTA	19-36232990		
FREDERICO WESTPHALEN	55-37441850	LAGUNA	48-36461221	S JOSE CAMPOS	19-32239508		
GETULIO VARGAS	54-3411888	LAURO MULLER	48-4642302	S JOSE DO RIO PARDO	19-36085740		
GIRUA	55-33611764	MARAVILHA	49-6640052	S JOSE RIO PRETO	17-32325680		
GRAVATAI	51-4882830	PNHALZINHO	49-7461014	S JOSE RIO PRETO	17-2352381		
HORIZONTINA	55-3371680	PORTO LINAHO	42-35232839	SALTO	11-40236563		
HIRAIARAS	54-3551359	RIO DO SUL	47-5211920	SANTO ANDRE	11-49905288		
IJUI	55-3327766	SAO MIGUEL D'OESTE	49-36220026	SANTOS	13-32272947		
IMBE	51-36272704	SEARA	49-4521034	SANTOS	13-32847339		
LAJEADO	51-37145155	SOMBRIO	48-5331225	SAO CARLOS	16-33614913		
MARAU	54-33424571	TAIO	47-8620576	SAO JOSE DO CAMPOS	12-39122728		
MONTENEGRO	51-6424187	TUBARAO	48-6224448	SAO JOSE RIO PRETO	17-2355241		
NIONOAI	54-3621126	TUBARAO	48-6261651	SAO PAULO	11-2964262		
NOVA PRATA	54-3262328	UNIO DE JARU	49-5230373	SAO PAULO	11-42036116		
NOVO HAMBURGO	51-33823191	URUSSANGA	48-4451137	SAO PAULO	11-49799184		
OSORIO	51-36632524	VIDEIRA	49-35660376	SAO PAULO	11-38659897		
PALMEIRA MISSOES	55-37421407	XANXERE	49-4333026	SAO PAULO	11-62156667		
PANAMBI	55-33753488			SAO PAULO	11-49545517		
PASSO FUNDO	54-3311104	SÃO PAULO		SAO PAULO	11-36726766		
PELOTAS	53-3222633	AGUAS DE LINDOIA	19-38241524	SAO PAULO	11-66949011		
PORTO ALEGRE	55-3231691	AMERICANA	19-34022610	SAO PAULO	11-20271116		
PORTO ALEGRE	55-32356653	AMPARO	19-38072674	SAO PAULO	11-39757996		
PORTO ALEGRE	51-32268934	ARACATUBA	18-36218775	SAO PAULO	11-62976464		
RIO GRANDE	53-32323211	ARARAQUARA	16-33368710	SAO PAULO	11-56679695		
SANTA DO LIVRAMENTO	55-32411899	ATIBAIA	11-44118145	SAO PAULO	11-38751333		
SANTA MARIA	55-32222325	AVARE	14-37322142	SAO PAULO	11-55321515		
SANTA ROSA	55-35719991	BARRFETOS	17-33222742	SAO PAULO	11-62884811		
SANTA VITORIA DA PALMAR	53-2633992	BATATAIS	16-37644455	SAO PAULO	11-32217317		
SANTA ANGELO	55-33131183	BAURIL	14-32239551	SAO PAULO	11-37714070		
SANTO AUGUSTO	55-37811511	BIRIGUI	18-36424011	SAO PAULO	11-25770899		

CERTIFICADO DE GARANTIA NO BRASIL

Este aparelho é garantido pela Philips da Amazônia Indústria Eletrônica Ltda., por um período superior ao estabelecido por lei. Porém, para que a garantia tenha validade, é imprescindível que, além deste certificado, seja apresentada a nota fiscal de compra do produto.

A Philips da Amazônia Indústria Eletrônica Ltda. assegura ao proprietário consumidor deste aparelho as seguintes garantias, a partir da data de entrega do produto, conforme expresso na nota fiscal de compra, que passa a fazer parte deste certificado:

Garantia para rádios e reprodutores de CD portáteis (sem caixa acústica destacável): 180 dias

Garantia para os demais produtos da marca Philips: 365 dias.

Esta garantia perderá sua validade se:

- O defeito apresentado for ocasionado por uso indevido ou em desacordo com o seu manual de instruções.
- O produto for alterado, violado ou consertado por pessoa não autorizada pela Philips.
- O produto for ligado a fonte de energia (rede elétrica, pilhas, bateria, etc.) de características diferentes das recomendadas no manual de instruções e/ou no produto.
- O número de série que identifica o produto estiver de alguma forma adulterado ou rasurado.

Estão excluídos desta garantia defeitos decorrentes do descumprimento do manual de instruções do produto, de casos fortuitos ou de força maior, bem como aqueles causados por agentes da natureza e acidentes. Excluem-se igualmente desta garantia defeitos decorrentes do uso dos produtos em serviços não doméstico/residencial regular ou em desacordo com o uso recomendado. **ESTÃO EXCLUÍDAS DA GARANTIA ADICIONAL AS PILHAS OU BATERIAS FORNECIDAS JUNTO COM O CONTROLE REMOTO.**

Nos municípios onde não exista oficina autorizada de serviço Philips, as despesas de transporte do aparelho e/ou do técnico autorizado, correm por conta do Sr. Consumidor requerente do serviço.

A garantia não será válida se o produto necessitar de modificações ou adaptações para habilitá-lo a operar em qualquer outro país que não aquele para o qual foi designado, fabricado, aprovado e/ou autorizado, ou ter sofrido qualquer dano decorrente deste tipo de modificação.

Philips da Amazônia Indústria Eletrônica Ltda.

Dentro do Brasil, para informações adicionais sobre o produto ou para eventual necessidade de utilização da rede de oficinas autorizadas, ligue para o Centro de Informações ao Consumidor (CIC). Em São Paulo - Capital e demais localidades com DDD 011 - tel. 2121-0203, nas demais localidades e estados - tel. 0800 701 02 03 (discagem direta gratuita), ou escreva para Caixa Postal: nº 21.315 - CEP04602-970 - São Paulo - SP, ou envie um e-mail para: cic@philips.com.br
Horário de atendimento: de segunda à sexta-feira, das 08:00 às 20:00 h; aos sábados das 08:00 às 13:00h.

*Para atendimento fora do Brasil, contate a Philips local ou a:
Philips Consumer Service
Beukenlaan 2
5651 CD Eindhoven
The Netherlands*

Certificado de Garantía en Argentina

Artefacto:

Modelo:

**Fabricante/Importador: Philips Argentina S.A.
y/o Fábrica Austral de Productos Eléctricos S.A.**

Dirección: Vedia 3892 - Buenos Aires

Fecha de Venta:

--

Nro. de serie

Firma y sello de la casa vendedora.

PHILIPS ARGENTINA S.A. en adelante denominada “la empresa”, garantiza al comprador de este artefacto por el término de (6) meses a partir de la fecha de adquisición, el normal funcionamiento contra cualquier defecto de fabricación y/o vicio de material, y se compromete a reparar el mismo —sin cargo alguno para el adquirente— cuando el mismo fallare en situaciones normales de uso y bajo las condiciones que a continuación se detallan:

1. Este certificado de garantía es válido únicamente en la Republica Argentina. El certificado debe ser completado por la casa vendedora y ser presentado por el usuario conjuntamente con la factura original de compra.
2. Serán causas de anulación de esta garantía en los casos que corresponda:
 - 2.1. Uso impropio o distinto del uso doméstico.
 - 2.2. Exceso o caídas de tensión eléctrica que impliquen uso en condiciones anormales.
 - 2.3. Instalación y/o uso en condiciones distintas a las marcadas en el “Manual de instalación y uso” que se adjunta a esta garantía.
 - 2.4. Cualquier intervención al artefacto por terceros no autorizados por la empresa.
3. La garantía carecerá de validez si se observare lo siguiente:
 - 3.1. Enmiendas o raspaduras en los datos del certificado de garantía o factura.
 - 3.2. Falta de factura original de compra que detalle tipo de artefacto, modelo, número de serie y fecha que coincida con los del encabezamiento del presente certificado.
4. No están cubiertos por esta garantía los siguientes casos:
 - 4.1. Los daños ocasionados al exterior del gabinete.
 - 4.2. Las roturas, golpes, caídas o rayaduras causadas por traslados.
 - 4.3. Los daños o fallas ocasionados por deficiencias, sobretensiones, descargas o interrupciones del circuito de alimentación eléctrica o rayos, deficiencias en la instalación eléctrica del domicilio del usuario o conexión del artefacto a redes que no sean las especificadas en el Manual de Uso del mismo.
 - 4.4. Las fallas, daños, roturas o desgastes producidos por el maltrato o uso indebido del artefacto y/o causadas por inundaciones, incendios, terremotos, tormentas eléctricas, golpes o accidentes de cualquier naturaleza.
 - 4.5. Las fallas o daños ocasionados en desperfectos en la línea telefónica.
 - 4.6. Las fallas producidas por una mala recepción ocasionada en el uso de una antena deficiente o en señales de transmisión débiles.
5. Las condiciones de instalación y uso del artefacto se encuentran detalladas en el Manual de Uso del mismo.
6. La empresa no asume responsabilidad alguna por los daños personales o a la propiedad al usuario o a terceros que pudieran causar la mala instalación o uso indebido del artefacto, incluyendo en este último caso a la falta de mantenimiento.
7. En caso de falla, el usuario deberá requerir la reparación a la empresa a través del Service Oficial y/o Talleres Autorizados más próximos a su domicilio y cuyo listado se acompaña al presente. La empresa a segura al usuario la reparación y/o reposición de piezas para su correcto funcionamiento en un plazo no mayor a 30 días contados a partir de la fecha de solicitud de reparación, salvo caso fortuito o fuerza mayor.

8. Toda intervención del servicio técnico realizada a pedido del usuario dentro del plazo de garantía, que no fuera originada por falla o defecto alguno cubierto por este certificado, deberá ser abonado por el interesado de acuerdo a la tarifa vigente.
9. El presente certificado anula cualquier otra garantía implícita o explícita, por la cual y expresamente no autorizamos a ninguna otra persona, sociedad o asociación a asumir por nuestra cuenta ninguna responsabilidad con respecto a nuestros productos.
10. En caso de que durante el período de vigencia de esta garantía el artefacto deba ser trasladado a las Delegaciones Oficiales y/o Talleres Autorizados de Service para su reparación, el transporte será realizado por la empresa y serán a su cargo los gastos de flete y seguros y cualquier otro que deba realizarse para su ejecución.



PHILIPS

Red de Talleres Autorizados en Argentina

CAPITAL FEDERAL

ATTENDANCE S.A.

- Av. Monroe 3351 (C1430BKA) Cap. Fed.
 - Tel.: 4545-5574/0704 ó 6775-1300
 - Ventas de Repuestos y Accesorios
 - Tel.: 4545-0854

DIG TRONIC

- Av. San Martín 1762 (C1416CRS) Cap. Fed.
 - Tel.: 4583-1501

ELECTARG S.R.L.

- Av. Córdoba 1357 (C1055AAD) Cap. Fed.
 - Ventas de Repuestos y Accesorios
 - Tel.: 4811-1050

Caballito Electarg J. M. Moreno 287 4903-6967/6854/8983

BUENOS AIRES

Azul	Herlein Raúl Horacio	Av. 25 de Mayo 1227	(02281) 428719
Bahía Blanca	Neutron	Soler 535	(0291) 4535229
Bragado	Yacovino Juan J.	San Martín 2141	(02342) 424147
Campana	Electricidad Krautor	Lavalle 415	(03489) 432919
Chivilcoy	Fama	Coronel Suárez 110	(02346) 424129
Junin	Junin Service	Alsina 537	(02362) 442754
La Plata	Da Tos e Hijos	Calle 68 N° 1532	(0221) 4516021
La Plata	Service Técnico La Plata	Av. 51 N° 1051 esq. 16	(0221) 4108155
Mar de Ajó	Tauro Electrónica	Catamarca 14	(02257) 421750
Mar del Plata	Central Service	Olazábal 2249	(0223) 4721639/4729367
Mar del Plata	Service Integral	Diag. Pueyrredón 3229	(0223) 4945633
Necochea	Eléctronica Camejo	Calle 63 N° 1745	(02262) 426134
Pehuajó	Catcagni Carlos Alberto	Zubiría 794	(02396) 472665
Pergamino	ACV Sistemas	Dr. Alem 758	(02477) 421177
Pergamino	El Service	Juan B. Justo 1931	(02477) 418000

San Nicolás	Servitec	Bv. Alvarez 148	(03461) 454729/429578
San Pedro	Eléctronica Menisale	Mitre 1695	(03329) 425523
Tandil	Lazzarini Oscar Rafael	Pellegrini 524	(02293) 442167
Trenque Lauquen	Labruna Electrónica	Av. San Martín 426	(02392) 423248
Tres Arroyos	Saini Fabián y Sergio	Av. Belgrano 562	(02983) 427369
Zárate	Eléctronica Spinozzi	Ituzaingó 1030	(03487) 427353

GRAN BUENOS AIRES

Avellaneda	Casa Torres S.A.	Av. Mitre 2559	4255-5854
Florencio Varela	Casa Torres S.A.	San Martín 2574	4255-5854
Gregorio de Laferrere	Eléctronica Alvarez	Honorio Luque 6084	4626-1322
Lomas de Zamora	Attendance S.A. Lomas	Laprida 485	4292-8900
Merlo	Argentronica S.H.	Pte. Cámpora 2175	(0220) 4837177/4829934
Moreno	Argentronica S.H.	Bm.é. Mitre 2977 loc.2	(0237) 4639500
Morón	Servotronic	Ntra. Sra. del Buen Viaje 1222	4627-5656
Olivos	Appliance	Av. Libertador 2684	4794-7700
Quilmes	Casa Torres S.A.	E. Ríos esq. Gran Canaria	4255-5854
Ramos Mejía	Electarg S.R.L. Suc.	Belgrano 224	4656-0619
San Miguel	Servotronic San Miguel	Belgrano 999	4664-4131
Villa Ballester	Servotronic	J. Hernández 3101	4767-2515/4768-5249

CATAMARCA

Catamarca	Omicron Central de Serv.	San Martín 225	(03833) 427235
-----------	--------------------------	----------------	----------------

CHACO

Resistencia	Freschi Jorge Oscar	Av. Avalos 320	(03722) 426030
-------------	---------------------	----------------	----------------

CHUBUT


Comodoro Rivadavia	C.A.S. S.R.L.	Alem 145	(0297) 4442629
Trelew	Fagtron Electrónica	Brasil 253	(02965) 427073

CORDOBA


Córdoba Capital	Servelco S.R.L.	Pje. E. Marsilla 635 (0351) 4724008/4732024
Río Cuarto	Maurutto Victor G.	Bv. Almaguer 487 (0358) 4660204
Río Cuarto	Capaldi Abel	Paunero 832 (0358) 4623003
Río Tercero	Service Omega	Homero Manzi 149 (03571) 423330
San Francisco	Acuña Walter Electrónica	M. Moreno 360 (03564) 425367
Villa María	Grasso Electrónica	Bv. Alvear 541 (0353) 4521366
Villa María	Vanguard Sist. Electrónicos	México 421 (0353) 4532951

Meet Philips at the Internet
<http://www.philips.com>

English



MCM158



Printed in China

PDCC-JH-0823