Always there to help you

Register your product and get support at www.philips.com/support



BDP2110



User manual



Safety and important notice

Read and understand all instructions before you use this Blu-ray disc/ DVD player. If damage is caused by failure to follow the instructions, the warranty does not apply.

Safety

Risk of electric shock or fire!

- Before you make or change any connections, make sure that all devices are disconnected from the power outlet.
- Never expose the product and accessories to rain or water. Never place liquid containers, such as vases, near the product. If liquids are spilt on or into the product, disconnect it from the power outlet immediately. Contact Philips Consumer Care to have the product checked before use
- Never place the product and accessories near naked flames or other heat sources, including direct sunlight.
- Never insert objects into the ventilation slots or other openings on the product.
- Where the mains plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.
- Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.
- Disconnect the product from the power outlet before lightning storms.
- When you disconnect the power cord, always pull the plug, never the cable.

Risk of short circuit or fire!

- For identification and supply ratings, see the type plate at the back or bottom of the product.
- Before you connect the product to the power outlet, ensure that the power

voltage matches the value printed on the back or bottom of the product. Never connect the product to the power outlet if the voltage is different.

Risk of injury or damage to the product!

- Visible and invisible laser radiation when open. Avoid exposure to beam.
- Do not touch the disc optical lens inside the disc compartment.
- Never place the product or any objects on power cords or on other electrical equipment.
- If the product is transported in temperatures below 5°C, unpack the product and wait until its temperature matches room temperature before connecting it to the power outlet.

Risk of overheating!

 Never install this product in a confined space. Always leave a space of at least four inches around the product for ventilation. Make sure that curtains or other objects never cover the ventilation slots on the product.

Risk of contamination!

- Do not mix batteries (old and new or carbon and alkaline, etc.).
- Danger of explosion if batteries are incorrectly replaced. Replace only with the same or equivalent type.
- Remove batteries if they are exhausted or if the remote control is not to be used for a long time.
- Batteries contain chemical substances, they should be disposed of properly.

Risk of swallowing batteries!

 The product/remote control may contain a coin/button type battery, which can be swallowed. Keep the battery out of reach of children at all times! If swallowed, the battery can cause serious injury or death. Severe internal burns can occur within two hours of ingestion.

- If you suspect that a battery has been swallowed or placed inside any part of the body, seek immediate medical attention.
- When you change the batteries, always keep all new and used batteries out of reach of children. Ensure that the battery compartment is completely secure after you replace the battery.
- If the battery compartment cannot be completely secured, discontinue use of the product. Keep out of reach of children and contact the manufacturer.



This is CLASS II apparatus with double insulation, and no protective earth provided.



Care for your product

- Do not insert any objects other than discs into the disc compartment.
- Do not insert warped or cracked discs into the disc compartment.
- Only use microfiber cloth to clean the product.

Care of the environment

Disposal of your old product



Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.

Do not throw away the product with the normal household waste at the end of its life, but hand it in at an official collection point or recycling. By doing this, you help to preserve the environment.

Copyright



This item incorporates copy protection technology that is protected by U.S. patents and other intellectual property rights of Rovi Corporation. Reverse engineering and disassembly are prohibited.

This product incorporates proprietary technology under license from Verance Corporation and is protected by U.S. Patent 7,369,677 and other U.S. and worldwide patents issued and pending as well as copyright and trade secret protection for certain aspects of such technology. Cinavia is a trademark of Verance Corporation. Copyright 2004-2013 Verance Corporation. All rights reserved by Verance. Reverse engineering or disassembly is prohibited.

Cinavia notice


This product uses Cinavia technology to limit the use of unauthorized copies of some commercially-produced film and videos and their soundtracks. When a prohibited use of an unauthorized copy is detected, a message will be displayed and playback or copying will be interrupted.


More information about Cinavia technology is provided at the Cinavia Online Consumer Information Center at http://www.cinavia.com. To request additional information about Cinavia by mail, send a postcard with your mailing address to: Cinavia Consumer Information Center, P.O. Box 86851, San Diego, CA, 92138, USA.

Open source software

Philips Electronics Singapore hereby offers to deliver, upon request, a copy of the complete corresponding source code for the copyrighted open source software packages used in this product for which such delivery is requested by the respective licenses. This offer is valid up to three years after product purchase to anyone in receipt of this information. To obtain source code, please send your request in English with product type to open.source@philips.com. If you prefer not to use email or if you do not receive confirmation receipt within 2 weeks after mailing to this email address, please write in English to "Open Source Team, Philips Intellectual Property & Standards, P.O. Box 220, 5600 AE Eindhoven, The Netherlands". If you do not receive timely confirmation of your letter, please email to the email address above. The texts of the licenses and acknowledgements for open source software used in this product are included in the printed user manual.













HDMI OUT








COAXIAL















Contents

1	Use your Blu-ray disc/ DVD player Basic play control Video, audio and picture options DivX videos Play a musical slideshow Auto play BonusView on Blu-ray BD-Live on Blu-ray Set up a network Use Philips EasyLink	2 3 4 5 5 6 6
2	Change settings Picture Sound Network (installation, status) Preference (languages, parental control) Advanced options (clear memory)	7 7 8 8 8 9
3	Update software Update software via USB	9
4	Product specifications	10
5	Troubleshooting	13

1 Use your Bluray disc/ DVD player

Congratulations on your purchase, and welcome to Philips! To fully benefit from the support that Philips offers (e.g. product software upgrade), register your product at www.philips.com/welcome.

Basic play control



During play, press the following buttons to control.


Button	Action
<u></u>	Turn on the player, or switch
	to standby.
A	Access the home menu.

DISC MENU Access or exit the disc menu or Pop-up menu. TOP MENU Access the main menu of a video disc. Navigate the menus. Press ▲ ▼ to rotate a picture clockwise or counter-clockwise during slideshow. OK Confirm a selection or entry. Return to a previous display menu. Access more options during play. Color Select tasks or options for buttons Blu-ray discs. Open or close the disc compartment. Start or resume play. Pause play. Press repeatedly to slow forward frame by frame. Stop play. II Pause play. Press repeatedly to change the search speed. Press II once, and then press To slow forward. AUDIO Select a subtitle language. Subtitle Select a item to play. Enter values.	<u> </u>		
or Pop-up menu. TOP MENU Access the main menu of a video disc. Navigate the menus. Press ▲ ▼ to rotate a picture clockwise or counter-clockwise during slideshow. OK Confirm a selection or entry. Return to a previous display menu. Access more options during play. Color Select tasks or options for buttons Blu-ray discs. Open or close the disc compartment. Start or resume play. Pause play. Press repeatedly to slow forward frame by frame. Stop play. Skip to the previous or next track, chapter or file. Fast backward or forward. Press repeatedly to change the search speed. Press II once, and then press To slow forward. AUDIO Select an audio language or channel. Substitle Select an item to play.	Button	Action	
TOP MENU Access the main menu of a video disc. Navigate the menus. Press ▲ ▼ to rotate a picture clockwise or counter-clockwise during slideshow. OK Confirm a selection or entry. Return to a previous display menu. Access more options during play. Color Select tasks or options for buttons Blu-ray discs. Open or close the disc compartment. Start or resume play. Pause play. Press repeatedly to slow forward frame by frame. Stop play. Skip to the previous or next track, chapter or file. Fast backward or forward. Press repeatedly to change the search speed. Press I once, and then press To slow forward. AUDIO Select an audio language or channel. Substitle Select a subtitle language. Alphanumeric Select an item to play.	DISC MENU		
video disc. Navigate the menus. Press ▲ ▼ to rotate a picture clockwise or counter-clockwise during slideshow. OK Confirm a selection or entry. Return to a previous display menu. Access more options during play. Color Select tasks or options for buttons Blu-ray discs. Open or close the disc compartment. Start or resume play. Pause play. Press repeatedly to slow forward frame by frame. Stop play. Skip to the previous or next track, chapter or file. Fast backward or forward. Press repeatedly to change the search speed. Press ■ once, and then press To slow forward. AUDIO Select an audio language or channel. Substitute Select a subtitle language. Alphanumeric Select an item to play.			
Navigate the menus. Press ▲ ▼ to rotate a picture clockwise or counter-clockwise during slideshow. OK Confirm a selection or entry. Return to a previous display menu. Access more options during play. Color Select tasks or options for buttons Blu-ray discs. Open or close the disc compartment. Start or resume play. Pause play. Press repeatedly to slow forward frame by frame. Stop play. Skip to the previous or next track, chapter or file. Fast backward or forward. Press repeatedly to change the search speed. Press I once, and then press To slow forward. AUDIO Select an audio language or channel. SUBTITLE Select a subtitle language. Alphanumeric Select an item to play.	TOP MENU		
Press ▲ ▼ to rotate a picture clockwise or counter-clockwise during slideshow. OK Confirm a selection or entry. Return to a previous display menu. Access more options during play. Color Select tasks or options for buttons Blu-ray discs. Open or close the disc compartment. Start or resume play. Pause play. Press repeatedly to slow forward frame by frame. Stop play. Skip to the previous or next track, chapter or file. Additional press repeatedly to change the search speed. Press I once, and then press To slow forward. AUDIO Select an audio language or channel. Substitute Select a subtitle language. Alphanumeric Select an item to play.		video disc.	
clockwise or counter-clockwise during slideshow. OK Confirm a selection or entry. Return to a previous display menu. Access more options during play. Color Select tasks or options for buttons Blu-ray discs. Open or close the disc compartment. Start or resume play. Pause play. Press repeatedly to slow forward frame by frame. Stop play. Skip to the previous or next track, chapter or file. Add/bb Fast backward or forward. Press repeatedly to change the search speed. Press II once, and then press b to slow forward. AUDIO Select an audio language or channel. SUBTITLE Select a subtitle language. Alphanumeric Select an item to play.	▲▼∢ ►	Navigate the menus.	
during slideshow. OK Confirm a selection or entry. Return to a previous display menu. Access more options during play. Color Select tasks or options for buttons Blu-ray discs. Open or close the disc compartment. Start or resume play. Pause play. Press repeatedly to slow forward frame by frame. Stop play. Skip to the previous or next track, chapter or file. Add/bb Fast backward or forward. Press repeatedly to change the search speed. Press II once, and then press b to slow forward. AUDIO Select an audio language or channel. SUBTITLE Select a subtitle language. Alphanumeric Select an item to play.		Press ▲ ▼ to rotate a picture	
OK Confirm a selection or entry. Return to a previous display menu. Access more options during play. Color Select tasks or options for buttons Blu-ray discs. Open or close the disc compartment. Start or resume play. Pause play. Press repeatedly to slow forward frame by frame. Stop play. I Skip to the previous or next track, chapter or file. Fast backward or forward. Press repeatedly to change the search speed. Press I once, and then press To slow forward. AUDIO Select an audio language or channel. SUBTITLE Select a subtitle language. Alphanumeric Select an item to play.			
Return to a previous display menu. Access more options during play. Color Select tasks or options for buttons Blu-ray discs. Open or close the disc compartment. Start or resume play. Pause play. Press repeatedly to slow forward frame by frame. Stop play. Skip to the previous or next track, chapter or file. Fast backward or forward. Press repeatedly to change the search speed. Press once, and then press To slow forward. AUDIO Select an audio language or channel. SUBTITLE Select a subtitle language. Alphanumeric Select an item to play.			
menu. Access more options during play. Color Select tasks or options for buttons Blu-ray discs. A Open or close the disc compartment. Start or resume play. Pause play. Press repeatedly to slow forward frame by frame. Stop play. Skip to the previous or next track, chapter or file. Fast backward or forward. Press repeatedly to change the search speed. Press ■ once, and then press To slow forward. AUDIO Select an audio language or channel. SUBTITLE Select a subtitle language. Alphanumeric Select an item to play.	OK	Confirm a selection or entry.	
menu. Access more options during play. Color Select tasks or options for buttons Blu-ray discs. A Open or close the disc compartment. Start or resume play. Pause play. Press repeatedly to slow forward frame by frame. Stop play. Skip to the previous or next track, chapter or file. Fast backward or forward. Press repeatedly to change the search speed. Press ■ once, and then press To slow forward. AUDIO Select an audio language or channel. SUBTITLE Select a subtitle language. Alphanumeric Select an item to play.	→	Return to a previous display	
play. Color Select tasks or options for buttons Blu-ray discs. △ Open or close the disc compartment. ▷ Start or resume play. II Pause play. Press repeatedly to slow forward frame by frame. Stop play. Skip to the previous or next track, chapter or file. ✓ ✓ ✓ ► Fast backward or forward. Press repeatedly to change the search speed. Press II once, and then press ▶ to slow forward. AUDIO Select an audio language or channel. SUBTITLE Select a subtitle language. Alphanumeric Select an item to play.		menu.	
play. Color Select tasks or options for buttons Blu-ray discs. △ Open or close the disc compartment. ▷ Start or resume play. II Pause play. Press repeatedly to slow forward frame by frame. Stop play. Skip to the previous or next track, chapter or file. ✓ ✓ ✓ ► Fast backward or forward. Press repeatedly to change the search speed. Press II once, and then press ▶ to slow forward. AUDIO Select an audio language or channel. SUBTITLE Select a subtitle language. Alphanumeric Select an item to play.		Access more options during	
Blu-ray discs. △ Open or close the disc compartment. ► Start or resume play. □ Pause play. Press repeatedly to slow forward frame by frame. □ Stop play. Skip to the previous or next track, chapter or file. ✓ ✓ / ► Fast backward or forward. Press repeatedly to change the search speed. Press □ once, and then press ► to slow forward. AUDIO Select an audio language or channel. SUBTITLE Select a subtitle language. Alphanumeric Select an item to play.		play.	
A Open or close the disc compartment. ► Start or resume play. ■ Pause play. Press repeatedly to slow forward frame by frame. ■ Stop play. ■ Skip to the previous or next track, chapter or file. ■ Fast backward or forward. Press repeatedly to change the search speed. Press ■ once, and then press ► to slow forward. AUDIO Select an audio language or channel. SUBTITLE Select a subtitle language. Alphanumeric Select an item to play.	Color	Select tasks or options for	
compartment. Start or resume play. Pause play. Press repeatedly to slow forward frame by frame. Stop play. Skip to the previous or next track, chapter or file. Fast backward or forward. Press repeatedly to change the search speed. Press ■ once, and then press to slow forward. AUDIO Select an audio language or channel. SUBTITLE Select a subtitle language. Alphanumeric Select an item to play.	buttons	Blu-ray discs.	
Pause play. Press repeatedly to slow forward frame by frame. Stop play. Skip to the previous or next track, chapter or file. Fast backward or forward. Press repeatedly to change the search speed. Press ■ once, and then press > to slow forward. AUDIO Select an audio language or channel. SUBTITLE Select a subtitle language. Alphanumeric Select an item to play.	<u> </u>	Open or close the disc	
Pause play. Press repeatedly to slow forward frame by frame. Stop play. Skip to the previous or next track, chapter or file. Fast backward or forward. Press repeatedly to change the search speed. Press ■ once, and then press >> to slow forward. AUDIO Select an audio language or channel. SUBTITLE Select a subtitle language. Alphanumeric Select an item to play.		compartment.	
Press repeatedly to slow forward frame by frame. Stop play. Skip to the previous or next track, chapter or file. Fast backward or forward. Press repeatedly to change the search speed. Press ■ once, and then press >> to slow forward. AUDIO Select an audio language or channel. SUBTITLE Select a subtitle language. Alphanumeric Select an item to play.	•	Start or resume play.	
forward frame by frame. Stop play. Skip to the previous or next track, chapter or file. Fast backward or forward. Press repeatedly to change the search speed. Press ■ once, and then press To slow forward. AUDIO Select an audio language or channel. SUBTITLE Select a subtitle language. Alphanumeric Select an item to play.	II	Pause play.	
forward frame by frame. Stop play. Skip to the previous or next track, chapter or file. Fast backward or forward. Press repeatedly to change the search speed. Press ■ once, and then press To slow forward. AUDIO Select an audio language or channel. SUBTITLE Select a subtitle language. Alphanumeric Select an item to play.		Press repeatedly to slow	
Skip to the previous or next track, chapter or file. ✓✓/ ➤➤ Fast backward or forward. Press repeatedly to change the search speed. Press ■■ once, and then press ➤> to slow forward. AUDIO Select an audio language or channel. SUBTITLE Select a subtitle language. Alphanumeric Select an item to play.			
Skip to the previous or next track, chapter or file. ✓✓/ ➤➤ Fast backward or forward. Press repeatedly to change the search speed. Press ■■ once, and then press ➤> to slow forward. AUDIO Select an audio language or channel. SUBTITLE Select a subtitle language. Alphanumeric Select an item to play.		Stop play.	
track, chapter or file. ✓✓/ ►► Fast backward or forward. Press repeatedly to change the search speed. Press II once, and then press ►► to slow forward. AUDIO Select an audio language or channel. SUBTITLE Select a subtitle language. Alphanumeric Select an item to play.	 		
Fast backward or forward. Press repeatedly to change the search speed. Press once, and then press to slow forward. AUDIO Select an audio language or channel. SUBTITLE Select a subtitle language. Alphanumeric Select an item to play.			
search speed. Press ■ once, and then press > to slow forward. AUDIO Select an audio language or channel. SUBTITLE Select a subtitle language. Alphanumeric Select an item to play.	4 4 / >>	·	
search speed. Press ■ once, and then press > to slow forward. AUDIO Select an audio language or channel. SUBTITLE Select a subtitle language. Alphanumeric Select an item to play.		Press repeatedly to change the	
Press ■ once, and then press ▶ to slow forward. AUDIO Select an audio language or channel. SUBTITLE Select a subtitle language. Alphanumeric Select an item to play.			
AUDIO Select an audio language or channel. SUBTITLE Select a subtitle language. Alphanumeric Select an item to play.		•	
channel. SUBTITLE Select a subtitle language. Alphanumeric Select an item to play.		▶► to slow forward.	
channel. SUBTITLE Select a subtitle language. Alphanumeric Select an item to play.	AUDIO	Select an audio language or	
Alphanumeric Select an item to play.			
Alphanumeric Select an item to play.	SUBTITLE	Select a subtitle language.	
	•		
Enter letters via SMS style			
entry.		,	

Video, audio and picture options

More options are available for video or picture play from a disc or USB storage device.

Video options



Access more options during video play.


- [Audio language]: Select an audio language.
- [Subtitle language]: Select a subtitle language.
- [Subtitle shift]: Change the subtitle position on the screen. Press ▲ ▼ to change the subtitle position.
- [Info]: Display play information.
- [Character set]: Select a character set that supports the DivX video subtitle (only for DivX videos).
- [Time search]: Skip to a specific time via the numeric buttons on the remote control.
- [2nd audio language]: Select the second audio language (only for Blu-ray discs that support BonusView).
- [2nd subtitle language]: Select the second subtitle language (only for Blu-ray discs that support BonusView).
- [Titles]: Select a title.
- [Chapters]: Select a chapter.
- [Angle list]: Select a camera angle.
- [Menus]: Display a disc menu.
- [PIP selection]: Display a picture-in-picture window (only for Blu-ray discs that support BonusView).

- [Zoom]: Zoom into a video picture. Press
 ◆ to select a zoom factor.
- [Repeat]: Repeat a chapter or title.
- [Repeat A-B]: Mark two points within a chapter for repeat play, or turn off repeat mode
- [Picture settings]: Select a predefined color setting.



· Available video options depend on the video source.


Picture options



Access more options during slideshow.

- [Rotate +90]: Rotate a picture 90 degrees clockwise.
- **[Rotate -90]**: Rotate a picture 90 degrees counter-clockwise.
- **[Zoom]**: Zoom into a picture. Press **◄** ▶ to select a zoom factor.
- [Info]: Display picture information.
- [Duration per slide]: Set a display interval for a slideshow.
- [Slide animation]: Select a transition effect for a slideshow.
- [Picture settings]: Select a predefined color setting.
- [Repeat]: Repeat a selected folder.

Audio options



Press \equiv repeatedly to cycle through the following options.

- Repeat the current track.
- Repeat all the tracks on the disc or folder.
- Play audio tracks in a random loop.
- Turn off a repeat mode.

DivX videos

You can play DivX videos from a disc or a USB storage device.

VOD code for DivX

- Before you purchase DivX videos and play them on this player, register this player on www.divx.com using the DivX VOD code.
- Display the DivX VOD code: press ♠, and select [Setup] > [Advanced] > [DivX® VOD Code].

DivX subtitles

- Press **SUBTITLE** to select a language.
- If the subtitle is not displayed correctly, change the character set that supports the DivX subtitle. Select a character set: press
 and select [Character set].

Character	Languages	
set		
[Standard]	English, Albanian, Danish, Dutch,	
	Finnish, French, Gaelic, German,	
	Italian, Kurdish (Latin), Norwegian,	
	Portuguese, Spanish, Swedish, and	
	Turkish	

Character	Languages
[Central Europe]	Albanian, Croat, Czech, Dutch, English, German, Hungarian, Irish, Polish, Romanian, Slovak, Slovene, and Serbian
[Cyrillic]	Bulgarian, Belorussian, English, Macedonian, Moldavian, Russian, Serbian, and Ukrainian
[Greek]	Greek
[Baltic]	Estonian, Latvian and Lithuanian
[Chinese]	Simplified Chinese
[Chinese- Traditional]	Traditional Chinese
[Korean]	English and Korean



Note

- To use the subtitles, make sure that the subtitle file
 has the same name as the DivX video file name. For
 example, if the DivX video file is named "movie.avi",
 save the subtitle file as "movie.srt", or "movie.sub".
- This player can play subtitle files in the following formats: .srt, .sub, .txt, .ssa, and .smi.

Play a musical slideshow

Play music and pictures simultaneously to create a musical slideshow.

- 1 From a disc or connected USB storage device, play a music file.
- 2 Press **5**, and go to the picture folder.
- 3 Select a picture from the same disc or USB, and press OK to start slideshow.
- 4 Press to stop slideshow.
- 5 Press again to stop music play.

Auto play

This player can automatically play a disc or a video file.

Auto play disc

When this player is switched on, the disc automatically plays.

- 1 Press ♠ (Home).
- 2 Select [Setup], and then press OK.
- 3 Select [Preference] > [Auto play disc]> [On].
 - The feature is turned on.
 - To turn off the feature, select [Off]. The disc will not automatically play.

Auto play video sequentially

If two or more video files are available in the same folder from a USB storage device, the next video file automatically plays after the end of a video.

- 1 Press ♠ (Home).
- 2 Select [Setup], and then press OK.
- 3 Select [Preference] > [Auto play after video] > [On].
 - The feature is turned on.
 - To turn off the feature, select [Off]. The next video file will not automatically play after the end of a video in the same folder.

BonusView on Blu-ray

View special content (such as commentaries) in a small screen window.

This feature is only applicable to Blu-ray discs compatible with BonusView (also known as picture in picture).

- 1 During play, press **≡**.
 - → The options menu is displayed.
- 2 Select [PIP selection] > [PIP], and press OK.
 - → PIP options [1]/[2] depend on the video contents.
 - → The secondary video window is displayed.
- 3 Select [2nd audio language] or [2nd subtitle language], and press OK.

BD-Live on Blu-ray

Access exclusive online services, such as movie trailers, games, ringtones and other bonus contents.

This feature is only applicable to Blu-ray discs that are BD-Live enabled.

- 1 Prepare the Internet connection and set up a network (see "Set up a network").
- 2 Connect a USB storage device to the ← (USB) connector on this player.
 - A USB storage device is used to store the downloaded BD-Live content.
 - To delete the BD-Live previously downloaded on the USB storage device for memory release, press ↑ and select [Setup] > [Advanced] > [Clear memory].
- 3 Play a disc that is BD-Live enabled.
- 4 On the disc menu, select the BD-Live icon, and press **OK**.
 - → BD-Live starts to load. The loading time depends on the disc and the Internet connection.
- 5 On the BD-Live interface, select an item to access.



Note

- BD-Live services vary from discs and countries.
- When you use BD-Live, data on the disc and this player are accessed by the content provider
- Use a USB storage device with at least 1GB of free space to store the download.

Set up a network

Connect this player to the Internet to access the following service:

 BD-Live: access online bonus features (applicable to Blu-ray discs that are BD-Live enabled).

- 1 Connect this player to the Internet through wired (Ethernet) connection.
 - Connect a network cable (not supplied) to the LAN port on the back panel of this player.



- 2 Perform the network installation.
 - 1) Press f.
 - 2) Select [Setup], and press OK.
 - 3) Select [Network] > [Network installation], and press OK.
 - **4)** Follow the instructions on the TV screen to complete the installation.



Caution

 Before you connect to a network, familiarize yourself with the network router and networking principles. If necessary, read documentation accompanying network components. Philips is not responsible for lost, damaged, or corrupt data.

Use Philips EasyLink

This player supports Philips EasyLink which uses the HDMI CEC (Consumer Electronics Control) protocol. You can use a single remote control to control EasyLink compliant devices that are connected through HDMI. Philips does not guarantee 100% interoperability with all HDMI CEC devices.

- 1 Connect the HDMI CEC compliant devices through HDMI, and turn on the HDMI CEC operations on the TV and other connected devices (see the user manual of the TV or other devices for details).
- 2 Press ♠.
- 3 Select [Setup] > [EasyLink].
- Select [On] under the options: [EasyLink], [One Touch Play] and [One Touch Standby].
 - → EasyLink function is turned on.

One Touch Play

When a video disc is in the disc compartment, press ▶ to wake up the TV from standby, and then play a disc.

One Touch Standby

When a connected device (for example TV) is put to standby with its own remote control, this player is put to standby automatically.

2 Change settings

This section helps you change the settings of this player.







Video	TV display •	16:9 Widescreen
	HDMI video •	Auto
Audio	HDMI Deep Color ●	Auto
Network	Picture settings •	Standard
EasyLink		
Preference		
Advanced		



lote

- · You cannot change a menu option that is grayed out.
- To return to the previous menu, press . To exit the menu, press .

Picture

- 1 Press
- 2 Select [Setup] > [Video] to access the video setup options.
- **[TV display]**: Select a picture display format to fit the TV screen.
- **[HDMI video]**: Select an HDMI video resolution.
- [HDMI Deep Color]: Display colors with more shades and hues when the video content is recorded in Deep Color and the TV supports this feature.
- [Picture settings]: Select a predefined color setting.



 If you change a setting, make sure that the TV supports the new setting.

Sound

- 1 Press ♠.
- 2 Select [Setup] > [Audio] to access the audio setup options.
- [Night mode]: Select quiet or full dynamic sound. Night mode decreases the volume of loud sound and increases the volume of soft sound (such as speech).
- [HDMI audio]: Set an HDMI audio format when this player is connected through HDMI.
- [Digital audio]: Select an audio format for the sound output when this player is connected through a digital connector (coaxial).
- [PCM downsampling]: Set the sampling rate for PCM audio output when this player is connected through a digital connector (coaxial).



Note

- For settings related to HDMI, the TV must be connected through HDMI.
- Night mode is only available for Dolby® TrueHD / Dolby® Digital Plus encoded DVD and Blu-ray discs.

Network (installation, status...)

- 1 Press ♠.
- 2 Select [Setup] > [Network] to access the network setup options.
- [Network installation]: Start a wired installation to make the network work,
- [View network settings]: Display the current network status.

Preference (languages, parental control...)

- 1 Press ♠.
- 2 Select [Setup] > [Preference] to access the preference setup options.
- [Menu language]: Select an onscreen display menu language.
- [Audio]: Select an audio language for video.
- [Subtitle]: Select a subtitle language for video.
- [Disc menu]: Select a menu language for a video disc.
- [Parental control]: Restrict access to discs that are encoded with ratings. Input "0000" to access the restriction options. To play all discs irrespective of the rating, select level "8"
- [Screen saver]: Enable or disable screen saver mode. If enabled, the screen enters idle mode after 10 minutes of inactivity (for example, in pause or stop mode).
- [Auto subtitle shift]: Enable or disable subtitle shift. If enabled, the subtitle position is changed automatically to fit the TV screen (this feature works with some Philips TVs only).
- [Change password]: Set or change a
 password to play a restricted disc. Input
 "0000" if you do not have a password or if
 you have forgotten your password.
- [Auto standby]: Enable or disable auto standby. If enabled, the player switches to standby after 18 minutes of inactivity (for example, in pause or stop mode).
- **[VCD PBC]**: Display or skip the content menu for VCD and SVCD.
- [Auto play disc]: Enable or disable the automatic disc playback after power on.
- [Auto play after video]: Enable or disable sequential playback of videos from USB.



- If your preferred language is not available for disc language, audio or subtitle, you can select [Other] from the menu options and input 4-digit language code which can be found at the back of this user manual.
- If you select a language which is not available on a disc, this player uses the default language of the disc.

Advanced options (clear memory...)

- 1 Press **n**.
- 2 Select [Setup] > [Advanced] to access the advanced setup options.
- [BD-Live security]: Restrict or allow access to BD-Live (only for non-commercial, usercreated BD-Live discs).
- [Downmix mode]: Control 2-channel stereo audio output.
- [Software update]: Update software through a USB storage device.
- [Clear memory]: Delete the previous BD-Live download on the USB storage device. A "BUDA" folder is automatically created to store the BD-Live download.
- [DivX® VOD Code]: Display the DivX® registration code or the deregistration code for this player.
- **[Version information]**: Display the software version of this player.
- [Restore default settings]: Reset this player to the default settings made at the factory, except for password and parental control level.



Vote

- You cannot restrict Internet access on commercial Blu-ray discs.
- Before you purchase DivX videos and play them on this player, register this player on www.divx.com with the DivX VOD code.

3 Update software

Before you update the software of this player, check the current software version:

Press ♠, and then select [Setup] >
 [Advanced] > [Version information], and
 press OK.

Update software via USB

- 1 Check the latest software version on www. philips.com/support.
 - Search for your model and click on "Software and drivers".
- 2 Download the software into a USB storage device.
 - Unzip the download, and make sure that the unzipped folder is named "UPG".
 - 2 Put the "UPG" folder in the root directory.
- 3 Connect the USB storage device to the ← (USB) connector on this player.
- 4 Press ♠, and select [Setup].
- 5 Select [Advanced] > [Software update] > [USB].
 - → If an upgrade media is detected, you are prompted to start the update.
- **6** Follow the instructions on the TV screen to update the software.
 - → When the update is complete, this player automatically turns off and on again.

Caution

 Do not turn off the power or remove the USB storage device when the software update is in progress because you might damage this player.

4 Product specifications



Note

 Specifications and design are subject to change without notice.

Region code

This player can play discs with the following region codes.

DVD	Blu-ray	Countries
		Russia, India

Media formats

- BD-Video
- DVD-Video, DVD+R/+RW, DVD-R/-RW, DVD+R/-R DL (Dual Layer)
- VCD/SVCD
- Audio CD, CD-R/CD-RW, MP3 media, WMA media, JPEG files
- DivX (Ultra)/DivX Plus HD media, MKV media
- USB storage device

File formats

- Audio:
 - .aac, .mka, .mp3, .wma, .wav, .m4a, .flac, .ogg
- Video:
 - .avi, .divx, .mp4, .m4v, .ts, .mov, .mkv, .m2ts, .mpg, .mpeg, .3gp
- Picture: .jpg, .jpeg, .gif, .png

Audio formats

This product supports the following audio files.

Exten-	Con-	Audio	Bit rate
sion	tainer	codec	
.mp3	MP3	MP3	Up to 320 kbps
.wma	ASF	WMA	Up to 192 kbps
		WMA Pro	Up to 768kbps
.aac	AAC	AAC, HE-	Up to 192 kbps
		AAC	
.wav	WAV	PCM	27.648 Mbps
.m4a	MKV	AAC	192 kbps
		ALAC	Up to 192kHz
			sampling rate
.mka	MKA	PCM	27.648 Mbps
		AC-3	640kbps
		DTS core	1.54 Mbps
		MPEG	912 kbps
		MP3	Up to 320 kbps
		WMA	Up to 192 kbps
		WMA Pro	Up to 768kbps
		AAC, HE-	Up to 192 kbps
		AAC	
.flac	FLAC	FLAC	Up to 24 bit per
			sample
.ogg	OGG	Vorbis	Variable bit rate,
			maximum block
-			size 4096
		FLAC	Up to 192kHz
			sampling rate
		OGGPCM	No limitation
		MP3	Upto 320 kbps

Video formats

If you have a high definition TV, this product allows you to play your video files with:

- Resolution: 1920 x 1080 pixels at
- Frame rate: 6 ~ 30 frames per second.

.avi files in AVI container (or .ts files in TS container)

Audio codec	Video codec	Bit rate
PCM, AC-3,	DivX 3.11,	10 Mbps max
DTS core,	DivX 4.x,	
MP3,WMA,	DivX 5.x,	
DD+	DivX 6.x	
	MPEG 1,	40 Mbps
	MPEG 2	
	MPEG 4 SP /	38.4 Mbps
	ASP	
	H.264/AVC up	25 Mbps
	to HiP@5.1	
	WMV9	45 Mbps

.divx files in AVI container

Audio codec	Video codec	Bit rate
PCM, AC-3,	DivX 3.11,	10 Mbps max
DTS core,	DivX 4.x,	
MP3, WMA,	DivX 5.x,	
DD+	DivX 6,x	

.mp4 or .m4v files in MP4 container

Audio codec	Video codec	Bit rate	
AC-3, MPEG, MP3, AAC, HE-AAC, DD+	MPEG 1, MPEG 2	40 Mbps	
	MPEG 4 ASP	38.4 Mbps	
	H.264/AVC up to HiP@5.1	25 Mbps	

.mov files in MOV container

Audio codec	Video codec	Bit rate
AC-3, MPEG,	MPEG 1,	40 Mbps
MP3, AAC,	MPEG 2	
HE-AAC		
	MPEG 4 ASP	38.4 Mbps
	H.264/AVC up	25 Mbps
	to HiP@5.1	

.mkv files in MKV container

Audio codec	Video codec	Bit rate
PCM, AC-3, DTS core, MPEG, MP3, WMA, AAC, HE-AAC, DD+, FLAC	DivX Plus HD	30 Mbps
	MPEG 1, MPEG 2	40 Mbps
	MPEG 4 ASP	38.4 Mbps
	H.264/AVC up to HiP@5.1	25 Mbps
	WMV9	45 Mbps

.m2ts files in MKV container

Audio codec	Video codec	Bit rate
PCM, AC-3,	MPEG 1,	40 Mbps
DTS core,	MPEG 2	
MPEG, MP3,		
WMA, AAC,		
HE-AAC,		
DD+		
	MPEG 4 ASP	38.4 Mbps
	H.264/AVC up	25 Mbps
	to HiP@5.1	
	WMV9	45 Mbps

.mpg and .mpeg files in PS container

Audio codec	Video codec	Bit rate
PCM, DTS	MPEG 1,	40 Mbps
core, MPEG,	MPEG 2	
MP3		

.3gp files in 3GP container

Audio codec	Video codec	Bit rate		
AAC, HE- AAC	MPEG 4 ASP	38.4 Mbps		
	H.264/AVC up to HiP@5.1	25 Mbps max		

Video

- Signal system: PAL / NTSC
- HDMI output: 480i/576i, 480p/576p, 720p, 1080i, 1080p, 1080p/24Hz

Audio

- Digital output: 0.5 Vp-p (75 ohm)
 - Coaxial
- HDMI output
- Sampling frequency:
 - MP3: 32 kHz, 44.1 kHz, 48 kHz
 - WMA: 44.1 kHz, 48 kHz
- Constant bit rate:
 - MP3: 112 kbps 320 kpbs
 - WMA: 48 kpbs 192 kpbs

USB

- Compatibility: Hi-Speed USB (2.0)
- Class support: USB Mass Storage Class
- File system: FAT16, FAT32
- USB port: 5V ==, 500mA
- Support HDD (a portable hard disc drive): an external power source may be needed.

Main unit

- Power supply rating:
 220-240V~, 50Hz -60Hz
- Power consumption: 10 W
- Power consumption in standby mode:
 < 0.5 W
- Dimensions (w x h x d): 270 x 41 x 199.3 (mm)
- Net Weight: 0.92 kg

Operating Temperature & Humidity

• 0°C to 45°C, 5% to 90% Humidity for all climates.

Storage Temperature & Humidity

-40 °C to 70 °C, 5% to 95%

Accessories

- Remote control and batteries
- User manual
- HDMI cable

Laser

- LaserType (Diode): AlGalnN (BD), AlGalnP (DVD/CD)
- Wave length: 398nm to 413nm (BD), 645nmto664nm(DVD),770nmto800nm(CD)
- Output power: 1.7mW (BD), 0.19mW(DVD), 0.25mW (CD)

Standby information

- When the product remains inactive for 18 minutes, it automatically switches to standby or networked standby.
- The power consumption in standby or networked standby is less than 0.5W.

5 Troubleshooting

A

Warning

 Risk of electric shock. Never remove the casing of the player.

To keep the warranty valid, never try to repair the player yourself.

If you have problems using this player, check the following points before you request service. If you still have a problem, register your player and get support at www.philips.com/support. If you contact Philips, you will be asked for the model and serial number of this player. The model number and serial number are on the back of this player. Write the numbers here: Model No. _______ Serial No.

Main unit

The buttons on this player do not work.

 Disconnect this player from the power supply for a few minutes, and then reconnect.

Picture

No picture.

 Make sure that the TV is switched to the correct source input for this player.

No picture on HDMI connection.

- Make sure that the HDMI cable is not faulty. If it is faulty, replace with a new HDMI cable.
- On the remote control, press and then press "731" (numeric buttons) to recover picture display. Or wait for 10 seconds for auto recovery.
- If this player is connected to an unauthorized display device with an HDMI cable, the audio and video signals may not be output.

The disc does not play high-definition video.

- Make sure that the disc contains highdefinition video.
- Make sure that the TV supports highdefinition video

Sound

No audio output from the TV.

- Make sure that the audio cables are connected to the audio input of the TV.
- Make sure that the TV is switched to the correct source input for this player.

No audio output from the loudspeakers of the external audio device (home theater or amplifier).

- Make sure that the audio cables are connected to the audio input of the audio device.
- Switch the external audio device to the correct audio source input.

No sound on HDMI connection.

 You may not hear any sound from the HDMI output if the connected device is non-HDCP compliant or only DVIcompatible.

No secondary audio output for Picture-in-Picture feature.

 When [Bitstream] under the [HDMI audio] or [Digital audio] menu is selected, interactive sound like secondary sound for Picture-in-Picture feature is muted. Deselect [Bitstream].

Play

Cannot play a disc.

- Clean the disc.
- Make sure that the disc is correctly loaded.
- Make sure that this player supports the disc. See "Specifications".
- Make sure that this player supports the region code of the DVD or BD.
- For DVD±RW or DVD±R, make sure that the disc is finalized

Cannot play DivX video files.

- Make sure that the DivX video file is complete.
- Make sure that the video file name extension is correct.

DivX subtitles do not display correctly.

- Make sure that the subtitle file has the same name as the DivX video file.
- Make sure that the subtitle file has an extension name supported by this player (.srt, .sub, .txt, .ssa, or .smi).

Cannot read the contents of a connected USB storage.

- Make sure that the format of the USB storage device is compatible with this player.
- Make sure that the file system on the USB storage device is supported by this player.
- For a USB HDD (a portable hard disc drive), an external power source may be needed.

'No entry' or 'x' sign is displayed on the TV.

• The operation is not possible.

EasyLink feature does not work.

 Make sure that this player is connected to the Philips brand EasyLink TV, and the EasyLink option is turned on (see "Use your Blu-ray disc/ DVD player" > "Use Philips EasyLink").

Cannot access BD-Live features.

- Make sure that this player is connected to the network (see "Use your Blu-ray disc/ DVD player" > "Set up a network").
- Make sure that the network installation is made (see "Use your Blu-ray disc/ DVD player" > "Set up a network").
- Make sure that the Blu-ray disc supports BD-Live features.
- Clear memory storage (see "Change settings" > "Advanced options (BD-Live security, clear memory...)").

Network

Network is not found or distorted.

- Make sure that the network is correctly connected (see "Use your Blu-ray disc/ DVD player" > "Set up a network").
- Make sure that the network installation is made (see "Use your Blu-ray disc/ DVD player" > "Set up a network").
- Check the router connection (refer to the user manual for the router).

Internet speed is slow.

 You need a high speed Internet connection for your router.



'Blu-ray Disc ™ ' and 'Blu-ray Disc ™ ' logo are trademarks of Blu-ray Disc Association.



HDMI, and HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI licensing LLC in the United States and other countries.



Manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories.



This DivX Certified® device has passed rigorous testing to ensure it plays DivX® video. To play purchased DivX movies, first register your device at vod.divx.com. Find your registration code in the DivX VOD section of your device setup menu.

DivX Certified® to play DivX® and DivX Plus® HD (H.264/MKV) video up to 1080p HD, including premium content.

DivX®, DivX Certified®, DivX Plus® HD and associated logos are trademarks of DivX, LLC and are used under license.

Covered by one or more of the following U.S. patents: 7,295,673; 7,460,668; 7,515,710; 7,519,274; 8,301,793; 8,649,669; 8,656,183.



For DTS patents, see http://patents.dts.com.
Manufactured under license from DTS Licensing
Limited. DTS, the Symbol, & DTS and the
Symbol together are registered trademarks, and

DTS 2.0+Digital Out is a trademark of DTS, Inc. © DTS, Inc. All Rights Reserved.



BONUSVIEWTM

'BD LIVE ™ ' and 'BONUSVIEW ™ ' are trademarks of Blu-ray Disc Association.



'DVD Video' is a trademark of DVD Format/Logo Licensing Corporation.



Oracle and Java are registered trademarks of Oracle and/or its affiliates. Other names may be trademarks of their respective owners.

WARRANTY

This product is covered under warranty against any defect arising out of faulty or defective material or workmanship for a period of 12 Months from the date of purchase.

Should a defect develop during the period of warranty, Gibson Innovations India Private Limited undertakes to repair this product free of charge through an Authorised Philips service center.

If the purchaser shifts his residence to other town, the warranty will be valid at the nearest Authorised Philips service center.

The Warranty is not valid in case:

- Proof of purchase is not accompanied with this warranty form
- This warranty form is not completed immediately after purchase
- This product is not used according to this manual
- · Defects are caused by improper or reckless use
- Any repair work are done by person other than Authorised Philips service center
- Any modification or alteration of any nature are made in the apparatus
- · The serial number is tampered
- Defects due to causes beyond control like lightning, abnormal voltage, Acts of God or while in transit to the purchaser's residence

Maintenance Tips for products that play a disc:

- Always keep a Disc loaded in this product tray.
- Keep this product away from the dusty areas. Keep it covered with a dust cover.
- Clean this product Lens after every 20 Discs played by a Lens cleaner disc.
- Clean the CDs / VCD / DVD / MP3 CD before inserting in this product.

Gibson Innovations India Private Limited

Registered office: Address 4th floor, Block -1, Vatika Business Park, Sector - 49, Sohna Road, Gurgaon - 122018 (Haryana) India

For Any Sales & Service Enquiry:

Email us at customercare.indiaaphilips.com

Call us on Tel No. 1800-102-2929 (toll free) 1860-180-1111*

0124-429-1111*

* Standard Call rates apply

	Pls fill the following	a for vour ref	ference and w	arrantv validitv:
--	------------------------	----------------	---------------	-------------------

•	Model No	_ Serial No
•	Bill No.	Date of Purchase
•	Purchaser's Name	Location
•	Telephone No	
•	Dealer Name Stamp & Sign	

Language Code

Abkhazian	6566	Inupiaq	7375	Р	Pushto	8083
Afar	6565	Irish	7165	R	Russian	8285
Afrikaans	6570	Íslenska	7383		Quechua	8185
Amharic	6577	Italiano	7384	R	Raeto-Romance	8277
Arabic	6582	lvrit	7269	R	Romanian	8279
Armenian	7289	Japanese	7465	R	Rundi	8278
Assamese	6583	Javanese	7486	S	Samoan	8377
Avestan	6569	Kalaallisut	7576	S	ango	8371
Aymara	6589	Kannada	7578		Sanskrit	8365
Azerhaijani	6590	Kashmiri	7583		Sardinian	8367
Bahasa Melayu	7783	Kazakh	7575		Serbian	8382
Bashkir	6665	Kernewek	7587	_	Shona	8378
Belarusian	6669	Khmer	7577		Shqip	8381
Bengali	6678	Kinyarwanda	8287		Sindhi	8368
Bihari	6672	Kirghiz	7589		Sinhalese	8373
Bislama	6673	Komi	7586		Slovensky	8373
Bokmål, Norwegian	7866	Korean	7579		Slovenian	8376
Bosanski	6683	Kuanyama; Kwanyama	7574	_	Somali	8379
Brezhoneg	6682	Kurdish	7585		Sotho: Southern	8384
Bulgarian	6671	Lao	7679		South Ndebele	7882
Burmese	7789	Latina	7665		Sundanese	8385
Castellano, Español	6983	Latvian	7686		Suomi	7073
Catalán	6765	Letzeburgesch;	7666		Swahili	8387
Chamorro	6772	•	7673		Swati	8383
Chechen	6769	Limburgan; Limburger	7678		owati Svenska	8386
		Lingala	7684			8476
Chewa; Chichewa; Nyanja		Lithuanian	768 4 7666		agalog a hitian	8489
中文	9072	Luxembourgish;				
Chuang; Zhuang	9065	Macedonian	7775		a jik	8471
Church Slavic; Slavonic	6785	Malagasy	7771		a mil	8465
Chuvash	6786	Magyar	7285		atar	8484
Corsican	6779	Malayalam	7776		elugu	8469
Česky	6783	Maltese	7784		hai 	8472
Dansk	6865	Manx	7186		ibetan 	6679
Deutsch	6869	Maori	7773		igrin ya	8473
Dzongkha	6890	Marathi	7782		o nga (onga Islands)	8479
English	6978	Marshallese	7772		songa	8483
Esperanto	6979	Moldavian	7779		swana	8478
Estonian	6984	Mongolian	7778		rkçe	8482
Euskara	6985	Nauru	7865		urkmen	8475
Ελληνικά	6976	Navaho; Navajo	7886		w i	8487
Faroese	7079	Ndebele, North	7868		ighur	8571
Français	7082	Ndebele, South	7882		krainian	8575
Frysk	7089	Ndonga	7871		r du	8582
Fijian	7074	Nederlands	7876	-	zbek	8590
Gaelic; Scottish Gaelic	7168	Nepali	7869		ietnamese	8673
Gallegan	7176	Norsk	7879		o lapuk	8679
Georgian	7565	Northern Sami	8369	2	a Iloon	8765
Gikuyu; Kikuyu	7573	North Ndebele	7868		elsh	6789
Guarani	7178	Norwegian Nynorsk;	7878	(o lof	8779
Gujarati	7185	Occitan; Provencal	7967		hosa	8872
Hausa	7265	Old Bulgarian; Old Slavonic			iddish	8973
Herero	7290	Oriya	7982		oruba	8979
Hindi	7273	Oromo	7977	Z	Zulu	9085
Hiri Motu	7279	Ossetian; Ossetic	7983			
Hrwatski	6779	Pali	8073			
Ido	7379	Panjabi	8065			
Interlingua (Internationa	1)7365	Persian	7065			
Interlingue	7365	Polski	8076			
Inuktitut	7385	Português	8084			



Specifications are subject to change without notice
© 2015 Koninklijke Philips N.V. All rights reserved.

Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

