## Always there to help you

Register your product and get support at www.philips.com/support



DVP2880X



# User manual



# Safety and important notice

Read and understand all instructions before you use this DVD player. If damage is caused by failure to follow the instructions, the warranty does not apply.

## Safety

#### Risk of electric shock!

- Never expose the product and accessories to rain or water. Never place liquid containers, such as vases, near the product. If liquids are split on or into the product, disconnect it from the power outlet immediately. Contact Philips Consumer Care to have the product checked before use.
- Never place the product and accessories near naked flames or other heat sources, including direct sunlight.
- Never insert objects into the ventilation slots or other openings on the product.
- Where the mains plug or an appliance coupler is used as the disconnect device, it shall remain readily operable.
- Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.
- Disconnect the product from the power outlet before lightning storms.
- When you disconnect the power cord, always pull the plug, never the cable.

#### Risk of short circuit or fire!

- Before you connect the product to the power outlet, make sure that the power voltage matches the value printed on the back of the product.
- Avoid applying pressure on the power plugs. Loose power plugs can cause arcing or fire.

#### Risk of injury or damage to the product!

- To avoid exposure to laser radiation, do not disassemble.
- Do not touch the optical lens inside the disc compartment.
- Never place the product or any objects on power cords or on other electrical equipment.
- If the product is transported in temperatures below 5°C, unpack the product and wait until its temperature matches room temperature before connecting it to the power outlet.

#### Risk of overheating!

 Never install this product in a confined space. Always leave a space of at least four inches around the product for ventilation. Make sure that curtains or other objects never cover the ventilation slots on the product.

#### Risk of contamination!

- Remove the batteries if flat or if the remote control is not to be used for a long time.
- Batteries contain chemical substances. They should be disposed of properly.

#### Risk of swallowing batteries!

 The product/remote control may contain a coin type battery, which can be swallowed.
 Keep the battery out of reach of children at all times!





#### Note

- For identification and supply ratings, see the type plate at the back or bottom of the product.
- Before you make or change any connections, make sure that all devices are disconnected from the power outlet.

## Care for your product

- Do not insert any objects other than discs into the disc compartment.
- Do not insert warped or cracked discs into the disc compartment.
- Remove discs from the disc compartment if you are not using the product for an extended period of time.
- Only use microfiber cloth to clean the product.

#### Care of the environment



human health.

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused. Never dispose of your product with other household waste. Please inform yourself about the local rules on the separate collection of electrical and electronic products and batteries. The correct disposal of these products helps prevent potentially negative consequences on the environment and human health. Your product contains batteries, which cannot be disposed of with normal household waste. Please inform yourself about the local rules on separate collection of batteries. The correct disposal of batteries helps prevent potentially negative consequences on the environment and

Please visit www.recycle.philips.com for additional information on a recycling center in your area.

### Compliance



This is CLASS II apparatus with double insulation, and no protective earth provided.


## Copyright




Be responsible Respect copyrights


This item incorporates copy protection technology that is protected by U.S. patents and other intellectual property rights of Rovi Corporation. Reverse engineering and disassembly are prohibited.





















# 



## Contents

1	Use your DVD player Basic play control Video options Control photo play Repeat play Skip play Play DivX videos Use Philips EasyLink	2 3 3 3 3 4
2	Change settings General (sleep, standby) Picture Sound Preference (languages, parental control)	5 5 5 6 6
3	Software update	7
4	Specifications	7
5	Troubleshooting	8

## 1 Use your DVD player

Congratulations on your purchase, and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

## Basic play control



During play, press the following buttons to control the player.

Button	Action
(1)	Turn on the player, or
O .	switch to standby.
<u> </u>	Open or close the disc
	compartment.
<b>f</b>	Access the home menu,
DISC MENU	Access or exit the disc
	menu.
<b>≡</b> OPTIONS	Access more options
	during video play.
<b>▲▼</b>	Navigate the menus.
	Slow forward or backward.
	Press repeatedly to change
	a search speed.
<b>◄ / ▶ ▶</b>	Navigate the menus.
	Fast forward or backward.
	Press repeatedly to change
	a search speed.
OK	Confirm a selection or
	entry.
⊅ BACK	Return to a previous
	display menu.
■ STOP	Stop play.
►II	Start, pause or resume play.
<b>        </b>	Skip to the previous or
	next track, chapter or file.
SUBTITLE	Select a subtitle language.
GOTO	Skip to a title, a chapter or
	a track.
AUDIO	Select an audio language or
	channel.
	Fit the picture display to
	the TV screen.
	Zoom the picture in or out.
VOLUME	Activate volume control,
	and then press ◀◀ / ▶▶ to
	change a volume level.
REPEAT/REPEAT A-B	Select a repeat play option.

## Video options

During video play, press **OPTIONS** to access the following options.

- [Info]: Display the current play information.
- **[PBC]**: Display or skip the content menu for VCD and SVCD.
- [Aspect ratio]: Select a picture display format to fit the TV screen.
- [Volume]: Change a volume level.
- [Angle]: Select a camera angle from which video is viewed.

### Control photo play

During photo play, use the remote control to control the play.

Button	Action			
$\overline{\blacktriangle}$	Rotate a picture horizontally/			
	vertically.			
<b>44/ &gt;&gt;</b>	Rotate a picture anti-clockwise/			
	clockwise.			
<b>=</b>	Access to select [Color] to			
<b>OPTIONS</b>	display a picture in color or black			
	and white.			
	Access to select [Photo preview]			
	to display pictures in thumbnail.			
	Zoom in or out of a photo.			
OK	Start or resume a play.			
	Stop a play.			

## Repeat play

During play, press **REPEAT/REPEAT A-B** repeatedly to select a repeat play option.

- Repeat the current title, chapter, or track.
- Repeat all the contents on a disc.
- Repeat play for a specific section.

#### To Repeat play for a specific section

- 1 Press REPEAT/REPEAT A-B repeatedly to select  $\triangle$  A as a start point.
- Press REPEAT/REPEAT A-B again to select AB as an end point.
  - → The repeat play of the marked section starts.
- 3 To cancel repeat play, press REPEAT/ REPEAT A-B until [Off] is displayed.



#### Note

 Repeat play of the marked section is only possible within a title or track.

## Skip play

You can skip play to a specific title, chapter or track.

- 1 During play, press GOTO.
  - → An input field bar is displayed, and "0" blinks
- 2 Press ▲ ▼ to select a digit as a title, chapter, or track number.
- 3 After a digit is selected, press ◀◀ / ▶▶ to change a digit position.
- 4 If necessary, repeat step 2 and 3 to complete the input of a title, chapter, or track number.
- 5 Press OK.
  - → The play skips to the selected title, chapter or track.

## Play DivX videos

You can play DivX videos from a disc.

#### VOD code for DivX

- Before you purchase DivX videos and play them on this player, go to vod.divx.com to register this player using the DivX VOD code.
- Display the DivXVOD code: press ♠, and select [Setup] > [General] > [DivX(R) VOD Code].

#### DivX subtitles

- Press SUBTITLE to select a language.
- If subtitles are not displayed correctly, change the character set that supports
   DivX subtitles. Select a character set: press
   ♠, and select [Setup] > [Preference] > [DivX Subtitle].

Character set	Languages
[Standard]	English, Albanian, Danish, Dutch, Finnish, French, Gaelic, German, Italian, Kurdish (Latin), Norwegian, Portuguese, Spanish, Swedish and Turkish



#### Note

- To use the subtitles, make sure that the subtitle file
  has the same name as the DivX video file name. For
  example, if the DivX video file is named "movie.avi",
  save the subtitle file as "movie.srt", or "movie.sub".
- This player can play subtitle files in the following formats: .srt, .sub, .txt, .ssa, and .smi.

## Use Philips EasyLink

This player supports Philips EasyLink which uses the HDMI CEC (Consumer Electronics Control) protocol. You can use a single remote control to control EasyLink compliant devices that are connected through HDMI. Philips does not guarantee 100% interoperability with all HDMI CEC devices.

- 1 Connect the HDMI CEC compliant devices through HDMI, and turn on the HDMI CEC operations on the TV and other connected devices (see the user manual of the TV or other devices for details).
- 2 Press ♠.
- 4 Select [On] under the options: [EasyLink], [One Touch Play] and [One Touch Standby].
  - → EasyLink function is turned on.

#### One Touch Play

When you play a disc on this player, the TV automatically switches to the correct video input source.

#### One Touch Standby

When a connected device (for example TV) is put to standby with its own remote control, this player is put to standby automatically.

## 2 Change settings

This section helps you change the settings of this player.







General	Disc Lock	Unlock
General	OSD Language	English
Video	Sleep Timer	• Off
Video	Auto Standby	• On
Audio	DivX(R) VOD Code	Registration
Preference		



#### Note

- You cannot change a menu option that is grayed out.
- To access [Preference], stop the disc play.
- To return to the previous menu, press 3. To exit the menu, press 1.

## General (sleep, standby...)

- 1 Press 🖈.
- 2 Select [Setup] > [General] to access the general setup options.
  - [Disc Lock]: Lock or unlock a disc for play. To play a locked disc, you need to input your password: press ▲ ▼ to enter a digit, and press ◄ / ▶ to change a digit position. The default password is "136900".
  - [OSD Language]: Select a language for on-screen menu.
  - [Sleep Timer]: Set a period of time for this player to switch automatically to standby mode from play.
  - [Auto Standby]: Enable or disable auto standby. If enabled, this player switches automatically to standby after 15 minutes of inactivity (for example, in pause or stop mode).

 [DivX(R) VOD Code]: Display the DivX® registration code and deregistration code.

#### **Picture**

- 1 Press  $\spadesuit$ .
- 2 Select [Setup] > [Video] to access the video setup options.
  - [TV System]: Select a TV system that matches your TV. By default, this setting matches the common TVs in your country.
  - [Aspect ratio]: Select a picture display format to fit the TV screen.
  - [Picture Setting]: Select a predefined color setting, or customize a setting.
  - [Closed Caption]: Enable this feature to show the sound effects in subtitles.
     Applicable only when both a disc and a TV support this feature.
  - [HD JPEG]: Enable this feature to view high-definition pictures through HDMI connection.
  - [HDMI Setup]:Set up for HDMI connection.
    - [Resolution]: Select a resolution for high definition videos.
    - [HDMI Deep Color]: Create vivid images with more color details when the video content is recorded in Deep Color and the TV supports this feature.
    - [Wide Screen]: Select a display format for wide screen videos.
    - [EasyLink Setup]: See "Use your DVD player" > "Use Philips EasyLink" for details.

#### Sound

- 1 Press f.
- 2 Select [Setup] > [Audio] to access the audio setup options.
  - [Analogue Output]: Select an audio format for sound output when this player is connected through the AUDIO OUT L/R connectors.
  - [Digital Audio]: Select an audio format for sound output when this player is connected through the COAXIAL connector:
    - [Digital Output]: Select a type of digital output: [Off] - Disable digital output; [All] - Support multi-channel audio formats; [PCM Only] - Downmix to two-channel audio signal.
    - [LPCM Output]: Select a LPCM (Linear Pulse Code Modulation) output sampling rate. The higher the sampling rate, the better the sound quality. [LPCM Output] is enabled only when [PCM Only] is selected under [Digital Output].
  - [HDMI Audio]: Enable or disable the audio output through HDMI connection.
  - [Audio Sync]: Set a delay time for audio output to match the video play.
  - [Volume]: Change a volume level.
  - [Sound Mode]: Select a preset sound effect.
  - [Night Mode]: Select quiet or full dynamic sound. Night mode decreases the volume of loud sound and increases the volume of soft sound (such as speech).



#### Note

Night mode is only available for Dolby encoded DVD discs.

## Preference (languages, parental control...)

- 1 Press ♠.
- 2 Select [Setup] > [Preference] to access the preference setup options.
  - [Audio]: Select an audio language for video.
  - [Subtitle]: Select a subtitle language for video.
  - [Disc Menu]: Select a menu language for a video disc.
  - [Parental Control]: Restrict access to discs that are encoded with ratings. Input "136900" to access the restriction options: When the password field is highlighted, press OK to enter an input stage, press ▲ ▼ to select a digit and press ◄ ✓ / ▶▶ to change a digit position.
  - **[PBC]**: Display or skip the content menu for VCD and SVCD.
  - [Password]: Set or change a password to play a restricted disc. Input "136900" if you do not have a password or if you have forgotten your password
  - [DivX Subtitle]: Select a character set that supports the subtitle of your DivX video.
  - **[Version Info]**: Display the software version for this player.
  - [Default]: Reset all settings to the factory default, except for the settings for [Disc Lock], [Parental Control] and [Password].



#### Note

- If your preferred language is not available for disc language, audio or subtitle, you can select [Others] from the menu options and input 4-digit language code which can be found at the back of this user manual.
- The rating levels are country-dependent. To allow all discs to be played, select [8 Adult].

## 3 Software update

## =

Note

Power supply must not be interrupted during software update.

To check for updates, compare the current software version of this player with the latest software version (if available) at the Philips website.

- 1 Press f.
- 2 Select [Setup] > [Preference] > [Version Info], and then press OK.
- Write down the model name and the software version number.
- 4 Visit www.philips.com/support to check for the latest software version, using the model name and software version number.
- Refer to the upgrade instructions given on the website to complete the software update.

## 4 Specifications



Vote

· Specifications are subject to change without notice

#### Region code

This player can play discs with the following region code.

# DVD region code Countries Latin America

#### Playable media

- DVD, DVD-Video, VCD, SVCD, Audio CD
- DVD+R/+RW, DVD-R/-RW, DVD+R/-R DL (Dual Layer), CD-R/-RW (maximum 200 folders and 9999 files)

#### File format

- Video: MPEG 1, MPEG 2
- Picture: .jpg, .jpeg

#### Video

- Signal system: PAL, NTSC, Multi
- Composite video output: 1 Vp-p (75 ohm)
- HDMI output: 480i, 480p, 576i, 576p, 720p, 1080i, 1080p, Auto

#### Audio

- 2-channel analog output
  - Audio Front L&R: 2 Vrms (47k Ohm)
- Digital output: 0.5 Vp-p (75 Ohm)
  - Coaxial
- HDMI output

#### Main unit

- Dimensions (W  $\times$  H  $\times$  D): 270  $\times$  37.5  $\times$  209 (mm)
- Net Weight: 1.0 kg

#### Power

- Power supply rating: 110-127V~, 60Hz
- Power consumption: <11W</li>
- Power consumption in standby mode: <0.5W</li>

#### Accessories supplied

- Remote control and one battery
- User Manual
- HDMI cable
- AV cables

#### Laser specification

- Type: Semiconductor laser InGaAIP (DVD), AIGaAs (CD)
- Wave length: 658 nm (DVD), 790 nm (CD)
- Output Power: 7.0 mW (DVD), 10.0 mW (VCD/CD)
- Beam divergence: 60 degrees

## 5 Troubleshooting

To keep the warranty valid, never try to repair the player yourself.

If you have problems using this player, check the following points before you request service. If you still have a problem, register your player and get support at www.philips.com/support. If you contact Philips, you will be asked for the model and serial number of this player. The model number and serial number are on the back of this player. Write the numbers here: Model No. \_\_\_\_\_\_\_ Serial No.

#### No picture.

- The TV video input channel is not correctly selected (see the TV's user manual).
- If you have changed a TV system setting, switch back to the default setting.

#### No picture on HDMI connection.

- If this player is connected to an unauthorized display device, the audio/ video signal cannot be output.
- If the HDMI cable is faulty, replace it with a new HDMI cable.
- If you have changed the setting for HDMI video resolution, switch to its default mode.

#### No sound output from the TV.

 Make sure that the audio cables are correctly connected between this player and the TV.

#### No sound during DivX video playback.

• The audio codes are not supported.

#### No sound on HDMI connection.

- If the connected device is non-HDCP compliant or only DVI-compatible, no sound can be heard from the HDMI output.
- Make sure that [HDMI Audio] is set to [On].

## No audio output from the loudspeakers of the connected external audio device (for example, stereo system, amplifier receiver).

- Make sure that the audio cables or coaxial cable are correctly connected.
- Switch the external audio device to correct audio input source.

#### Disc cannot be read.

- Make sure that this player supports the disc (see "Specifications" > "Playable media").
- For a recorded disc, make sure that the disc is finalized

#### Files cannot be displayed or read.

- Make sure that this player supports these files (see "Specifications" > "File format").
- Make sure that the number of files or folders does not exceed the supported limit of this player (maximum 200 folders or 9999 files).
- If a maximum number of folders exceeds 200, files in any folder which is outside the 200 folders cannot be read regardless of the total files stored on the media which are within the maximum number of files.

#### DivX video files cannot be played.

- Make sure that the DivX video file is complete.
- Make sure that the file extension is correct.

#### DivX subtitles do not display correctly.

- Make sure that the subtitle file has the same name as the DivX video file.
- Make sure that the subtitle file has an extension name supported by this player (.srt, .sub, .txt, .ssa, or .smi).
- Select the character set that supports the subtitle (see "Use your DVD player" > "DivX videos").

#### EasyLink feature does not work.

 Make sure that this player is connected to the Philips brand EasyLink TV, and the EasyLink option is turned on (see "Use your DVD player" > "Use Philips EasyLink").



ABOUT DIVX VIDEO: DivX® is a digital video format created by DivX, LLC, a subsidiary of Rovi Corporation. This is an official DivX Certified® device that plays DivX video. Visit divx.com for more information and software tools to convert your files into DivX videos. ABOUT DIVX VIDEO-ON-DEMAND: This DivX Certified® device must be registered in order to play purchased DivX Video-on-Demand (VOD) movies. To obtain your registration code, locate the DivX VOD section in your device setup menu. Go to vod.divx.com for more information on how to complete your registration.

DivX®, DivX Ultra®, DivX Certified® and associated logos are trademarks of Rovi Corporation or its subsidiaries and are used under license.

DivX Ultra<sup>®</sup> Certified to play DivX<sup>®</sup> video with advanced features and premium content,

#### HDMI"

HDMI, the HDMI logo, and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI licensing LLC in the United States and other countries.



Dolby and the double-D symbol are registered trademarks of Dolby Laboratories.



'DVD Video' is a trademark of DVD Format/ Logo Licensing Corporation.

## Language Code

Abkhazian	6566	Inupiag	7375	Pushto	8083
Afar	6565	Irish	7165	Russian	8285
Afrikaans	6570	Íslenska	7383	Ouechua	8185
Amharic	6577	Italiano	7384	Raeto-Romance	8277
Arabic	6582	Ivrit	7269	Romanian	8279
Armenian	7289	Japanese	7465	Rundi	8278
Assamese	6583	lavanese	7486	Samoan	8377
Avestan	6569	Kalaallisut	7576	Sango	8371
Aymara	6589	Kannada	7578	Sanskrit	8365
Azerhaijani	6590	Kashmiri	7583	Sardinian	8367
Bahasa Melayu	7783	Kazakh	7575	Serbian	8382
Bashkir	6665	Kernewek	7587	Shona	8378
Belarusian	6669	Khmer	7577	Shqip	8381
Bengali	6678	Kiinei Kinyarwanda	8287	Sindhi	8368
Bihari	6672	Kirghiz	7589	Sinhalese	8373
Bislama	6673	Komi	7586	Slovensky	8373
Bokmål, Norwegian	7866	Korean	7579	Slovenian	8376
Bosanski	6683	Kuanyama; Kwanyama	7574	Somali	8379
Brezhoneg	6682	Kuanyama, Kwanyama Kurdish	7585	Sotho: Southern	8384
•	6671	Lao	7679	South Ndebele	7882
Bulgarian Burmese	7789	Latina	7665	Sundanese	8385
	6983	Latina	7686	Suomi	7073
Castellano, Español Catalán	6765		7666	Swahili	8387
Chamorro	6772	Letzeburgesch;	7673	Swati	8383
		Limburgan; Limburger		Svenska	8386
Chechen	6769	Lingala	7678		
Chewa; Chichewa; Nyanja		Lithuanian	7684	Tagalog	8476
中文 Character <b>Z</b> haracter	9072	Luxembourgish;	7666	Tahitian	8489
Chuang; Zhuang	9065	Macedonian	7775	Tajik Tamil	8471
Church Slavic; Slavonic Chuvash	6785 6786	Malagasy	7771 7285	Tatar	8465 8484
Corsican	6779	Magyar Malayalam	7776	Telugu	8469
Česky	6783	Maltese	7784	Thai	8472
Dansk	6865	Manx	7186	Tibetan	6679
Deutsch	6869	Maori	7773	Tigrinya	8473
Dzongkha	6890	Marathi	7782	Tonga (Tonga Islands)	8479
English	6978	Marshallese	7772	Tsonga	8483
Esperanto	6979	Moldavian	7779	Tswana	8478
Estonian	6984	Mongolian	7778	Türkce	8482
Euskara	6985	Nauru	7865	Turkmen	8475
Ελληνικά	6976	Navaho; Navajo	7886	Twi	8487
Faroese	7079	Ndebele, North	7868	Uighur	8571
Français	7082	Ndebele, South	7882	Ukrainian	8575
Frysk	7089	Ndonga	7871	Urdu	8582
Fijian	7074	Nederlands	7876	Uzbek	8590
Gaelic; Scottish Gaelic	7168	Nepali	7869	Vietnamese	8673
Gallegan	7176	Norsk	7879	Volapuk	8679
Georgian	7565	Northern Sami	8369	Walloon	8765
Gikuyu; Kikuyu	7573	North Ndebele	7868	Welsh	6789
Guarani	7178	Norwegian Nynorsk;	7878	Wolof	8779
Gujarati	7185	Occitan; Provencal	7967	Xhosa	8872
Hausa	7265	Old Bulgarian; Old Slavonic	6785	Yiddish	8973
Herero	7290	Oriya	7982	Yoruba	8979
Hindi	7273	Oromo	7977	Zulu	9085
Hiri Motu	7279	Ossetian; Ossetic	7983		
Hrwatski	6779	Pali	8073		
Ido	7379	Panjabi	8065		
Interlingua (Internationa		Persian	7065		
Interlingue	7365	Polski	8076		
Inuktitut	7385	Português	8084		



Especificações sujeitas a alterações sem aviso prévio
© 2015 Koninklijke Philips N.V. All rights reserved.
Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

