www.philips.com/welcome

DVP3588



EN User manual



Contents

1	Important	4
	Safety and important notice	4
	Trademark notice	2
2	Your DVD player	
	Playable media	
	Product overview	5
3	Connect	7
	Connect audio/video cables	7
	Optional audio connections	7
	Connect USB flash drive	8
	Connect power	3
4	Get started	8
	Prepare the remote control	8
	Find the TV input channel	9
	Select menu display language	9
	Turn on progressive scan	9
	Use Philips EasyLink	10
5	Play	10
	Play a disc	10
	Play video	10
	Play music	12
	Play photo	12
	Play from a USB flash drive	13
6	Other features	13
	Media copy	13
	Create MP3 files	14
7	Adjust settings	14
	General setup	14
	Audio setup	15
	Video setup	16
	Preferences	17
8	Additional information	19
	Update software	19
	Care	19
	Specifications	19
9	Troubleshooting	19
10	Glossary	20

1 Important

Safety and important notice



Warning

- Risk of overheating! Never install the product in a confined space. Always leave a space of at least 4 inches around the product for ventilation. Ensure curtains or other objects never cover the ventilation slots on the product.
- Never place the product, remote control or batteries near naked flames or other heat sources, including direct sunlight
- · Avoid high temperature, moisture, water and dust.
- This unit must not be exposed to dripping or splashing.
- Never place any object or items that can damage this unit (e.g., liquid filled objects, lighted candles).
- · Never place this product on other electrical equipment.
- · Keep away from this product during lightning storms.
- Where the mains plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.
- Visible and invisible laser radiation when open. Avoid exposure to beam.

About Progressive Scan

Consumers should note that not all high definition television sets are fully compatible with this product and may cause artifacts to be displayed in the picture. In case of 525 or 625 progressive scan picture problems, it is recommended that the user switch the connection to the 'standard definition' output. If there are questions regarding our TV set compatibility with this model 525p and 625p DVD player, please contact our customer service center.

Disposal of your old product and batteries

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.



Never dispose of your product with other household waste. Please inform yourself about the local rules on the separate collection of electrical and electronic products and batteries. The correct disposal of these products helps prevent potentially negative consequences on the environment and human health.

Your product contains batteries, which cannot be disposed of with normal household waste. Please inform yourself about the local rules on separate collection of batteries. The correct disposal of batteries helps prevent potentially

negative consequences on the environment and human health.

Please visit www.recycle.philips.com for additional information on a recycling center in your area.

Copyright notice



Be responsible Respect copyrights

This item incorporates copy protection technology that is protected by U.S. patents and other intellectual property rights of Rovi Corporation. Reverse engineering and disassembly are prohibited.



Trademark notice



Windows Media and the

Windows logo are trademarks, or registered trademarks of Microsoft Corporation in the United States and/or other countries.

DOLBY

DIGITAL Manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories.



Digital Surround Manufactured under license under U.S. Patent #'s: 5,451,942; 5,956,674; 5,974,380; 5,978,762; 6,487,535 & other U.S. and worldwide patents issued & pending. DTS and the Symbol are registered trademarks & DTS Digital Surround and the DTS logos are trademarks of DTS, Inc. Product includes software. © DTS, Inc. All Rights Reserved.



VIDEO 'DVD Video' is a trademark of DVD Format/Logo Licensing Corporation.

ULTRA

ABOUT DIVX VIDEO: DivX® is a digital video format created by DivX, Inc. This is an official DivX Certified device that plays DivX video. Visit www.divx.com for more information and software tools to convert your files into DivX video. ABOUT DIVX VIDEO-ON-DEMAND: This DivX Certified® device must be registered in order to play DivX Video-on-Demand (VOD) content. To generate the registration code, locate the DivX VOD section in the device setup menu. Go to vod. divx.com with this code to complete the registration process and learn more about DivX VOD. DivX® and DivX Ultra® are registered trademarks of DivX. Inc., and are used under license.

The USB-IF Logos are trademarks of Universal Serial Bus Implementers Forum, Inc.

HDMI, and HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI licensing LLC.

2 Your DVD player

Congratulations on your purchase, and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

Playable media

This product can play:

- DVD, DVD-Video, DVD+R/+RW, DVD-R/-RW, DVD+R/-R DL (Dual Layer)
- Video CD/SVCD
- Audio CD, CD-R/CD-RW,
- MP3 media, WMA media, WMV media, DivX (Ultra) media, JPEG files
- USB flash drive


Region codes

You can play discs with the following region codes.

DVD region code	Countries
(5)	India


Product overview

Main Unit



- ① (Standby-On)
 - Turn on the unit or switch to standby.
- 2) Disc compartment
- (3) Display panel
- - Open or close the disc compartment.
- (5) II (Play/Pause)
 - Start, pause or resume disc play.
- (6) •<₩ (USB) jack
 - Connect a USB flash drive.

Remote control



- (1) (
 - Turn on the unit or switch to standby.
- (2)
 - Open or close the disc compartment.

3 DISC MENU

- · Access or exit the disc menu.
- Switch to the disc mode.

- During a photo slideshow, switch between Fun Mode (color) and Simple Mode (black and white).
- For VCD and SVCD, turn on or off PBC (playback control).

(4) AV4>

- Navigate the menus.
 - Search fast-forward (▶) or fast-backward (◀).
 - Search slow-forward (▲) or slowbackward (▼).

(5) SACK

• Return to the previous display menu.

(6) |◀/▶|

 Skip to the previous or next title, chapter, or track.

(7) ←

Switch to the USB mode.

(8) Numeric buttons

Select an item to play.

9 SUBTITLE

- Select a subtitle language on a disc.
- Access the menu of copying/deleting USB audio files.

(10) **E** ZOOM

- Fit the piture display to the TV screen.
- Zoom the picture in or out.

(11) VOLUME

Display the current volume level and use
 (◀) or (▶) navigation buttons to set the
 volume level between 0 ~ 20.

(12) REPEAT/REPEAT A-B

- Select or turn off repeat mode.
- · Repeat play for a specific section.

3 AUDIO/CREATE MP3

- Select an audio language or channel on a disc.
- Access the menu of creating MP3 files.
- (14)
 - Stop play.

(15) ▶ | 1

Start, pause or resume disc play.

(16) 1 INFO

- For discs, access the play options or display the current disc status.
- For slideshows, display a thumbnail view of photo files.

(17) OK

Confirm an entry or selection.

18) SETUP

Access or exit the setup menu.

3 Connect

Make the following connections to use this product.

Basic connections:

- Video
- Audio

Optional connections:


- Route audio to other devices:
 - · Digital amplifier/receiver
 - Analogue stereo system
- USB flash drive

Connect audio/video cables

Select the best video connection that TV can support.

- Option 1: Connect to the HDMI jack (for a HDMI, DVI or HDCP-compliant TV).
- Option 2: Connect to the component video jacks (for a standard TV or Progressive Scan TV).
- Option 3: Connect to the composite video jack (for a standard TV).

Option 1: Connect to the HDMI jack




- Connect an HDMI cable (supplied) to
 - the **HDMI OUT** jack on this product.
 - the HDMI input jack on the TV.



Note


 If the device supports HDMI CEC, you can control compliant devices with a single remote control (see "Get started" > "Use Philips EasyLink").

Option 2: Connect to the component video jacks



- 1 Connect the component video cables (not supplied) to:
 - the Y Pb Pr jacks on this product.
 - the COMPONENT VIDEO input jacks on the TV.
- 2 Connect the audio cables (supplied) to:
 - the AUDIO OUT FRONT L/R jacks on this product.
 - the audio input jacks on the TV.

Option 3: Connect to the video (CVBS) jack




- 1 Connect a composite video cable (supplied) to:
 - the TV OUT jack on this product.
 - the video input jack on the TV.
- 2 Connect the audio cables (supplied) to:
 - the AUDIO OUT FRONT L/R jacks on this product.
 - the audio input jacks on the TV.

Optional audio connections


Connect the audio from this product to other devices to enhance sound.

Connect multi channel receiver




- 1 Connect the audio cables (not supplied) to:
 - the AUDIO OUT (FRONT L/R, REAR L/R, CENTER and SUBWOOFER) jacks on this product.
 - the audio input jacks on the device.

Connect to digital amplifier/receiver




- 1 Connect a coaxial cable (not supplied) to:
 - the COAXIAL jack on this product.
 - the COAXIAL/DIGITAL input jack on the device.

Connect analogue stereo system



- 1 Connect the audio cables (supplied) to:
 - the AUDIO OUT FRONT L/R jacks on this product.
 - the audio input jacks on the TV.

Connect USB flash drive



1 Connect a USB flash drive to the jack on this product.



Note

- This product can only play/view MP3, WMA, WMV, DivX (Ultra) or JPEG files that are stored on a USB flash drive.
- Press the button to access the content and play the files.

Connect power



Caution

- Risk of product damage! Ensure that the power supply voltage corresponds to the voltage printed on the back of the product.
- Before connecting the AC power cord, ensure you have completed all other connections.



Note


- The type plate is located on the back of the product.
- 1 Connect the AC power cable to the wall
 - → The product is ready to be set up for use.

4 Get started

Prepare the remote control

- 1 Press and push the battery compartment to slide it open (see "1" in the illustration).
- Insert two AAA batteries with correct polarity (+/-) as indicated.

Push and slide back the battery compartment (see "3" in the illustration).





- If you are not going to use the remote control for a long time, remove the batteries.
- Do not mix batteries (old and new or carbon and alkaline, etc.).
- Batteries contain chemical substances, so they should be disposed of properly.

Find the TV input channel

- 1 Press \circ to turn on this product.
- Turn on the TV and switch to the video input channel (refer to the TV user manual on how to select the A/V input channel).

Select menu display language



Note

 If this product is connected to a HDMI CEC compliant TV, skip this setting, It switches automatically to the same OSD menu language as per your TV setting (if the language set on TV is supported by this product).

General Setup	
Disc Lock	o Auto (ENG)
OSD Language	O English
Sleep Timer	o हिंदी
Auto Standby	
DivX(R) VOD Code	
	Disc Lock OSD Language Sleep Timer Auto Standby


- 1 Press SETUP.
 - → [General Setup] menu is displayed.
- 2 Select [OSD Language], and then press ▶.
- 3 Press ▲▼ to select a language, and then press OK.

Turn on progressive scan



Note

 To use the progressive scan feature, you must connect a progressive scan TV with the component video jacks (see "Connect" > "Connect audio/video cables" > "Option 2: Connect to the component video jacks" for details).



- Turn on the TV to the correct viewing channel for this product.
- 2 Press SETUP.
- Press ▼ to select [Video Setup].
- 4 Select [Progressive] > [On], and then press OK.
 - → A warning message is displayed.
- 5 To proceed, select [Ok] and then press OK.
 - → The progressive setup is complete.



Note

- If a blank/distorted screen is displayed, wait for 15 seconds for the auto recovery.
- If no picture is displayed, turn off the progressive scan mode as follows:
 - Press ≜ to open the disc compartment.
 - 2) Press the Numeric button '1'.
- 6 Press SETUP to exit the menu.
- You can now turn on the progressive scan mode on the TV (see the TV user manual).



Note

 During play, when the progressive scan mode is on for both this product and the TV, distorted picture may display. In this case, turn off the progressive scan feature on both this product and the TV.

Use Philips EasyLink

This product supports Philips EasyLink which uses the HDMI CEC (Consumer Electronics Control) protocol. You can use one single remote control to control EasyLink-compliant devices that are connected through HDMI connectors.



Note

 To enable the EasyLink feature, you must turn on the HDMI CEC operations on the TV and on other devices connected to TV. Refer to the TVs/devices manual for details.

One-touch play

- 1 Press \circ to turn on this product.
 - The TV (if supports one-touch play) automatically turns on and switches to the correct video-in channel.
 - → If a disc is loaded in this product, disc play automatically starts.

One-touch standby

- 1 Press and hold Φ on the remote control for more than 3 seconds.
 - All the connected devices (if the device supports one-touch standby) automatically switch to standby.



Note

 Philips does not guarantee 100% interoperability with all HDMI CEC devices.

5 Play

Play a disc



Caution

- Do not place any objects other than discs into the disc compartment.
- Do not touch the disc optical lens inside the disc compartment.
- 1 Press ≜ to open the disc compartment.
- 2 Insert a disc with its label facing up.
- 3 Press ≜ to close the disc compartment and start disc play.



Note

- Check the types of discs supported (see "Your DVD player" > "Playable media").
- If the password entry menu is displayed, enter the password before you can play the locked or restricted disc (see "Adjust settings" > "Preferences" > [Parental Control]).

Play video



Note

 Some operations may not work with some discs. See the information accompanying the disc for details.

Control video play

- 1 Play a title.
- 2 Use the remote control to control the play.

Button	Action
►II	Start, pause or resume disc play.
	Stop disc play.
 	Skip to a previous/next title or chapter.
44 >>	Search fast-backward or fast- forward. Press repeatedly to change the search speed.
▲, ▼	Search slow-forward or slow- backward. Press repeatedly to change the search speed. For VCD/SVCD, slow-backward search is not available.
AUDIO/ CREATE MP3	Select an audio language or channel available on a disc.
SUBTITLE	Select a subtitle language available on a disc.
REPEAT/ REPEAT A-B	Select or turn off repeat mode. Repeat play for a specific section.
ED ZOOM (Screen fit)	Fit the picture format to the TV screen. Press repeatedly until the image is scaled to fit to the TV screen.
© ZOOM	Toggle between screen aspect ratio and different zoom factor. To pan through the zoomed image, press the Navigation buttons.
① INFO	Access the play options and display the current disc status.

Access DVD menu

- 1 Press DISC MENU to access the disc root
- 2 Select a play option, then press OK.
 - In some menus, press the Numeric buttons to input your selection.

Access VCD menu

The PBC (playback control) feature is available for VCD/SVCD, which can display the contents menu for you to select a play option. The PBC is on by default in the factory.



Note

- See "Adjust settings" > "Preferences" > [PBC] on how to turn PBC on or off.
- 1 Display the contents menu via one of the following ways:
 - If PBC is on, load in a VCD/SVCD.
 - During play with PBC on, press
 BACK.
- Press the Numeric buttons to select a play option, and then press OK to start play.
 - If PBC is turned off, it skips the menu display and starts play from the first track.

Preview disc contents

- 1 During play, press INFO.
 - → The disc status menu is displayed.
- 2 Select [Preview], and then press ▶.
- 3 Select a preview option, and then press **OK**.
 - → A thumbnails preview screen is displayed.
 - To go to the next/previous preview screen, select [Prev] or [Next], and then press OK.
 - To start play, press OK at the selected thumbnail picture.

Skip play to a specific time

- 1 During play, press I INFO.
 - → The disc status menu is displayed.
- 2 Select an option for the current elapsed playing time, and then press ▶.
 - [TT Time] (title time)
 - [CH Time] (chapter time)
 - [Disc Time]
 - [Track Time]
- 3 Press the Numeric buttons to enter the time to skip to, then press OK.

Display play time

- 1 During play, press INFO.
 - → The disc status menu is displayed.
- 2 Select [Time Disp.], and then press ▶.
 - → The display options vary from disc type.
 - Select an option, and then press **OK**.

View DVD play from different angles

- 1 During play, press I INFO.
 - → The disc status menu is displayed.
- 2 Select [Angle], and then press.
- 3 Press the Numeric buttons to change the angle.
 - → Play changes to the selected angle.



Vote

· Applicable only to discs that contain multi-angle scenes.

Repeat play for a specific section

- 1 During play, press REPEAT/REPEAT A-B at the start point.
- 2 Press REPEAT/REPEAT A-B again to set the end point.
 - → Repeat play starts.
- 3 To cancel repeat play, press REPEAT/REPEAT A-B again.



Note

 The marked section for repeat play is only possible within a track/title.

Play DivX® (Ultra) video

DivX® (Ultra) video is a digital media format that retains high quality despite a high rate of compression. You can enjoy DivX® (Ultra) video on this DivX (Ultra) certified product.

- 1 Insert a disc or USB flash drive that contains the DivX (Ultra) videos.
 - For USB, press
 - → A contents menu is displayed.
- 2 Select a title to play, then press **OK**.
 - You may select subtitle/audio language.



· You can only play DivX (Ultra) video that is rented or purchased with the DivX registration code of this product (see "Adjust Settings" > "General setup" > [DivX(R) VOD Code]).

Play music

Control a track

- Play a track.
- Use the remote control to control the play.

Button	Action
►II	Start, pause or resume disc play.
	Stop disc play.
 ⊲ , ▶	Skip to a previous/next track.
1 2 3 4 5 6 7 8 9	Select an item to play.
◄◄ , ▶▶	Searches fast-backward or fast-forward. Press repeatedly to change the search speed.
REPEAT/ REPEAT A-B	Select or turn off repeat mode. Repeat options may vary from disc type.

Quick skip play

During play, press in INFO repeatedly to select an option.

Display	Action
[Disc Go To]	Skip play to a specific time within the disc.
[Track Go To]	Skip play to a specific time within a track.
[Select Track]	Skip play to a specific track number.

Press the numeric buttons to change the time/ number to skip to.

Play MP3/WMA music

MP3/WMA is a type of highly compressed audio file (files with .mp3, .wma extensions).

- Insert a disc or USB flash drive that contains the MP3/WMA music.
 - For USB, press C.
 - → A contents menu is displayed.
- If play does not automatically start, select a track to play.
 - To select another track/folder, press ▲▼, then press OK.



Note

- · For disc recorded in multiple sessions, only the first session is played.
- · For a WMA file that is protected by Digital Rights Management (DRM), it cannot be played on this product.
- This product does not support MP3PRO audio format.
- · For any special character that is present in the MP3 track name (ID3) or album name, it might not be displayed correctly on the screen because these characters are not supported.
- · Folders/files that exceed the supported limit of this product cannot be displayed or played.

Play photo

Play photo as slideshow

You can play IPEG photos (files with .jpeg or .jpg extensions).

- Insert a disc or USB flash drive that contains the IPEG photos.
 - For USB, press .
 - → Slideshow begins (for Kodak disc), or a contents menu (for JPEG disc) is displayed.
- Select a photo, and then press OK to start slideshow.
 - → For a photo recorded with the "exif" format, the display orientation is automatically optimized.
- To display photos in color (fun mode) or in black and white (simple mode), press DISC MENU.
- To preview the photos in thumbnail, press INFO.
 - To select a photo, press the Navigation buttons.
 - To enlarge the selected photo and start slideshow, press OK.
 - To return to the menu, press **SACK**.

Note

- It may require longer time to display the disc content on the TV due to the large number of songs/photos compiled onto one disc/USB flash drive.
- If the JPEG photo is not recorded with an 'exif' type file, the actual thumbnail picture cannot be shown on the screen. It is replaced by a 'blue mountain' thumbnail picture.
- This product can only display digital camera pictures according to the JPEG-EXIF format, typically used by almost all digital cameras. It cannot display Motion JPEG, or pictures in formats other than JPEG, or sound clips associated with pictures.
- Folders/files that exceed the supported limit of this product cannot be displayed or played.

Control photo play

- 1 Play a photo slideshow.
- 2 Use the remote control to control the play.

Action
Rotate a photo anti-clockwise/clockwise.
Rotate a photo horizontally/ vertically.
Zoom in or out of a photo. Play pauses in zoom mode.
Stop a play.

Play musical slideshow

Create a musical slideshow to play MP3/WMA music files and JPEG photo files simultaneously.



lote

- To create a musical slideshow, you must store the MP3/ WMA and JPEG files on the same disc/USB flash drive.
- 1 Play MP3/WMA music.
- 2 Press SACK to return to the main menu.
- 3 Navigate to the photo folder/album and press OK to start slideshow play.
 - Slideshow begins and continues till the end of the photo folder or album.
 - → Audio continues to play until the end of the disc.
 - To stop slideshow play, press ■.
 - To stop music play, press again.

Play from a USB flash drive



Note


- This product plays/views MP3, WMA, WMV, DivX (Ultra) or JPEG files that are stored on a USB flash drive.
- 1 Connect a USB flash drive to the jack on this product.
- 2 Press the button.
 - → A contents menu is displayed.
- 3 If play does not start automatically, select a file to play.
 - For more information, see the chapters "Play music", "Play photo" and "Play video" for details.
- **4** To stop play, press ■.
 - To switch to the disc mode, press the
 ★ button.

6 Other features

Media copy

You can copy files (such as MP3, WMA or JPEG) from disc to a USB flash drive.

- Insert a disc that contains the MP3/WMA/ JPEG files.
- In the stop mode, connect the USB flash drive to the ••• jack on this product.
- 3 Select a file to copy, then press SUBTITLE.
- 4 Select [Yes] in the menu, then press OK.



- Once complete, a new folder is created automatically in the USB flash drive to store all the new files.
- To stop copy progress, press ■, then press OK.



- · When you copy, never press any button.
- Copy-protected media cannot be copied.

Create MP3 files

With this product, you can convert audio CDs into MP3 audio files. The created MP3 audio files are saved in the USB flash drive.

- Insert an audio CD.
- 2 Connect a USB flash drive to the * jack on this product.
- 3 During disc play, press AUDIO/CREATE MP3. → The MP3 creation menu is displayed.
- Select [Yes] in the menu, and then press OK.

Create MP3			
OPT	IONS	TRA	CK
Speed	Normal	O Track01	04:14
Bitrate	128kbps	O Track02	04:17
CRT ID3	Yes	O Track03	03:58
Device	USB 1	O Track04	04:51
SUMMARY		O Track05	03:53
Press [OK] button		O Track06	04:09
to change speed.		O Track07	04:38
Start	Exit	Select all	Deselect all

Select a conversion option in the **[OPTIONS]** panel, and then press OK repeatedly to select an item.

Option	Description
[Speed]	Select a copying speed.
[Bitrate]	Select a quality level. Higher bitrate for better sound quality and bigger file size.
[CRT ID3]	Copy track information into the MP3 file.
[Device]	The created files can only be saved in a USB flash drive.

- Press ▶ to access the [TRACK] panel.
- Select an audio track, and then press **OK**.
 - To select another track, repeat step 7.
 - To select all tracks, select [Select all] in the menu, and press OK.
 - To deselect all tracks, select [Deselect all] in the menu, and press OK.

- Select [Start] in the menu, and then press OK to start to convert.
 - → Once complete, a new folder is created automatically in the USB flash drive to store all the new MP3 files.
 - To exit the menu, select [Exit], and then press OK.



Note

- When you convert, never press any button.
 - DTS CDs and copy-protected CDs cannot be converted.
 - Writer-protected or password-protected USB flash drives cannot be used to store MP3 files.

Adjust settings



Note

· If the setup option is grayed out, it means the setting cannot be changed at the current state.

General setup

General Setup	
Disc Lock OSD Language Sleep Timer Auto Standby DivX(R) VOD Code	

- Press SETUP.
 - → [General Setup] menu is displayed.
 - Press ▶ to enter the submenu.
- Select an option, and then press **OK**.
 - Select a setting, and then press OK.
 - To return to the previous menu, press
 - To exit the menu, press SETUP.

[Disc Lock]

Set the play restriction for a disc which is loaded in the disc compartment (maximum 20 discs can be locked).

[Lock] - Restrict the access to the current disc. At the next time when you want to play this disc or unlock it, you need to enter the password.

• [Unlock] - Play all discs.

[OSD Language]

Select a language for on-screen menu.

[Sleep Timer]

Switch automatically to standby at the preset time.

- [Off] Disable sleep mode.
- [15 Mins], [30 Mins], [45 Mins], [60 Mins] Select the countdown time for this product to
 switch to standby.

[Auto Standby]

Turn on/off the auto standby mode.

- [On] Switch to standby after 15 minutes of inactivity (for example, in pause or stop mode).
- [Off] Disable the auto standby mode.

[DivX(R) VOD Code]

Display the DivX® registration code and deregistration code.

- [Registration] Obtain a registration code to register this product on website.
- [Deregistration] Obtain a deregistration code to cancel the registration of this product on website.



Note

 Use this product's DivX registration code when you rent or purchase video from www.divx.com/vod. The DivX videos rented or purchased through the DivX® VOD (Video On Demand) service can be played only on the device to which it is registered.

Audio setup

	Audio Setup	
*	Analogue Output	
₩	Digital Audio	
-4	HDMI Audio	
-4	Audio Sync	
	Volume	
	Sound Mode	
\\\	Speaker Setup	
ا ت	CD Upsampling	

- 1 Press SETUP.
 - → [General Setup] menu is displayed.
- Press ▼ to select [Audio Setup], and then press ► to enter the submenu.
- 3 Select an option, and then press **OK**.
- 4 Select a setting, and then press **OK**.
 - To return to the previous menu, press

 → BACK.
 - To exit the menu, press SETUP.

[Analogue Output]

Select an analogue setting based on the audio device that is connected through the analogue audio jack.

- **[LT/RT]** For the surround sound output through two speakers.
- [Stereo] For the stereo output.
- [Multi Channel] For multi-channel output.

[Digital Audio]

Select a digital setting based on the digital amplifier/ receiver that is connected through the digital jack (coaxial/digital).

- [Digital Output] Select a type of digital output.
 - [AII] Support multi-channel audio formats.
 - [Off] Disable digital output.
 - [PCM Only] Downmix to two-channel audio format.
 - [LPCM Output] Select the LPCM (Linear Pulse Code Modulation) output sampling rate.
 - [48kHZ] For discs recorded at sampling rate of 48 kHz.
 - [96kHZ] For discs recorded at sampling rate of 96 kHz.



Note

- [LPCM Output] setting is only available if the [Digital Output] is set to [PCM Only].
- The higher the sampling rate, the better the sound quality.

[HDMI Audio]

Select the HDMI audio setting when you connect this product and the TV with an HDMI cable.

- [On] Allow audio output through the TV and the speaker system. If the audio format on the disc is not supported, it will be downmixed to two-channel sound (linear-PCM).
- [Off] Disable the audio output from HDMI devices connected to this player.

[Audio Sync]

Set the delay time for audio output when you play a video disc.

- 1. Press OK.
- 2. Press ◆▶ to set the delay time.
- 3. Press **OK** to confirm and exit.

[Volume]

Set the default volume level when you play a disc.

- 1. Press OK.
- 2. Press ◆▶ to set the volume.
- 3. Press OK to confirm and exit.

[Sound Mode]

Select a preset sound effect to enhance the audio output.

- [3D] Select a virtual surround sound effect that is produced from the left and right audio channels.
- [Movie Mode] Select a sound effect for movies.
- [Music Mode] Select a sound effect for music.

[Speaker Setup]

Optimize the surround output for the connected speakers.

[CD Upsampling]

For better sound quality in stereo mode, convert the music CD to a higher sampling rate.

- [Off] Turn off CD-upsampling.
- [88.2kHz] Convert to twice the original sampling rate.
- [176.4kHz] Convert to four times the original sampling rate.

[Night Mode]

Make loud sound level softer and soft sound level louder so that you can watch the DVD movies at a low volume, without disturbing others.

- [On] Enjoy quiet viewing at night.
- [Off] Enjoy surround sound with a full dynamic range.



Note

Applicable only to Dolby Digital encoded DVDs.

Video setup

	Video Setup
-	TV System
*	TV Display
-1	Progressive
	Picture Setting
	My Wallpaper
\cup	HD JPEG
17/	HDMI Setup

- Press SETUP.
 - → [General Setup] menu is displayed.

- Press ▼ to select [Video Setup], and then press > to enter the submenu.
- 3 Select an option, and then press **OK**.
- Select a setting, and then press OK.
 - To return to the previous menu, press **⇒** BACK.
 - To exit the menu, press SETUP.

[TV System]

Change this setting if the video does not appear correctly. By default, this setting matches the most common setting for TVs in your country.

- [PAL] For a PAL-system TV.
- [Multi] For TV that is compatible with both PAL and NTSC.
- [NTSC] For an NTSC-system TV.

[TV Display]

Select a display format:







4:3 Pan Scan (PS)

4:3 Letter Box (LB)

16:9 (Wide Screen)

- [4:3 Pan Scan] For a 4:3 screen TV: full-height display with the trimmed sides.
- [4:3 Letter Box] For a 4:3 screen TV: widescreen display with black bars on the top and bottom of the screen.
- [16:9] For a wide-screen TV: display ratio 16:9.

[Progressive]

If a progressive scan TV is connected to this product, turn on the progressive scan mode.

- [On] Turn on progressive scan.
- [Off] Turn off progressive scan mode.



Note

 For more detailed description, see "Get started" > "Turn on progressive scan".

[Picture Setting]

Select a predefined set of picture color settings or customize the personal setting.

- [Standard] Original color setting.
- [Bright] Vibrant color setting.
- [Soft] Warm color setting.
- [Personal] Customize the color setting. Set the level of brightness, contrast, tint and color saturation, then press OK.

[My Wallpaper]

Select a picture as the wallpaper.

[Default picture] - The default wallpaper preset as the Philips logo.

- **[Saved picture]** A captured video image or JPEG photo.
- [Current picture] Capture a video image or JPEG photo and save it on the product.
- 1. Play a video or photo slideshow.
- 2. Select a video image or photo: press ▶ to pause, and then press SETUP.
- Navigate to the option ([Video Setup] > [My Wallpaper] > [Current picture]).
- 4. Press **OK** to confirm.
 - → One video image or JPEG photo is saved as wallpaper.
 - → A newly saved image or photo replaces the earlier one.

[HD JPEG]

Enjoy untouched and uncompressed JPEG pictures at its original resolution when you connect this product and the TV with an HDMI cable.

- [On] Display high definition picture.
- [Off] Display standard picture.

[HDMI Setup]

When you connect this proudct and the TV with an HDMI cable, select the best HDMI setup that the TV can support.

- [Resolution] Select a video resolution that is compatible with the TV display capability.
 - [Auto] Detect and select the best supported video resolution automatically.
 - [480i],[480p], [576i], [576p],[720p],
 [1080i], [1080p] Select a video
 resolution that is best supported by the
 TV. See the TV manual for details.
- [Wide Screen Format] Define the wide screen format for disc play.
 - [Super Wide] Center position of the screen is stretched less than the side (applicable only when the video resolution is set to 720p, 1080i or 1080p).
 - [4:3 Pillar Box] No stretching of picture. Black bars are displayed on both sides of the screen (applicable only when the video resolution is set to 720p, 1080i or 1080p).
 - [Off] Picture is displayed according to the disc format.
- [EasyLink Setup] If this product is connected to HDMI CEC compliant TV/devices, all connected devices can respond to the following commands simultaneously.
 - [EasyLink] Turn on/off all EasyLink features.

- [One Touch Play] Turn on or off the feature of one-touch play.
 - When EasyLink is enabled, press \circ .
 - → This product turns on.
 - → The TV (if the TV supports one-touch play) automatically turns on and switches to the video-in channel.
 - → Disc play starts if there is a disc in this product.
- [One Touch Standby] Turn on or off the feature of one-touch standby.

When EasyLink is enabled, press and hold \odot for at least three seconds.

→ All connected HDMI CEC compliant devices switch to standby mode.



Note

- You must turn on the HDMI CEC operations on the TV/ devices before you can enjoy the EasyLink controls. See the TV/devices manual for details.
- Philips does not guarantee 100% interoperability with all HDMI CEC compliant devices.

Preferences



Note

· Stop disc play before you can access to [Preferences].

	Preferences	
4	Audio	
*	Subtitle	
-1	Disc Menu	
-4	Parental Control	
$\overline{}$	PBC	
<u> </u>	Mp3/Jpeg Nav	
√	Password	
	DivX Subtitle	

- 1 Press SETUP.
 - → [General Setup] menu is displayed.
- 2 Press ▼ to select [Preferences], and then press ▶ to enter the submenu.
- 3 Select an option, and then press **OK**.
- 4 Select a setting, and then press OK.
 - To return to the previous menu, press
 BACK.
 - To exit the menu, press **SETUP**.

[Audio]

Select an audio language for disc play.

[Subtitle]

Select a subtitle language for disc play.

[Disc Menu]

Select a disc menu language.



Note

- · If the language you have set is not available on the disc, the disc uses its own default language.
- For some DVDs, the subtitle/audio language can only change from the disc menu.
- · To select the languages that are not listed in the menu, select [Others]. Then check the Language Code list at the back of this user manual and enter the respective language code.

[Parental Control]

Restrict access to discs that are unsuitable for children. These types of discs must be recorded with ratings.

- 1 Press OK
- 2. Select a rating level, then press OK.
- 3. Press the numeric buttons to enter the password.



Note

- Rated DVDs above the level you set in [Parental Control] require a password to be played.
- · The ratings are country-dependent. To allow all discs to play, select '8'.
- Some discs have ratings printed on them but are not recorded with ratings. This function has no effect on such discs.

[PBC]

Turn on or off the content menu of VCDs/SVCDs with PBC (playback control) feature.

- [On] Display the index menu when you load a disc for play.
- [Off] Skip the menu and start play from the first track.


[Mp3/|peg Nav]

Select to display the folders or display all the files.

- [View Files] Display all the files.
- [View Folders] Display the folders of MP3/ WMA files.

[Password]

Set or change the password for locked discs and play restricted DVDs.



- 1. Press the Numeric buttons to enter '136900' or the last set password at [Old Password] field.
- 2. Enter the new password at [New Password] field.
- 3. Enter the new password again at [Confirm PWD] field.
- 4. Press OK to exit the menu.



Note

· If you forget the password, enter '136900' before you set a new password.

[DivX Subtitle]

Select a character set that supports the DivX subtitle.

[Standard] - English, Irish, Danish, Estonian, Finnish, French, German, Italian, Portuguese, Luxembourgish, Norwegian (Bokmål and Nynorsk), Spanish, Swedish, Turkish



Note

Ensure that the subtitle file has the exact same file name as the movie file. If for example the file name of the movie is 'Movie.avi', then you need to name the text file 'Movie.sub' or 'Movie.srt'.

[Version Info]

Display the software version of this product.



Note

This information is required when you want to find out if a newest software version is available at the Philips website that you may download and install on this product.

[Default]

Reset all the settings of this product to factory default, except for [Disc Lock], [Parental Control] and [Password] settings.

8 Additional information

Update software

For software updates, check the current software version of this product to compare with the latest software (if available) at the Philips website.



Caution

- Power supply must not be interrupted during software upgrade.
- 1 Press SETUP.
- 2 Select [Preferences] > [Version Info], and then press OK.
- Write down the file name, and then press SETUP to exit the menu.
- 4 Visit www.philips.com/support to check for the latest software version, using the file name for this product.
- 5 Refer to the upgrade instructions on the website for more information.



Note

 Disconnect the power cord for a few seconds and connect again to turn on the product.

Care



Caution

 Never use solvents such as benzene, thinner, cleaners available commercially, or anti-static sprays intended for discs.

Clean discs

Wipe the disc with a micro fibre cleaning cloth from the centre to the edge in a straight line movement.

Specifications



Note

· Specification and design are subject to change without notice

USB

- Compatibility: Hi-Speed USB (2.0)
- Class support: UMS (USB Mass Storage Class)
 Video
- Signal system: PAL / NTSC
- Composite video output: 1 Vpp ~ 75 ohm
- Component video output: 0.7 Vpp ~ 75 ohm

 HDMI output: 480i, 480p, 576i, 576p, 720p, 1080i, 1080p

Audio

- Analog stereo output
- Signal to noise ratio (1 kHz): > 90 dB (A-weighted)
- Dynamic Range (1 kHz): > 80 dB (A-weighted)
- Crosstalk (1 kHz): > 90 dB
- Distortion/noise: (1 kHz): > 75 dB
- MPEG MP3: MPEG Audio L3
- Digital output
 - Coaxial
- HDMI output

Main unit

- Dimensions (w x h x d): $360 \times 39 \times 209$ (mm)
- Net Weight: approximately 1.48 kg

Davisan

- Power supply rating: 110 240V, 50/60HZ
- Power consumption: < 10 W
- Power consumption in standby mode: < 0.1 W

Accessories supplied

- · Remote control and batteries
- HDMI cable
- Audio/Video cables
- User Manual
- Ouick Start Guide

Laser specification

- Type: Semiconductor laser InGaAIP (DVD), AIGaAs (CD)
- Wave length: 655 nm (DVD), 790 nm (CD)
- Output Power: 7.0 mW (DVD), 10.0 mW (VCD/CD)
- Beam divergence: 60 degrees

9 Troubleshooting



Warning

 Risk of electric shock. Never remove the casing of the product.

To keep the warranty valid, never try to repair the product yourself.

If you have problems using this product, check the following points before you request service. If you still have a problem, register your product and get support at www.philips.com/welcome.

If you contact Philips, you will be asked for the model and serial number of your product. The model number and serial number are on the back of your product. Write the numbers here:

10del No	 	 	
Serial No.			

Main unit

The buttons on this unit do not work.

 Disconnect this product from the power outlet for a few minutes, then connect again.

No reaction to the remote control.

- Connect this product to the power outlet.
- Point the remote control at the IR sensor located on the front panel of this product.
- · Insert the batteries correctly.
- Insert new batteries in the remote control.

Picture

No picture.

- See the TVs user manual on how to select the correct input on the TV. Change the TV channel until you see the Philips screen.
- If you have turned on the progressive scan setting or change the TV system setting, switch back to default mode: 1) Press ≜ to open the disc compartment. 2) Press the Numeric button '1' (for progressive scan) or the Numeric button'3' (for TV system).

No picture on HDMI connection.

- If this product is connected to an unauthorized display device with an HDMI cable, the audio/ video signal may not be output.
- Check if the HDMI cable is faulty. Replace a new HDMI cable.
- If this happens when you change the HDMI video resolution, you have to switch to its default mode: 1) Press ≜ to open the disc compartment. 2) Press the numeric button "1".

Sound

No audio output from the TV.

- Ensure that the audio cables are connected to the audio input of the TV.
- Assign the audio input of the TV to the corresponding video input. See the TV user manual for details.

No audio output from the loudspeakers of the audio device (stereo system/amplifier/receiver).

- Ensure that the audio cables are connected to the audio input of the audio device.
- Turn on the audio device to its correct audio input source.

No sound on HDMI connection.

- You may not hear any sound from the HDMI output if the connected device is non-HDCP compliant or only DVI-compatible.
- Ensure that the [HDMI Audio] setting is turned on.

No sound during DivX video playback

The audio codec may not be supported by this product.

Play

The disc cannot be played.

- The disc is badly scratched, deformed, or dirty.
 Replace or clean the disc.
- Use the correct disc format or file format.

DivX video files cannot be played.

- Ensure that the DivX video file is complete.
- Ensure that the file name extension is correct.
- Due to Digital Rights issue, the DRMprotected video files cannot be played through an analog video connection (e.g. composite, component and scart). Use an HDMI connection to play these files.

The aspect ratio of the screen is not aligned with the TV display setting.

• The aspect ratio is fixed on the disc.

DivX subtitles are not displayed correctly.

- Ensure that the subtitle file name is the same as the movie file name.
- Select the correct character set.
 - Press SETUP.
 - Select [Preferences] > [DivX Subtitle] in the menu.
 - Select the character set that supports the subtitle.

10 Glossary

Α

Aspect ratio

Aspect ratio refers to the length to height ratio of TV screens. The ratio of a standard TV is 4:3, while the ratio of a high-definition or wide TV is 16:9. The letter box allows you to enjoy a picture with a wider perspective on a standard 4:3 screen.



DivX Video-On-Demand

This DivX Certified ® device must be registered in order to play DivX Video-on-Demand (VOD) content. To generate the registration code, locate the DivX VOD section in your device setup menu. Go to vod.divx.com with this code to complete the registration process and learn more about DivX video.

Н

HDMI

High-Definition Multimedia Interface is a high-speed digital interface that can transmit uncompressed high definition video and digital multichannel audio. It delivers high quality picture and sound quality, completely free from noise. HDMI is fully backward-compatible with DVI.

As required by the HDMI standard, connecting to HDMI or DVI products without HDCP (Highbandwidth Digital Content Protection) will result in no Video or Audio output.



JPEG

A very common digital still picture format. A still-picture data compression system proposed by the Joint Photographic Expert Group, which features small decrease in image quality in spite of its high compression ratio. Files are recognized by their file extension '.jpg' or '.jpeg.'



MP3

A file format with a sound data compression system. MP3 is the abbreviation of Motion Picture Experts Group 1 (or MPEG-1) Audio Layer 3. With the MP3 format, one CD-R or CD-RW can contain about 10 times more data than a regular CD.



PBC

Playback Control. A system where you navigate through a Video CD/Super VCD with on-screen menus that are recorded onto the disc. You can enjoy interactive playback and search.

Progressive scan

The progressive scan displays twice the number of frames per second than in an ordinary TV system. It offers higher picture resolution and quality.



WMA

Windows Media™ Audio. Refers to an audio compression technology developed by Microsoft Corporation. WMA data can be encoded with Windows Media player version 9 or Windows Media player for Windows XP. Files are recognized by their file extension '.wma.'

WMV [Windows Media Video]

Refers to a video compression technology developed by Microsoft Corporation. WMV content can be encoded by using Windows Media[®] Encoder 9 series. Files are recognised by their file extension 'wmv'.

W	/Λ	D	D	Λ	N	т	V

This APPARATUS IS covered under warranty against any defect arising out of faulty or defective material or workmanship for a period of 6 months from date of purchase.

Should a defect develop during the period of warranty, Philips Electronics India Limited undertakes to repair the apparatus free of charge through an Authorised Philips service Center. If the purchaser shifts his residence to other town, the warranty will be valid at the nearest Authorised Philips service Center.

This warranty is not valid in case:

- 1. The apparatus is not used according to this manual;
- 2. Defects are caused by improper or reckless use;
- 3. Any repair work are done by person other than Authorised Philips Service Center;
- 4. Any modification or alteration of any nature are made in the apparatus;
- 5. The serial number is tampered
- 6. This warranty form is not completed immediately after purchase.

Maintenance Tips for your DVD Player:

- Always keep a Disc loaded in your DVD Player tray.
- Keep the player away from the dusty areas. Keep it covered with a dust cover.
- Clean your DVD Player Lens after every 20 discs played.
 Use the 2 brush Philips DVD Lens Cleaner SVC2520 for best results.
- Clean the CDs / VCD / DVD / MP3 CD before inserting in your DVD Player.

"For unlimited listening pleasure use Philips earphones / headphones". Over 20 models to choose from

Philips Electronics India Limited

For any sales or service related queries:

Visit us on web at www.philips.com/support or


Call us on Tel. No.: 1860-180-1111 (BSNL / MTNL)* 011-6600-1111 (GSM / WLL)*

* "standard call rates apply"

Language Code

Abkhazian	6566	Inupiaq	7375	Pushto	8083
Afar	6565	ļrish ,	7165	Russian	8285
Afrikaans	6570	Íslenska	7383	Quechua	8185
Amharic	6577	Italiano	7384	Raeto-Romance	8277
Arabic	6582	lvrit	7269	Romanian	8279
Armenian	7289	Japanese	7465	Rundi	8278
Assamese	6583	Javanese	7486	Samoan	8377
Avestan	6569	Kalaallisut	7576	Sango	8371
Aymara	6589	Kannada	7578	Sanskrit	8365
Azerhaijani	6590	Kashmiri	7583	Sardinian	8367
Bahasa Melayu	7783	Kazakh	7575	Serbian	8382
Bashkir	6665	Kernewek	7587	Shona	8378
Belarusian	6669	Khmer	7577	Shqip	8381
Bengali	6678	Kinyarwanda	8287	Sindhi	8368
Bihari	6672	Kirghiz	7589	Sinhalese	8373
Bislama	6673	Komi	7586	Slovensky	8373
Bokmål, Norwegian	7866	Korean	7579	Slovenian	8376
Bosanski	6683	Kuanyama; Kwanyama	7574	Somali	8379
Brezhoneg	6682	Kurdish	7585	Sotho; Southern	8384
Bulgarian	6671	Lao	7679	South Ndebele	7882
Burmese	7789	Latina	7665	Sundanese	8385
Castellano, Español	6983	Latvian	7686	Suomi	7073
Catalán	6765	Letzeburgesch;	7666	Swahili	8387
Chamorro	6772	Limburgan; Limburger	7673	Swati	8383
Chechen	6769	Lingala	7678	Svenska	8386
Chewa; Chichewa; Nyanja		Lithuanian	7684	Tagalog	8476
中文	9072	Luxembourgish;	7666	Tahitian	8489
Chuang; Zhuang	9065	Macedonian	7775	Tajik	8471
Church Slavic; Slavonic	6785	Malagasy	7771	Tamil	8465
Chuvash	6786	Magyar	7285	Tatar	8484
Corsican	6779	Malayalam	7776	Telugu	8469
Česky	6783	Maltese	7784	Thai	8472
Dansk	6865	Manx	7186	Tibetan	6679
Deutsch	6869	Maori	7773	Tigrinya	8473
Dzongkha	6890	Marathi	7782	Tonga (Tonga Islands)	8479
English	6978	Marshallese	7772	Tsonga (Tonga Islands)	8483
Esperanto	6979	Moldavian	7779	Tswana	8478
Estonian	6984	Mongolian	7778	Türkce	8482
Euskara	6985	Nauru	7865	Turkmen	8475
Ελληνικά	6976	Navaho; Navajo	7886	Twi	8487
Faroese	7079	Ndebele, North	7868	Uighur	8571
Français	7077	Ndebele, South	7882	Ukrainian	8575
Frysk	7082	Ndonga	7871	Urdu	8582
Fijian	7074	Nederlands	7876	Uzbek	8590
Gaelic; Scottish Gaelic	7168	Nepali	7869	Vietnamese	8673
Gaelic; Scottish Gaelic Gallegan	7176	Norsk	7879	Voladuk	8679
	7565	Northern Sami	8369	Walloon	8765
Georgian Gikuyu; Kikuyu	7565 7573	Northern Sami North Ndebele	7868	Welsh	6789
	7178		7878	Wolof	8779
Guarani	7178 7185	Norwegian Nynorsk;	7878 7967	VVOIOT Xhosa	
Gujarati		Occitan; Provencal			8872
Hausa	7265	Old Bulgarian; Old Slavonic	6785	Yiddish	8973
Herero	7290	Oriya	7982	Yoruba	8979
Hindi	7273	Oromo	7977	Zulu	9085
Hiri Motu	7279	Ossetian; Ossetic	7983		
Hrwatski	6779	Pali	8073		
Ido	7379	Panjabi	8065		
Interlingua (Internationa		Persian	7065		
Interlingue	7365	Polski	8076		
Inuktitut	7385	Português	8084		







@ 2010 Koninklijke Philips Electronics N.V. All rights reserved. $\label{eq:DVP3588_94_UM_V3.0_1025}$