

PHILIPS

D141
D146

Philips cordless phone

Philips cordless
phone with answering
machine



Extended user documentation

Register your product and get support at
www.philips.com/support

Contents

1	Important safety instructions	3
2	Your phone	4
	What is in the box	4
	Overview of the phone	5
	Overview of the base station	6
3	Get started	7
	Connect the base station	7
	Switch on the handset	8
	Configure your phone (country dependent)	8
	Change the remote access PIN code (for D146)	9
	Charge the handset	9
	Check the battery level	9
	What is standby mode?	9
	Display icons	10
	Check the signal strength	10
4	Calls	12
	Make a call	12
	Answer a call	12
	End a call	12
	Adjust the earpiece/speaker volume	13
	Mute the microphone	13
	Turn the speaker on or off	13
	Make a second call	13
	Answer a second call	13
	Switch between two calls	13
	Make a conference call with the external callers	13
5	Intercom and conference calls	14
	Make a call to another handset	14
	Make a conference call	14
6	Text and numbers	16
	Enter text and numbers	16
7	Phonebook	17
	View the phonebook	17
	Search a record	17
	Call from the phonebook	17
	Add a record	17
	Edit a record	18
	Delete a record	18
	Delete all records	18
8	Call log	19
	View the call records	19
	Save a call record to the phonebook	19
	Return a call	19
	Delete a call record	20
	Delete all call records	20
9	Redial list	21
	View the redial records	21
	Redial a call	21
	Save a call record to the phonebook	21
	Delete a redial record	21
	Delete all redial records	21
10	Phone settings	22
	Sound settings	22
	Name the handset	22
	Set the date and time	23
	Set the display language	23
11	Telephone answering machine	24
	Turn the answering machine on or off	24
	Set the answering machine language	24
	Announcements	24
	Incoming messages	25
	Set the ring delay	26
	Remote access	26

12 Services	29
Auto conference	29
Auto prefix	29
Network type	30
Select the recall duration	30
Dial mode	30
Auto clock	30
Register the handset or additional handsets	31
Unregister the handsets	31
Restore default settings	32

13 Technical data	33
--------------------------	-----------

14 Notice	34
Declaration of conformity	34
Use GAP standard compliance	34
Compliance with EMF	34
Disposal of your old product and battery	34

15 Frequently asked questions	36
--------------------------------------	-----------

16 Appendix	39
Text and number input tables	39

1 Important safety instructions

Power requirements

- This product requires an electrical supply of 100–240 volts AC. In case of power failure, the communication can be lost.
- The voltage on the network is classified as TNV-3 (Telecommunication Network Voltages), as defined in the standard EN 60950.



Warning

- The Electrical network is classified as hazardous. The only way to power down the charger is to unplug the power supply from the electrical outlet. Ensure that the electrical outlet is always easily accessible.

To avoid damage or malfunction



Caution

- Use only the power supply listed in the user instructions.
- Dispose of used batteries according to the instructions.
- The integrated battery shall not be exposed to excessive heat such as sunshine, fire or the like.
- Always use the cables provided with the product.
- Do not allow the charging contacts or the battery to come into contact with metal objects.
- Do not let small metal objects come into contact with the product. This can deteriorate audio quality and damage the product.

- Metallic objects may be retained if placed near or on the handset receiver.
- Do not use the product in places where there are explosive hazards.
- Do not open the handset, base station or charger as you could be exposed to high voltages.
- For pluggable equipment, the socket-outlet shall be installed near the equipment and shall be easily accessible.
- Handsfree activation could suddenly increase the volume in the earpiece to a very high level: make sure the handset is not too close to your ear.
- This equipment is not designed to make emergency calls when the power fails. An alternative has to be made available to allow emergency calls.
- Do not allow the product to come into contact with liquids.
- Do not use any cleaning agents containing alcohol, ammonia, benzene, or abrasives as these may harm the set.
- Do not expose the phone to excessive heat caused by heating equipment or direct sunlight.
- Do not drop your phone or allow objects to fall on your phone.
- Active mobile phones in the vicinity may cause interference.

About operating and storage temperatures

- Operate in a place where temperature is always between 0°C to +40°C (up to 90% relative humidity).
- Store in a place where temperature is always between -20°C and +45°C (up to 95% relative humidity).
- Battery life may be shorter in low temperature conditions.

2 Your phone

Congratulations on your purchase and welcome to Philips!

To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

What is in the box



Handset**



Base station (D141)



Base station (D146)



Charger**



Power adapter**



Line cord*



Guarantee




Short user manual



Note

- * In some countries, you have to connect the line adapter to the line cord, then plug the line cord to the telephone socket.
- ** In multi-handset packs, there are additional handsets, chargers and power adapters.

Overview of the phone



① Earpiece

② ▲

- Scroll up on the menu.
- Increase the earpiece/speaker volume.
- Access the phonebook in standby mode.

③ REDIAL/C

- Delete text or digits.
- Cancel operation.
- Access the redial list.

④ ☎

- End the call.
- Exit the menu/operation.
- Press and hold to switch the handset on or off (only when the power switch is on).

⑤ ▼

- Scroll down on the menu.
- Decrease the earpiece/speaker volume.
- Access the call log in standby mode.

⑥ 0

- Press to enter a space during text editing.
- Press and hold to lock/unlock the keypad in standby mode.

⑦ #

- Press and hold to enter a pause.

⑧ (for D141) or / (for D146)

- Mute or unmute the microphone.
- Access to the answer machine menu in standby mode (for D146 only).
- Listen to new messages from the answering machine (for D146 only).

⑨ Power switch

⑩ Microphone

⑪ 🔊

- Turn the speaker phone on/off.
- Make and receive calls through the speaker.

⑫ *INT

- Set the dial mode (pulse mode or temporary tone mode). This function is country dependent.
- Press and hold to switch between the intercom call and external call.
- Press and hold to make an intercom call (for multi-handset version only).

⑬ R

- Make and receive calls.
- Recall key.

⑭ MENU/OK


- Access the main menu.
- Confirm selection.
- Enter the options menu.
- Select the function displayed on the handset screen directly above the key.

⑮ Loudspeaker

① •)

- Press to find handsets.
- Press and hold to enter the registration mode.

D146




① •)

- Press to find handsets.
- Press and hold to enter the registration mode.

Overview of the base station

D141



3 Get started



Caution

- Make sure that you have read the safety instructions in the 'Important safety instructions' section before you connect and install your handset.

Connect the base station



Warning


- Risk of product damage! Ensure that the power supply voltage corresponds to the voltage printed on the back or the underside of the phone.
- Use only the supplied power adapter to charge the batteries.



Note

- If you subscribe to the digital subscriber line (DSL) high speed internet service through your telephone line, ensure you install a DSL filter between the telephone line cord and the power socket. The filter prevents noise and caller ID problems caused by the DSL interference. For more information on the DSL filters, contact your DSL service provider.
- The type plate is located on the bottom of the base station.

- 1 Connect each end of the power adapter to:
 - the micro USB socket at the bottom of the base station;
 - the power socket on the wall.
- 2 Connect each end of the line cord to:
 - the telephone socket at the bottom of the base station;
 - the telephone socket on the wall.




- 3 Connect each end of the power adapter to (for multi-handset version only):
 - the micro USB socket at the bottom of the extra handset charger.
 - the power socket on the wall.


The base station is equipped with a micro-USB socket. It allows connection to a power bank as an alternative source of power during AC power outage.

Note

- For the minimum requirement of the power bank, see the chapter "Technical Data".
- While using a power bank as an alternative power source, it may drain very soon if you charge the handset at the same time.



Switch on the handset



Note

- The batteries will not charge if the handset switch is not turned on.

Configure your phone (country dependent)

- 1 When using your phone for the first time, you see a welcome message.
- 2 Press MENU/OK.

Set the country/language

Select your country/language, then press MENU/OK to confirm.

- ↳ The country/language setting is saved.



Note

- The country/language setting option is country dependent. If no welcome message is displayed, it means the country/language setting is preset for your country.

To re-set the language, see the following steps.

- 1 Select MENU/OK > [PHONE SETUP] > [LANGUAGE], then press MENU/OK to confirm.
- 2 Select a language, then press MENU/OK to confirm.
 - ↳ The setting is saved.



Set the date and time

- 1 Press MENU/OK.
- 2 Select [PHONE SETUP] > [DATE/TIME], then press MENU/OK to confirm.
- 3 Press the numeric buttons to enter the date, then press MENU/OK to confirm.
 - ↳ The time setting menu is displayed on the handset.
- 4 Press the numeric buttons to enter the time.
 - If the time is in 12-hour format, press  ▲ /  ▼ to select [AM] or [PM].
- 5 Press MENU/OK to confirm.

Change the remote access PIN code (for D146)

Note

- The default answering machine remote access PIN code is 0000 and it is important to change it to ensure the security.

- 1 Press  /  or MENU/OK > [ANSW MACHINE] > MENU/OK.
- 2 Select [REMOTE ACC.] > [CHANGE PIN], then press MENU/OK to confirm.
- 3 Enter the old PIN/passcode, then press MENU/OK to confirm.
- 4 Enter the new PIN/passcode, then press MENU/OK to confirm.
- 5 Enter the new PIN/passcode again, then press MENU/OK to confirm.
 - ↳ The setting is saved.

Charge the handset

Place the handset on the base station or the charging cradle to charge the handset. When the handset is placed correctly on the base station, you hear a docking sound.

- ↳ The handset starts charging.


Note

- Charge the batteries for 8 hours before first use.
- If the handset becomes warm when the batteries are being charged, it is normal.





You can activate or deactivate the docking tone.

Your phone is now ready to use.

Check the battery level



The battery icon displays the current battery level.

	When the handset is off the
	base station/charger, the
	bars indicate the battery
	level (full, medium and
	low).
	When the handset is on the
	base station/charger, the
	bars flash until charging is
	complete.
	The empty battery icon
	flashes. The battery is low
	and needs recharging.

The handset turns off if the batteries are empty. If you are on the phone, you hear warning tones when the batteries are almost empty. The call gets disconnected after the warning.

What is standby mode?

Your phone is in standby mode when it is idle. The handset name (or date and time) is displayed on the standby screen.

















Tip

- Press and hold MENU/OK to switch between the handset name and date and time display.

Display icons

In standby mode, the icons shown on the main screen tell you what features are available on your handset.

Icon	Descriptions
	When the handset is off the
	base station/charger, the bars
	indicate the battery level (from
	full to low).
	When the handset is on the
	base station/charger, the bars
	keep scrolling until charging is
	complete.
	The empty battery icon flashes
	and you hear an alert tone.
	The battery is low and needs
	recharging.
	It displays the connection
	status between the handset
	and base station. The more
	bars are shown, the better the
	signal strength is.
	It remains steadily on when
	browsing incoming calls in the
	call log.
	It indicates an outgoing call in
	the redial list.
	It flashes when there is a new
	missed call or when browsing
	new missed calls.
	It remains steadily on when
	browsing the missed calls in call
	log that are already read.
	It flashes when receiving
	incoming call.
	It remains steadily on during a
	call.
	The speaker is on.
	The ringer is off.
	Answering machine (D146 only):
	it flashes when there is a new
	message or when the memory
	is full. It is displayed when the
	telephone answering machine
	is turned on.

✉ It flashes when there is a new voice message.
It flashes when there is a new voice message.
It remains steadily on when the voice messages are already viewed in the call log.
The icon is not shown when there is no voice message.

▲ / ▼ It is displayed when you scroll up/down a list/increase and decrease the volume.

▶ There are more digits on the right. Press REDIAL/C to read.

Check the signal strength

■ ■ ■ ■ ■ The number of bars indicates the connection status between the handset and base station. The more bars are shown, the better the connection is.

- Make sure the handset is connected to the base station before you make or receive calls and carry out the phone functions and features.
- If you hear warning tones when you are on the phone, the handset is almost out of battery or the handset is out of range. Charge the battery or move the handset close to the base station.

4 Calls

Note

- When the power fails, the phone cannot access emergency services.


Tip

- Check the signal strength before you make a call or when you are in a call (see 'Check the signal strength' on page 11).

Note

- The talk time of your current call is displayed on the call timer.
- If you hear warning tones, the phone is almost out of battery or out of range. Charge the battery or move the phone close to the base station.

Answer a call

When there is an incoming call, press  to answer the call.

Warning

- When the handset rings or when the handsfree is activated, keep the handset away from your ear to avoid ear damage.

Note

- The caller ID service is available if you have registered to the caller ID service with your service provider.

Tip

- When there is a missed call, a notification message appears.


Make a call

You can make a call in these ways:


- Normal call.
- Predial call.

You can also make a call from the redial list (see 'Redial a call' on page 21), phonebook list (see 'Call from the phonebook' on page 17) and call log (see 'Return a call' on page 19).

Normal call

- 1 Press .
- 2 Dial the phone number.
 - ➡ The number is dialed out.
 - ➡ The duration of your current call is displayed.

Predial call


- 1 Dial the phone number.
 - To erase a digit, press REDIAL/C.
 - To enter a pause, press and hold #.
- 2 Press  to dial out the call.

Turn off the ringer of an incoming call

When the phone rings, press REDIAL/C.

End a call

You can end a call in these ways:

- Press .
- Place the handset to the base station or charging cradle.

Adjust the earpiece/speaker volume

Press ▲ / ▼ to adjust the volume during a call.

- ➔ The earpiece/speaker volume is adjusted and the phone is back to the call screen.

Mute the microphone

- 1 Press during a call.
 - ➔ [MUTE ON] is displayed on the handset.
 - ➔ The caller cannot hear you, but you can still hear his voice.
- 2 Press again to unmute the microphone.
 - ➔ You can now communicate with the caller.

Turn the speaker on or off

Press .

Make a second call

Note

- This service is network dependent. Check with your network provider for operation.

- 1 Press during a call.
 - ➔ The first call is put on hold.
- 2 Dial the second number.
 - ➔ The number displayed on the screen is dialed out.

Answer a second call

Note

- This service is network dependent.

When there is a periodical beep to notify you of an incoming call, you can answer the call in these ways:

- 1 Press and to answer the call.
 - ➔ The first call is put on hold, and you are now connected to the second call.
- 2 Press and to end the current call and answer the first call.

Switch between two calls

Note

- This service is network dependent. Check with your network provider for operation.

Press and .

- ➔ The current call is put on hold, and you are now connected to the other.

Make a conference call with the external callers

Note

- This service is network and country dependent. Check with the service provider for operation and additional charges.

When you are connected to two calls, press , then .

- ➔ The two calls are combined and a conference call is established.



5 Intercom and conference calls

An intercom call is a call to another handset that shares the same base station. A conference call involves a conversation between you, another handset user and the outside callers.

Make a call to another handset

Note

- If the base station only has 2 registered handsets, press and hold *INT to make a call to another handset.

- 1 Press and hold *INT .
 - ↳ For multi-handset versions, the handsets available for intercom are displayed, then go to step 2.
 - ↳ For two-handset versions, the other handset rings, then go to step 3.
- 2 Select a handset.
 - ↳ The selected handset rings.
- 3 Press  on the selected handset.
 - ↳ The intercom is established.
- 4 Press REDIAL/C or  to cancel or end the intercom call.

While you are on the phone

You can go from one handset to another during a call:

- 1 Press and hold *INT.
 - ↳ The current caller is put on hold.
 - ↳ For multi-handset versions, the handsets available for intercom are displayed, then go to step 2.
- 2 Select a handset, then press MENU/OK to confirm.
 - ↳ Wait for the other side to answer your call.

Switch between calls

Press and hold *INT to switch between the outside call and the intercom call.

Make a conference call

A 3-way conference call is between you, another handset user and the outside callers. It requires two handsets to share the same base station.

During an external call

- 1 Press and hold *INT to initiate an internal call.
 - ↳ The external caller is put on hold.
 - ↳ For multi-handset versions, the handsets available for intercom

are displayed, then go to step 2.

- ↳ For two-handset versions, the other handset rings, then go to step 3.

- 2 Select a handset, then press **MENU/OK** to confirm.
 - ↳ The selected handset rings.
- 3 Press **⏏** on the selected handset.
 - ↳ The intercom is established.
- 4 Press **MENU/OK**.
 - ↳ You are now in a 3-way conference call with an external call and a selected handset.
- 5 Press **⏏** to end the conference call.



Note

- Press **⏏** to join an ongoing conference with another handset if [SERVICES] > [CONFERENCE] is set to [AUTO].

During the conference call

- 1 Press and hold ***INT** to put the internal call on hold and go back to the external call.
 - ↳ The internal call is put on hold.
- 2 Press and hold ***INT** again to put the external call on hold and go back to the internal call.
 - ↳ The external call is put on hold.
- 3 Press **MENU/OK** to go back to the conference call.








Note

- If a handset hangs up during the conference call, the other handset remains connected to the external call.

6 Text and numbers

You can enter text and numbers for handset name, phonebook records, and other menu items.

Enter text and numbers

- 1 Press once or several times on the alphanumeric key to enter the selected character.
- 2 Press REDIAL/C to delete a character. Press and hold REDIAL/C to delete all characters. Press   and   to move the cursor left and right.
- 3 Press 0  to add a space.



Note

- For information on key mapping of characters and numbers, see the chapter 'Appendix'.



7 Phonebook

This phone has a phonebook that stores up to 50 records. You can access the phonebook from the handset. Each record can have a name up to 12 characters long and a number up to 24 digits long.

View the phonebook

Note

- You can view the phonebook on one handset only each time.

- 1 Press   or press MENU/OK > [PHONEBOOK] > [VIEW] to access the phonebook list.
- 2 Select a contact and view the available information.

Search a record



You can search the phonebook records in these ways:

- Scroll the contacts list.
- Enter the first character of the contact.




Scroll the contact list

- 1 Press   or press MENU/OK > [PHONEBOOK] > [VIEW] to access the phonebook list.
- 2 Press   and   to scroll through the phonebook list.

Enter the first character of a contact

- 1 Press   or press MENU/OK > [PHONEBOOK] > [VIEW] to access the phonebook list.
- 2 Press the alphanumerical key that matches the character.
 - ↳ The first record that starts with this character is displayed.

Call from the phonebook

- 1 Press   or press MENU/OK > [PHONEBOOK] > [VIEW] to access the phonebook list.
- 2 Select a contact in the phonebook list.
- 3 Press  to make the call.

Add a record



Note

- If your phonebook memory is full, the handset displays a notification message. Delete some records to add new ones.
- When you change the number of a record, the new number will overwrite the old number.

- 1 Press MENU/OK.
- 2 Select [PHONEBOOK] > [ADD NEW], then press MENU/OK to confirm.
- 3 Enter the name, then press MENU/OK to confirm.
- 4 Enter the number, then press MENU/OK to confirm
 - ↳ Your new record is saved.



Tip

- Press and hold # to insert a pause.
- Press once or several times on the alphanumeric key to enter the selected character.
- Press REDIAL/C to delete the character. Press  or  to move the cursor left and right.

Delete all records

Press MENU/OK.

- 1 Select [PHONEBOOK] > [DELETE ALL], press MENU/OK to confirm.
↳ A confirmation request is displayed on the handset.
- 2 Press MENU/OK to confirm.
↳ All records are deleted.

Edit a record


- 1 Press MENU/OK.
- 2 Select [PHONEBOOK] > [EDIT], then press MENU/OK to confirm.
- 3 Select a contact, then press MENU/OK to confirm.
- 4 Edit the name, then press MENU/OK to confirm.
- 5 Edit the number, then press MENU/OK to confirm.
↳ The record is saved.

Delete a record

- 1 Press MENU/OK.
- 2 Select [PHONEBOOK] > [DELETE], then press MENU/OK to confirm.
- 3 Select a contact, then press MENU/OK to confirm.
↳ A confirmation request is displayed on the handset.
- 4 Press MENU/OK to confirm.
↳ The record is deleted.



8 Call log

The call log stores the call history of all missed or received calls. The incoming call history includes the name and number of the caller, call time and date. This feature is available if you have registered to the caller ID service with your service provider. Your phone can store up to 20 call records. The call log icon on the handset flashes to remind you of any unanswered calls. If the caller allows the display of his identity, you can view his name or number. The call records are displayed in chronological order with the most recent received call at the top of the list.


 **Note**

- Make sure that the number in the call list is valid before you can call back directly from the call list.


The icons shown on the screen tell you whether they are missed/received calls.

Icons	Description
	It remains steadily on when browsing incoming calls in the call log.
	It flashes when there is a new missed call. It remains steadily on when browsing the missed calls in call log.



View the call records

- 1 Press  ▼.
↳ The incoming call log is displayed.
- 2 Select a record, then press MENU/OK and select [VIEW] for more available information.

Save a call record to the phonebook

- 1 Press  ▼.
↳ The incoming call log is displayed.
- 2 Select a record, then press MENU/OK to confirm.
- 3 Select [SAVE NUMBER], then press MENU/OK to confirm.
- 4 Enter and edit the name, then press MENU/OK to confirm.
↳ The record is saved.

Return a call

- 1 Press  ▼.
- 2 Select a record on the list.
- 3 Press  to make the call.

Delete a call record

- 1 Press **⏏** ▼.
 - ↳ The incoming call log is displayed.
- 2 Select a record, then press **MENU/OK** to confirm.
- 3 Select **[DELETE]**, then press **MENU/OK** to confirm.
 - ↳ A confirmation request is displayed on the handset.
- 4 Press **MENU/OK** to confirm.
 - ↳ The record is deleted.

Delete all call records

- 1 Press **⏏** ▼.
 - ↳ The incoming call log is displayed.
- 2 Press **MENU/OK** to enter the options menu.
- 3 Select **[DELETE ALL]**, then press **MENU/OK** to confirm.
 - ↳ A confirmation request is displayed on the handset.
- 4 Press **MENU/OK** to confirm.
 - ↳ All records are deleted.


9 Redial list

The redial list stores the call history of dialed calls. It includes the names and/or numbers you have called. This phone can store up to 10 redial records.

View the redial records

Press REDIAL/C.

Redial a call

- 1 Press REDIAL/C.
- 2 Select a record, then press .
↳ The number is dialed out.

Save a call record to the phonebook

- 1 Press REDIAL/C to enter the list of dialed calls.
- 2 Select a record, then press MENU/OK to confirm.
- 3 Select [SAVE NUMBER], then press MENU/OK to confirm.
- 4 Enter and edit the name, then press MENU/OK to confirm.
↳ The record is saved.

Delete a redial record

- 1 Press REDIAL/C to enter the list of dialed calls.
- 2 Select a record, then press MENU/OK to confirm.
- 3 Select [DELETE], then press MENU/OK to confirm.
↳ A confirmation request is displayed on the handset.
- 4 Press MENU/OK to confirm.
↳ The record is deleted.

Delete all redial records

- 1 Press REDIAL/C to enter the list of dialed calls.
- 2 Select a record, then press MENU/OK to confirm.
- 3 Select [DELETE ALL], then press MENU/OK to confirm.
↳ A confirmation request is displayed on the handset.
- 4 Press MENU/OK to confirm.
↳ All records are deleted.

10 Phone settings

You can customize the settings to make it your own phone.

Sound settings

Set the handset's ringtone volume

You can select among 5 ringtone volume levels or [OFF].

- 1 Press MENU/OK.
- 2 Select [PHONE SETUP] > [SOUNDS] > [RING VOLUME], then press MENU/OK to confirm.
- 3 Select a volume level, then press MENU/OK to confirm.
↳ The setting is saved.

Set the handset's ringtone for internal calls

You can select from 10 ringtones for internal calls.

- 1 Press MENU/OK.
- 2 Select [PHONE SETUP] > [SOUNDS] > [RINGTONE INT], then press MENU/OK to confirm.
- 3 Select a ringtone, then press MENU/OK to confirm.
↳ The setting is saved.

Set the handset's ringtone for external calls

You can select from 10 ringtones for external calls.

- 1 Press MENU/OK.
- 2 Select [PHONE SETUP] > [SOUNDS] > [RINGTONE EXT], then press MENU/OK to confirm.
- 3 Select a ringtone, then press MENU/OK to confirm.
↳ The setting is saved.

Set the key tone

Key tone is the sound made when you press a key on the handset.

- 1 Press MENU/OK.
- 2 Select [PHONE SETUP] > [SOUNDS] > [KEY TONE], then press MENU/OK to confirm.
- 3 Select [ON]/[OFF], then press MENU/OK to confirm.
↳ The setting is saved.

Set the docking tone

Docking tone is the sound made when you place the handset on the base station or charger.

- 1 Press MENU/OK.
- 2 Select [PHONE SETUP] > [SOUNDS] > [DOCKING TONE], then press MENU/OK to confirm.
- 3 Select [ON]/[OFF], then press MENU/OK to confirm.
↳ The setting is saved.

Name the handset

The name of the handset can be up to 10 characters. It is displayed on

the handset screen in standby mode. You can press and hold MENU/OK to switch between the handset name and date and time display.

- 1 Press MENU/OK.
- 2 Select [PHONE SETUP] > [PHONE NAME], then press MENU/OK to confirm.
- 3 Enter or edit the name. To erase a character, press REDIAL/C.
- 4 Press MENU/OK to confirm.
↳ The setting is saved.

Set the date and time

For information, see 'Set the date and time'.

Set the display language



Note

- This feature only applies to models with multiple-language support.
- Languages available vary from country to country.

- 1 Press MENU/OK.
- 2 Select [PHONE SETUP] > [LANGUAGE], then press MENU/OK to confirm.
- 3 Select a language, then press MENU/OK to confirm.
↳ The setting is saved.

11 Telephone answering machine

Note

- Available only for D146.

Your phone includes a telephone answering machine that records unanswered calls when it is on. By default, the answering machine is set to the [RECORD ALSO] mode. You can access the answering machine remotely and change the settings through the answering machine menu on the handset.

Turn the answering machine on or off

- 1 Press / or MENU/OK > [ANSW MACHINE] > MENU/OK.
- 2 Select [ON/OFF] > [ON]/[OFF], then press MENU/OK to confirm.
- 3 Select [RECORD ALSO]/ [ANSWER ONLY] when the answer machine is on, then press MENU/OK to confirm.
↳ The setting is saved.

Note

- [RECORD ALSO] means calls are answered and messages are recorded.
- [ANSWER ONLY] means calls are only answered, messages are not recorded.
- When the answering machine is switched on, it answers incoming calls after a certain number of rings based on the ring delay setting.

Set the answering machine language

Note

- This feature only applies to models with multiple-language support.

The answering machine language is the language for the announcements.



- 1 Press / or MENU/OK > [ANSW MACHINE] > MENU/OK.
- 2 Select [LANGUAGE], then press MENU/OK to confirm.
- 3 Select a language, then press MENU/OK to confirm.
↳ The setting is saved.

Announcements

The announcement is the message your caller hears when the answering machine picks up the call. The answering machine has 2 default announcements: the [RECORD ALSO] mode and [ANSWER ONLY] mode.

Record an announcement



The maximum length of the announcement you can record is 3 minutes. The newly recorded announcement automatically replaces the old one.

- 1 Press  /  or MENU/OK > [ANSW MACHINE] > MENU/OK.
- 2 Select [ANNOUNCEMENT], then press MENU/OK to confirm.
- 3 Select [RECORD ALSO] or [ANSWER ONLY], then press MENU/OK to confirm.
- 4 Select [RECORD NEW], then press MENU/OK to confirm.
- 5 Start recording close to the microphone after the beep.
- 6 Press MENU/OK to stop recording or the recording stops after 3 minutes.

Note

- Make sure that you speak close to the microphone when you record an announcement.



Listen to the announcement

- 1 Press  /  or MENU/OK > [ANSW MACHINE] > MENU/OK.
- 2 Select [ANNOUNCEMENT], then press MENU/OK to confirm.
- 3 Select [RECORD ALSO] or [ANSWER ONLY], then press MENU/OK to confirm.
- 4 Select [PLAY], then press MENU/OK to confirm.
 - ↳ You can listen to the current announcement.

Note

- You can no longer listen to the announcement when you pick up an incoming call.

Restore the default announcement

- 1 Press  /  or MENU/OK > [ANSW MACHINE] > MENU/OK.
- 2 Select [ANNOUNCEMENT], then press MENU/OK to confirm.
- 3 Select [RECORD ALSO] or [ANSWER ONLY], then press MENU/OK to confirm.
- 4 Select [USE DEFAULT], then press MENU/OK to confirm.
 - ↳ A confirmation request is displayed on the handset.
- 5 Press MENU/OK to confirm.
 - ↳ The default announcement is restored.

Incoming messages

Each message can be up to 3 minutes long. When you receive new messages, the new message indicator on the handset flashes.

Note

- If you pick up the phone when the caller leaves a message, the recording stops and you can talk to the caller directly.
- If the memory is full, the answering machine switches to [ANSWER ONLY] automatically. Delete old messages to record new ones.

Listen to the incoming message

You can listen to the incoming messages in the sequence they are recorded.

- If there are new messages, press / to listen.
- If there is no new message, press / or [ANSW MACHINE] > [PLAY], then MENU/OK to listen to old messages.
- Press MENU/OK > [ANSW MACHINE] > [PLAY], then press MENU/OK to confirm.
 - ↳ New messages start playing.
 - Old messages start playing if there is no new message.
- Press REDIAL/C to stop listening.
- Press MENU/OK to enter the options menu.
- Press / to increase/decrease the volume.

Delete an incoming message

- 1 When you listen to the message, press MENU/OK to enter the options menu.
- 2 Select [DELETE], then press MENU/OK to confirm.
 - ↳ The current message is deleted.

Delete all old incoming messages

- 1 Press / or MENU/OK > [ANSW MACHINE] > MENU/OK.
- 2 Select [DELETE ALL], then press MENU/OK to confirm.
 - ↳ A confirmation request is displayed on the handset.
- 3 Press MENU/OK to confirm.
 - ↳ All old messages are permanently deleted.



Note

- You can delete the read messages only. No deleted messages can be recovered.

Set the ring delay

You can set the number of times the phone rings before the answering machine picks up the call.

- 1 Press / or MENU/OK > [ANSW MACHINE] > MENU/OK.
- 2 Select [RING DELAY], then press MENU/OK to confirm.
- 3 Select a new setting, then press MENU/OK to confirm.
 - ↳ The setting is saved.



Note

- Make sure that the answering machine is switched on before this feature can be applied.



Tip

- When you access the answering machine remotely, you are recommended to set the ring delay to [TOLL SAVER] mode. This is a cost effective way to manage your messages. When there are new messages, the answering machine picks up the call after 3 rings; When there is no messages, it picks up the call after 5 rings.

Remote access



You can operate your answering machine when you are away from home. Simply make a call to your phone with a touch tone phone and enter your 4-digit PIN code.

Note



- The remote access PIN code is the same as your system PIN. The preset PIN is 0000.

Activate/deactivate the remote access

You can allow or block remote access to the answering machine.

- 1 Press  /  or MENU/OK > [ANSW MACHINE] > MENU/OK.
- 2 Select [REMOTE ACC.], then press MENU/OK to confirm.
- 3 Select [ACTIVATE]/[DEACTIVATE], then press MENU/OK to confirm.
↳ The setting is saved.

Change the PIN/passcode

- 1 Press  /  or MENU/OK > [ANSW MACHINE] > MENU/OK.
- 2 Select [REMOTE ACC.] > [CHANGE PIN], then press MENU/OK to confirm.
- 3 Enter the old PIN/passcode, then press MENU/OK to confirm.
- 4 Enter the new PIN/passcode, then press MENU/OK to confirm.
- 5 Enter the new PIN/passcode again, then press MENU/OK to confirm.
↳ The setting is saved.

Access the answering machine remotely

- 1 Make a call to your home number with a touch tone phone.
- 2 Enter # when you hear the announcement.
- 3 Enter your PIN code.
↳ You now have access to your answering machine, and you can listen to the new messages.

Note

- You have 2 chances to enter the correct PIN code before your phone hangs up.

- 4 Press a key to carry out a function. See the Remote access commands table below for a list of available functions.

Note

- When there is no message, the phone hangs up automatically if no key is pressed for 8 seconds.
- When the answering machine is turned off but the remote access function is activated, the answering machine will still pick up the call in [ANSWER ONLY] mode after 10 rings.

Remote access commands

Key	Function
1	Listen to the previous message.
2	Listen to messages.
3	Skip to the next message.
6	Delete the current message.
7	Switch the answering machine on (not available when you listen to the messages).
8	Stop listening to the message.
9	Switch the answering machine off. (not available when you listen to the messages).

12 Services

The phone supports a number of features that help you handle and manage the calls.

Auto conference

To join an external call with another handset, press .

Note

- This feature is available only for multi-handset versions.

Activate/Deactivate auto conference

- 1 Press MENU/OK.
- 2 Select [SERVICES] > [CONFERENCE], then press MENU/OK to confirm.
- 3 Select [AUTO]/[OFF], then press MENU/OK to confirm.
→ The setting is saved.

Auto prefix

This feature checks and formats your outgoing call number before it is dialed out. The prefix number can replace the detect number you set in the menu. For example, you set 604 as the detect number and 1250 as the prefix. When you have dialed out a number such as 6043338888, your phone changes the number to 12503338888 when it dials out.

Note

- The maximum length of a detect number is 5 digits. The maximum length of an auto prefix number is 10 digits.
- This is a country dependent feature.

Set auto prefix

- 1 Press MENU/OK.
- 2 Select [SERVICES] > [AUTO PREFIX], then press MENU/OK to confirm.
- 3 Press MENU/OK. Enter the detect number, then press MENU/OK to confirm.
- 4 Press MENU/OK. Enter the prefix number, then press MENU/OK to confirm.
→ The setting is saved.

Note

- This is a country dependent feature.
- To enter a pause, press and hold #.
- If the prefix number is set and the detect number is left empty, the prefix number is added to all outgoing calls.
- The feature is unavailable if the dialed number starts with * and #.

Network type

Note

- This is a country dependent feature. It only applies to models with network type support.

- 1 Press MENU/OK.
- 2 Select [SERVICES] > [NETWORK TYPE], then press MENU/OK.
- 3 Select a network type, then press MENU/OK.
↳ The setting is saved.

Tip

- Select [PSTN] if the phone is connected to a fixed line (e.g. at home).
- Select [PBX] if the phone is connected to a private telephone line (e.g. in the office).

Select the recall duration

Make sure that the recall time is set correctly before you can answer a second call. In normal case, the phone is already preset for the recall duration. You can select among 3 options: [SHORT], [MEDIUM] and [LONG]. The number of available options varies with different countries. For details, consult your service provider.

- 1 Press MENU/OK.
- 2 Select [SERVICES] > [RECALL TIME], then press MENU/OK to confirm.
- 3 Select an option, then press MENU/OK to confirm.
↳ The setting is saved.

Dial mode

Note

- This feature is country dependent and only applies to models that support both tone and pulse dial.

Dial mode is the telephone signal used in your country. The phone supports tone (DTMF) and pulse (rotary) dial. Consult the service provider for detailed information.

Set the dial mode

- 1 Press MENU/OK.
- 2 Select [SERVICES] > [DIAL MODE], then press MENU/OK to confirm.
- 3 Select a dial mode, then press MENU/OK to confirm.
↳ The setting is saved.

Note

- If your phone is in pulse dial mode, press *INT during a call for temporary tone mode. Digits entered for this call are then sent out as tone signals.

Auto clock

Note

- This service is network dependent.
- Make sure you have subscribed to the caller ID service before you use this feature.

It synchronizes the date and time on your phone with the public switched telephone network (PSTN) automatically. For the date to be

synchronized, make sure the current year is set.

- 1 Press MENU/OK.
- 2 Select [SERVICES] > [AUTO CLOCK], then press MENU/OK to confirm.
- 3 Select [ON]/[OFF], then press MENU/OK.
↳ The setting is saved.

Register the handset or additional handsets

You can register additional handsets to the base station. The base station can register up to 4 handsets.

- 1 You can register your handset as follows:
 - If the handset is in [UNREGISTERED] status, press MENU/OK.
 - If the handset is in [SEARCHING] and [UNAVAILABLE] status, press MENU/OK > [SERVICES] > [REGISTER] > MENU/OK.
- 2 Press and hold **••** on the base station for 10 seconds.
- 3 Enter the system PIN. Press REDIAL/C to make corrections. Then press MENU/OK to confirm the PIN.
↳ Registration is complete in less than 2 minutes. The base automatically assigns a handset number to the handset.

Note

- If the PIN is incorrect or no base is found within a certain period, a notification message will be displayed on your handset.
- If registration fails, unplug the power adapter from the base station and plug it back. Wait for 15 seconds, and then repeat the registration procedure.
- The preset PIN is 0000. No change can be made on it.
- The handset and the base station are GAP compliant, which means they guarantee the minimum functions: register a handset, take the line, make a call and receive a call. The advanced features may not be available if you use them with other makes.
- To register the handset to another GAP-compliant base station, follow the registration procedure of that base station.

Unregister the handsets

If two or more handsets share the same base station, you can unregister the handset or other handsets.

- 1 Press MENU/OK.
- 2 Select [SERVICES] > [UNREGISTER], then press MENU/OK to confirm.
- 3 Enter the system PIN. (The preset PIN is 0000). Press REDIAL/C to remove the number.
- 4 Select the handset number to be unregistered.
- 5 Press MENU/OK to confirm.
↳ The handset is unregistered.

Tip

- The handset number is displayed beside the handset name in standby mode.



Note

- A handset cannot unregister itself if it is the only handset registered to the base station.

Restore default settings

You can reset your phone settings to the original factory settings.

- 1 Press MENU/OK.
- 2 Select [SERVICES] > [RESET], then press MENU/OK to confirm.
 - ↳ A confirmation request is displayed on the handset.
- 3 Press MENU/OK to confirm.
 - ↳ All settings are reset.

13 Technical data

General specification and features

- Talk time: 10 hours
- Standby time: 200 hours
- Range indoor: 50 meters
- Range outdoor: 300 meters
- Phonebook list with 50 entries
- Redial list with 10 entries
- Call log with 20 entries
- Answering machine with 25 minutes recording time
- Caller identification standard support: FSK, DTMF

Battery

- Rechargeable Ni-MH 2.4V 300mAh non-removable batteries

Power adapter

Base and charger

- SPPS: SSY050050-UK, input: 100–240 V~, 50/60 Hz 200 mA, output: 5 Vdc 500 mA

Alternative power source

- Power bank: output: 5Vdc, 500mA (minimum)

RF output power

- < 24 dBm

Frequency band

- 1880 MHz ~ 1900 MHz

Power consumption

- Power consumption in idle mode: around 0.70 W (D141); 0.75 W (D146)

Weight and dimensions

- Handset: 100.5 grams
155 x 50 x 25.6 mm (H x W x D)
- Base: 54.5 grams
93.5 x 84.3 x 31 mm (H x W x D)
- Charger: 36 grams
81.6 x 72 x 31 mm (H x W x D)

14 Notice

Declaration of conformity

Hereby, Gibson Innovations declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. You can find the Declaration of Conformity on www.p4c.philips.com.

Use GAP standard compliance

The GAP standard guarantees that all DECT™ GAP handsets and base stations comply with a minimum operating standard irrespective of their make. The handset and base station are GAP compliant, which means they guarantee the minimum functions: register a handset, take the line, make a call and receive a call. The advanced features may not be available if you use them with other makes. To register and use this handset with a GAP compliant base station of different make, first follow the procedure described in the manufacturer's instructions, then follow the procedure described in this manual for registering a handset. To register a handset from different make to the base station, put the base station in registration mode, then follow the procedure described in the handset manufacturer's instructions.

Compliance with EMF

This product complies with all applicable standards and regulations regarding exposure to electromagnetic fields.

Disposal of your old product and battery



Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.



This symbol on a product means that the product is covered by European Directive 2012/19/EU.



This symbol means that the product contains batteries covered by European Directive 2013/56/EU which cannot be disposed of with normal household waste.

Inform yourself about the local separate collection system for electrical and electronic products and batteries. Follow local rules and never dispose of the product and batteries with normal household waste. Correct disposal of old products and batteries helps prevent negative consequences for the environment and human health.



When this logo is attached to a product, it means a financial contribution has been paid to the associated national recovery and recycling system.

Environmental information

All unnecessary packaging has been omitted. We have tried to make the packaging easy to separate into three materials: cardboard (box), polystyrene foam (buffer) and polyethylene (bags, protective foam sheet.)

Your system consists of materials which can be recycled and reused if disassembled by a specialized company. Please observe the local regulations regarding the disposal of packaging materials, exhausted batteries and old equipment.

15 Frequently asked questions

My handset displays [SEARCHING] or [UNAVAILABLE], or [UNREGISTERED], what do I do??

- Make sure that the base station has power supply.
- The handset is out of range. Move it closer to the base station.
- The handset is not paired with the base. Register the handset to the base station.



Tip

- For further information, see 'Register the handset or additional handsets' on the Services section.

If I fail to pair (register) the additional handsets to the base station, what do I do?

- Your base memory is full. Unregister the unused handsets and try again (see 'Unregister handsets' on page 39).
- If registration fails, unplug the power adapter from the base station and plug it back. Wait for 15 seconds, and then repeat the registration procedure (see 'Register the handset or additional handsets' on page 39)

The range is short. How can I improve it?


The range is subject to environmental factors, like electrical devices or walls in between.

- Move the base station to another corner/room.
- Move the base station away from other electrical appliances nearby that could interfere with the range (like routers, TV, radio, etc.).
- Do not put the base station on a metallic desk or a metallic table top.

I have chosen a wrong country in Welcome screen, what do I do?

Reset your phone settings to the original factory settings (see 'Restore default settings' on page 40).

I have chosen a wrong language which I cannot read, what do I do?

- 1 Press  to go back to the standby screen.
- 2 Press MENU/OK to access the main menu screen.
- 3 Select [PHONE SETUP] > [LANGUAGE], then you see one of the following texts appear on the screen:

CONFIG. TÉL > LANGUE

PHONE SETUP > LANGUAGE

TEL.-SETUP > SPRACHE

CONF. TELEF. > LINGUA

- 4 Select it to access the language options.
- 5 Select your own language.

The handset loses connection with the base or the sound interrupts during a call.

- The handset is nearly out of range. Move it closer to the base station.
- Re-register the handset to the base station.

No dialing tone/no free line.

- Check your phone connections.
- The handset is out of range. Move it closer to the base station.
- The handset is in [SEARCHING] or [UNAVAILABLE] status. Register the handset to the base station.

No docking tone.

- The handset is not placed properly on the base station/charger.
- The charging contacts are dirty. Disconnect the power supply first and clean the contacts with a damp cloth.

[VOICEMAIL] is displayed on the handset. What do I do?

You receive the [VOICEMAIL] alert when you have new voice messages stored in your network. The voice mail service is managed by your service provider but not on the phone itself.

Contact your service provider for the settings.

The handset on the charger does not charge.

- Make sure that the power switch is at 'ON' position.
- Make sure the handset is placed properly on the charger. If the docking tone is turned on, you can hear the docking tone when you place the handset on the charging cradle. The battery icon animates when charging.
- The charging contacts are dirty. Disconnect the power supply first and clean the contacts with a damp cloth.
- The battery is not fully recharged. Leave the handset on the charging cradle for at least 8 hours or until the battery icon on the handset stops scrolling and indicates full bar.

No display.

- Make sure the batteries are charged.
- Make sure there is power and the phone is connected.

Bad audio (crackles, echo, etc.).

- The handset is nearly out of range. Move it closer to the base station.
- The phone receives interference from the nearby electrical appliances. Move the base station away from them.
- The phone is at a location with thick walls. Move the base away from them.
- The phone receives interference from the DSL (digital subscriber line) connection. Install a DSL filter to prevent the noise. Contact your service provider for the DSL filter.

The handset does not ring.

- Make sure the handset ringtone is turned on.
- Make sure the handset is registered to the base station.

The caller ID does not display.

- The service is not activated. Check with your service provider.
- The caller's information is withheld or unavailable.



Note

- If the above solutions do not help, disconnect the power supply from both the handset and base station. Try again after 1 minute.

16 Appendix

Text and number input tables

key	Characters (for English/Latin)
0	space 0
1	- 1
2	A B C 2
3	D E F 3
4	G H I 4
5	J K L 5
6	M N O 6
7	P Q R S 7
8	T U V 8
9	W X Y Z 9
*	* ? / \ ()
#	# ' , - &

key	Characters (for Norwegian/Danish)
0	space 0
1	- 1
2	A Æ B C 2
3	D E F 3
4	G H I 4
5	J K L 5
6	M N O 6
7	P Q R S 7
8	T U V 8
9	W X Y Z 9
*	* ? / \ ()
#	# ' , - &

Key	Characters (for Greek)
0	space 0
1	- 1
2	A B Γ 2
3	Δ E Z 3
4	H Θ 4
5	K Λ M 5
6	N Ξ O 6
7	Π P Σ 7
8	T Υ Φ 8
9	X Ψ Ω 9
*	* ? / \ ()
#	# ' , - &

key	Characters (for Polish)
0	space 0
1	- 1
2	A B C 2
3	D E F 3
4	G H I 4
5	J K L Ł 5
6	M N O 6
7	P Q R S 7
8	T U V 8
9	W X Y Z 9
*	* ? / \ ()
#	# ' , - &



2017 © Gibson Innovations Limited. All rights reserved.
This product has been manufactured by, and is sold
under the responsibility of Gibson Innovations Ltd., and
Gibson Innovations Ltd. is the warrantor in relation to
this product.
Philips and the Philips' Shield Emblem are registered
trademarks of Koninklijke Philips N.V.

UM_D141-146_05_EN_V1.0
WK1707

