

PHILIPS

Corded phone

CORD026

User manual

CORD026B/61
CORD026W/61



2021 © MMD Hong Kong Holding Limited. All rights reserved. Specifications are subject to change without notice.

Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license. This product has been manufactured by and is sold under the responsibility of MMD Hong Kong Holding Limited or one of its affiliates, and MMD Hong Kong Holding Limited is the warrantor in relation to this product.

CORD026B/W_61_UM_EN_V1.0



Register your product and get support at
www.philips.com/support

Introduction

Dear customer, thank you for choosing our CORD026 multi-functional corded phone. Adopting the latest integrated circuits with stable performance, this phone meets the national standards, and features unique and elegant look, smooth shape and buttons with comfortable hand feel. It can display and store the call detail record produced by the telephone exchange, such as caller's number and time of the call, which makes it easy for you to review and dial back. With high anti-interference and lightning protection performance, and reliable quality, this phone is ideal for business and home use.

Read this manual carefully before use so that you can fully take advantage of the functions of this product.


Features

- FSK/DTMF dual system caller ID
- Storage of up to 10 blocked numbers
- Storage of up to 10 speed dial numbers
- Missed call and incoming call indicator
- 16-digit call display
- Storage of up to 38 incoming call logs (12-digit)
- Storage of up to 12 outgoing call logs (12-digit)
- Call and ringer mute function
- Up to 24 ringer melodies to choose from
- Speakerphone function
- Pre-dialing and automatic number matching
- Call transfer function

Contents

Package content	3
Terms and definitions.....	3
Product overview.....	4
Get started.....	5
Phone settings.....	6
1. Set date/time	6
2. Set local area code	6
3. Set PCODE	7
4. Set screen brightness	7
5. Set alarm.....	7
6. Set dialing method	8
Functions	9
1. Speaker	9
2. Redial.....	9
3. Delete	9
4. Mute	9
5. Block list.....	10
6. Volume.....	10
7. Missed call	10
8. Answered call.....	11
9. Outgoing call.....	11
10. Brightness/Flash.....	11
11. Ringer/Hold	11
12. Speed dial (☎ 1-☎10)	12
13. Pre-dialing and automatic number matching.....	12
14. New incoming call	12
15. Power loss data protection.....	12
Troubleshooting.....	13


Package content



Terms and definitions

1. **Off-hook:** the state produced by picking up the handset off the hook switch or pressing Speaker (📞) in Standby mode.
2. **On-hook:** the state produced by placing the handset onto the hook switch; or pressing Speaker (📞) in Speakerphone mode.
3. **Cut off (reset):** to press the hook switch in Handset mode when the called party is busy; or to press (📞) twice in Speakerphone mode, the phone will make a long beep again.
4. **Caller ID:** caller's number, time of the call and other call detail records displayed on the screen when a call comes in.







Product overview








Get started

1. Connect each end of the line cord to the telephone socket at the back of the unit and the telephone socket on the wall. Install the supplied two batteries correctly.
2. Connect the coil cord to the base and handset.
3. Install this product in a cool, dry and well-ventilated area away from corrosive gas.

Phone settings








Note: When the phone is idle, press  to enter the Settings mode, the LCD displays **SEE 1 DATE**. Press  or  to scroll to a setting menu, and press  to enter the setting. When the setting is completed, press  to save the setting and enter the next setting menu. Press  to exit the Settings mode. If no operation is executed within about 7 seconds, the phone will automatically exit the Settings mode.

1. Set date/time






Press  to enter the Settings mode, the LCD displays **SEE 1 DATE**. Press  again to enter the date/time setting menu, the year display flashes. Press  or  to set the year. Then press  to move to the month (M) setting. In the same way, you can set the date, hour and minute display in sequence.

(Note: When the incoming call uses FSK signal, time of the call will be updated automatically; if it uses DTMF signal, time won't be changed.)

2. Set local area code






Press  to enter the Settings mode. Scroll to **SEE 2 CODE**. Press  to enter local area code setting menu, the LCD displays **CODE ----**. Press  to set the code, the first "-" flashes (if the local area code has been set, it will be displayed and its first digit flashes). Press  or  to set or change the first digit to 0-9. Press  to move to the second digit and set it. After all digits are finished, press  to confirm the setting. (up to 5 digits can be set)

3. Set PCODE






Press  to enter the Settings mode. Scroll to **SE 3 PCODE**. Press  to enter the PCODE setting menu, the LCD displays **PCODE -** and the "-" flashes (if the PCODE has been set, it will be displayed). Press  or  to set or change it to 0-9. Press  to confirm the setting.

(Note: After a PCODE is set, when dialing back the incoming call number, predialing or storing a phone number, if the number has 6 or more digits and its first digit is different from the PCODE, the PCODE will be added to the number. Each time the PCODE is dialed, the phone will be paused automatically for 1 second.)








4. Set screen brightness

Press  to enter the Settings mode. Scroll to **SE 4 LCD**. Press  to enter screen brightness setting menu, the LCD displays **LCD 3**. Press  or  to set the screen brightness (5 levels are available). Press  to confirm the setting.

5. Set alarm

Press  to enter the Settings mode. Scroll to **SE 5 ALARM**. Press  to enter alarm setting menu, the LCD displays **00-00 OFF** (hour/minute). Press  or  to set the first digit of the hour display. Press  to save the first digit and move to the second digit of hour. In this way, you can set the minute display. The alarm is turned on/off by selecting ON (alarm is enabled) or OFF (alarm is disabled). (With the alarm enabled, when the set time is reached, the phone automatically rings for about 1 minute. Press any button to stop it. However, if the time is reached when the phone is off-hook or a call comes in, the alarm will be automatically canceled.)

6. Set dialing method

Press  to enter the Settings mode. Press  or  scroll to the dialing method setting menu, the LCD displays **SE 6 P.T.** Press  to enter the setting menu. Press  or  to select (TONE = tone dialing, which is the default setting) or (PULSE = pulse dialing). Press  to confirm the setting.

Functions



1. Speaker

Press to turn the base speakerphone on or off. When you are on a call using the handset, press to switch to the speakerphone.



2. Redial

Press to dial the last number dialed, the pre-dialed number, or the incoming or outgoing number currently displayed.




3. Delete

Press  to delete the incoming or outgoing number displayed. Press and hold  for 3 seconds to clear all incoming or outgoing numbers. In Settings mode, press to exit the setting. When pre-dialing, press to delete the pre-dialed number digit by digit.









4. Mute




4.1 Mute a call: During a call, press  to mute the microphone, the other party cannot hear you temporarily. Press  again to unmute.

4.2 Mute/unmute ringer: When a call is ringing, press to mute the ringer.

When the phone is on-hook, pressing this button will disable the ringer function,    is displayed. The phone won't ring when a call comes in. To reactivate the ringer, press this button again.


5. Block list





5.1 Set block list: When the phone is on-hook, press and hold  for 3 seconds to access the block list, the LCD displays the serial number  on the top and  at the bottom. Press  or  to select a serial number (01-10). Enter the phone number you want to block, and press  to store it in the block list. To set more blocked numbers, press  or  again to select another serial number, then finish the setting in the same way.

5.2 Delete or change block list: When the phone is on-hook, press and hold  for 3 seconds to access the block list. Select a serial number and press  to delete the blocked phone number; or modify it by entering a new number. Press  to confirm.






5.3 Use block list: When an incoming call number matches any of the blocked numbers, the phone will automatically hang up the call, and it won't ring or store the call record.

6. Volume




6.1 Speakerphone volume: In Speakerphone mode, press  to adjust the speakerphone volume (Max. is 2).

6.2 Ringer volume: When the phone is on-hook, press  to adjust the ringer volume. Options include 1-4 (Max. is 4) and    (Gradually increasing). Select the volume, then pick up the handset or let the phone automatically exit the menu to save the setting.



7. Missed call

Press to view the number, date and time of the missed calls. Press  or  to scroll up and down. Pick up the handset or press  to dial back the displayed directory, or press  to delete it. (For long-distance number which requires a 0 in front of it, press  twice)

8. Answered call


Press to view the number, date and time of the answered calls. Press ▲ or ▼ to scroll up and down. Pick up the handset or press  to dial back the displayed directory, or press  to delete it. (For long-distance number which requires a 0 in front of it, press  twice)

9. Outgoing call




Press to view the number and time of the outgoing calls. Pick up the handset or press  to dial back the displayed directory, or press  to delete it.

10. Brightness/Flash

10.1 Screen brightness: In on-hook mode, press repeatedly to adjust the screen brightness to a desired level (5 brightness levels are available). Pick up the handset or let the phone automatically exit the menu to save the setting.

10.2 Flash: During a call, press  to put the current call on hold and take the new call. The phone will turn to the new call in 600 ms.

11. Ringer/Hold

11.1 Select ringer melody: When the phone is on-hook, press  to enter the ringer melody setting menu, the LCD displays . There are 24 melodies to choose from and the default setting is Melody 01. Press ▲ or ▼ to select a melody, the phone will automatically enter off-hook mode and ring the melody. Press  or pick up the handset to save your selection.


11.2 Call hold: While on a call, press this button to hold the call. The other party will hear a melody but cannot hear you. Press again to return to the call.

Note: In Call Hold mode, if you are using the handset, placing the handset onto the hook switch will automatically switch the phone to Speakerphone Call Hold mode. To resume the held call, pick up the handset again.

12. Speed dial (☎ 1~☎ 10)

12.1 Set speed dial number: A: Pre-dialed number + Settings + Mi (☎ 1~☎ 10); B: Incoming or outgoing call number + Settings + Mi (☎ 1~☎ 10).




12.2 Dial speed dial number: Directly press Mi (☎ 1~☎ 10), the corresponding speed dial number stored will be automatically dialed.

12.3 View and delete speed dial number: When the phone is on-hook, press and hold Mi (☎ 1~☎ 10) for 3 seconds to view the corresponding speed dial number. Press  to delete the number.

Note: 10 speed dial numbers can be stored in the memory and won't be lost even during a power outage. To add more than ten numbers, the oldest ones will be overwritten.

13. Pre-dialing and automatic number matching

13.1 Pre-dialing: When the phone is on-hook, manually enter the phone number. Pick up the handset or press , the phone automatically dials the pre-dialed number.

13.2 Automatic number matching: When the phone is on-hook, press and hold [8] for about 5 seconds. If the LCD displays , the automatic number matching function is turned on, the phone automatically matches the first digits pre-dialed and displays the matched numbers in the memory. Select the number you want to dial and press , the phone automatically dials. To turn off this function, press and hold [8] for about 5 seconds until the LCD displays . (Default setting is OFF)

14. New incoming call

14.1 Missed call indicator: When a call is missed, the missed call indicator flashes. When you press the Missed call button to review the number, the indicator stops flashing.

14.2 Incoming call indicator: When a call comes in and is ringing, the incoming call indicator flashes.

15. Power loss data protection

Speed dial numbers, blocked numbers and pre-dialed numbers will be automatically stored during a power outage. When the phone is idle, manually enter "*#6182#" to delete these numbers stored.

Troubleshooting

Fault	Possible cause	Solution
No dial tone in off-hook mode	Phone line cord is not securely plugged into the phone base	Reconnect
No sound heard from the handset	Coil cord is not securely plugged into the handset or the phone base	Reconnect or replace the coil cord
Caller ID does not work	You did not subscribe to the caller ID service	Subscribe to this service from your service provider
	Caller did not transmit caller ID	
	Caller's number is encrypted or under protection	
Local caller ID includes local area code	Irregular code sending from the local exchange	See "Set local area code" on page 6

Note: If you encounter any other problems during use or the solution explained above cannot solve the problem, please contact your local distributor or the local service center authorized by us.