

Register your product and get support at:
www.philips.com/welcome

Car Entertainment System

CEM250



EN User manual

ZH-HK 使用手冊

ZH-CN 用户手册

PHILIPS

Contents

1 Important	2	7 Adjust sound	20
Safety	2	Adjust volume	20
Notice	2	Mute	20
		Turn Dynamic Bass Boost (DBB) on/off	20
		Select preset equalizer	20
		Other sound settings	20
2 Your car audio system	4		
Introduction	4	8 Adjust system settings	21
What's in the box	4	Set PIN code	21
Overview of the main unit	5	Set bluetooth connection	21
Overview of the remote control	6	Select blackout setting	21
		Turn demo mode on/off	21
		Change button backlight color	21
3 Get started	8	Select start volume	21
Install the car audio	8	Turn beep sound on/off	22
Install remote control battery	12	Turn display scroll on/off	22
Turn on	13	Select shock-protect setting	22
Set clock	13	Reset	22
4 Listen to radio	14	9 Additional information	23
Tune to a radio station	14	Detach the front panel	23
Store radio stations in memory	14	Replace fuse	23
Tune to a preset station	14	Remove the unit	23
5 Use bluetooth devices	15	10 Product information	24
Pairing bluetooth devices	15		
Play audio files	15	11 Troubleshooting	25
Voice dialing	15		
Make a call	15	12 Glossary	26
Call waiting	15		
Call transfer	16		
Terminate call	16		
6 Play audio files	17		
Play a disc	17		
Play from USB/SD/SDHC/MMC device	17		
Control play	18		
Search for an MP3/WMA track	18		
View play information	18		
Intro play	18		
Shuffle play	19		
Repeat play	19		
Connect external sound source	19		

1 Important

Safety

- Read and understand all instructions before you use your apparatus. If damage is caused by failure to follow instructions, the warranty does not apply.
- This apparatus is designed for negative ground (earth) 12V DC operation only.
- To ensure safe driving, adjust the volume to a safe and comfortable level.
- Improper fuses can cause damage or fire. When you need to change the fuse, consult a professional.
- Use only the supplied mounting hardware for a safe and secure installation.
- To avoid short circuit, do not expose the apparatus, remote control or remote control batteries to rain or water.
- Never insert objects into the ventilation slots or other openings on the apparatus.
- Clean the apparatus and frame with a soft, damp cloth. Never use substances such as alcohol, chemicals or household cleaners on the apparatus.
- Never place any objects other than discs into the apparatus.
- Never use solvents such as benzene, thinner, cleaners available commercially, or anti-static sprays intended for discs.
- Visible and invisible laser radiation when open. Avoid exposure to beam.
- Risk of damage to the apparatus screen! Never touch, push, rub or strike the screen with any object.



Caution

- Use of controls or adjustments or performance of procedures other than herein may result in hazardous radiation exposure or other unsafe operation.

Notice



Be responsible
Respect copyrights

The making of unauthorized copies of copy-protected material, including computer programs, files, broadcasts and sound recordings, may be an infringement of copyrights and constitute a criminal offence. This equipment should not be used for such purposes.

This apparatus includes these labels:




Class II equipment symbol



This symbol indicates that the apparatus has a double insulation system.

Recycling



Your product is designed and manufactured with high quality materials and components, which can be recycled and reused. When you see the crossed-out wheel bin symbol attached to a product, it means the product is covered by the European Directive 2002/96/EC:



Never dispose of your product with other household waste. Please inform yourself about the local rules on the separate collection of electrical and electronic products. The correct disposal of your old product helps prevent potentially negative consequences on the environment and human health.

Your product contains batteries covered by the European Directive 2006/66/EC, which cannot be disposed of with normal household waste. Please inform yourself about the local rules on separate collection of batteries. The correct disposal of batteries helps prevent potentially negative consequences on the environment and human health.

Environmental information

All unnecessary packaging has been omitted. We have tried to make the packaging easy to separate into three materials: cardboard (box), polystyrene foam (buffer) and polyethylene (bags, protective foam sheet.)

Your system consists of materials which can be recycled and reused if disassembled by a specialized company. Please observe the local regulations regarding the disposal of packaging materials, exhausted batteries and old equipment.

Any changes or modifications made to this device that are not expressly approved by Philips Consumer Lifestyle may void the user's authority to operate the equipment.

2009 © Koninklijke Philips Electronics N.V. All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners. Philips reserves the right to change products at any time without being obliged to adjust earlier supplies accordingly.

2 Your car audio system

Congratulations on your purchase, and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

Introduction

With the in-car audio system, you can enjoy your drive while you listen to:

- FM or AM (MW) radio
- Audio from CD or MP3 disc
- Audio from your mobile phone
- Audio from a USB drive
- Audio from a SD/SDHC/MMC card
- Audio from external devices


Besides, you can make a call, answer and hang up a call on the audio system.

What's in the box


Check and identify the contents of your package:

- ① Car audio system
- ② Remote control
- ③ Microphone
- ④ Microphone hold
- ⑤ Rubber cushion
- ⑥ Disassembly tool (2 pieces)
- ⑦ Front panel
- ⑧ Carrying case for front panel
- ⑨ Trim plate
- ⑩ Screw (4 pieces)
- ⑪ User manual

- ⑫ Quick start guide
- ⑬ Standard connector



Overview of the main unit



① I (green/red)

- Answer phone (green).
- Dial number (green).
- View call log (green).
- Terminate call (red).

② ▲/DBB

- Select tuner band.
- Select MP3/WMA folder.
- Scroll up menu.
- Turn on or off Dynamic Bass Boost (DBB) sound.

③ SOURCE

- Select audio source.
- Connect or disconnect bluetooth connection.

④ MUTE

- Turn the unit on or off.
- Adjust volume.
- Confirm selection.
- Enter characters for search.
- Dial phone number.
- Mute or restore the volume.


⑤ MENU / DISP







- Display radio frequency, clock and radio program type (if available).
- Display track, elapsed time, artist, album, title, folder, file and clock.
- Access system menu.

- ⑥ ↶
 - Return to previous menu.
 - Stop search.
 - Disable screen blackout.
- ⑦ **Display panel**
- ⑧ 🔒
 - Unlock the panel
- ⑨ **USB socket**
- ⑩ **External device socket**
- ⑪ 6
 - Select preset station 6.
- ⑫ 5
 - Select preset station 5.
- ⑬ **SHUF, 4**
 - Set shuffle play mode.
 - Select preset station 4.
- ⑭ **3, REP**
 - Set repeat play mode.
 - Select preset station 3.
- ⑮ **INTRO, 2**
 - Turn intro play on or off.
 - Select preset station 2.
- ⑯ **1, ▶ II**
 - Start play
 - Pause or resume play.
 - Select preset station 1.
- ⑰ ⏮ / ⏭
 - Tune to a radio station
 - Skip/search for MP3/WMA track.
- ⑱ **EQ/Audio**
 - Select equalizer (EQ) setting.
 - Access audio setting menu.
- ⑲ **▼/SEARCH**
 - Select tuner band.
 - Store radio stations automatically.
 - Scroll up or down menu.
 - Select MP3/WMA folder.
 - Search a track or folder.
- ⑳ **Panel power connection**

- ㉑ **Disc slot**
- ㉒ ▲
 - Take disc out.
- ㉓ **RESET**
 - Restore default settings
- ㉔ **SD/MMC card slot**

Overview of the remote control



- ①  • Tune to a radio station
• Skip/search for a track.
- ②  • Mute or restore volume.
- ③ **⓪PWR**
• Turn the unit on or off.
- ④ **MENU**
• Access system menu.
- ⑤ **AUDIO**
• Access audio setting menu.
- ⑥ **5/6/7/8/9/0+**
• Select track or preset radio station.
• Enter phone number.
- ⑦  • Answer phone.
• Dial number.
- ⑧ **1▶||**
• Start play from the beginning of the first track.
• Pause or resume play.
• Select preset station 1.
• Enter phone number.
- ⑨ **SHUF, 4**
• Set shuffle play mode.
• Select preset station 4.
• Enter phone number.
- ⑩ **SEL**
• Confirm selection.
- ⑪  • Tune for radio station
• Skip/search for MP3/WMA track.
- ⑫  • Return to previous menu.
• Disable screen blackout.
- ⑬ **SOURCE**
• Select audio source.
- ⑭ **VOLUME +/-**
• Adjust volume.
- ⑮ **EQ**
• Select EQ setting.
- ⑯ **DBB**
• Turn on or off Dynamic Bass Boost (DBB) sound.
- ⑰ **SEARCH**
• Set radio station memory automatically.
• Search a track or folder.
- ⑱ **DISP**
• Display radio frequency, clock and radio program type (if available).
• Display MP3/WMA elapsed time, last listened radio frequency, and clock.
- ⑲  • Terminate call
- ⑳ **3, REP**
• Set repeat play mode.
• Select preset station 3.
• Enter phone number.
- ㉑ **INTRO, 2**
• Turn intro play on or off.
• Select preset station 2.
• Enter phone number.

3 Get started

! Caution

- Use the controls only as stated in this user manual.

Always follow the instructions in this chapter in sequence.

If you contact Philips, you will be asked for the model and serial number of your apparatus. The model number and serial number are on the bottom of your apparatus. Write the numbers here:

Model No. _____

Serial No. _____

Install the car audio

These instructions are for a typical installation. However, if your car has different requirements, make the corresponding adjustment. If you have any questions regarding installation kits, consult your Philips car audio dealer.

! Caution

- This unit is designed for negative ground (earth) 12V DC operation only.
- Always install this unit in the car dashboard. Other locations can be dangerous as the rear of the unit heats up during use.
- To avoid short-circuit: before you connect, ensure that the ignition is off.
- Ensure that you connect the yellow and red power supply leads after all other leads are connected.
- Ensure that all loose leads are insulated with electrical tape.
- Ensure that the leads do not get caught under screws or in parts that will move (e.g. seat rail).
- Ensure that all ground (earth) leads are run to a common ground (earth) point.
- Use only the supplied mounting hardware for a safe and secure installation.
- Improper fuses can cause damage or fire. When you need to change the fuse, consult a professional.

Note on the power supply lead (yellow)

- When you connect other devices to this apparatus, ensure that the rating of the car circuit is higher than the total fuse value of all the connected devices.


Notes on speaker connection

- Never connect speaker wires to the metal body or chassis of the car.
- Never connect speaker wires with stripes to one another.

Overview of parts

These are the supplied parts needed to connect and install this unit.

- ① In-car audio system
- ② Sleeve
- ③ Front panel
- ④ Standard connector
- ⑤ Trim plate
- ⑥ Rubber cushion
- ⑦ Disassembly tools
- ⑧ Screws (4 pieces)




Connection: for cars with ISO connectors


! Caution

- Ensure that all loose leads are insulated with electrical tape.


- 1 Pull out the ISO connectors from car dashboard and connect them to the bigger end of the supplied standard connector.



- 2 Connect the other end of the supplied standard connector to the unit.



- 3 Connect the antenna and amplifier as illustrated, if applicable.




	Connector	Connect to
1	MIC	Microphone
2	REAR LINE OUT R	Rear right speaker
3	REAR LINE OUT L	Rear left speaker
4	SUB OUT	Subwoofer
5	ANTENNA	Antenna

Connection: for cars without ISO connectors

! Caution


- Be sure to connect the black ground (earth) lead first.

1 Connect the antenna and amplifier as illustrated, if applicable.



3 Check the car's wiring carefully and connect them to the supplied standard connector.

(B)




	Connector	Connect to
1	MIC	Microphone
2	REAR LINE OUT R	Rear right speaker
3	REAR LINE OUT L	Rear left speaker
4	SUB OUT	Subwoofer
5	ANTENNA	Antenna

1	Green/black strip	Left speaker (Rear)
2	White/black strip	Left speaker (Front)
3	Gray/black strip	Right speaker (Front)
4	Purple/black strip	Right speaker (Rear)


2 Cut off the bigger end of the supplied standard connector.

e	RED	Ignition key +12V DC when ON/ACC
f	BLUE	Motor/electric antenna relay control lead/Amplifier relay control lead
g	BLACK	Ground
h	ORANGE/WHITE	Illumination switch
i	YELLOW	To the +12V car battery which is energized at all times

- 4** Connect the supplied standard connector to the unit.




- 3** Remove the mounting sleeve with the supplied disassembly tools.




Mount in the dashboard

- 1** If the car does not have an on-board drive or navigation computer, disconnect the negative terminal of the car battery.
- If you disconnect the car battery in a car that has an on-board drive or navigation computer, the computer may lose its memory.
 - If the car battery is not disconnected, to avoid short-circuit, ensure that bare wires do not touch each other.
- 2** Remove the two screws on the top of the unit.




- 4** Ensure that car dashboard opening is within these measurements:




- 5** Install the sleeve into the dashboard and bend the tabs outward to fix the sleeve.

Note

- Skip this step if the unit is not fixed by sleeve but by supplied screws.




- 6** Place the supplied rubber cushion over the end of the mounting bolt.



- 7** Slide the unit into the dashboard until you hear a click sound.
- 8** Reconnect the negative terminal of the car battery.

Attach the front panel

- 1** Attach the trim plate.



- 2** Insert the right side of the panel in the chassis until it is correctly engaged.
- 3** Press the left side of the panel and point the left hole at the left pillar.
- 4** Release the panel to engage the left side.

Install remote control battery

! Caution


- Risk of explosion! Keep batteries away from heat, sunshine or fire. Never discard batteries in fire.
- Risk of decreased battery life! Never mix different brands or types of batteries.
- Risk of product damage! When the remote control is not used for long periods, remove the batteries.
- Perchlorate Material - special handling may apply. See www.dtsc.ca.gov/hazardouswaste/perchlorate.

For first-time use:

- 1 Remove the protective tab to activate the remote control battery.

To replace the remote control battery:

- 1 Open the battery compartment.
- 2 Insert 1 CR2025 batteries with correct polarity (+/-) as indicated.
- 3 Close the battery compartment.

**View clock**

- 1 Press **MENU/DISP** repeatedly until the clock is displayed.

Turn on

- 1 Press **⏻** to turn on the unit.
 - To turn off the unit, press **⏻** for 3 seconds.

Set clock

- 1 Press **MENU/DISP** for 3 seconds.
- 2 Press **▲** or **▼** repeatedly until the currently time is displayed.
- 3 Turn **⏻** clockwise to set hour.
- 4 Press **⏻** to confirm.
- 5 Turn **⏻** anti-clockwise to set minute.
- 6 Press **⏻** to confirm.

4 Listen to radio

Tune to a radio station

- 1 Press **SOURCE** repeatedly to select Tuner.
- 2 Press **▲** or **▼** to select band: **[FM1]**, **[FM2]**, **[FM3]**, **[AM1]**, or **[AM2]**.
- 3 Press **◀◀** or **▶▶** to tune to a radio station manually.
 - ↳ The radio station is broadcast.
 - ↳ To search for a radio station automatically, press **SEARCH** for 3 seconds.

Select tuner sensitivity

You can adjust the tuner sensitivity if you want to receive more radio stations or only stations with strong signal.

- 1 Press **MENU/DISP** for over 2 seconds.
- 2 Press **▲** or **▼** repeatedly until **[LOCAL]** or **[DX]** is displayed.
- 3 Rotate **⊖** to select a setting:
 - **[LOCAL]** (local): Only stations with strong signal can be broadcast.
 - **[DX]** (distance): Stations with strong and weak signals can be broadcast.
- 4 Press **⊖** to confirm the selection.

Select stereo/mono broadcasting

For stations with weak signals: to improve the reception, change to monoaural sound.

- 1 Press **MENU/DISP** for 3 seconds.
- 2 Press **▲** or **▼** repeatedly until **[STEREO]** or **[MONO]** is displayed.
- 3 Turn **⊖** to select a setting:
 - **[STEREO]**: stereo broadcast.
 - **[MONO]**: mono broadcast.
- 4 Press **⊖** to confirm the selection.

Store radio stations in memory

You can store up to 6 stations in each band.

Store stations automatically

- 1 Press **SEARCH** for 3 seconds.
 - ↳ The six strongest stations of the selected band are saved in preset channels 1-6 automatically.

Store stations manually

- 1 Tune to a station that you want to store.
- 2 Press one of the numbered buttons **1** to **6** for 3 seconds.
 - ↳ The station is saved in the selected channel.

Tune to a preset station

- 1 Press **▲** or **▼** to select band.
- 2 Press the number button **1** to **6** to select the preset station.

5 Use bluetooth devices

With this car audio system, you can listen to audio files from a player or make a call if bluetooth connection is available on your phone or player.

Pairing bluetooth devices

You can pair your bluetooth device with the unit as follows:

- 1 Turn on bluetooth function on the device.
- 2 Setup bluetooth function on your device.
- 3 Select "CEM250" in the pairing list.
- 4 Enter default password "0000".
 - ↳ "[CONNECT]" is displayed on the panel if pairing succeeds.

Play audio files

You can listen to audio from a bluetooth device and control playback with the unit.

- 1 Press **SOURCE** repeatedly to select **[BT MUSIC]**.
 - To play, press **1, ►||**.
 - To pause, press **1, ►||** again.

Voice dialing

You can dial a number by voice if your mobile phone supports voice dialing.

- 1 Press **☎** for 3 seconds.
 - ↳ **[VOIC DIAL]** is displayed.
- 2 Speak a name stored in contact list stored in the phone.
 - ↳ The unit repeats the number and calls out.

↳ **[NO MATCH]** is displayed if the unit does not recognize a number.

Make a call

- 1 Press **SOURCE** repeatedly to select **[BT MUSIC]**.
- 2 Press **☎**.
- 3 Press **▲** or **▼** to select from the following list:
 - **[DIAL NUM]**: dial a number directly
 - **[DIALLED]**: dialled number
 - **[MISSED]**: missed call
 - **[RECEIVED]**: received call
 - **[ME PBK]**: Phone directory
 - **[SIM PBK]**: SIM card directory
- 4 Press **⓪** to confirm the selection. To dial a number directly, select **[DIAL NUM]**.
 - 1 Press 0-9 to enter phone number.
 - Press **◀◀/▶▶** to change a number.
 - Press **↶** to reset entered numbers.
 - 2 Press **☎** to dial. To use a number in call log or directory, select the options other than **[DIAL NUM]**.
 - 1 Turn **⓪** to select a number from call log or directory.
 - 2 Press **☎** to dial.


Call waiting

If there is another incoming call during call, **[CALL WAITING]** flashes on the display panel.


- 1 Press **☎** to terminate the present call.
 - ↳ The other call is automatically answered.
 - ↳ The first call is terminated.

Call transfer

You can transfer voice from loudspeaker to mobile phones during call.

- 1 Press .
↳ [TRANSFER] is displayed.

Terminate call

- ① Press  to terminate call.

6 Play audio files

Note

- Ensure that the disc or device contains playable files.





Play a disc

Note

- You cannot play CDs encoded with copyright protection technologies.

You can play commercially available audio CDs and these discs:

- CD-Recordables (CD-R)
- CD-Re-writables (CD-RW)
- MP3 CDs
- WMA CDs

- 1 Press  on the front panel to release the panel.
- 2 Insert a CD with the printed side facing up.
- 3 Close the panel.
- 4 Press 1,  to start play.
 - To pause CD play, press 1 .
 - To resume CD play, press 1  again.

Remove the CD

To take out the CD,


- 1 Press .
- 2 Press  beside the disc slot.


Play from USB/SD/SDHC/ MMC device

Note

- Ensure that the USB or SD/SDHC/MMC device contains playable music.


Insert the USB device

- 1 Open the cover marked  on the front panel.



- 2 Insert the USB device into the USB socket.
 - ↳ The unit starts playing from the USB device automatically.

Remove the USB device


- 1 Press and hold  to turn off the unit.
- 2 Remove the USB device.

Insert a card

Note

- This unit supports SD, SDHC, and MMC cards.

- 1 Press **▲** to release the panel.
- 2 Insert the SD or MMC card into the card slot.
 - ↳ The unit starts playing from the SD/MMC card automatically.



Remove the card

- 1 Press **⏻** to turn off the unit.
- 2 Press the card until you hear a click sound.
 - ↳ The card is now disengaged.
- 3 Remove the card.

Control play

- To select a folder, press **▲** or **▼**.
- To skip to the previous/next track, press **⏮** or **⏭**.
- To search backward/forward rapidly within the current track, press **⏮** or **⏭** for 3 seconds.
- To pause, press **1▶||**.
- To resume play, press **1▶||** again.

Search for an MP3/WMA track

- 1 Press **SEARCH** for 3 seconds.
 - ↳ Search menu is displayed.
 - ↳ **[FILE]**: search by track name.
 - ↳ **[FOLDER]**: search by folder sequence.
- 2 Turn **⊙** to select **[FILE]** and then press **⊙** to confirm.
- 3 Turn **⊙** to enter a character and then press **⊙**.
- 4 Repeat step 3 until the search term is complete.
- 5 Press **⊙** for 3 seconds to start search.
 - ↳ When search is finished, a list of matching tracks are displayed.
- 6 Turn **⊙** to skip over the list.
- 7 Press **⊙** to select a track.

View play information

- 1 During play USB/SD/MMC device, press **MENU/DISP** repeatedly to view:
 - Track number and elapsed play time
 - Artist
 - Album
 - Title
 - Folder
 - File
 - Clock

Intro play

You can play the first 10 seconds of each track.

- 1 During play, press **INTRO, 2** to select:
 - **[INT ON]** : After the first 10 seconds of each track have been played, play stops.
 - **[INT OFF]** : Cancel intro play and start normal play.

Shuffle play

You can play the tracks in random order.

- 1 During play, press **SHUF, 4** to select:
 - **[SHUF ON]**: start shuffle play for all tracks.
 - **[SHUF OFF]**: cancel shuffle play.

Repeat play

- 1 During play, press **3, REP** repeatedly to select:
 - **[RPT 1]** (repeat one track): play the current track repeatedly.
 - **[RPT FOLD]** (repeat a folder): play all tracks in the current folder repeatedly.
 - **[RPT ALL]** (repeat all tracks): play all tracks repeatedly.

Connect external sound source

- 1 Connect the external sound source to **MP3 LINK** socket with a 3.5 mm cable.
- 2 Press **SOURCE** repeatedly until **[MP3 LINK]** is displayed.
- 3 Operate the external component (refer to the instructions supplied with the external component).

7 Adjust sound

Adjust volume

- 1 Turn \odot clockwise/anticlockwise to increase/decrease volume.

Mute

You can turn off the sound of your audio.

- 1 During play, press **MUTE** \odot .
 - To turn the sound back on, press **MUTE** \odot again.

Turn Dynamic Bass Boost (DBB) on/off

- 1 Press **DBB** for 3 seconds, the current setting is displayed:
 - ↳ **[DBB ON]** :The Dynamic Bass Boost (DBB) function is on.
 - ↳ **[DBB OFF]** :The DBB function is off.
- 2 Press **DBB** again for 3 seconds to change the DBB setting.

Select preset equalizer

- 1 Press **EQ/Audio**.
 - ↳ The current Equalizer setting is displayed.
- 2 Press **EQ/Audio** again repeatedly to select a preset EQ:
 - **[USER]** (user)
 - **[FLAT]** (flat)
 - **[POP]** (pop)
 - **[TECHNO]** (techno)
 - **[ROCK]** (rock)
 - **[CLASSIC]** (classic)
 - **[JAZZ]** (jazz)
 - **[OPTIMAL]** (optimal)

Other sound settings

You can also edit user preset EQ.

- 1 Press **EQ/Audio** for 3 seconds.
- 2 Press \blacktriangle or \blacktriangledown repeatedly to select the item to be adjusted:
 - **[BAS]** (bass) range: -7 to +7.
 - **[MID]** (bass) range: -7 to +7.
 - **[TRE]** (treble) range: -7 to +7.
 - **[BAL]** (balance) range: 12L to 12R. (L = left speaker, R = right speaker)
 - **[FAD]** (fader) range: 12R to 12F. (R = rear speaker, F = front speaker)
 - **[LPF]** (low pass filter) range: 60, 80, 100, 200.
 - **[MPF]** (mid pass filter) range: 500, 1K, 1.5K, 2.5K.
 - **[HPF]** (high pass filter) range:10K, 12.5K, 15K, 17.5K.
 - **[SW ON]/[SW OFF]** (subwoofer volume on or off)
 - **[SWVOL]** (subwoofer volume) range: 0 to 15.
- 3 Turn \odot to select a value.
- 4 Press \odot to confirm.

8 Adjust system settings

Set PIN code

You can set a password for bluetooth connection.

- 1 Press **MENU/DISP** for 3 seconds.
- 2 Press **▲** or **▼** repeatedly to until **[PIN CODE]** is displayed.
- 3 Press **⏻** to confirm selection.
- 4 Turn **⏻** and then press **⏻** to enter a digit.
- 5 Repeat step 4 to enter other three digits.

Set bluetooth connection

You can set whether the set connects to last bluetooth device automatically.

- 1 Press **MENU/DISP** for 3 seconds.
- 2 Press **▲** or **▼** repeatedly to until **[AUTO ON]** or **[AUTO OFF]** is displayed.
 - **[AUTO ON]**:The unit connects to last bluetooth device automatically.
 - **[AUTO OFF]**: does not connect automatically
- 3 Press **⏻** to confirm selection.

Select blackout setting

You can set the screen to turn off automatically after the unit is idle for 10 or 20 seconds.

- 1 Press **MENU/DISP** for 3 seconds.
- 2 Turn **⏻** to select a setting:
 - **[BKO 10 S]** :Turn off the screen automatically 10 seconds after last operation.
 - **[BKO 20 S]** :Turn off the screen automatically 20 seconds after last operation.
 - **[BKO OFF]** : Never turn off the screen.
- 3 Press **⏻** to confirm.

Turn demo mode on/off

When demo mode is on, when the unit is idle for more than 2 minutes, all functions are displayed.

- 1 Press **MENU/DISP** for 3 seconds.
- 2 Press **▲** or **▼** repeatedly to until **[DEMO]** is displayed.
 - ↳ The screen shows current Demo mode setting.
- 3 Turn **⏻** to select a setting:
 - **[DEMO ON]** :Turn on the demo mode.
 - **[DEMO OFF]** :Turn off the demo mode.
- 4 Press **⏻** to confirm.

Select start volume

Each time you turn on the unit, it can play at the last listened volume or at the preset volume.

- 1 Press **MENU/DISP** for 3 seconds.
- 2 Press **▲** or **▼** repeatedly to until **[V - LAST]** or **[V - ADJ]** is displayed.
- 3 Turn **⏻** to select a setting:
 - **[V - LAST]** : Each time you turn on the unit, the volume remains from its previous use.
 - **[V - ADJ]** : Each time you turn on the unit, the volume is at the preset level.
- 4 Press **⏻** to confirm.

Store preset volume

You can turn on the unit at a preset volume.

- 1 Select **[V - ADJ]** as the start volume.
- 2 Press **MENU/DISP** for 3 seconds.
- 3 Press **▲** or **▼** repeatedly to until **[A-VOL]** is displayed.
- 4 Turn **⏻** to select a value: 0 - 47.
- 5 Press **⏻** to confirm.

Turn beep sound on/off

Each time you press a button, the unit beeps. You can turn off/on this beep sound.

- 1 Press **MENU/DISP** for 3 seconds.
- 2 Press **▲** or **▼** repeatedly to until **[BEEP ON]** or **[BEEP OFF]** is displayed.
- 3 Rotate **⊖** to select a setting:
 - **[BEEP ON]**: Turn on the beep sound.
 - **[BEEP OFF]**: Turn off the beep sound.
- 4 Press **⊖** to confirm.

Turn display scroll on/off

For track information that is longer than the display panel: you can select to cut off the remainder of the text, or scroll to display the full text.

Note

- If any special characters are present in the MP3 track name or album name, it may not display correctly on the screen because these characters are not supported.
- Some WMA is protected by Digital Rights Management (DRM), it cannot be played on the unit.
- Folders/files exceed the supported limit of the unit are not displayed or played.

- 1 Press **MENU/DISP** for 3 seconds.
- 2 Press **▲** or **▼** repeatedly to until **[ROLL ON]** or **[ROLL OFF]** is displayed.
- 3 Turn **⊖** to select a setting:
 - **[ROLL ON]** (scroll on): Auto scroll during play.
 - **[ROLL OFF]** (scroll off): No auto scroll display.
- 4 Press **⊖** to confirm.

Select shock-protect setting


You can select the shock protection setting, depending on the stability of your car and the condition of the road.

- 1 Press **MENU/DISP** for 3 seconds.
- 2 Press **▲** or **▼** repeatedly until **[ESP]** is displayed.
- 3 Turn **⊖** to select a setting:
 - **[ESP 12]**: select this when the road is smooth and there are few bumps.
 - **[ESP 45]** select this when the road is bumpy and unstable.
- 4 Press **⊖** to confirm the selection.

Reset

You can reset the unit to its default setting.


- 1 Detach the front panel.
- 2 Press the reset button by using a ball-point pen or a similar tool.
 - ↳ Preset adjustments such as preset channels and sound adjustments are erased.




9 Additional information

Detach the front panel

You can detach the front panel to deter theft.

- 1 Press  to release the panel.
- 2 Press the left side of the panel rightward.




- 3 Pull the panel towards you to detach it from the chassis.
- 4 Store the panel in the supplied carry case to protect it from dirt or damage.

Replace fuse

If the fuse is damaged,

- 1 Check the electric connection.
- 2 Buy a fuse that matches the voltage of the damaged fuse.

- 3 Replace the fuse.




Note

- If the new fuse gets damaged again, there may be an internal malfunction. Consult your Philips dealer.

Remove the unit

You can remove the unit from the dashboard.

- 1 Detach the front panel.
- 2 Pull out the unit by using the removal keys.



10 Product information



Note

- Product information is subject to change without prior notice.

Power supply	12 V DC (11 V - 16 V), negative ground
Fuse	15 A
Suitable speaker impedance	4 - 8 Ω
Maximum power output	50 W x 4 channels
Continuous power output	24 W x 4 channels (4 Ω 10% T.H.D.)
Pre-Amp output voltage	2.0V (USB play mode; 1 kHz, 0 dB, 10 k Ω load)
Subwoofer output voltage	2.0V (USB play mode: 61 Hz, 0 dB, 10 k Ω load)
Aux-in level	\geq 500 mV
Dimensions (W x H x D)	188 x 58 x 190 mm
Weight	1.36 kg

Radio

Frequency range - FM	87.5 - 108.0 MHz (Europe) 87.5 - 107.9 MHz (American)
Frequency range - AM(MW)	522 - 1620 KHz (Europe) 530 - 1710 KHz (American)
Usable sensitivity - FM	8 μ V
Usable sensitivity - AM(MW) (S/N = 20 dB)	30 μ V

Compatible USB devices:

- USB flash memory (USB 2.0 or USB1.1)
- USB flash players (USB 2.0 or USB1.1)
- memory cards (SD / MMC / SDHC)

Supported formats:

- USB or memory file format: FAT16, FAT32
- MP3 bit rate (data rate): 32-320 Kbps and variable bit rate
- WMA v9 or earlier
- Directory nesting up to a maximum of 8 levels
- Number of albums/ folders: maximum 99
- Number of tracks/titles: maximum 999
- ID3 tag v2.0 or later
- File name in Unicode UTF8 (maximum length: 128 bytes)

Unsupported formats:

- Empty albums: an empty album is an album that does not contain MP3/WMA files, and is not be shown in the display.
- Unsupported file formats are skipped. For example, Word documents (.doc) or MP3 files with extension .dlf are ignored and not played.
- AAC, WAV, PCM audio files
- DRM protected WMA files (.wav, .m4a, .m4p, .mp4, .aac)
- WMA files in Lossless format
- ISO9660, Joliet
- Maximum title number: 512 (depending on file name length)
- Maximum album number: 255
- Supported sampling frequencies: 32 kHz, 44.1kHz, 48 kHz
- Supported Bit-rates: 32~256 (kbps), variable bit rates

11 Troubleshooting



Caution

- Never remove the casing of this apparatus.

To keep the warranty valid, never try to repair the system yourself.

If you encounter problems when using this apparatus, check the following points before requesting service. If the problem remains unsolved, go to the Philips web site (www.philips.com/support). When you contact Philips, ensure that your apparatus is nearby and the model number and serial number are available.

No power or no sound.

- Car engine is not on. Turn the car engine on.
- Cable is not correctly connected. Check connections.
- Fuse is burnt. Replace fuse (see 'Reset' on page 22).
- Volume is too low. Adjust volume.
- If the above solutions cannot help, press the RESET button.
- Ensure that the track played is of a compatible format.

Noise in broadcasts.

- Signals are too weak. Select other stations with stronger signals.
- Check the connection of the car antenna.
- Change broadcast from Stereo to mono (see 'Select stereo/mono broadcasting' on page 14).

Cannot play disc

- Ensure that the disc label is inserted with the printed side facing up.
- Wipe the disc with fibre cleaning cloth from the centre to the edge in a straight line.
- This disc may be defective. Play another disc.
- Ensure that the CD is a finalised CD/CD-R/CD-RW.

- Ensure that the CD is not encoded with copyright protection technologies.

The CD skips tracks

- Ensure that the CD is not damaged or dirty.
- Ensure that random mode is deactivated.

Disc cannot be ejected

- Press and hold ▲.

Preset stations lost.

- Battery cable is not correctly connected. Connect the battery cable to the terminal that is always live.

Display show ERR-1

- The disc, USB or SD device cannot be read in two minutes.

Display show ERR-3

- USB/SD/MMC data error.
- Disc is upside down. Ensure the printed side is facing up.

Display show ERR-5

- Communication error or component is damaged.

12 Glossary

M

MMC

MultimediaCard. A type of memory card with a flash memory.

MP3

A file format with a sound data compression system. MP3 is the abbreviation of Motion Picture Experts Group 1 (or MPEG-1) Audio Layer 3. With the MP3 format, one CD-R or CD-RW can contain about 10 times more data than a regular CD.

S

SD

Secure Digital. A type of memory card with a flash memory.

SDHC

Secure Digital High Capacity (SDHC) is a type of flash memory card based on the SDA 2.00 specification. The SDA 2.00 specification enables SD cards to reach higher capacities from 4GB to 32GB, and growing.

W

WMA (Windows Media Audio)

An audio format owned by Microsoft, is a part of Microsoft Windows Media technology. Includes Microsoft Digital Rights Management tools, Windows Media Video encoding technology, and Windows Media Audio encoding technology.

