

Micro Hi-Fi System

MCM9
MCM11

User manual

Manuel d'utilisation

Manual del usuario

使用説明

MCM9



MCM11



PHILIPS

México



Es necesario que lea cuidadosamente su instructivo de manejo.

	PRECAUCIÓN - ADVERTENCIA	
	No abrir, riesgo de choque eléctrico	
	ATENCIÓN	
	Verifique que el voltaje de alimentación sea el requerido para su aparato	
Para evitar el riesgo de choque eléctrico, no quite la tapa. En caso de requerir servicio, dirijase al personal calificado.		

Descripción: **Minisistema de Audio**
Modelo : **MCM9/21, MCM11/21**
Alimentación: **110-127 / 220-240V~; 50-60 Hz**
Consumo: **45 W (MCM9), 40W (MCM11)**
Importador: **Philips Mexicana, S.A. de C.V.**
Domicilio: **Av. La Palma No. 6
Col. San Fernando La Herradura
Huixquilucan**
Localidad y Tel: **Edo. de México C.P. 52784
Tel. 52 69 90 00**
Exportador: **Philips Electronics HK, Ltd.**
País de Origen: **China**
N° de Serie: _____

**LEA CUIDADOSAMENTE ESTE INSTRUCTIVO
ANTES DE USAR SU APARATO.**

AVISO IMPORTANTE

Philips Mexicana, S.A. de C.V. no se hace responsable por daños o desperfectos causados por:

- Maltrato, descuido o mal uso, presencia de insectos o roedores (cucarachas, ratones etc.).*
- Cuando el aparato no haya sido operado de acuerdo con el instructivo del uso, fuera de los valores nominales y tolerancias de las tensiones (voltaje), frecuencia (ciclaje) de alimentación eléctrica y las características que deben reunir las instalaciones auxiliares.*
- Por fenómenos naturales tales como: temblores, inundaciones, incendios, descargas eléctricas, rayos etc. o delitos causados por terceros (choques asaltos, riñas, etc.).*

CAUTION

Use of controls or adjustments or performance of procedures other than herein may result in hazardous radiation exposure or other unsafe operation.

English 4

Français 23

Español 43

中文 63

English

Français

Español

中文

Energy Star

As an ENERGY STAR® Partner, Philips has determined that this product meets the ENERGY STAR® guidelines for energy efficiency.



General Information

Supplied accessories	5
Environmental information	5
Care and safety information	5

Functional Overview

Main unit and remote control	6–7
Control buttons available on the remote only	7

Connections

Step 1: Connecting FM/MW antennas	8
Step 2: Connecting the speakers	9
Step 3: Connecting the AC power cord	9
Step 4: Inserting batteries into the remote control	9
Using the remote control to operate the system	9

Basic Operations

Switching on/off	10
Switching to an active mode	10
Switching to Eco Power standby mode	10
Switching to standby mode (view clock)	10
Demonstration mode	10
Setting the clock	10
Dimming system's display screen	11
Volume control	11
Sound control	11
Incredible Surround	11
Bass/Treble	11
Natural (Flat) sound	11

Disc Operations

Playable discs	12
Loading disc	12
Basic playback controls	12
Playing an MP3/WMA disc	13
Repeat and Shuffle	13
Repeat play	13
Random play	13
Programming the disc tracks	14
Checking the programme	14
Clearing the programme	14

Tuner Operations

Tuning to radio stations	15
Presetting radio stations	15
Using the Plug and Play	15
Automatic presetting	16
Manual presetting	16
Selecting a preset radio station	16
Deleting a preset radio station	16
Changing tuning grid	16

Tape Operations/Recording

Playing a tape	17
General information on recording	17
Preparation for recording	18
One touch recording	18
CD Synchronised start recording	18

Timer Operations

Timer setting	19
Activating/Deactivating the timer	19
Checking the timer setting	19
Temporarily deactivating the wake up timer	20
Setting the Sleep Timer	20

Other Connection

Listening to an external source	20
---------------------------------------	----

Specifications


.....	21
-------	----

Troubleshooting

.....	22
-------	----

Refer to the type plate on the rear or bottom of the system for identification and supply ratings.

Supplied accessories



- Remote control and two AA batteries.
- MW loop antenna
- FM wire antenna
- AC power cord
- Mains plug adaptor (for version /21 only)

Environmental information

All unnecessary packaging has been omitted. We have tried to make the packaging easy to separate into three materials: cardboard (box), polystyrene foam (buffer) and polyethylene (bags, protective foam sheet).

Your system consists of materials which can be recycled and reused if disassembled by a specialised company. Please observe the local regulations regarding the disposal of packaging materials, exhausted batteries and old equipment.

Care and safety information

Avoid high temperatures, moisture, water and dust

- Do not expose the system, batteries or discs to humidity, rain, sand or excessive heat (caused by heating equipment or direct sunlight). Always keep the disc tray closed to avoid dust on the lens.
- No naked flame sources, such as lighted candles, should be placed on the apparatus.
- No objects filled with liquids, such as vases, shall be placed on the apparatus.

Avoid condensation problem

- The lens may cloud over when the system is suddenly moved from cold to warm surroundings, making it impossible to play a disc. Leave the system in the warm environment until the moisture evaporates.

Do not block the vents

- In a cabinet, allow about 10cm (4 inches) of free space all around the system for adequate ventilation.

Care of disc

- To clean a CD, wipe it in a straight line from the centre towards the edge using a soft, lint-free cloth. A cleaning agent may damage the disc!
- Write only on the printed side of a CDR(W) and only with a soft felt-tipped pen.
- Handle the disc by its edge, do not touch the surface.

Care of the cabinet

- Use a soft cloth slightly moistened with a mild detergent solution. Do not use a solution containing alcohol, spirits, ammonia or abrasives.

Finding a suitable location

- Place the system on a flat, hard, and stable surface.


Built-in safety circuit

- Under extreme conditions, this system may switch to standby mode automatically. If this happens, let the system cool down before reusing it.

Cleaning the Heads and the Tape Paths

- To ensure good recording and playback quality, clean the heads, the capstan(s), and pressure roller(s) after every 50 hours of tape operation.
- Use a cotton swab slightly moistened with cleaning fluid or alcohol.
- You also can clean the heads by playing a cleaning tape once.

Functional Overview



Main unit and remote control

① **STANDBY ON**

- Switches to Eco Power standby mode or turns on the system.
- *Switches to standby mode.

② **ECO POWER** indicator

- Lights up when the system is in Eco Power standby mode.

③ **Disc tray**

④ **Display screen**

⑤ **iR**

- Point the remote control towards this sensor.

⑥ **CD / TUNER / TAPE /AUX/CDR**

- Selects the relevant active mode.
- **CD**: switches to CD mode.
- **TUNER**: toggles between FM and MW band.
- **TAPE**: switches to Tape mode.
- **AUX/CDR**: toggles between AUX and CDR mode.

⑦ **DEMO STOP**

- Exits an operation.
- **CD**: stops playback or clears a programme.
- **TUNER**: *erases a preset radio station.
- **TAPE**: stops playback or recording.

(only on the main unit)

- *Turns on/off the demonstration mode.

⑧ **▶||**

- **CD**: starts/pauses playback.
- **TAPE**: starts playback or selects other side of the tape during playback.
- **CLOCK**: toggles between hour and minutes setting.

(only on the main unit)

- **TUNER**: *enters Plug & Play mode and/or starts preset radio station installation.

⑨

- Plug in the headphones jack. The speakers output will be cancelled.

* = Press and hold the button for more than two seconds.

10 TUNING ◀◀ ▶▶ (▼ALBUM/TITLE▲)

- **CD:** *searches backward/forward or selects a track.
- **MP3/WMA:** *selects an album or selects a title (track).
- **TUNER:** tunes the radio frequency up/down.
- **TAPE:** rewind or fast forward.
- **CLOCK:** sets the hours or minutes.

11 REC

- *starts recording on a tape.

12 OPEN/CLOSE

- Opens/closes the tape deck door.

13 Tape deck

14 BASS/TREBLE (+ -)

- Selects a desired BASS (low tone) or TREBLE (high tone) level.

15 MASTER VOLUME (VOL + -)

- Adjusts the volume level.

16 CLOCK

- Switches to clock display mode or enter clock setting mode.

17 DIM

- Selects different levels of brightness for display panel.

18 OPEN/CLOSE ▲

- Opens/closes the disc tray.

Control buttons available on the remote only

19 REPEAT

- Repeats a track/disc/all programmed tracks.

20 TAPE A/R

- Selects the desired tape playback modes : one side, both sides or auto replay.

21 ◀ ▶

- **MP3/WMA:** selects an MP3/WMA title (track).
- **CD:** selects a track.
- **TUNER:** selects a preset radio station.
- **TAPE:** selects other side of the tape.

22 ◀ ▶

- **MP3/WMA:** selects an album from MP3/WMA disc.
- **CD:** searches backward/forward.
- **TUNER:** tunes the radio frequency up/down.
- **TAPE:** rewind or fast forward.
- **CLOCK:** sets the hours or minutes.

23 TIMER

- Displays the timer setting or enter timer setting mode.

24 INC. SURR.

- Turns on/off the incredible surround sound effect.

25 MUTE

- Mutes or restores the volume.

26 SLEEP

- Sets the sleep timer function.

27 SNOOZE

- Temporarily deactivate the wake up timer.

28 TIMER ON/OFF

- Turns on/off timer function.

29 NATURAL

- Selects flat sound effect.

30 DISPLAY

- Displays the album and title name for MP3/WMA disc.

31 PROGRAM


- **CD:** starts or confirms tracks programming.
- **TUNER:** starts *automatic/manual preset programming.
- **CLOCK:** selects 12- or 24-hour clock display.

32 SHUFFLE

- Turns on/off random play mode.

33 ⏻

- Switches to Eco Power standby mode.
- *Switches to standby mode.



WARNING!

- Please note that the voltage selector located at the rear of this system is preset at 220V from the factory. For countries that operate at 110V-127V, please adjust to 110V-127V before you switch on the system.
- Use only the supplied speakers. The combination of the main unit and speakers provide the best sound. Using other speakers can damage the unit and sound quality will be negatively affected.
- Never make or change connections with the power switched on.
- Connect the AC power cord to the power outlet only after you have finished hooking up everything.

Step 1: Connecting FM/MW antennas

- Place the MW loop antenna on a shelf or attach it to a stand or wall.
- Extend the FM antenna and fix its ends to the wall.
- Adjust the position of the antennas for optimal reception.
- Position the antennas as far as possible from a TV, VCR or other radiation source to prevent unwanted noise.
- For better FM stereo reception, connect external FM antenna.

Step 2: Connecting the speakers

Connect the speaker wires to the SPEAKERS terminals, right speaker to "R" and left speaker to "L", coloured (marked) wire to "+" and black (unmarked) wire to "-". Fully insert the stripped portion of the speaker wire into the terminal as shown.


Helpful Hints:

- Ensure that the speaker cables are correctly connected. Improper connections may damage the system due to short-circuit.
- Do not connect more than one speaker to any one pair of + / - speaker terminals.

Step 3: Connecting the AC power cord

"AUTO INSTALL - PRESS PLAY" may appear on the display panel when the AC power cord is plugged into the power outlet for the first time. Press ►|| on the main unit to store all available radio stations or press ■ to exit (refer to "Tuner Operations").

Step 4: Inserting batteries into the remote control



- 1 Open the battery compartment cover.
- 2 Insert two batteries type R06 or AA, following the indications (+ -) inside the compartment.
- 3 Close the cover.

Using the remote control to operate the system

- 1 Aim the remote control directly at the remote sensor (iR) on the main unit.
- 2 Select the source you wish to control by pressing one of the source select keys on the remote control (for example CD, TUNER).
- 3 Then select the desired function (for example ►||, ◀, ▶).

CAUTION!

- Remove batteries if they are exhausted or will not be used for a long time.
- Do not use old and new or different types of batteries in combination.
- Batteries contain chemical substances, so they should be disposed of properly.

Basic Operations

Switching on/off

Switching to an active mode

- Press **CD, TUNER, TAPE** or **AUX/CDR**.

Switching to Eco Power standby mode

- Press **⏻**.
 - ECO POWER button lights up.
 - The display screen will go blank.

Switching to standby mode (view clock)

- Press and hold **⏻**.
 - The clock appears.
 - While in standby mode, pressing **CLOCK** button will switch the system to Eco Power standby mode.

Helpful Hint:

– Before switching the system to Eco Power standby or standby mode, make sure you have deactivated the the demonstration mode.

Demonstration mode

If the demonstration mode is active, whenever you switch the system to Eco Power standby or standby mode, it will begin showing the various features offered by the system.

To activate the demonstration


- In Eco Power standby/standby mode, press and hold **■** on the main unit until "DEMO ON" appears.

To deactivate the demonstration

- Press and hold **■** on the main unit until "DEMO OFF" appears.

Setting the clock

The clock can be set in either 12-hour or 24-hour mode ("11:59 PM" or "23:59" for example).



- 1 Press and hold **CLOCK** until the clock time starts flashing.
- 2 Press **PROGRAM** repeatedly to change between 12-hour and 24-hour clock mode.
- 3 Press **◀** or **▶** (◀◀ or ▶▶ on the main set) repeatedly to set the hour.
- 4 Press **⏸** to change to minutes setting, then press **◀** or **▶** (◀◀ or ▶▶ on the main set) repeatedly to set the minutes.
- 5 Press **CLOCK** again to store the setting.
 - The clock will start working.

To view the clock time in any active mode

- Press **CLOCK once**.
 - The clock is displayed for a few seconds.

Helpful Hints:

– The clock setting will be erased when the system is disconnected from the power supply.
– The system will exit clock setting mode if no button is pressed within 90 seconds.

Dimming system's display screen

You can select the desired brightness for the display panel.

- In any active mode, press **DIM** repeatedly to select DIM 1, DIM 2, DIM 3 or DIM OFF display.
→ **DIM** shows on the display screen, except DIM OFF mode.

Volume control

- Adjust **MASTER VOLUME** (or press **VOL +/–** on remote) to increase or decrease the sound level.
→ "VOL MUTE" is the minimum volume level and "0 dB" is the maximum volume level.
- **To switch off the volume temporarily**
- Press **MUTE** on the remote.
→ Playback will continue without sound and "MUTE" appears.
→ To restore the volume, press MUTE again or increase the volume level.

Sound control

Incredible Surround

The Incredible Surround magnifies the virtual distance between the front speakers for an incredibly wide, enveloping, stereo effect.

- Press **INC. SURR.** repeatedly.
→ If activated, **INCREDIBLE SURROUND** shows on the display.
→ If deactivated, "IS OFF" appears.

Bass/Treble

The BASS (low tone) and TREBLE (high tone) feature enables you to define the sound-processor settings.

- Adjust **BASS** or **TREBLE** (or press **BASS + –/TREBLE + –** on the remote) repeatedly to select the desired Bass or Treble level.
→ "BASS XX" or "TREBLE XX" appears.
"XX" denotes the level as follows :
Min → -2 ... → 0 → 1... → +2 → Max ...

Natural (flat sound)

This feature allows you to temporarily switch off the sound setting (e.g. Incredible Surround - OFF, Bass/Treble setting - 0dB).

- Press **NATURAL** on the remote.
→ Pressing the same button will restore the previous sound setting.
→ Pressing INC. SURR or BASS/TREBLE button will turn off the natural sound mode.

IMPORTANT!

- This system is designed for regular discs. Therefore, do not use any accessories such as disc stabiliser rings or disc treatment sheets, etc., as offered on the market, because they may jam the changer mechanism.
- Do not load more than one disc onto the tray.


Playable discs

This system is able to play:

- All pre-recorded audio CDs
- All finalised audio CDR and audio CDRW discs
- MP3-CDs (CD-ROMs with MP3 tracks)
- WMA-CDs (CD-ROMs with WMA tracks)



Loading disc



- 1 Press **OPEN/CLOSE** ▲ button to open the disc tray.
- 2 Load a disc with the label side is facing up. For double-sided discs, load the side you want to play face up.
- 3 Press **OPEN/CLOSE** ▲ button again to close the disc tray.
→ "READING" is displayed. The total number of tracks and the playing time will appear on the display.

Helpful Hint:

- To ensure good system performance, wait until the disc tray completely read the disc before proceeding.

Basic playback controls

Unless stated, all operations described are based on Remote Control use.

To start playback

- Press ►||.

To select a desired track

- Press ◀ or ▶ (◀◀ or ▶▶ on the main set) repeatedly until the desired track is displayed.
→ During random play (shuffle mode), pressing ◀ will not affect the current playback.

To search for a particular passage during playback

- Press and hold ◀◀ or ▶▶ (◀◀◀ or ▶▶▶ on the main set) and release it when the desired passage is located.
→ For CD disc, the volume will be reduced.
→ For MP3/WMA disc, the volume will be reduced.


To interrupt playback

- Press ►||.
→ To resume normal playback, repeat the above.

To stop playback

- Press ■.
→ If the system remains in stop mode for 30 minutes, it will switch to Eco Power standby mode.

Playing an MP3/WMA disc



- 1 Load an MP3/WMA disc.
 - The disc reading time may exceed 10 seconds due to the large number of songs compiled into one disc.
 - "RD2 T000" is displayed. RD is the current album number and 000 is the current title number.
- 2 Press ◀▶ (or press and hold ◀▶▶▶) on the system) to select a desired album.
- 3 Press ◀▶ (or press ◀▶▶▶) on the system) to select a desired title.
- 4 Press ▶|| to start playback.
- During playback, press **DISPLAY** to show the album and title name.

Supported MP3/WMA disc formats:

- ISO9660, Joliet, UDF 1.5
- Maximum title number : 400 (depending on filename length)
- Maximum album number : 40
- Supported sampling frequencies: 32 kHz, 44.1 kHz, 48 kHz
- Supported Bit-rates : 32~256 (kbps), variable bitrates
- ID3 tags : V1.1,V2.2,V2.3,V2.4

IMPORTANT:

- For DRM protected WMA files, use Windows Media Player 10 (or later) for CD burning/conversion. Visit www.microsoft.com for details about Windows Media Player and WM DRM (Windows Media Digital Rights Management).

Repeat and Shuffle

You can select and change the various play modes before or during playback.

Repeat play

- 1 Press **REPEAT** on the remote repeatedly to select :

REPEAT TRACK	REPEAT DISC	REPEAT PROG TRACK	REPEAT PROG
(A)	(B)	(C)	(D)

- (A) – to repeat playback of the current track.
- (B) – to repeat playback of the current disc.
- (C) – to repeat playback of the current programmed track (only if the programme mode is active)
- (D) – to repeat playback of all the programmed tracks (only if the programme mode is active)

- 2 To resume normal playback, press **REPEAT** until "OFF" appears.

Random play

- Press **SHUFFLE** on the remote to turn on/off the shuffling mode.
 - If activated, **SHUFFLE** shows on the display and the repeat mode (if any) will be cancelled.
 - If programme mode is active, only the programmed tracks will be played in random order.


Helpful Hint:

- Pressing the **OPEN/CLOSE** button will cancel all repeat and shuffling modes.

Disc Operations

Programming the disc tracks

Programming tracks is possible when playback is stopped. Up to 99 tracks can be stored in the memory in any order.



- 1 Load the desired disc on the disc tray (refer to "Loading disc").
- 2 Press **CD** to select a disc.
- 3 Press **PROGRAM** to start programming.
→ **PROG** starts flashing.
- 4 Press **◀** or **▶** (**◀◀** or **▶▶** on the main set) repeatedly to select the desired track.
- For MP3/WMA disc, press **◀◀** / **▶▶** and **◀** / **▶** (**◀◀** or **▶▶** on the main set) to select the desired album and title for programming.
- 5 Press **PROGRAM** to store.
- Repeat **steps 4~5** to select other tracks.
→ If you attempt to programme more than 99 tracks, "PROGRAM FULL" appears.
- 6 To start programme play, press **▶||**
- 7 To stop playback or to end the programming, press **■** **once**.
→ **PROG** stays and the programme mode remains active.

Helpful Hints:

- If the total playing time reached 100 minutes or if one of the programmed tracks has a number greater than 30, then "----:--" will appear instead of the total playing time.
- For MP3/WMA discs always display "----:--".
- The system will exit programming mode if no button is pressed within 20 seconds.

Checking the programme

- 1 Stop playback and press **◀** or **▶** (**◀◀** or **▶▶** on the main set) repeatedly.
- 2 Press **▶||** to start playback from the current programmed track.

Clearing the programme

- Stop playback, then press **■** to clear the programme.
OR

Press the **OPEN/CLOSE ▲** button of the disc tray.

→ **PROG** disappears from the display and "PROGRAM CLEAR" appears.

Helpful Hint:

- If the system is disconnected from the power supply or you switch to other source mode, the programme will be erased.

IMPORTANT!

Make sure the FM and MW antennas are connected.

Tuning to radio stations

- 1 Press **TUNER** to enter tuner mode. To select another waveband (FM or MW), press **TUNER** again.
- 2 Press and hold **◀◀** or **▶▶** (**◀◀◀** or **▶▶▶** on the main set) until the frequency indication starts to change, then release.
 - "SEARCH" appears.
 - The system automatically tunes to the next strong signal radio reception.
 - **∞** lights up for FM stereo reception.

For tuning to a weak signal station

- Press **◀◀** or **▶▶** (**◀◀◀** or **▶▶▶** on the main set) briefly and repeatedly until an optimal reception is found.

Presetting radio stations

You can store up to 40 preset radio stations in the memory, starting from FM and followed by MW bands.

Helpful Hints:

- The system will exit presetting mode if no button is pressed within 20 seconds.
- If no stereo frequency is detected during Plug and Play, "CHECK ANTENNA" appears.

Using the Plug and Play

Plug and Play allows you to store all available radio stations automatically.



- 1 Connect the system to the power supply, "AUTO INSTALL - PRESS PLAY" appears.
OR
In Eco Power standby/standby mode, press and hold **▶▶** on the main unit until "AUTO INSTALL - PRESS PLAY" appears.
- 2 Press **▶▶** on the main unit to start installation.
 - "INSTALL TUNER AUTO" appears.
 - All previously stored radio stations will be replaced.
 - Once completed, the last tuned radio station will play.

Tuner Operations

Automatic presetting

You can start the automatic presetting from a selected preset number:

- 1 In tuner mode, press **◀** or **▶** (**◀◀** or **▶▶** on the main set) to select a preset number.
- 2 Press and hold **PROGRAM** until "AUTO" appears.
→ If a radio station is stored in one of the presets, the same radio station will not store under another preset number.
→ If no preset number is selected, automatic preset will begin from preset (1) and all your former presets will be overridden.

Manual presetting

You can choose to store only the favourite radio stations.

- 1 Tune to your desired radio station (refer to "Tuning to radio stations").
 - 2 Press **PROGRAM**.
→ The preset number starts flashing. If you want to store the radio station in another preset number, press **◀** or **▶** (**◀◀** or **▶▶** on the main set).
 - 3 Press **PROGRAM** again to store.
- Repeat **steps 1~3** to store other radio stations.

Selecting a preset radio station

- In tuner mode, press **◀** or **▶** (**◀◀** or **▶▶** on the main set).
→ The preset number, radio frequency, and waveband will appear.

Deleting a preset radio station


- Press and hold **■** until "PRESET DELETE" appears.
→ The current preset radio station will be deleted.
→ All other preset radio stations with higher numbers are decreased by one.

Changing tuning grid *(not available for all versions)*

In North and South America, the frequency step between adjacent channels in the MW band is 10 kHz (9 kHz in some areas). The preset frequency step in the factory is 9 kHz.

IMPORTANT!

Changing the tuning grid will erase all previously stored preset radio stations.



- 1 Disconnect the system from the AC power supply (pull out the AC power cord).
- 2 While holding down **TUNER** and **▶** on the main unit, reconnect the system to the AC power supply.
→ The display will show "GRID 9" or "GRID 10".

Helpful Hints:


- GRID 9 and GRID 10 indicate that the tuning grid is in step of 9 kHz and 10 kHz respectively.
- The FM tuning grid also will be changed from 50 kHz to 100 kHz or vice versa.

IMPORTANT!

- Before playing a tape, check and tighten slack tape with a pencil. Slack tape may get jammed or may burst in the mechanism.
- C-120 tape is extremely thin and is easily deformed or damaged. It is not recommended for use in this system.
- Store the tapes at room temperature and do not put them too close to a magnetic field (for example, a transformer, TV or speaker).

Playing a tape

- 1 Press **TAPE** to select tape mode.
- 2 Press **OPEN/CLOSE**  to open the tape deck door.
- 3 Insert a recorded tape and close the tape deck door:
→ Load the tape with the open side downward and full spool to the left.



- 4 Press **▶||** to start playback.

To change the playback side

- Press **◀** or **▶** on the remote.
→ During playback, you can press **▶||** on the system to change the playback side.
→ **◀** (BACK) or **▶** (FRONT) appears on the display, depending on the tape side selected.

To change the playback mode

- Press **TAPE A/R** on the remote repeatedly to select the different playback modes.
 -  : playback on one side of the tape only.
 -  : both sides are played once.
 -  : both sides are played repeatedly, up to 10 times each side unless you press **■**.

To rewind or fast forward

- 1 Stop playback, then press **◀◀** / **▶▶** (**◀◀** or **▶▶** on the main set) on the remote.
- 2 Press **■** when you reached the desired passage.
→ The tape will stop automatically at the end of rewinding or fast forwarding.

To stop playback



- Press **■**.

Helpful Hint:

- During rewinding or fast forwarding of a tape, it is also possible to select another source (CD or TUNER, for example).

General information on recording

- For recording, use only tape of IEC type I (normal tape).
- The recording level is set automatically, regardless of the position of the Volume, Incredible Surround, BASS/TREBLE and so forth.
- The tape is secured at both ends with leader tape. At the beginning and end of the tape, nothing will be recorded for six to seven seconds.
- To prevent accidental recording, break out the tab on the left shoulder of the tape side you want to protect.
- If "CHECK TAPE" is displayed, the protection tab has been broken. Put a piece of clear adhesive tape over the opening.



Tape Operations/Recording

IMPORTANT!

Recording is permissible if copyright or other rights of third parties are not infringed upon.

Preparation for recording

- 1 Press **TAPE**.
- 2 Load a recordable tape into the tape deck.
- 3 Press **◀** or **▶** on the remote to select the recording tape side.
 - **◀** appears on the display for the reverse side.
 - **▶** appears on the display for the forward side.
- 4 Press **TAPE A/R** on the remote repeatedly to select a recording mode.
 - **↔** for recording on one side only.
 - **↔** for recording on both sides.
- 5 Prepare the source to be recorded.
 - CD** – load the disc.
 - TUNER** – tune to the desired radio station.
 - AUX/CDR** – connect external equipment.

When recording is in progress

- **REC** starts flashing.
- It is not possible to change tape side.
- It is not possible to listen to another source.
- It is not possible to activate the timer function.

One touch recording

- 1 Press **CD**, **TUNER** or **AUX** to select the recording source.
- 2 Start playback of the selected source.
- 3 Press **REC** until **REC** icon starts flashing on the display panel to start recording.

To stop recording

- Press **■** on the system.

Helpful Hint:

– One Touch Recording is not possible in TAPE mode, "SELECT SOURCE" will appear.

CD Synchronised start recording

- 1 Press **CD**.
- If you want to start recording from a desired track, press **◀** or **▶** (**◀◀** or **▶▶** on the main set).
 - You can programme the tracks in the order you want them to be recorded (refer to "CD Operation - Programming the disc tracks").
- 2 Press **REC** to start recording.
 - The disc will start playback automatically.

To select another track during recording

- 1 Press **▶||** to interrupt recording.
- 2 Press **◀** or **▶** to select the desired track.
- 3 Press **▶||** to resume recording.

To stop recording


- Press **■**.
 - Recording and disc playback will stop simultaneously.

Timer setting

The system can switch on to CD, TUNER or TAPE mode automatically at a preset time, serving as an alarm to wake you up.

IMPORTANT!

- Before setting the timer, ensure that the clock is set correctly.
- if recording is in progress, the timer function will not be activated.
- The volume of the timer will increase gradually to the last tuned volume level. If the last tuned volume level is too low, the set will then increase to a predetermined minimum audible level.



- 1 Press **TIMER** on the remote.
→ 🕒 icon starts flashing.
- 2 Press **CD, TUNER** or **TAPE** to select the wake-up source.
→ The selected source will be lighted while other available sources are flashing.
- 3 Press **◀** or **▶** (◀◀ or ▶▶ on the main set) repeatedly to set the hour.
- 4 Press **▶||** to change to minutes setting, then press **◀** or **▶** (◀◀ or ▶▶ on the main set) repeatedly to set the minutes.
- 5 Press **TIMER** to store the setting.
→ Once the timer is set, it will always switch on unless you deactivate it.
→ 🕒 icon remains on the display. It indicates the timer is activated.

- **At the preset time, the selected sound source will be played for 30 minutes before it switches to Eco Power standby mode** (if no button is being pressed within the time frame).
→ **CD** – playing the first track of the disc. If the disc tray is empty, it will switch to Tuner mode.
→ **TUNER** – playing the last tuned radio station.
→ **TAPE** – playing the tape.

Activating/Deactivating the timer

- Press **TIMER ON/OFF** on the remote to turn off the timer or turn on to the last setting again.
→ If activated, the timer information will display for a few seconds, then the system resumes to the last active source or stays in standby mode.
→ If deactivated, "OFF" appears.

Helpful Hint:

- The system will exit timer setting mode if no button is pressed within 90 seconds.

Checking the timer setting

- Press **TIMER** on the remote.
→ The timer information will display for a few seconds, then the system resumes to the last active source or stays in standby mode.

Temporarily deactivating the wake up timer

You are only able to activate the Snooze function within 30 seconds after the timer wake up from standby mode.

- 1 After timer wake up, press **SNOOZE** on the remote.
→ The system will switch to standby mode for five minutes. After that, it resumes the timer last selected source again.
- 2 To cancel the snooze function, press **SNOOZE** again.

Setting the Sleep Timer

The sleep timer enables the system to switch to Eco Power standby mode automatically at a preset time


- 1 Press **SLEEP** on the remote repeatedly until it reaches the desired preset turn-off time.
→ The selections are as follows (time in minutes):
15 → 30 → 45 → 60 → 90 → 120 → OFF → 15 ...
→ **SLEEP** appears on the display, except if "OFF" is selected.
→ To view or change the setting, repeat the above.
- 2 Before the system switches to Eco Power standby mode, a countdown of 10 seconds is displayed.
"SLEEP 10" → "SLEEP 9" ... → "SLEEP 1" → "SLEEP"

To cancel the sleep timer

- Press **SLEEP** repeatedly until "OFF" appears, or press the **STANDBY ON**  button.

Listening to an external source

You can listen to the sound of the connected external device through your system's speakers.



- 1 Use the red/white audio cables to connect the system's **AUX/CDR IN (R/L)** terminals to the AUDIO OUT terminals on the other audio/visual device (such as a TV, VCR, Laser Disc player, DVD player or CD recorder)
→ If the connecting device has only a single audio out terminal, connect it to the AUX/CDR IN left terminal. Alternatively, you can use a "single to double" cinch cable, but the output sounds still remain mono.
- 2 Press **AUX/CDR** repeatedly.
→ Select "AUX" when connecting to a TV, VCR or Laser Disc player.
→ Select "AUX/CDR" when connecting to a CD recorder or DVD player.
- 3 Press **PLAY** on the connected device to start playback.

Helpful Hints:

- All the sound control features (INC SURR, for example) are available for selection.
- Always refer to the owner's manual of the other equipment for complete connection and use details.

AMPLIFIER

Output power	
- MCM9	1800 W PMPO 2 × 50 W RMS ⁽¹⁾
- MCM11	2500 W PMPO 2 × 75 W RMS ⁽¹⁾
Signal-to-noise ratio	≥ 75 dBA (IEC)
Frequency response	50 – 20000 Hz, –3 dB
Input sensitivity	
AUX/CDR In	500 mV/1V
Output	
Speakers	≥ 6 Ω
Headphones	32 Ω – 1000 Ω
(1) (6 Ω, 1 kHz, 10% THD)	

DISC PLAYER

Programmable tracks	99
Frequency response	20 – 20000 Hz, –3 dB
Signal-to-noise ratio	≥ 76 dBA
Channel separation	≥ 60 dB (1 kHz)
MPEG 1 Layer 3 (MP3-CD) MPEG AUDIO	
MP3/WMA-CD bit rate	32-256 kbps (128 kbps advised)
Sampling frequencies	32, 44.1, 48 kHz

TUNER

FM wave range	87.5 – 108 MHz
MW wave range (9 kHz)	531 – 1602 kHz
MW wave range (10 kHz)	530 – 1700 kHz
Tuning grid	9/10 kHz
Number of presets	40
Antenna	
FM	75 Ω wire
MW	Loop antenna

TAPE PLAYER

Frequency response	
CrO ₂ tape (type II)	80 – 12500 Hz, –8 dB
Normal tape (type I)	80 – 12500 Hz, –8 dB
Signal-to-noise ratio	
CrO ₂ tape (type II)	≥ 50 dBA
Normal tape (type I)	≥ 47 dBA
Wow and flutter	≤ 0.4% DIN

SPEAKERS

System	2 way, Bass reflex
Impedance	6 Ω
Woofer	1 × 5.25" Aluminium con woofer
Tweeter (MCM9)	2" Ferro Fluid Cone Dome tweeter
Tweeter (MCM11)	Ribbon tweeter
Dimensions (w × h × d)	
- MCM9	175 × 254 × 196 (mm)
- MCM11	175 × 254 × 215 (mm)
Weight	
- MCM9	3 kg each
- MCM11	3.1 kg each

GENERAL

Material/finish	Polystyrene/Metal
AC Power	
For Version /21-21M	110 – 127 / 220 – 240V; 50/60 Hz Switchable
For Version /30	230 – 240V; 50 Hz
Power Consumption	
Active- MCM9	45 W
- MCM11	40 W
Standby	< 15 W
Eco Power Standby	< 0.6 W
Dimensions (w × h × d)	175 × 252 × 350 (mm)
Weight (without speakers)	5.0 kg

Specifications and external appearance are subject to change without notice.

Troubleshooting

WARNING

Under no circumstances should you try to repair the system yourself, as this will invalidate the warranty. Do not open the system as there is a risk of electric shock.

If a fault occurs, first check the points listed below before taking the system for repair. If you are unable to remedy a problem by following these hints, consult your dealer or Philips for help.

Problem	Solution
Radio reception is poor.	<ul style="list-style-type: none">✓ If the signal is too weak, adjust the antenna or connect an external antenna for better reception.✓ Increase the distance between the system and your TV or VCR.
“NO DISC” is displayed or the disc cannot be played.	<ul style="list-style-type: none">✓ Insert a disc.✓ Load in the disc with label facing up.✓ Replace or clean the disc, see “Care and safety information”.✓ Use a finalised CD-R(W) or a correct format disc.
The system does not react when buttons are pressed.	<ul style="list-style-type: none">✓ Remove and reconnect the AC power cord and switch on the system again.
Recording or playback cannot be made.	<ul style="list-style-type: none">✓ Use only NORMAL (IEC I) tape.✓ Apply a piece of adhesive tape over the missing tab space.
The tape deck door cannot open.	<ul style="list-style-type: none">✓ Remove and reconnect the AC power plug and switch on the system again.
Sound cannot be heard or is of poor quality.	<ul style="list-style-type: none">✓ Adjust the volume.✓ Disconnect the headphones.✓ Check that the speakers are connected correctly.✓ Check that the AC power cord is connected properly.
The remote control does not function properly.	<ul style="list-style-type: none">✓ Select the source (CD or TUNER, for example) before pressing the function button (▶ , ◀◀ ▶▶▶).✓ Reduce the distance between the remote control and the system.✓ Replace the battery.✓ Point the remote control directly toward the IR sensor.
The timer is not working.	<ul style="list-style-type: none">✓ Set the clock correctly.✓ Press TIMER ON/OFF to switch on the timer.✓ If recording is in progress, stop the recording.
The system displays features automatically and buttons start flashing.	<ul style="list-style-type: none">✓ Press and hold DEMO STOP on the main unit to switch off the demonstration mode.