

Always there to help you
Register your product and get support at
www.philips.com/support




Short User Manual

DCM3160







PHILIPS



Specifications are subject to change without notice.
2014 © WOOX Innovations Limited. All rights reserved.
Philips and the Philips' Shield Emblem are registered trademarks of
Koninklijke Philips N.V. and are used by WOOX Innovations Limited
under license from Koninklijke Philips N.V.
DCM3160_79_Short User Manual_V1.0



Before using your product, read all accompanying safety information.





Note:

In standby mode: ON ↔ Standby mode
In Eco power standby mode: ON ↔ Eco power standby mode



ON → Eco power standby mode ↔ Standby mode

After this product stays inactive for 15 minutes, it automatically switches to the normal standby mode.
After this product stays in the normal standby mode for 15 minutes, it automatically switches to the eco power standby mode.



- 1 In standby mode, press and hold **CLOCK** for more than 2 seconds.
- 2 Press **◀▶** to select **24** or **12** hour format, and then press **CLOCK**.
- 3 Press **◀▶** to set the hour, and then press **CLOCK**.
- 4 Press **◀▶** to set the minute, and then press **CLOCK**.





Note: If no button is pressed in 90 seconds during setting, **DCM3160** exits clock setting without saving earlier operations.



Note: Make sure that you have set the clock correctly. If the selected alarm source is unavailable, this product switches to FM mode automatically.

- 1 In standby mode, press and hold **SLEEP/TIMER** for 2 seconds.
- 2 Press **◀▶** to select an alarm source (disc, tuner, usb, or dock), and then press **SLEEP/TIMER** to confirm.
- 3 Press **◀▶** repeatedly to set the hour, and then press **SLEEP/TIMER** to confirm.
- 4 Press **◀▶** to set the minute, and then press **SLEEP/TIMER** to confirm.
- 5 Press **◀▶** to set the alarm volume, and then press **SLEEP/TIMER** to confirm.

To stop the alarm, press **⏻** or **switch to another mode**.
To deactivate the alarm timer, press **SLEEP/TIMER** in standby mode.



Program tracks

This function allows you to program 20 tracks in the desired sequence.

- 1 In DISC or USB mode, press **■** to stop play.
- 2 Press **PROG** to activate the program mode.
- 3 Press **◀▶** to select a track.
 - For MP3 tracks, press **▲▼** to select an album first, and then press **◀▶** to select a track.
- 4 Press **PROG** to confirm.
- 5 Press **▶▶** to play the programmed tracks.

To erase the program

Press **■** twice.

▶▶	Start, pause, or resume play.
■	Stop play.
▲▼	Select an album or a folder.
◀▶	Press to skip to the previous or next track. Press and hold to search backward/forward within a track.
REPEAT/SHUFFLE	To select a repeat play mode: [REPEAT ONE]: play the current track repeatedly. [REPEAT ALB]: play the current album repeatedly. [REPEAT ALL]: play all tracks repeatedly. [SHUFFLE]: play all tracks randomly. [OFF]: Return to normal play.
VOL +/-	Increase or decrease the volume.
MUTE	Mute or restore sound.
SOUND	Enrich sound effect with DSC: balanced, clear, powerful, warm, and bright.
DISPLAY	Adjust display brightness.

