

DECT 214

User Manual







Charge handset(s) for 24 hours before use.

PHILIPS

INSTALLING

DeCT 214



Installing your telephone

◆ Inserting / Replacing battery pack / Telephone connection

Warning: To insert battery pack and /or to connect your telephone, please refer to the drawings printed on the inside cover.

With the help of the installation drawings :

- 1.- Plug the line cord (A) into the line socket on your DECT 214 base station.
Plug the power cable (B) into the power socket on your DECT 214 base station.
Plug the power supply unit into the wall socket.
Connect the telephone line cord into the wall socket.
- 2.- Open the battery door on the handset by sliding it down.
- 3.- Connect the battery pack to the connector inside the handset. Place the battery pack with sticker face up and wires along the left side of the battery pack.
- 4.- Replace the battery door.
- 5.- Put the handset on the base and charge for 24 hours before use.

◆ Charging / Recharging the telephone (See battery status icon on page 4.)

On first use or when inserting a new battery, charge the battery with the handset for **at least 24 hours**. This ensures optimal battery life reached after 3 cycles of charge/uncharge. The battery needs to be charged if you hear a beep when using the telephone. The battery life is about 300 hours in stand-by time and 18 hours in communication.

◆ Configuring the phone for use

Don't change your configuration code if you live in UK or Northern Ireland. Your product is already factory configured with the right settings.

Warning : This product is **ONLY** designed to be used in countries **LISTED** below.

Country		Code
Northern Ireland	 →  →  →  → 44 → 	44
UK		44

Warning : If you live in the country in the table below, you **must** enter the relevant configuration code using the key sequence shown followed by your country code.

Rep. of Ireland	 →  →  →  → 153 → 	153
-----------------	---	-----

For Example to configure for Republic of Ireland :



Advice : If you have bought your product in any of the above countries but want to use it in another one, you can enter the configuration code, according to the above tables, in order to activate the right country settings. Nevertheless, you have to change the telephone line cord adapter according to the country where you want to use it.

Disposal instructions for old products :

The WEEE directive (Waste Electrical and Electronic Equipment; 2002/96/EC) has been put in place to ensure that products are recycled using best available treatment, recovery and recycling techniques to ensure human health and high environmental protection.

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.

Do not dispose of your old product in your general household waste bin.

Inform yourself about the local separate collection system for electrical and electronic products marked by this symbol :



Use one of the following disposal options :

1. Dispose of the complete product (including its cables, plugs and accessories) in the designated WEEE collection facilities.
2. If you purchase a replacement product, hand your complete old product back to the retailer. He should accept it as required by the WEEE directive.

Environment & Safety

◆ **Safety information** : This equipment is not designed for making emergency calls when the power fails. An alternative should be made available for access to emergency calls.

◆ **Power requirements** : The product requires an electrical supply of 220-240 volts, single phase alternating current, excluding IT installations defined in standard EN 60-950.

◆ **WARNING!** The electrical network is classified as dangerous according to criteria in the standard EN 60-950. The only way to power down this product is by unplugging the power supply from the electrical outlet. Ensure the electrical outlet is located close to the apparatus and is always easily accessible.

◆ **Telephone connection** : The voltage on the network is classified as TNV-3 (Telecommunication Network Voltages, as defined in the standard EN 60-950). Following a power cut, date and time settings, as well as the call in progress are lost.

◆ **Safety precautions** : Do not allow the handset to come into contact with liquids. Do not open the handset or the base station. This could expose you to high voltages. Do not allow the charging contacts or the battery to come into contact with conductive materials.

◆ **Environmental care** : Please remember to observe the local regulations regarding the disposal of your packaging materials, exhausted batteries and old phone and where possible promote their recycling

● **You can install your product immediately and start using the phone after charging it for 24 hours.**

● **You need to perform an operator setting if you are not connected to the main operator network in your country. (see page 11)**

● **In case you need to change the battery pack, always use a NiMH AAA 730 x 2 rechargeable battery pack .**

DECT 214 multihandset packs

The information included in this manual are valid for DECT 214 multihandset packs.

Philips has marked the battery and packaging with standard symbols designed to promote the recycling and appropriate disposal of your eventual waste.



Batteries should not be disposed of with general household waste.



A financial contribution has been paid to the associated national recovery & recycling system.



DECT 214

Keypad



Talk key

p 6



Phonebook keys

p 7



Call log key

p 8



Redial list & correction key

p 6



Validation and intercom key

p 9



Loudspeaker key

p 6



Programming and recall type key

p 11



















Volume key


p 6

DECT 214 Base Station

Screen Icons

 Handset ringer settings	p 10
 Handset registering / unregistering	p 11
 Technical settings	p 11
 Battery charge status :  charge in progress -  fully charged -  low	p 1
 Call log / Voicemail Box *	p 8
 Loudspeaker	p 6
 Friend phonebook	p 7
 Call in progress -  Internal call	p 9
 Family phonebook	p 7
 Base / Handset link	p 10
 Alarm	p 12
 Temperature	p 12

* subject to a subscription with your operator



Using the telephone



Making a call

◆ Answering a call / Hanging up



→ answer the call.

To end the conversation, press the key again or replace the handset on the base station.

◆ Calling directly



→ dial the phone number.

◆ Predialling the number before calling

Dial the phone number →



◆ Calling from a phonebook



to scroll through the list

◆ Adjusting the volume (earpiece or loudspeaker)



Using handsfree on the handset



on DECT 2.14 handset

◆ Activating / Deactivating the loudspeaker



Warning: Handsfree activation could suddenly increase the volume in the earpiece to a very high level. Make sure the handset is not too close to your ear.



flashes on an incoming call.

To correct entries use



.

3 volume levels are available for both the earpiece and the loudspeaker.



Using the Redial list and Correction key

◆ Accessing / exiting the redial list



/



to scroll through the redial list to exit

◆ Calling a number from the redial list



to scroll through the redial list

◆ Deleting a number from the redial list



to delete the current entry

to scroll through the redial list

The redial list contains the last 5 numbers called : from the latest to the oldest.

◆ Storing one of the redial list numbers into one of your phonebooks



◆ Number correction



corrects :

- a digit when predialling.
- a digit or a character when entering names in the phonebooks.

A long press on aborts any procedure in progress.



Creating and changing phonebook entries

The telephone has two phonebooks :



A 20-entry family phonebook (see VIP feature p.10)



A 20-entry friends phonebook. (see VIP feature p.10)

◆ Creating an entry

Each entry contains a name (max.10 characters) and a number (max. 16 digits).

1. Enter the phone number and press or .

Note :To insert a pause, long press on .

2. Enter the name and press to validate.

◆ Changing an entry (name)



◆ Changing an entry (number)



◆ Deleting an entry



You can also create an entry from the redial list and the call log*.

Press or to access or exit the phonebooks.

* Subject to a subscription with your operator.

Using the call log

This feature is available if you have registered to the caller identification service with your operator.

The call log stores the last 10 external calls received :

- answered calls
- unanswered calls
- Voicemail box service information *

* Subject to a subscription with your operator.

◆ Accessing / exiting the call log





◆ Consulting the call log

The screen can either display :

- the caller's number *
- the caller's name (if known in the phonebook, or if sent by the network)*
- stars if it is an unidentified call **
- 0 dashes if non recognised number

You can display, the phone number, the time and date of the call

by pressing .

Press  to return to consulting mode.

* Subject to a subscription with your operator for the Caller Line Identification and/or Name Display services.

** Withheld caller identification

◆ Calling a number from the call log




◆ Deleting an entry from the call log




◆ Storing one of the log numbers into your phonebooks



 flashes if there is a new message on the Voicemail box. (subject to a subscription with your operator).

Time and date depends on the network.

Note : If the

 icon keeps on flashing after having consulted all the messages on your Voicemail box and after having read all the call log entries, you can switch them off by deleting the call log entry which corresponds to the message.



Using the intercom

This function can only be used with a multi-handset configuration. It allows you to make free internal calls and transfer external calls from one handset to another.

◆ Internal call





short press to call all the handsets in idle mode.





long press, enter the handset number (1 to 4) to call the selected handset in idle mode.

* If the handset does not belong to the DECT 2.14 range, this function may not be available.

Press  or  to answer or hang up the internal call.

◆ Fast call transfer



During a call in progress you can transfer the call without waiting for the

other handset to pick up:  → .

All the handsets ring.

◆ Call transfer to a specific handset

During a call in progress you transfer the call to a specific handset :

Long press on  → enter the handset number (1 to 4) → .

Intercom & call transfer are only possible with handsets* registered to the same base station.

During transfer, the person on hold will hear music.

4 handsets can be registered to the same base station.



Paging


This feature allows you to locate the handset(s).

Press  on the base station, all the subscribed handsets ring. Once located, press any key on the handset to stop ringing or press  again.




Customising the telephone





Programming the phone

To enter the programming mode press .




Icons representing the menus will then be displayed on the screen :

-  Volume and melody settings (VIP melodies*)
-  Handset registering
-  Other settings

Use  and  to navigate within the menus.


Once the menu is selected with  and  keys, press  to confirm your choice.

Icons : flashing to select the menu and steady once entered in the menu.




Note : Each menu has one or several options. The options will appear on the screen one after the other by pressing . To exit the programming mode at any time press  or  (long press) .

Handset ringer settings




◆ **Ringer Volume (option 1 out of 4 : 1/4)**
 Scroll through the different volume settings using  or  keys. Press  to validate your choice.





*A VIP melody can be associated to each phonebook. When ringing, the VIP melody helps you identify the caller's group.




◆ **Handset Melody (option 2/4)**
 Scroll through the 7 different melodies using  or  keys. Press  to validate.




◆ **Friends phonebook (VIP) Melody* (option 3/4)**
 Scroll through the 7 different melodies using  or  keys. Press  to validate.



 is blinking when selecting the friends phonebook melody.

◆ **Family phonebook (VIP) Melody* (option 4/4)**
 Scroll through the 7 different melodies using  or  keys. Press  to validate.




 is blinking when selecting the family phonebook melody.



* Subject to a subscription with your operator to the Caller Line Identification service.

Handsets registering/unregistering

4 handsets can be registered to the base station. A handset can only be associated with 1 base station.

◆ **To register another handset**
 First enter registration mode by unplugging and plugging back in the power adapter to the electricity supply.



Once the  menu is selected, enter the RC* code written under the base and press  to confirm.

Warning : If you wish to associate a non-Philips handset to the DECT 214 base station, make sure that these handsets are GAP compliant otherwise they will not operate properly.

◆ **To unregister the handset you use**



◆ **To unregister all the handsets (except the handset you are using)**



*RC code (Registration Code) is written under the base.

Warning : Once unregistered, the handset is no longer operational.


Technical settings (country dependent)

If your network operator is not the main national network operator, you may have to change the line settings. Some of the following settings are available subject to a subscription with your operator and also technical availability.

The options on this menu are country dependent and some may not exist in certain countries.


To enter the following settings :  →  or  →  → 

To scroll through the menus

Press  to exit the programming option.

◆ **Changing Caller Identification type**

The Caller Identification service (Name and Number) is available subject to a subscription to your operator (according to availability). (Country dependent)





◆ **Changing the dial mode**



This allows you to select either DTMF tone dialling (faster dialling, access to operator services) or pulse dialling (also called “Loop disconnect” and used in countries without DTMF capability). The default value is TONE. (Country dependent, you may not be able to change to “Pulse”).



◆ **Changing recall type (flash setting)**

The use of some services accessed with  (call waiting, call forward...) will depend on the flash setting (Short/Long) according to your installation type (Public, PABX). (country dependent)



 : Short.
 : Long.

Using the clock on the base

Setting the clock time

◆ **Adjusting the date and time**

Long press  →  or  → 

Adjust second, hour, minute, year, month, day respectively.

The digits to be adjusted flash during the process

Setting the alarm time

◆ **Adjusting the time for alarm alert**

Long press  →  or  → 

The digits to be adjusted flash during the process

Switching off the alarm

◆ **Adjusting / Deactivating the alarm**

 to select  on or off.

◆ **Repeat alarm**



Alarm alert stops temporarily and resumes after 5 minutes.

Alarm alert can be stopped by pressing any keys


Repeat alarm can be repeated for 3 times

Viewing the time

Short press  to activate the display backlight to read time at night.

Changing time format



◆ **12 or 24-hour time format**

 to select

Note: If you have set the 12-hour time format, **a** (ante meridiem) or **p** (post meridiem) are displayed.

Changing temperature units

◆ **°C (degree Celsius) or °F (degree Fahrenheit)**



 to select  in °C (default) or °F

Troubleshooting

◆ Telephone troubleshooting....

● **Please read this user guide carefully before calling your Philips Customer Care Center.**

● **IF NEEDED, check that the appropriate country code is set in the phone :**  →  →  →  (see page 1).

PROBLEMS	CAUSES	SOLUTIONS
- No dialling tone when pressing  .	- The base station is not properly connected to electricity or to the telephone sockets. - Too far from the base station - Battery pack is low (low battery icon is displayed).	- Check the connections.(inside cover). - Move closer to the base - Charge battery pack. (inside cover).
-  icon is blinking.	- The handset is not registered. - The handset is out of range.	- Register the handset to the base station. (p 10) - Move closer to the base station.
- When the handset is placed on the charging unit, no beep is heard.	- The handset is not placed correctly on the base station charging unit. - Charging contacts are dirty.	- Take the handset off the base station and put it back again. - Clean them with a clean and dry cloth.
- Battery icon remains empty although the handset has charged for 24 hours.	Handset battery pack is defective.	Please contact your PHILIPS dealer in order to purchase new rechargeable battery pack.
- No symbol on the display.	- Battery pack is uncharged. - The product is not properly connected	Charge battery pack. (inside cover). Make sure your product is plugged in. (inside cover).
- A phonebook entry has not been memorised.	The phonebook you wish to use is full.	Delete some entries to free memory space.
- Bad audio quality (crackles, muted, echo, etc.).	- Interference from nearby electrical appliance. - Base station installed in a room with thick walls. - You are using the handset too far from the base station.	- Try to plug the base station in elsewhere. - Install the base station in a different room. - Move closer to the base station.
- Caller display does not work.	Service not activated, wrong operator or wrong setting.	Check your subscription with your operator.

◆ Declaration of Conformity :

We,
PHILIPS Consumer Electronics
Route d'Angers
72081 Le Mans Cedex 9
France

Declare that the products DECT214xx are in compliance with ANNEX IV of the R&TTE-Directive 1999/5/EC and then with the following essential requirements :

Article 3.1 a : (protection of the health & the safety of the user)

Safety : EN 60950-1 (10/2001)

SAR : EN 50371 (2002)

Article 3.1 b : (protection requirements with respect to electromagnetic compatibility)

EMC : ETSI EN 301 489-6 V1.2.1 (08/2002) & ETSI EN 301 489-1 V1.4.1 (08/2002)

Article 3.2 : (effective use of the radio spectrum)

Radio : EN 301 406 V1.5.1 (2003)

The presumption of conformity with the essential requirements regarding Council Directive 1999/5/EC is ensured.

Date : 19/08/2005


Le Mans



CE 0682

Quality Manager
DECT & Home Telephony

The product can only be connected to the analogue telephone network in the countries indicated on the back cover of this manual.

The  marking certifies compliance with technical regulations in accordance with the Directive 1999/5/EC for the safety of the user, electromagnetic perturbations and for radio spectrum.

© 2005

Philips Consumer Electronics

DECT & Home Telephony

All rights reserved

Printed in China

www.philips.com



UK

3 1 1 1 2 8 5 2 5 6 7 1