

Register your product and get support at

www.philips.com/welcome

CSS9216



User manual

Benutzerhandbuch

Mode d'emploi

Brukerhåndbok

Manual del usuario

Användarhandbok

Εγχειρίδιο χρήσης

Brugervejledning

Gebruiksaanwijzing

Manuale utente

Manual do utilizador

Käyttöopas

Kullanım kılavuzu

PHILIPS

Contents

1 Help and support	2
FAQs	2
Contact Philips	2

2 Notice	2
Compliance	2
Mains fuse	3
Trademarks	3

3 Important	3
Safety	3
Care for your product	4
Care of the environment	4

4 Your SoundHub	5
Main unit	5
Subwoofer	5
Remote control	5

5 Connect your SoundHub	6
Connect speakers	6
Connectors	7
Connect audio from TV and other devices	8
Listen to a connected device	8
Connect to a Wi-Fi network	8

6 Use your SoundHub	13
Choose your sound	13
MP3 player	14
Play audio from an AirPlay device	14

7 Change settings	15
Setup menu options and settings	15
Apply factory settings	16

8 Update software	17
Check software version	17
Update software through computer	17

9 Product specifications	17
---------------------------------	----

10 Troubleshooting	18
---------------------------	----

11 Index	19
-----------------	----

1 Help and support

FAQs

If you have a problem, refer to the frequently asked questions (FAQs) for this SoundBar at www.philips.com/support.
If you still need help, contact Philips Consumer Care in your country.



Warning

- Do not attempt to repair your SoundBar yourself. This may cause severe injury, irreparable damage to your SoundBar, or void your warranty.

Contact Philips

If you contact Philips, you will be asked for the model and serial number of your product. The model number and serial number are on the back or bottom of your product. Note the numbers before you call Philips:
Model No. _____
Serial No. _____


2 Notice

This section contains the legal and trademark notices.

Compliance



This product is in compliance with the essential requirements and other relevant provisions of Directives 2006/95/EC (Low Voltage), 2004/108/EC (EMC).



* Wireless and Ethernet LAN functions are authorized for indoor use only.

Hereby, Philips Consumer Lifestyle, declares that this product (CSS9216) is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

A copy of the EC declaration of Conformity is available in the Portable Document Format (PDF) version of the user manual at www.philips.com/support.

Mains fuse

This information applies only to products with a UK mains plug.

This product is fitted with an approved molded plug. If you replace the fuse, use one with:

- the ratings shown on the plug,
- a BS 1362 approval, and
- the ASTA approval mark.

Contact your dealer if you are not sure about what type of fuse to use.

Caution: To conform with the EMC directive (2004/108/EC), do not detach the plug from the power cord.

Trademarks



Manufactured under license under U.S. Patent Nos: 5,956,674; 5,974,380; 6,487,535 & other U.S. and worldwide patents issued & pending. DTS, the Symbol, & DTS and the Symbol together are registered trademarks & DTS Digital Surround and the DTS logos are trademarks of DTS, Inc. Product includes software. © DTS, Inc. All Rights Reserved.



Manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories.



The Wi-Fi CERTIFIED Logo is a certification mark of the Wi-Fi Alliance.

3 Important

Read and understand all instructions before you use your SoundHub. If damage is caused by failure to follow instructions, the warranty does not apply.

Safety

Risk of electric shock or fire!

- Never expose the product and accessories to rain or water; Never place liquid containers, such as vases, near the product. If liquids are spilt on or into the product, disconnect it from the power outlet immediately. Contact Philips Consumer Care to have the product checked before use.
- Never place the product and accessories near naked flames or other heat sources, including direct sunlight.
- Never insert objects into the ventilation slots or other openings on the product.
- Where the mains plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.
- Disconnect the product from the power outlet before lightning storms.
- When you disconnect the power cord, always pull the plug, never the cable.

Risk of short circuit or fire!

- Before you connect the product to the power outlet, ensure that the power voltage matches the value printed on the back or bottom of the product. Never connect the product to the power outlet if the voltage is different.

Risk of injury or damage to the SoundHub!

- For wall-mountable products, use only the supplied wall mount bracket. Secure the wall mount to a wall that can support the combined weight of the product and the wall mount. Koninklijke Philips Electronics N.V. bears no responsibility for improper wall mounting that results in accident, injury or damage.
- Never place the product or any objects on power cords or on other electrical equipment.
- If the product is transported in temperatures below 5°C, unpack the product and wait until its temperature matches room temperature before connecting it to the power outlet.

- Parts of this product can be made of glass. Handle with care to avoid injury and damage.

Risk of overheating!

- Never install this product in a confined space. Always leave a space of at least four inches around the product for ventilation. Ensure curtains or other objects never cover the ventilation slots on the product.

Risk of contamination!

- Do not mix batteries (old and new or carbon and alkaline, etc.).
- Danger of explosion if batteries are incorrectly replaced. Replace only with the same or equivalent type.
- Remove batteries if they are exhausted or if the remote control is not to be used for a long time.
- Batteries contain chemical substances, they should be disposed of properly.

Risk of swallowing batteries!

- The product/remote control may or may not contain a coin/button type battery, which can be swallowed. Keep the battery out of reach of children at all times! If swallowed, the battery can cause serious injury or death. Severe internal burns can occur within two hours of ingestion.
- If the battery has been swallowed, seek immediate medical attention.
- When you change the batteries, always keep all new and used batteries out of reach of children. Ensure that the battery compartment is completely secure after you replace the battery.
- If the battery compartment cannot be completely secured, discontinue use of the product. Keep out of reach of children and contact the manufacturer:

Care of the environment



Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.



When this crossed-out wheeled bin symbol is attached to a product it means that the product is covered by the European Directive 2002/96/EC. Please inform yourself about the local separate collection system for electrical and electronic products.

Please act according to your local rules and do not dispose of your old products with your normal household waste.

Correct disposal of your old product helps to prevent potential negative consequences for the environment and human health.



Your product contains batteries covered by the European Directive 2006/66/EC, which cannot be disposed with normal household waste.

Please inform yourself about the local rules on separate collection of batteries because correct disposal helps to prevent negative consequences for the environmental and human health.


Care for your product

Use only microfiber cloth to clean the product.

4 Your SoundHub


Congratulations on your purchase, and welcome to Philips! To fully benefit from the support that Philips offers, register your SoundHub at www.philips.com/welcome.

Main unit




- ① Standby indicator
- ② Display panel

Subwoofer



- ① **LED indicator**
 - When the SoundHub is on standby, the **LED indicator** is red.
 - When the SoundHub is on, the **LED indicator** is white.
 - When the SoundHub is connecting to the network, the **LED indicator** blinks.

Remote control



- ① **⏻ (Standby-On)**
Switch the SoundHub on or to standby.
- ② **AUX**
Switch your audio source to the AUX connection.
- ③ **MUSIC iLINK**
Switch your audio source to the MUSIC iLINK connection.

- 4 **Navigation buttons** (◀/▶/▲/▼)
Navigate menus.
- 5 **OK**
Confirm an entry or selection.
- 6 **AUDIO SYNC**
Change the audio delay.
- 7 **NIGHT MODE**
Turn night mode on or off.
- 8 **⊘ (Mute)**
Mute or restore volume.
- 9 **+/- (Volume)**
Increase or decrease volume.
- 10 **TREBLE +/-**
Increase or decrease treble.
- 11 **BASS +/-**
Increase or decrease bass.
- 12 **SURR. SOUND**
Switch to auto, stereo, or 360 surround sound.
- 13 **AUTO VOLUME**
Turn auto volume on or off.
- 14 **SOUND MODE**
Select a sound mode.
- 15 **EXIT**
Exit a menu.
- 16 **SETUP**
 - Access the setup menu.
 - Press and hold to switch to Wi-Fi protected setup (WPS) mode.
- 17 **COAXIAL/OPTICAL**
Switch your audio source to the coaxial or optical connection.

5 Connect your SoundHub

This section helps you connect your SoundHub to a TV and other devices.

For information about the basic connections of your SoundHub and accessories, see the quick start guide. For a comprehensive interactive guide, see www.connectivityguide.philips.com.


Note

- For identification and supply ratings, see the type plate at the back or bottom of the product.
- Before you make or change any connections, make sure that all devices are disconnected from the power outlet.

Connect speakers

The speaker cables are color-coded for easy connection. To connect a speaker to your SoundHub, match the color on the speaker cable to the color on the connector.

Speaker position plays a critical role in setting up a surround sound effect. For best results, place your speakers and the subwoofer as shown below.



Note

- Surround sound depends on various factors such as room shape and size, type of wall and ceiling, windows and reflective surfaces, and speaker acoustics.

Follow these general guidelines, and then set up your subwoofer:

- Seating position:**
This is the center of your listening area.
- SPEAKER LEFT** (speaker left) and **SPEAKER RIGHT** (speaker right) speakers:
Place the left and right speakers in the front, and equidistant from the main unit in an arc, so that the two speakers are at same distance from your seating position. For best effect, point the speakers towards the seating position and place the speakers close to the ear level (when seated).
- SUBWOOFER** (subwoofer):
Place the subwoofer at least one meter to the left or right of the TV. Leave about ten centimeter clearance from the wall.

Setup


Set up your subwoofer through the setup menu.

- Press **SETUP** repeatedly to select **SUBW VOL** on the display panel.
- Press **OK**.
- Press the **Navigation buttons** (▲ / ▼) to change the volume.
- Press **OK** to confirm.
- Press **EXIT** to exit the menu.

Connectors


Connect other devices to your SoundHub.

Side right




- MUSIC iLINK**
Audio input from an MP3 player.

Rear connectors - main unit



- SUBWOOFER**
Connect to the supplied subwoofer.
- AUDIO IN-AUX 1/AUX 2**
Connect to an analog audio output on the TV or an analog device.
- DIGITAL IN-COAXIAL**
Connect to a coaxial audio output on the TV or a digital device.
- DIGITAL IN-OPTICAL**
Connect to an optical audio output on the TV or a digital device.

Rear connectors - subwoofer



- SPEAKERS-RIGHT/LEFT**
Connect to the supplied speakers.
- TO MAIN UNIT**
Connect to the main unit.
- AC MAINS~**
Connect to the power supply.

Connect audio from TV and other devices

Play audio from TV or other devices through your SoundHub.
Use the best quality connection available on other devices.


Note

- The audio connections in this user manual are only recommendations. You can use other connections too.

Option 1: Connect audio through a digital optical cable

Best quality audio


Using an optical cable, connect the **OPTICAL** connector on your SoundHub to the **OPTICAL OUT** connector on the device.
The digital optical connector might be labeled **SPDIF**, **SPDIF OUT**, or **OPTICAL**.



Option 2: Connect audio through a digital coaxial cable

Good quality audio


Using a coaxial cable, connect the **COAXIAL** connector on your SoundHub to the **COAXIAL/DIGITAL OUT** connector on the device.
The digital coaxial connector might be labeled **DIGITAL AUDIO OUT**.



Option 3: Connect audio through analog audio cables

Basic quality audio

Using an analog cable, connect the **AUX** connectors on your SoundHub to the audio connectors on the device.



Listen to a connected device

Before you can listen to a connected device, select the source for the device.

- 1 Press **AUX**, **COAXIAL/OPTICAL**, or **MUSIC iLINK** on the remote control to cycle through and select an audio source, as shown in the following table.

Source button	Display text	Audio source
AUX	AUX1 or AUX2	AUX input
COAXIAL/OPTICAL	COAX IN or OPTI IN	Coaxial or Optical input
MUSIC iLINK	I-LINK	MP3 input

Connect to a Wi-Fi network

Connect your SoundHub, AirPlay device and computer to the same Wi-Fi network to enjoy:

- Wireless music streaming from your AirPlay enabled device to your SoundHub.
- Update your SoundHub software through the computer.

! Caution

- Before you try to connect the SoundHub to a computer network, familiarize yourself with the network router, media server software, and network principles. If necessary, read documentation that accompanies the network components. Philips is not responsible for lost, damaged, or corrupt data.

What you need

- A wireless network router.
- An AirPlay enabled device:
 - iOS 4.3 and above on iPhone, iPod touch, or iPad.
 - iTunes 10.2 or later on Wi-Fi enabled computer.

Before you start

- Make sure that the wireless router is switched on and works properly.
- Check the type of wireless router you use. Some operations may vary when different types of wireless routers are used.

Connect SoundHub to a Wi-Fi network

Depending on the type of the router, connect your SoundHub to the Wi-Fi network in one of the following ways.

The SoundHub automatically connects to the last used Wi-Fi setup every time it is switched on.

Option 1: Connect SoundHub to a WPS router

Wi-Fi protected setup (WPS) enables you to connect devices to your router without a password. Simply enable the WPS function on both the router and your SoundHub and they are connected. Most of the WPS router carry the WPS logo: .

- 1 Press and hold **SETUP** for five seconds to switch to the WPS mode.
 - ↳ **PRESS WPS BUTTON ON ROUTER AND WAIT** is displayed on the display panel.
 - ↳ The subwoofer **LED indicator** blinks continuously.
- 2 Within ninety seconds, press the WPS button once on the router.
- 3 When the connection with the router is established, **WPS SUCCESS** is displayed on the display panel.

- 4 When the SoundHub joins the Wi-Fi network successfully, **READY FOR AIRPLAY** is displayed on the display panel.
 - ↳ The subwoofer **LED indicator** stops to blink and stays white.
- 5 If the connection fails or you are unable to press the WPS button on the router within ninety seconds, **WPS FAILED** is displayed on the display panel. Repeat steps 1 to 4 again.

☰ Note

- To enable AirPlay, make sure that your AirPlay device is connected to the same network as the SoundHub.


Option 2: Connect SoundHub to a non WPS router

Connect your SoundHub to a non WPS router through an AirPlay enabled device.


- 1 Press **SETUP** repeatedly to select **WIFI** on the display panel.
- 2 Press **OK**.
- 3 Press the **Navigation buttons** (**▲** / **▼**) to select **BROWSER SETUP**, and then press **OK**.
 - ↳ First, **PLEASE WAIT** is displayed on the display panel and the subwoofer **LED indicator** blinks continuously.
 - ↳ Then, the SoundHub creates a virtual network and **SELECT PHILIPS AIRPLAY NETWORK AND BROWSE 192.168.1.12** is displayed on the display panel. When you connect your AirPlay enabled device to this network, you can access the SoundHub setup web page.
- 4 On your iPod Touch, iPhone or iPad, select **Settings > Wi-Fi**.
 - On your Wi-Fi enabled computer, select the list of available wireless networks.





- 5 Select **Philips SoundHub AirPlay** (Philips SoundHub AirPlay) from the list of available wireless networks.




- 6 On your iPod Touch, iPhone or iPad, open **Safari** (Safari) to access the configuration page. Enter the IP address **192.168.1.12** at the address bar:
- On your computer, open the web browser and enter **192.168.1.12** at the address bar.
- ↳ The SoundHub web page is displayed. This page allows you to configure the SoundHub by connecting it to your home network.



- 7 From the Philips SoundHub web page, select the **Network Configuration** (network configuration) tab.



- 8 Select your router SSID from the pull-down list of **Service Set ID (SSID)** (service set ID).




- 10 Click **Apply** (apply) at the bottom of the page to apply your settings.
↳ A menu for confirmation of your settings pops up.



- 9 Enter your network key if required.
- For some routers, you may also need to tick **DHCP** under **Advance Setting** (advance setting).

- 11 Click **OK** on the popup menu to confirm your settings.



- ↳ **CONNECTING** is displayed on the display panel. The connection to the Philips SoundHub AirPlay network is lost because your SoundHub is connecting to the selected network.
- ↳ After the SoundHub joins the Wi-Fi network successfully, **READY FOR AIRPLAY** is displayed on the display panel. The subwoofer LED indicator stops to blink and stays white.
- ↳ If the connection fails, **NO CONNECTION** is displayed on the display panel. Repeat steps 1 to 11 again.

Note

- To enable AirPlay, make sure that your AirPlay device is connected to the same network as the SoundHub.

Connect an AirPlay device to the same Wi-Fi network

Connect your AirPlay device to the same network as the SoundHub.

- 1 On your iPod Touch, iPhone, or iPad, select **Settings > Wi-Fi**.
 - On your computer, select the list of available wireless networks.



- 2 Select your router SSID from the list of available wireless networks.



6 Use your SoundHub

This section helps you use the SoundHub to play audio from connected devices.

Before you start

- Make the necessary connections described in the quick start guide and the user manual.
- Switch the SoundHub to the correct source for other devices.

Choose your sound

This section helps you choose the ideal sound for your video or music.

Sound mode

Select predefined sound modes to suit your video or music.

- 1 Press **SOUND MODE** repeatedly to select a sound setting within three seconds on the display panel:
 - **AUTO**: Automatically select **MOVIE** or **MUSIC** based on the sound stream.
 - **MOVIE**: Enjoy a cinematic audio experience, specially enhanced for movies.
 - **MUSIC**: Recreate the original recording environment of your music, in the studio or at a concert.
 - **NEWS**: Hear every word with optimized speech and clear vocals.
 - **GAMING**: Enjoy thrilling arcade sounds, ideal for action-packed video games or loud parties.
 - **ORIGINAL**: Experience the original sound of your movies and music, without added sound effects.

Auto volume

Turn the auto volume on to keep the volume constant when you switch to a different source.

- 1 Press **AUTO VOLUME** repeatedly to select a setting within three seconds on the display panel:
 - **ON**: Turn on auto volume.
 - **OFF**: Turn off auto volume.

Night mode

For quiet listening, decrease the volume of loud sounds when you play discs. Night mode is only available for Dolby encoded DVD and Blu-ray discs.

- 1 Press **NIGHT MODE** repeatedly to select a setting within three seconds on the display panel:
 - **ON**: Turn on night mode.
 - **OFF**: Turn off night mode.



Note

- If auto volume is set to **ON**, you cannot enable the night mode.

Synchronize picture and sound

If the audio and video are not synchronized, delay the audio to match the video.

- 1 Press **AUDIO SYNC**.
- 2 Within two seconds, press the **Navigation buttons** (▲ / ▼) to change the delay shown on the display panel.
- 3 Press **AUDIO SYNC** again to exit.

Surround sound mode

Experience an immersive audio experience with surround sound modes.

- 1 Press **SURR. SOUND** repeatedly to select a setting within three seconds on the display panel:
 - **AUTO**: Surround sound based on the audio stream.
 - **STEREO**: Two-channel stereo sound. Ideal for listening to music.
 - **360SOUND**: Surround sound for best cinematic experience.



Note

- If you play a source with DTS, **DTS** is displayed on the display panel for two seconds.
- If you play a source with Dolby, **DOLBY D** is displayed on the display panel for two seconds.

Equalizer

Change the high frequency (treble) and low frequency (bass) settings of your SoundHub.

- 1 Press **TREBLE +/-** or **BASS +/-** within three seconds to change the frequency shown on the display panel.

MP3 player

Connect your MP3 player to play your audio files or music.

What you need

- An MP3 player.
- A 3.5mm stereo audio cable.

Play music

- 1 Connect the MP3 player to the SoundHub as described in the Quick start guide.
- 2 Press **MUSIC iLINK**.
↳ **I-LINK** is displayed on the display panel.
- 3 Press the buttons on the MP3 player to select and play audio files or music.


Play audio from an AirPlay device

Your SoundHub has an integrated AirPlay receiver that lets you stream music wirelessly from the Airplay enabled device.

Before you start

- Connect the AirPlay device to the same Wi-Fi network as the SoundHub (see 'Connect to a Wi-Fi network' on page 8).


- 1 On your iPod Touch, iPhone, or an iPad, open **iPod** (iPod).
 - On a computer; open iTunes 10.2 and above.
- 2 Tap or click the AirPlay icon.



- 3 Select **PHILIPS SoundHub** (Philips SoundHub) from the list.



- 4 Select and play audio file from your AirPlay device.



- 5 To control play from your AirPlay device, use the play buttons on your AirPlay device.

7 Change settings

This section helps you to change the settings of your SoundHub.

! Caution

- The settings are already configured for optimal performance. Unless you have a reason to change a setting, we recommend that you keep the default setting.

Setup menu options and settings

Setup menu option	Setting for the option
SUBW VOL	+5, +4, +3, ..., 0, ..., -3, -4, -5
DISPLAY	BRIGHT
	DIM 1
	DIM 2
SLEEP	OFF, 15 MIN, 30 MIN, 45 MIN, 60 MIN
WIFI	WPS
	BROWSER SETUP
IP ADDR	
VERSION	
RESET DEFAULT SETTINGS	

- 1 Press **SETUP** repeatedly to cycle through the options on the display panel.
- 2 Select an option, and then press **OK**.
- 3 Press the **Navigation buttons** (**▲** / **▼**) to select a setting for the option, and then press **OK**.

☰ Note

- If you do not press a button within ten seconds, the setup menu exits.
- To exit the menu, press **EXIT**.
- WIFI**, **IP ADDR**, and **RESET DEFAULT SETTINGS** are available about forty seconds after the SoundHub is switched on.

Display panel

Change the brightness of the SoundHub display panel.

- 1 Press **SETUP** repeatedly to select **DISPLAY** on the display panel.
- 2 Press **OK**.
- 3 Press the **Navigation buttons** (▲ / ▼) to select **BRIGHT**, **DIM 1**, or **DIM 2**, and then press **OK**.

Sleep timer

Set timers to switch the SoundHub to standby after a specified time.

- 1 Press **SETUP** repeatedly to select **SLEEP** on the display panel.
- 2 Press **OK**.
- 3 Press **Navigation buttons** (▲ / ▼) to set a sleep time on the display panel.
 - ↳ The sleep timer can be set up to 60 minutes. If the sleep timer is set to **OFF**, it switches off.



Note

- If you switch the SoundHub to standby, the sleep time that you have set is canceled.

IP address

Check the IP address if the SoundHub is successfully connected to the network.

- 1 Press **SETUP** repeatedly to select **IP ADDR** on the display panel.
- 2 Press **OK**.
 - ↳ The current IP address is displayed.



Note

- If the network connection fails or not yet connected, **NO CONNECTION** is displayed when **IP ADDR** is selected.

Apply factory settings

You can reset your SoundHub to the default settings programmed at the factory.

- 1 Press **SETUP** repeatedly to select **RESET DEFAULT SETTINGS** on the display panel.
- 2 Press **OK**.
 - ↳ **TO RESET PRESS OK** is displayed on the display panel.
- 3 Press **OK** again.
 - ↳ When the default settings are restored, **RESET OK** is displayed on the display panel, and the SoundHub automatically switches off and restarts.

8 Update software

To continue to get the best features and support for your SoundHub, update the software regularly. Compare the version of your current software with the latest version on www.philips.com/support.

Check software version

- 1 Press **SETUP** repeatedly to select **VERSION** on the display panel.
- 2 Press **OK**.
↳ The software version is displayed.

Update software through computer

Log in to your SoundHub web page to perform the software update.

- 1 Make sure that the SoundHub and computer are connected to the same Wi-Fi network (see 'Connect to a Wi-Fi network' on page 8).
- 2 Open a web browser on your computer.
- 3 Check and enter the IP address to access the configuration page (see 'IP address' on page 16).
- 4 Select the firmware update tab.
↳ The current firmware version is displayed.
- 5 If a newer version is available, download it from www.philips.com/support, and then click **OK**.
↳ A new page is displayed. Your SoundHub prepares for the firmware update.
- 6 Click **Select file** (Select file) and locate the firmware that you downloaded from www.philips.com/support.
- 7 Click **OK** to start the software update. Wait until the upgrade is complete.
↳ A new page is displayed when the upgrade is complete. Your SoundHub loads the new firmware, reconnects to your home network, and enables AirPlay.

9 Product specifications

Note

- Specifications and design are subject to change without notice.

Amplifier

- Total output power:
 - Europe and Asia: 400W RMS (30% THD)
 - Latin America: 320W RMS (10% THD)
- Frequency response: 20 Hz-20 kHz / ± 3 dB
- Signal-to-noise ratio: > 65 dB (CCIR) / (A-weighted)
- Input sensitivity:
 - AUX1, AUX2: 450 mV
 - Music iLink: 170 mV

Audio

- S/PDIF Digital audio input:
 - Coaxial: IEC 60958-3
 - Optical: TOSLINK

Main unit

- Dimensions (WxHxD): 150 x 41 x 126 mm
- Weight: 0.4 kg

Subwoofer

- Output power: 100W RMS (30% THD)
- Power supply: 220-240 V~, 50 Hz
- Power consumption: 55 W
- Standby power consumption: ≤ 0.5 W
- Impedance: 4 ohm
- Speaker drivers: 165 mm (6.5") woofer
- Frequency response: 20 Hz-150 Hz
- Dimensions (WxHxD): 196 x 397 x 357 mm
- Weight: 7.6 kg
- Cable length: 3 m

Speakers

- Output power: 2 x 150W RMS (30%THD)
- Speaker impedance: 6 ohm
- Drivers per speaker: 2 x 64 mm (2.5") full range woofer + 1 x 64 mm (2.5") woofer + 1 x 25.4 mm (1") soft-dome tweeter
- Frequency response: 150 Hz-20 kHz
- Dimensions (WxHxD): 99 x 247 x 117 mm
- Weight: 1.4 kg/each
- Cable length: 5 m

Remote control batteries

- 2 x AAA-R03-1.5V

10 Troubleshooting



Warning

- Risk of electric shock. Never remove the casing of the product.

To keep the warranty valid, never try to repair the product yourself.

If you have problems using this product, check the following sections before you request service. If you still have a problem, register your product and get support at www.philips.com/welcome.

Sound

No sound from SoundHub.

- Make sure that the SoundHub is not muted. Press  to select **MUTE OFF** on the display panel.
- Connect the audio cable from your SoundHub to your TV or other devices.
- Reset your SoundHub to its factory settings, and then switch it off and switch on again.
- On your remote control, press **AUX**, **COAXIAL/OPTICAL**, or **MUSIC iLINK** repeatedly to select the correct audio input on the display panel (see 'Listen to a connected device' on page 8).

Distorted sound or echo.

- If you play audio from the TV through the SoundHub, make sure that the TV is muted.

Audio and video are not synchronized.

- 1) Press **AUDIO SYNC**. 2) Within two seconds, press the **Navigation buttons** ( / ) to change the delay shown on the display panel. 3) Press **AUDIO SYNC** again to exit.

Play

AirPlay icon does not appear in iTunes.

- Make sure that the AirPlay device is connected to the same network as the SoundHub.
- Make sure that the network connection is connected successfully.
- Restart the **iPod** (iPod) application on your Airplay device.

Break AirPlay music streaming frequently.

- Make sure that the Auto channel scan option is enabled (if available on the Wi-Fi router).

- Make sure that the Wireless Intelligent Stream Handling (WISH) option is enabled (if available on the Wi-Fi router).
- Make sure that the Quality of Service (QoS) option is enabled (if available on the Wi-Fi router).
- Turn off other home routers.

Network

Wireless network distorted or not found.

- Make sure that your Wi-Fi router is Wi-Fi certified. The SoundHub is only compatible with Wi-Fi certified routers.
- Your SoundHub does not support WPS-Pin routers.
- Your SoundHub does not support all WPS-PBC routers. If your home routers are WPS-PBC routers, reset all settings in your router:
- Make sure that your router SSID name consists of normal characters or digits, with no space or special characters, such as %/#/*, inserted.
- Make sure that SSID broadcast on the Wi-Fi router is enabled.
- Make sure that the wireless network is not disturbed by microwave ovens, DECT phones, or other neighboring Wi-Fi devices.
- Make sure that there is no overlap between your wireless network and other nearby networks.

Wi-Fi setup page not found.

- Make sure that you enter the correct IP address (see 'IP address' on page 16).

RESTARTING appears on the display panel.

- SoundHub restarts automatically due to critical firmware problem.

GETTING IPADDRESS appears on the display panel.

- The SoundHub is obtained IP address from the DHCP server.

11 Index

A

AirPlay	
audio	14
Wi-Fi network	8
amplifier	17
audio	
auto volume	13
night mode	13
sound mode	13
specifications	17
surround sound mode	13
audio source	
remote control	8

B

brightness	16
-------------------	----

C

care	
environment	4
product	4
check current version	17
compliance	2
connect	
audio (analog cable)	8
audio (coaxial cable - digital)	8
audio (optical cable - digital)	8
audio from TV and other devices	8
non WPS router	9
Wi-Fi network	9
WPS router	9
connectors	
back connectors - main unit	7
back connectors - subwoofer	7
side connector	7

D

disable	
auto volume	13
night mode	13
display panel	5

E	
enable	
auto volume	13
night mode	13

F	
factory settings	16
FAQs	2

L	
legal notices	2

M	
main unit	
overview	5
specifications	17
mains fuse (UK only)	3
MP3	
play	14

N	
night mode	13

O	
overview	
connectors	7
main unit	5
remote control	5

P	
play	
from AirPlay device	14
MP3	14
troubleshooting	18
position	
connectors	7

R	
recycling	4
remote control	
batteries	18
overview	5

S	
safety	
disposal	4
use of the product	3
setup menu	
check current version	17
sleep timer	16
subwoofer volume	7
software	
check current version	17
update	17
sound	
predefined sound mode	13
surround sound mode	13
synchronize picture and sound	13
troubleshooting	18
SSID	12
subwoofer	
setup	7
subwoofer volume	7
synchronize picture and sound	13

T	
trademarks	3
troubleshooting	
play	18
sound	18

U	
update software	
check current version	17
from PC or Mac	17

V	
video	
synchronize picture and sound	13

Language Code

Abkhazian	6566	Inupiaq	7375	Pushto	8083
Afar	6565	Irish	7165	Russian	8285
Afrikaans	6570	Íslenska	7383	Quechua	8185
Amharic	6577	Italiano	7384	Raeto-Romance	8277
Arabic	6582	Ivrit	7269	Romanian	8279
Armenian	7289	Japanese	7465	Rundi	8278
Assamese	6583	Javanese	7486	Samoan	8377
Avestan	6569	Kalaallisut	7576	Sango	8371
Aymara	6589	Kannada	7578	Sanskrit	8365
Azerbaijani	6590	Kashmiri	7583	Sardinian	8367
Bahasa Melayu	7783	Kazakh	7575	Serbian	8382
Bashkir	6665	Kernewek	7587	Shona	8378
Belarusian	6669	Khmer	7577	Shqip	8381
Bengali	6678	Kinyarwanda	8287	Sindhi	8368
Bihari	6672	Kirghiz	7589	Sinhalese	8373
Bislama	6673	Komi	7586	Slovensky	8373
Bokmål, Norwegian	7866	Korean	7579	Slovenian	8376
Bosanski	6683	Kuanyama; Kwanyama	7574	Somali	8379
Brezhoneg	6682	Kurdish	7585	Sotho; Southern	8384
Bulgarian	6671	Lao	7679	South Ndebele	7882
Burmese	7789	Latina	7665	Sundanese	8385
Castellano, Español	6983	Latvian	7686	Suomi	7073
Catalán	6765	Letzeburgesch;	7666	Swahili	8387
Chamorro	6772	Limburgan; Limburger	7673	Swati	8383
Chechen	6769	Lingala	7678	Svenska	8386
Chewa; Chichewa; Nyanja	7889	Lithuanian	7684	Tagalog	8476
中文	9072	Luxembourgish;	7666	Tahitian	8489
Chuang; Zhuang	9065	Macedonian	7775	Tajik	8471
Church Slav; Slavonic	6785	Malagasy	7771	Tamil	8465
Chuvash	6786	Magyar	7285	Tatar	8484
Corsican	6779	Malayalam	7776	Telugu	8469
esky	6783	Maltese	7784	Thai	8472
Dansk	6865	Manx	7186	Tibetan	6679
Deutsch	6869	Maori	7773	Tigrinya	8473
Dzongkha	6890	Marathi	7782	Tonga (Tonga Islands)	8479
English	6978	Marshallese	7772	Tsonga	8483
Esperanto	6979	Moldavian	7779	Tswana	8478
Estonian	6984	Mongolian	7778	Türkçe	8482
Euskara	6985	Nauru	7865	Türkmen	8475
	6976	Navaho; Navajo	7886	Twi	8487
Faroese	7079	Ndebele, North	7868	Uighur	8571
Français	7082	Ndebele, South	7882	Ukrainian	8575
Frysk	7089	Ndonga	7871	Urdu	8582
Fijian	7074	Nederlands	7876	Uzbek	8590
Gaelic; Scottish Gaelic	7168	Nepali	7869	Vietnamese	8673
Galleghan	7176	Norsk	7879	Volapuk	8679
Georgian	7565	Northern Sami	8369	Walloon	8765
Gikuyu; Kikuyu	7573	North Ndebele	7868	Welsh	6789
Guarani	7178	Norwegian Nynorsk;	7878	Wolof	8779
Gujarati	7185	Occitan; Provençal	7967	Xhosa	8872
Hausa	7265	Old Bulgarian; Old Slavonic	6785	Yiddish	8973
Herero	7290	Oriya	7982	Yoruba	8979
Hindi	7273	Oromo	7977	Zulu	9085
Hiri Motu	7279	Ossetian; Ossetic	7983		
Hrwatski	6779	Pali	8073		
Ido	7379	Panjabi	8065		
Interlingua (International)	7365	Persian	7065		
Interlingue	7365	Polski	8076		
Inuktitut	7385	Português	8084		

