

# Quick start guide










Step A *Connect*

Step B *Setup*

Step C *Enjoy*

## What's in the Box?

You should find these items upon opening the box.



## Step A *Connect*

**1** Connect the speakers to the **SPEAKERS** (8ohm) terminals with two speaker cables. Right speaker to "R" and left speaker to "L", red wire to "+" and silver wire to "-".

**2** For radio reception, connect the supplied MW loop antenna wires to the **MAERIAL** jack.

### *Tip*

*It is unnecessary to connect the FM pigtail antenna since it is fixed to the main unit.*


**3** Connect the serial port marked **CONTROL CABLE** at the rear of the DVD player to the same port at the rear of the power amplifier with the supplied control cable.

**4** Connect the **VIDEO OUTPUT** jack at the rear of the DVD player to the video input jack on the TV using the supplied video cable (yellow).

### *Tip*


*See the User Manual for other TV connection options.*

**5** Connect the power cord of the DVD system to the AC power outlet.



## Setting up the TV













- 1 Press **STANDBY ON**  on the front panel of the DVD player or  on the remote to switch the DVD system on and then select the disc source.






- 2 Switch on the TV set and set to the correct video-in channel until the blue Philips DVD background screen appears on the TV.

**Tip**  
See your TV manual for more details.

## Setting TV type and preferences



- 1 Press **SYSTEM** on the remote to enter the system menu.
- 2 Press   on the remote to enter the 'Preference Page'. Then, select the color system matching your TV and the preferred audio, subtitle and disc menu languages using     and **OK** on the remote.
- 3 Press   on the remote to enter the 'General Setup Page' and select the preferred OSD language using     and **OK** on the remote.



**Tip**  
You can enter the 'Preference Page' in full stop mode only.


## Loading a disc

- 1 Select the disc source, then press **OPEN•CLOSE** at the top of the DVD player or  on the remote.







- 2 Load in a DVD disc with the label side facing up.

- 3 A disc menu pops up.



## Playback

- 1 Use     and **OK** or **Numeric Keypad (0-9)** on the remote to select a playback feature or item.









### Tip

Refer to the User Manual for playback of other types of discs.

- 2 Press **PRESET/▶II** (or  on the remote) to start playback.



## Types of Discs used on this DVD System

Type	Record	Playback	Edit
 DVD+RW	✗	✓	✗
 DVD VIDEO	✗	✓	✗
 VIDEO CD	✗	✓	✗
 Super VCD	✗	✓	✗
 AUDIO CD	✗	✓	✗
 VIDEO CD	✗	✓	✗
 MP3-CD	✗	✓	✗
 WMA	✗	✓	✗



2005 © Koninklijke Philips Electronics N.V.  
All rights reserved.

[www.philips.com](http://www.philips.com)