

User manual
Manuel d'utilisation
Manual del usuario
Benutzerhandücher
Gebruikershandleidingen
Manuale per l'utente
Användarhandböckerna
Brugermanual
Käyttöoppaita
Manual do usuário
εγχειρίδιο χρήσης



PHILIPS

Important notes for users in the U.K.

Mains plug

This apparatus is fitted with an approved 13 Amp plug. To change a fuse in this type of plug proceed as follows:

- 1 Remove fuse cover and fuse.
- 2 Fix new fuse which should be a BS1362 5 Amp, A.S.T.A. or BSI approved type.
- 3 Refit the fuse cover.

If the fitted plug is not suitable for your socket outlets, it should be cut off and an appropriate plug fitted in its place.

If the mains plug contains a fuse, this should have a value of 5 Amp. If a plug without a fuse is used, the fuse at the distribution board should not be greater than 5 Amp.

Note: The severed plug must be disposed of to avoid a possible shock hazard should it be inserted into a 13 Amp socket elsewhere.

How to connect a plug

The wires in the mains lead are coloured with the following code: blue = neutral (N), brown = live (L).

- As these colours may not correspond with the colour markings identifying the terminals in your plug, proceed as follows:
 - Connect the blue wire to the terminal marked N or coloured black.
 - Connect the brown wire to the terminal marked L or coloured red.
 - Do not connect either wire to the earth terminal in the plug, marked E (or \perp) or coloured green (or green and yellow).

Before replacing the plug cover, make certain that the cord grip is clamped over the sheath of the lead - not simply over the two wires.

Copyright in the U.K.

Recording and playback of material may require consent. See Copyright Act 1956 and The Performer's Protection Acts 1958 to 1972.

Italia

DICHIARAZIONE DI CONFORMITA'

Si dichiara che l'apparecchio MCM720 Philips risponde alle prescrizioni dell'art. 2 comma 1 del D.M. 28 Agosto 1995 n. 548.

Fatto a Eindhoven

Philips Consumer Electronics
Philips, Glaslaan 2
5616 JB Eindhoven, The Netherlands

Norge



Typeskilt finnes på apparatens underside.

Observer: Nettbryteren er sekundert innkoplet. Den innebygde nettdelen er derfor ikke frakoplet nettet så lenge apparatet er tilsluttet nettkontakten.

For å redusere faren for brann eller elektrisk støt, skal apparatet ikke utsettes for regn eller fuktighet.

CAUTION

Use of controls or adjustments or performance of procedures other than herein may result in hazardous radiation exposure or other unsafe operation.



DK

**Advarsel: Usynlig laserstråling ved åbning
når sikkerhedsafbrydere er ude af funktion.
Undgå udsættelse for stråling.**

**Bemærk: Netafbryderen er sekundært
indkoblet og afbryder ikke strømmen fra
nettet. Den indbyggede netdel er derfor
tilsluttet til lysnettet så længe netstikket
sidder i stikkontakten.**

S

Klass 1 laseraparat

**Varning! Om apparaten används på annat
sätt än i denna bruksanvisning specificerats,
kan användaren utsättas för osynlig
laserstrålning, som överskrider gränsen för
laserklass 1.**

**Observera! Stömbrytaren är sekundärt
kopplad och bryter inte strömmen från
nätet. Den inbyggda nätdelen är därför
ansluten till elnätet så länge stickproppen
sitter i vägguttaget.**

SF

Luokan 1 laserlaite

**Varoitus! Laitteen käyttäminen
muulla kuin tässä käyttöohjeessa mainitulla
tavalla saattaa altistaa käyttäjän
turvallisuusluokan 1 ylittävälle
näkömättömälle lasersäteilylle.**

**Oikeus muutoksiin varataan. Laite ei
saa olla alttiina tippu-ja roiskevedelle.**

**Huom. Toiminnanvalitsin on kytketty
toisiopuolelle, eikä se kytke laitetta irti
sähköverkosta. Sisäänrakennettu verkko-
osa on kytkettynä sähköverkkoon aina
silloin, kun pistoke on pistorasiassa.**

English 6

Français 25

Español 44

Deutsch 63

Nederlands 82

Italiano 101

Svenska 120

Dansk 139

Suomi 158

Português 176

Ελληνικά 195

English

Français

Español

Deutsch

Nederlands

Italiano

Svenska

Dansk

Suomi

Português

Ελληνικά

General Information

Supplied accessories	7
Environmental information	7
Safety information	7
About MP3 disc	7

Preparations

Rear connections	8-9
Power	
Antennas connection	
Speakers connection	
Optional connection	9
Connecting a USB device or memory card	
Connecting a non-USB device	
Inserting batteries into the remote control	10

Controls

Controls on the system and remote control	11
---	----

Basic Functions

Switching the system on	12
Switching the system to Eco Power standby mode	12
Power-saving automatic standby	12
Volume control	12
Sound control	12

CD / MP3-CD Operations

Discs for playback	13
Playing a disc	13
Text display	13
Selecting a different track	13
Finding a passage within a track	14
Selecting a desired Album/Track (MP3 disc only)	14
Different play modes: SHUFFLE and REPEAT	14
Programming the disc tracks	14
Reviewing the programme	14
Erasing the programme	14

Radio Reception

Tuning to radio stations	15
Programming radio stations	15
Automatic programming	
Manual programming	
Tuning to preset radio stations	16
RDS	16
Setting the RDS clock	

Tape Operation/Recording

Tape playback	17
Rewinding / Fast forwarding	17
General information on recording	17
Preparation for recording	18
Synchro start CD recording	18
One touch recording	18
Recording timer	18

External Sources

Using a non-USB device	19
Using a USB mass storage device	19-20

Clock/Timer

Clock setting	21
Timer setting	21
Activating and deactivating timer	
Sleep timer setting	21

Specifications

Maintenance

Troubleshooting

Disposal of your old product

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.

When this crossed-out wheeled bin symbol is attached to a product it means the product is covered by the European Directive 2002/96/EC



Please inform yourself about the local separate collection system for electrical and electronic products.

Please act according to your local rules and do not dispose of your old products with your normal household waste. The correct disposal of your old product will help prevent potential negative consequences for the environment and human health.

This product complies with the radio interference requirements of the European Community.

Supplied accessories

- 2 speaker boxes
- remote control
- MW loop antenna
- FM wire antenna

Environmental Information

All unnecessary packaging has been omitted. We have tried to make the packaging easy to separate into three materials: cardboard (box), polystyrene foam (buffer) and polyethylene (bags, protective foam sheet).

Your system consists of materials which can be recycled and reused if disassembled by a specialised company. Please observe the local regulations regarding the disposal of packaging materials, exhausted batteries and old equipment.

Safety Information

- Before operating the system, check that the operating voltage indicated on the typeplate (or the voltage indication beside the voltage selector) of your system is identical with the voltage of your local power supply. If not, please consult your dealer.
- Place the system on a flat, hard and stable surface.
- Place the system in a location with adequate ventilation to prevent internal heat build-up in your system. Allow at least 10 cm (4 inches) clearance from the rear and the top of the unit and 5 cm (2 inches) from each side.
- The ventilation should not be impeded by covering the ventilation openings with items, such as newspapers, table-cloths, curtains, etc.
- Do not expose the system, batteries or discs to excessive moisture, rain, sand or heat sources caused by heating equipment or direct sunlight.
- No naked flame sources, such as lighted candles, should be placed on the apparatus.
- No objects filled with liquids, such as vases, shall be placed on the apparatus.

- If the system is brought directly from a cold to a warm location, or is placed in a very damp room, moisture may condense on the lens of the disc unit inside the system. Should this occur, the CD player would not operate normally. Leave the power on for about one hour with no disc in the system until normal playback is possible.
- The mechanical parts of the set contain self-lubricating bearings and must not be oiled or lubricated.
- Install this unit near the AC outlet and where the AC power plug can be reached easily.
- **When the system is switched to Standby mode, it is still consuming some power. To disconnect the system from the power supply completely, remove the AC power plug from the wall socket.**


About MP3 disc

Supported formats

- ISO9660, Joliet, Multisession
- Max. track number plus album is 500
- Max. nested directory is 8 levels
- The max. album number is 99
- The max. MP3 programme track number is 20
- Supported VBR bit-rate
- Supported sampling frequencies for MP3 disc are: 32 kHz, 44.1 kHz, 48 kHz
- Supported Bit-rates of MP3 disc are: 32, 64, 96, 128, 192, 256 (kbps)

Sound Quality

Take note that MP3-CD compilations should best contain only MP3 tracks (.mp3). **To achieve a good MP3 quality, a bit rate of 128 kbps is recommended.**



Rear connections


The type plate is located at the rear of the system.

For users in the U.K.: please follow the instructions on page 2.

B Antennas Connection

Connect the supplied MW loop antenna and FM antenna to the respective terminals. Adjust the position of the antenna for optimal reception.

MW Antenna



- Position the antenna as far as possible from a TV, VCR or other radiation source.

A Power


Before connecting the AC power cord to the wall outlet, ensure that all other connections have been made.

WARNING!

- For optimal performance, use only the original power cable.
- Never make or change connections with the power switched on.

To avoid overheating of the system, a safety circuit has been built in. Therefore, your system may switch to Standby mode automatically under extreme conditions. If this happens, let the system cool down before reusing it (not available for all versions).

FM Antenna




- For better FM stereo reception, connect an outdoor FM antenna to the FM AERIAL (FM ANTENNA) terminal.

C Speakers Connection

Front Speakers

Connect the speaker wires to the SPEAKERS terminals, right speaker to "R" and left speaker to "L", coloured (marked) wire to "+" and black (unmarked) wire to "-".



- Fully insert the stripped portion of the speaker wire into the terminal as shown.

Notes:

- For optimal sound performance, use the supplied speakers.
- Do not connect more than one speaker to any one pair of +/– speaker terminals.
- Do not connect speakers with an impedance lower than the speakers supplied. Please refer to the SPECIFICATIONS section of this manual.

Optional connection

The optional equipment and connecting cords are not supplied. Refer to the operating instructions of the connected equipment for details.


Connecting a USB device or memory card

By connecting a USB mass storage device (including USB flash memory, USB flash players or memory cards) to the Hi-Fi system, you can enjoy the device's stored music through the powerful speakers of Hi-Fi system.


- Insert the USB device's USB plug into the  socket on the set.

OR

for the devices with USB cables:

- 1 Insert one plug of the USB cable (not supplied) to the  socket on the set.
- 2 Insert the other plug of the USB cable to the USB output terminal of the USB device.

for the memory card:

- 1 Insert the memory card into a card reader (not supplied).
- 2 Use a USB cable (not supplied) to connect the card reader into the  socket on the set.

Connecting a non-USB device


Use a cinch cable to connect **AUX IN** to the analogue audio out terminals of an external equipment (TV/VCR, Laser Disc player; DVD player or CD Recorder).

Note:

- If you are connecting equipment with a mono output (a single audio out terminal), connect it to the AUX IN left terminal. Alternatively, you can use a "single to double" cinch cable (the output sound still remain mono).

Inserting batteries into the remote control










Insert two batteries (type R03 or AAA) into the remote control with the correct polarity as indicated by the "+" and "-" symbols inside the battery compartment.



CAUTION!





- Remove batteries if they are exhausted or will not be used for a long time.
- Do not use old and new or different types of batteries in combination.
- Batteries contain chemical substances, so they should be disposed of properly.

Controls on the system and remote control


- ① **Eco Power/STANDBY ON** 
 - to switch the system on or to Eco Power standby/normal standby with clock display.
- ② **Display screen**
 - to view the current status of the system.
- ③ **BAND/DISPLAY**
 - for Tunerto select waveband : FM, MW or LW.
 - for CD/MP3-CD...to select disc information display mode.
- ④ **PROGRAM**
 - for CD/MP3-CD...to programme disc tracks.
 - for Tunerto programme preset radio stations.
- ⑤ **CLOCK SET/RDS**
 - for Tunerto activate RDS news.
 - for Clock(on the system only) to set the clock function.
- ⑥ **TUNING**  ( )
 - for CDto fast reverse/forward the disc.
 - for CD/MP3 CD...(on the system only) to select a desired track.
 - for Tunerto tune to a lower or higher radio frequency.
 - for Tapeto rewind or fast forward.
- ⑦ **ALBUM/PRESET/TIMER SET** 
 - for MP3-CDto select previous/next album.
 - for Tunerto select a preset radio station.
 - for Timer Set () (on the system only) to set the timer function.
- ⑧ **STOP** 
 - for CD/MP3-CD...to stop playback or to clear a programme.
 - for Tapeto stop playback or recording.
- ⑨ **PLAY/PAUSE** 
 - for CD/MP3 CD...to start or interrupt playback.
 - for Tapeto start playback.
- ⑩ **Tape deck**
- ⑪ **OPEN/CLOSE** 
 - to open tape compartment.
- ⑫ **DBB/INCREDIBLE SURROUND (IS)**
 - to create a super-enhanced stereo effect.
 - to enhance the bass.

- ⑬ **DSC (Digital Sound Control)**
 - to select the desired sound effect : OPTIMAL/ROCK/JAZZ/POP.
- ⑭ **VOLUME (VOL + / -)**
 - to increase or decrease the volume.
 - (on the system only) to adjust the hours and minutes for the clock/timer functions.
- ⑮ **SOURCE**
 - to select the respective sound source : USB/CD, TUNER, TAPE or AUX.
- ⑯ **RECORD**
 - to start recording.
- ⑰ **iR sensor**
 - infrared sensor for remote control.
- ⑱ **OPEN•CLOSE** 
 - to open or close the disc tray.
- ⑲  **Headphone**
 - Plugs in the headphones jack. The speakers output will be cancelled.
- ⑳ **USB DIRECT** 
 - jack for the external USB mass storage device.
- ㉑ **MODE**
 - to shuffle and repeat a track/disc.
- ㉒ 
 - to select a desired track.
- ㉓ **MUTE**
 - interrupts and resumes sound reproduction.
- ㉔ **TIMER**
 - to activate/deactivate the timer function.
- ㉕ **SLEEP**
 - to activate/deactivate or set the sleep timer.
- ㉖ 
 - to switch the system to standby mode.

Notes for remote control:

- First select the source you wish to control by pressing one of the source select keys on the remote control (for example CD, TUNER).
- Then select the desired function (for example    .


Basic Functions






IMPORTANT!

Before you operate the system, complete the preparation procedures.

Switching the system on

- Press **ECO POWER/STANDBY ON**  or **SOURCE**.
→ The system will switch to the last selected source.
- Press **CD/USB, TUNER, TAPE** or **AUX** on the remote control.
→ The system will switch to the selected source.

Switching the system to Eco Power Standby mode

- Press **ECO POWER/STANDBY-ON**  in the active mode.
→ The backlight of clock display is dim in standby.
- The volume level, interactive sound settings, last selected mode, source and tuner presets will be retained in the player's memory.
- To view the clock time in Standby mode, press and hold **ECO POWER/STANDBY-ON**  for 3 seconds or more.
→ The system enters the normal standby mode with clock display.
→ If the clock has not been set, "----:--" is displayed.
- Press and hold **ECO POWER/STANDBY-ON**  for 3 seconds or more to go back to Eco Power Standby mode.

Power-saving automatic standby

As a power-saving feature, the system will automatically switch to Standby mode if you do not press any buttons within 15 minutes after a disc or tape has stopped playing.

Volume control


Adjust **VOLUME (VOL + / -)** to increase or decrease the volume level.

→ Display shows the volume level "VOL" and a number from 1-31. "MIN" denotes the minimum volume level and "MAX" denotes the maximum volume level.

To switch off the volume temporarily

- Press **MUTE** on the remote control.
→ Playback will continue without sound and "MUTE" is displayed.
- To restore the volume, press **MUTE** again or increase/decrease the volume level.


Sound control



- Press **DSC** repeatedly to select the desired sound effect : **OPTIMAL, ROCK, JAZZ** or **POP**.
- Press **DBB/INCREDIBLE SURROUND** to switch on or off the surround sound effect or bass enhancement.
→ The sequences are as follows :
DBB → INCREDIBLE SURROUND. → DBB+INCREDIBLE SURROUND → DBB OFF
→ If the DBB is activated, **DBB** is shown briefly.
→ If the IS is activated, **INCREDIBLE SURROUND** scrolls.
→ If both the DBB and IS are activated, **DBB INCREDIBLE SURROUND** scrolls.


Note:

– The effect of **INCREDIBLE SURROUND** may vary with different types of music.



IMPORTANT!

The lens of the CD player should never be touched.



Discs for playback

This system is able to play :

- All pre-recorded audio CDs
- All finalised audio CDR and audio CDRW discs
- MP3-CDs (CD-ROMs with MP3 tracks)
- CD-ROM, CD-I, CDV, VCD, DVD or computer CDs, however, are not possible.

Playing a disc

- 1 Select **CD** source.
- 2 Press **OPEN•CLOSE ▲** on the top of the system to open the CD compartment.
→ "CD OPEN" is displayed.
- 3 Insert a disc with the printed side facing up and press **OPEN•CLOSE ▲** to close the CD door:
→ "READING" is displayed as the CD player scans the contents of a disc, and then the total number of tracks and album are shown.
- 4 Press **▶II** to start playback.

To interrupt playback

- Press **▶II**
- To resume playback, press **▶II** again.

To stop playback

- Press **■**.

Notes:

- Disc play will also stop when you select another source or the disc has reached the end.
- For MP3 disc, the disc reading time may exceed 10 seconds due to the large number of songs compiled into one disc.

Text display

In CD mode

- Press **BAND/DISPLAY** repeatedly to see the following information.
 - Track number and elapsed play time of current track.
 - Remaining play time of current track.
 - Total number of tracks played and total elapsed time.
 - Total remaining number of tracks and total remaining play time.

In MP3-CD mode

- Press **BAND/DISPLAY** repeatedly to select four display modes : Number, Track, Album and ID3.
 - Number** → The current album and track numbers are displayed briefly.
 - Track** → The current track name scrolls twice.
 - Album** → The current album name scrolls twice.
 - ID-3** → The ID-3 tag scrolls twice.

Selecting a different track

- Press **TUNING ◀◀◀▶▶▶** (◀▶▶) repeatedly until the desired track number appears in the display.
- If playback is stopped, press **▶II** to start playback.

CD/MP3-CD Operations

Finding a passage within a track

- 1 Press and hold down on **TUNING** |◀◀▶▶| (◀▶▶ on the remote control).
→ The disc is played at high speed.
- 2 When you recognize the passage you want, release **TUNING** |◀◀▶▶| (◀▶▶ on the remote control).
→ Normal playback continues.

Selecting a desired album/track

To select a desired album (MP3 disc only)

- Press **ALBUM/PRESET** ▼/▲ repeatedly.

To select a desired track

- Press **TUNING** |◀◀▶▶| (◀▶▶) repeatedly.

Different play modes: SHUFFLE and REPEAT

You can select and change the various play modes before or during playback.

- 1 Press **MODE** on the remote control to select :
→ **SHUFFLE** – tracks of the entire disc/ programme are played in random order:
→ **SHUFFLE and REP ALL** – to repeat the entire disc/ programme continuously in random order:
→ **REP ALL** – to repeat the entire disc/ programme.
→ **REPEAT** – to repeat the current track.
- 2 To return to normal playback, press **MODE** until the various SHUFFLE/ REPEAT modes are no longer displayed.
- You can also press ■ to cancel your play mode.

Note:

– If *Shuffle* is activated on a MP3-CD, all titles stored in the disc will be played in random order.

Programming the disc tracks

Programming tracks is possible when playback is stopped. Up to 20 tracks can be stored in the memory in any order.


- 1 Press **PROGRAM** to enter the programming mode.
→ A track number is shown and **PROG** flashes.
- 2 Press **TUNING** |◀◀▶▶| (◀▶▶) repeatedly to select your desired track number.
- For MP3 disc, press **ALBUM/PRESET** ▼/▲ and **TUNING** |◀◀▶▶| (◀▶▶) to select the desired album and track for programming.
- 3 Press **PROGRAM** to confirm the track number to be stored.
- 4 Repeat steps 2-3 to select and store all desired tracks.
- 5 To start playback of your disc programme, press ■ followed by ► II.
→ *PROG -- -- OK* is displayed briefly.
- If you attempt to programme more than 20 tracks, "FULL" will appear on the display. In this case :
→ The system will exit programming mode automatically.
→ Pressing ■ button will erase all the programmed tracks.
→ Pressing ► II button will start playback of the programmed tracks.

Reviewing the programme

In stop mode, press and hold **PROGRAM** until the display shows all your stored track numbers in sequence.

Erasing the programme

- Press ■ **once** when playback is stopped or **twice** during playback.
→ **PROG** disappears and "CLEAR" is displayed.



Tuning to radio stations

- 1 Select **TUNER** source.
→ "TUNER" is displayed briefly.
- 2 Press **BAND/DISPLAY** to select the desired waveband : FM, MW or LW.
- 3 Press down on **TUNING** (◀◀▶▶) (◀▶▶▶) on the remote control) and release the button.
→ The display will show "SEARCH" until a radio station with sufficient signal strength is found.
→ If a FM station is received in stereo, ∞ is shown.
- 4 Repeat step 3 if necessary until you find the desired station.
- To tune to a weak station, press **TUNING** (◀◀▶▶) (◀▶▶) on the remote control) briefly and repeatedly until you have found optimal reception.

Programming radio stations

You can store up to a total of 40 radio stations in the memory for each band.

Automatic programming

Automatic programming will start with a chosen preset number. From this preset number upwards, former programmed radio stations will be overridden.

- 1 Press **ALBUM/PRESET** ▼/▲ to select the preset number where programming should start.

Note:

→ If no preset number is selected, default is preset (1) and all your presets will be overridden.

- 2 Press **PROGRAM** for more than two seconds to activate programming.
→ All available stations are programmed.


Manual programming

- 1 Tune to your desired station (refer to "Tuning to radio stations").
- 2 Press **PROGRAM** to activate programming.
→ **PROG** flashes in the display.
- 3 Press **ALBUM/PRESET** ▼/▲ to allocate a number from 1 to 40 to this station.
- 4 Press **PROGRAM** again to confirm the setting.
→ **PROG** disappears, the preset number and the frequency of the preset station are shown.
- 5 Repeat the above four steps to store other stations.
- You can override a preset station by storing another frequency in its place.

Tuning to preset radio stations

- Press **ALBUM/PRESET** ▼/▲ until the desired preset station is displayed.

RDS

Radio Data System is a service that allows FM stations to show additional information. If you are receiving a RDS station,  **RDS** and the station name are displayed.

When automatic programming is used, RDS stations will be programmed first.

Scrolling through different RDS information

- Press **CLOCK SET/RDS** briefly and repeatedly to scroll through the following information (if available):
 - Station name
 - Radio text messages
 - Frequency


Setting the RDS clock

Some RDS radio station may be transmitting a real clock time at an interval of every minute. It is possible to set the clock by using a time signal which is broadcast together with the RDS signal.

- 1 Tune to a RDS station (refer to "Tuning to radio stations").
- 2 Press **CLOCK SET/RDS** for more than two seconds.
 - "SETR TM" is displayed.
 - When RDS time is read, "RDS" and RDS time value are displayed and the current time will be stored.

Note:

- Some RDS radio station may be transmitting a real time clock at a minute interval. The accuracy of the transmitted time depends on the transmitting RDS radio station.



Tape playback

- 1 Select **TAPE** source.
→ The display shows "**TAPE**" briefly, and the tape counter **000** is displayed.
- 2 Press **OPEN/CLOSE** to open the tape door:
- 3 Insert a recorded tape and close the tape door:
- 4 Load the tape with the open side downward and the full spool to the left.
- 4 Press **▶▶** to start playback.

To stop playback

- Press **■**.

To reset the tape counter display

- In stop mode, press **■** **once**.

Rewinding / Fast forwarding

- 1 Press **TUNING** (on the remote control).
→ The tape will stop automatically at the end of rewinding or fast forwarding.
→ During fast winding, you can monitor the tape message with the tape counter.
- 2 Press **■** to stop rewinding or fast forwarding.

General information on recording

- For recording, use only **NORMAL** (IEC type I) tapes on which the tabs have not yet been broken. This deck is not suited for recording on **METAL** (IEC IV) type tapes.
- The best recording level is set automatically. Altering the **VOLUME**, **INCREDIBLE SURROUND** or **DBB** will not affect the recording in progress.
- At the very beginning and end of the tape, no recording will take place during the 7 seconds when the leader tape passes the recorder heads.
- To protect a tape from accidental erasure, have the tape in front of you and break out the left tab. Recording on this side is no longer possible. If, however, you wish to record over this side again, cover the tabs with a piece of adhesive tape.

IMPORTANT!

Recording is permissible if copyright or other rights of third parties are not infringed upon.

Preparation for recording

- 1 Select **TAPE** source.
- 2 Load a recordable tape into tape deck with full spool to the left.
- 3 Prepare the source to be recorded.
CD – load the disc.
TUNER – tune to the desired radio station.
AUX – connect external equipment.

When recording is in progress

→ **REC** flashes.

- To stop recording, press **■**.
- It is not possible to listen to another source.
- It is not possible to activate the timer function.

Tape Operation / Recording

Synchro start CD recording

- 1 Select **CD** source.
- 2 Press **TUNING** |◀◀/▶▶| (◀▶ on the remote control) to select the desired track to start recording.
- 3 You can programme the tracks in the order you want them to be recorded (refer to "CD/MP3-CD Operations - Programming the disc tracks").
- 4 Press **RECORD** to start recording.
→ Playing of the CD programme starts automatically from the beginning of the CD. It is not necessary to start the CD player separately.


One touch recording

- 1 Select **CD**, **TUNER** or **AUX** source.
- 2 If necessary, start playback of the selected source.
- 3 Press **RECORD** to start recording.

Recording timer

To record from the radio, you will need to use a preset radio station and to set a start (ON) and finish (OFF) time.

- 1 Select the preset radio station to record from (refer to "Radio Reception - Tuning to preset radio stations").
- 2 In standby mode, press **TIMER SET** ▲ for more than two seconds.
→ The current selected source is displayed.
- 3 Press **SOURCE** repeatedly until "REC TUN" source is displayed.
- 4 Press **TIMER SET** ▲ to confirm the source.
→ "SET ON TIME" is displayed and the clock digits for the hours flash.

- 5 Adjust **VOLUME** on the front panel to set the hours.
- 6 Press **TIMER SET** ▲ again.
→ The clock digits for the minutes flash.
- 7 Adjust **VOLUME** on the front panel to set the minutes.
- 8 Press **TIMER SET** ▲ to confirm the recording start time.
→ "SET OFF TIME" is displayed and the clock digits for the hours flash.
- 9 Repeat steps 5-7 to set the finish time.
- 10 Press **TIMER SET** ▲ to confirm the timer settings.
→  is shown and the recording timer is now set.

Note:

— The recording timer will not be activated if the system is in tape play mode.

ORIGINAL COPYRIGHT NOTICE

The making of unauthorized copies of copy-protected material, including computer programmes, files, broadcasts and sound recordings, may be an infringement of copyrights and constitute a criminal offence. This equipment should not be used for such purposes.



**Be responsible
Respect copyrights**

Using a non-USB device

- 1 Connect the audio out terminals of the external equipment (TV, VCR, Laser Disc player, DVD player or CD Recorder) to the **AUX IN** terminals of your system.
- 2 Press **AUX** to select external equipment.

Note:

- All the sound control features (DSC or DBB, for example) are available for selection.
- Refer to the operating instructions for the connected equipment for details.

For Recording, please refer to “Tape Operation/Recording”.

Using a USB mass storage device

By connecting a USB mass storage device to the Hi-Fi system, you can enjoy the device's stored music through the powerful speakers of Hi-Fi system.

Playing a USB mass storage device Compatible USB mass storage devices

With the Hi-Fi system, you can use:

- USB flash memory (USB 2.0 or USB1.1)
- USB flash players (USB 2.0 or USB1.1)
- memory cards (requires an additional card reader to work with this Hi-Fi system)

Note:

- In some USB flash players (or memory devices), the stored contents are recorded using copyright protection technology. Such protected contents will be unplayable on any other devices (such as this Hi-Fi system).

Supported formats:

- USB or memory file format FAT12, FAT16, FAT32 (sector size: 512 - 65,536 bytes)
- MP3 bit rate (data rate): 32-320 Kbps and variable bit rate
- WMA v9 or earlier
- Directory nesting up to a maximum of 8 levels
- Number of albums/ folders: maximum 99
- Number of tracks/titles: maximum 500
- ID3 tag v2.0 or later
- File name in Unicode UTF8 (maximum length: 128 bytes)

The system will not play or support the following:

- Empty albums: an empty album is an album that does not contain MP3/WMA files, and will not be shown in the display.
- Non-supported file formats are skipped. This means that e.g.: Word documents .doc or MP3 files with extension .dlf are ignored and will not be played.
- AAC, WAV, PCM audio files
- DRM protected WMA files
- WMA files in Lossless format

How to transfer music files from PC to a USB mass storage device

By dragging and dropping music files, you can easily transfer your favorite music from PC to a USB mass storage device.

For the flash player, you can also use its music management software for the music transfer.


However, those WMA files may be unplayable for compatibility reasons.

External Sources

How to organize your MP3/WMA files on the USB mass storage device

This Hi-Fi system will browse the MP3/WMA files in the folders/sub-folders/titles order:

Example:



Organize your MP3/WMA files in different folders or subfolders as required.

Notes:


- If you have not organized MP3/WMA files into any albums on your disc, an album "01" will be automatically assigned for all those files.
- Make sure that the file names of MP3 files end with .mp3. and the file names of WMA files end with .wma.
- For DRM protected WMA files, use Windows Media Player 10 (or later) for conversion. Visit www.microsoft.com for details about Windows Media Player and WM DRM (Windows Media Digital Rights Management).

- 3 Play the USB's audio files as you do with the albums/tracks on a CD (See CD/MP3 Operations).

Notes:

- For compatibility reasons, the album/track information may differ from what it is displayed through flash players' music management software.
- File names or ID3 tags will be displayed as — if they are not in English.

- 1 Check the USB device has been properly connected. (See Installation: Connecting an additional appliance).
- 2 Press **SOURCE (CD/USB)** on the remote) once or more to select USB.
 -NO TRACK appears if no audio file is found in the USB device.



Clock setting

There are two possible methods for setting the clock: manually or automatically by using RDS.

Automatic clock setting

Refer to "Setting the RDS clock".

Manual clock setting

- 1 In standby mode, press and hold **CLOCK SET/ RDS**.
→ **SET CLOCK** is displayed briefly. Then, clock digits for the hours flash.
- 2 Adjust **VOLUME** to set the hours.
- 3 Press **CLOCK SET/RDS** again.
→ The clock digits for the minutes flash.
- 4 Adjust **VOLUME** to set the minutes.
- 5 Press **CLOCK SET/RDS** to confirm the time.

Timer setting

- The system can be used as an alarm clock, whereby the CD, TUNER or TAPE is switched on at a set time (one time operation). The clock time needs to be set first before the timer can be used.
- You can also use it to record a favourite tuner programme at a set period (refer to "Recording timer")
- During setting, if no button is pressed within 90 seconds, the system will exit timer setting mode automatically.

- 1 In standby mode, press **TIMER SET ▲** for more than two seconds.
- 2 Press **SOURCE** repeatedly to select the sound source.
→ **"SET TIME"** and **"SELECT SOURCE"** are displayed.
- 3 Press **TIMER SET ▲** to confirm your desired mode.
→ **"SET ON TIME"** is displayed and the clock digits for the hours flash.
- 4 Adjust **VOLUME** to set the hours.
- 5 Press **TIMER SET ▲** again.
→ The clock digits for the minutes flash.
- 6 Adjust **VOLUME** to set the minutes.
- 7 Press **TIMER SET ▲** to confirm the time.
→ The timer is now set and activated.

Activating and deactivating timer

- In standby or during playback, press **TIMER SET ▲ (TIMER on the remote control) once**.
→ Display shows if activated, and disappears if deactivated.

Sleep timer setting

The sleep timer enables the system to switch off by itself after a set period of time.

- 1 Press **SLEEP** on the remote control repeatedly to select a preset time.
→ The selections are as follows (time in minutes):
60 → 45 → 30 → 15 → 0 → 60 ...
→ **"SLEEP xx"** or **"0"** is displayed. "xx" is the time in minutes.
- 2 When you reach the desired length of time, stop pressing the **SLEEP** button.

To deactivate the sleep timer

- Press **SLEEP** repeatedly until **"0"** is displayed, or press **Eco Power/STANDBY ON**.

Specifications

AMPLIFIER

Output power	2 x 50 W RMS*
.....	2 x 100 W MPO
Signal-to-noise ratio	≥ 62 dBA (IEC)
Frequency response	40 – 15000 Hz, ± 3 dB
Impedance loudspeakers	6 Ω
Impedance headphones	32 Ω
* (4 Ω, 1 kHz, 10% THD)	

CD/MP3-CD PLAYER

Number of programmable tracks	20
Frequency range	20 – 20000 Hz
Signal-to-noise ratio	75 dBA
Channel separation	≥ 60 dB (1 kHz)
Total harmonic distortion.....	< 0.003%
MPEG 1 Layer 3 (MP3-CD)	MPEG AUDIO
MP3-CD bit rate	32-256 kbps
	(128 kbps advised)
Sampling frequencies	32, 44.1, 48 kHz

USB PLAYER

USB	12Mb/s, V1.1
.....	support MP3 and WMA files
Number of albums/folders	maximum 99
Number of tracks/titles	maximum 500

TUNER

FM wave range	87.5 – 108 MHz
LW wave range	153 – 279 kHz
MW wave range	531 – 1602 kHz
Sensitivity at 75 Ω	
– mono, 26 dB signal-to-noise ratio	2.8 μV
– stereo, 46 dB signal-to-noise ratio	61.4 μV
Selectivity	≥ 28 dB
Total harmonic distortion	≤ 5%
Frequency response	63 – 12500 Hz (± 3 dB)
Signal-to-noise-ratio	≥ 50 dBA

TAPE DECK

Frequency response	
Normal tape (type I)	80 – 12500 Hz (8 dB)
Signal-to-noise ratio	
Normal tape (type I)	50 dBA
Wow and flutter	≤ 0.4% DIN

SPEAKERS

2-way Bass reflex system	
Dimensions (w x h x d) ..	170 x 252 x 214 (mm)

GENERAL INFORMATION

AC Power	220 – 230 V / 50 Hz
Dimensions (w x h x d) ..	175 x 252 x 305 (mm)
Weight (with/without speakers)	
.....	approx. 8.96 / 4.84 kg
Eco Power Standby	< 1 W


Specifications and external appearance are subject to change without notice.

Cleaning the Cabinet

- Use a soft cloth slightly moistened with a mild detergent solution. Do not use a solution containing alcohol, spirits, ammonia or abrasives.

Cleaning Discs

- When a disc becomes dirty, clean it with a cleaning cloth. Wipe the disc from the centre out.
- Do not use solvents such as benzene, thinner, commercially available cleaners, or antistatic spray intended for analogue records.



Cleaning the disc lens


- After prolonged use, dirt or dust may accumulate at the disc lens. To ensure good playback quality, clean the disc lens with Philips CD Lens Cleaner or any commercially available cleaner. Follow the instructions supplied with cleaner.

Cleaning the Heads and the Tape Paths

- To ensure good recording and playback quality, clean the heads (A), the capstan(s) (B), and pressure roller(s) (C) after every 50 hours of tape operation.

Caution: Do not rotate the heads during cleaning.

- Use a cotton swab slightly moistened with cleaning fluid or alcohol.
- You can also clean the heads by playing a cleaning tape once.



Demagnetizing the heads

- Use a demagnetizing tape available at your dealer.

Troubleshooting

WARNING

Under no circumstances should you try to repair the system yourself, as this will invalidate the warranty. Do not open the system as there is a risk of electric shock.

If a fault occurs, first check the points listed below before taking the system for repair. If you are unable to remedy a problem by following these hints, consult your dealer or Philips for help.

Problem	Solution
"NO DISC" is displayed.	<ul style="list-style-type: none">✓ Insert a disc.✓ Check if the disc is inserted upside down.✓ Wait until the moisture condensation at the lens has cleared.✓ Replace or clean the disc, see "Maintenance".✓ Use a finalised CD-RW or CD-R.
Radio reception is poor.	<ul style="list-style-type: none">✓ If the signal is too weak, adjust the antenna or connect an external antenna for better reception.✓ Increase the distance between the Micro HiFi System and your TV or VCR.

Troubleshooting

Problem	Solution
Recording or playback cannot be made.	<ul style="list-style-type: none"> ✓ Clean deck parts, see "Maintenance". ✓ Use only normal (IEC I) tape for recording.
"CHK TAPE" is displayed.	<ul style="list-style-type: none"> ✓ Apply a piece of adhesive tape over the missing tab space.
The tape deck door cannot open.	<ul style="list-style-type: none"> ✓ Remove and reconnect the AC power plug and switch on the system again.
The system does not react when buttons are pressed.	<ul style="list-style-type: none"> ✓ Remove and reconnect the AC power plug and switch on the system again.
Sound cannot be heard or is of poor quality.	<ul style="list-style-type: none"> ✓ Adjust the volume. ✓ Disconnect the headphones. ✓ Check that the speakers are connected correctly. ✓ Check if the stripped speaker wire is clamped. ✓ Make sure the MP3-CD was recorded within 32-256 kbps bit rate with sampling frequencies at 48 kHz, 44.1 kHz or 32 kHz.
The left and right sound outputs are reversed.	<ul style="list-style-type: none"> ✓ Check the speaker connections and location.
The remote control does not function properly.	<ul style="list-style-type: none"> ✓ Select the source (CD or TUNER, for example) before pressing the function button (▶ II, ◀, ▶). ✓ Reduce the distance between the remote control and the system. ✓ Insert the batteries with their polarities (+/- signs) aligned as indicated. ✓ Replace the batteries. ✓ Point the remote control directly toward IR sensor on the front of the system.
The timer is not working.	<ul style="list-style-type: none"> ✓ Set the clock correctly. ✓ Press TIMER SET ▲ (TIMER on the remote control) to switch on the timer. ✓ If a recording is in progress, stop the recording.
The Clock/Timer setting is erased.	<ul style="list-style-type: none"> ✓ Power has been interrupted or the power cord has been disconnected. Reset the clock/timer.
Some files on the USB device are not displayed.	<ul style="list-style-type: none"> ✓ Check if the number of folders exceeds 99 or the number of titles exceeds 500.
"DEVICE NOT SUPPORTED" scrolls on the display.	<ul style="list-style-type: none"> ✓ Remove the USB mass storage device or select another source..