

DECT 311

User manual




**Charge handset(s)
for 24 hours before use.**


**This equipment is not designed for making
emergency telephone calls when the power fails.**


PHILIPS

Quick start guide

The **Pilot key** allows you to navigate the menus.

Up  : to go left in the menus & options.

Down  : to go right in the menus & options.



Press  : to select a menu or options and validate a setting.

It is also used as short cut to some menus.



Answer/end a call



Make a call

Predial number &  **or**  & dial number

Read Call log

 up and browse 





Redial a number

 up and browse  and 



Call from phonebook

 down and browse  and 



Add a name in the phonebook

Predial number and select  scroll to  **Store** and select , enter the name and press  **OK**

Adjust earpiece volume during call

Scroll up  to increase the volume ;  down to decrease

Adjust the handset loudspeaker volume

During a handsfree call, up  to increase ;  down to decrease


Mute the microphone

During call press  **Options** ; press  **Mute**

Unmute the microphone

Press  **Unmute**








Transfer a call/Intercom
(If at least 2 handsets)


Press  + number phone

To read an event







Press  **View**

To set the date and time






Press  to enter the carousel. Scroll to  **Handset** and select. , scroll to  **Date & time** and select. 
Press  to select **Set date** and enter the current date, press  **OK**

Scroll to **Set time** and enter the current time, press  **OK**

To set the handset ring tone

Press  to enter the carousel.
Scroll to  **Sounds** and select. 
Press  to select **Handset ring tones**,
Press  to select **External ring tone**,
browse through the list to hear the ring tones and select  your ring tone

DECT 311 Handset

Pilot key
 Press to enter the carousel or validate a choice
 - Scroll to navigate in the menus & options
- Move the cursor right/left
 - Scroll up to reach the **Call log** from idle mode
 - Scroll down to reach the **Phonebook** from idle mode
 Long press to unlock the keypad

Loudspeaker *
Press to take the line or activate the handset loudspeaker during a call

Keypad lock
- Short press to insert * when dialling
- Long press to lock/unlock the keypad in idle mode
- Long press to insert R (in between-digit pause) when predialling

SMS key
- Short press to reach **Send new SMS** menu from idle mode
- Short press from the Phonebook or the Call log to edit an SMS

Earpiece



Microphone

Talk
To take the line, answer a call or hang up

Clear/Recall
- To correct a digit when predialling or a character when editing
- Short press to go back one menu when navigating
- Long press to return to idle mode when navigating
- To insert R for operator services when on line

Do Not Disturb & case mode
- Short press to insert # when dialling
- Short press to switch case mode when editing
- Long press to activate/deactivate the "Do Not Disturb" mode
- Long press to insert a pause (P) when dialling

Call transfer/Intercom
- Short press to initiate or cancel internal call
- Short press to answer an internal call
- Short press during internal call to transfer the call or switch between internal call and external call

Alarm clock
- Short press to dial 0
- Long press to activate/deactivate the alarm clock





***Warning:** Handsfree activation could suddenly increase the volume in the earpiece to a very high level. Make sure the handset is not too close to your ear.

Icons on handset display

On first use, it may be necessary to wait for a few minutes of charge before seeing symbols on the display.



When charging, the battery bars scroll from empty to full status. When the handset discharges, the battery shows the status :

Full  , 2/3  , 1/3  and empty 



The ringer is deactivated.



A message on your operator voice mailbox



An external call is in progress. **When blinking**, this symbol indicates that there is an incoming call or that the line is already busy with an extra handset.



An internal call is in progress. **When blinking**, this symbol shows that there is an internal call with an extra handset.



The handset loudspeaker is activated.



The SMS function is activated. **When blinking**, this symbol indicates that a new SMS has been received. **When fast blinking**, it indicates that the SMS memory is full.



The handset is registered and in range of the base. **When blinking**, this symbol shows that the handset is not registered to the base.

DECT 311 base station

Paging key

The paging key enables you to locate a missing handset. Press the key until the handset starts to ring. Once retrieved, press any key on the handset to end paging.






Table of contents

Quick start guide	1	Intercom	
DECT 311 handset	2	Internal calls	20
Icons on the handset display	3	Call transfer	20
Base station DECT 311	3	Using conference call	21
Table of contents	4	Babysit mode	22
Menu structure	5	Phonebook	
Information		Add a name	23
Conformity, Environment and Safety	6	Viewing the phonebook	23
Using GAP	6	Call log	
Unpacking your DECT 311	6	Viewing the call log	26
Installing the phone		Deleting the call log	28
Installing the base station	7	Setting the call log	28
Installing and replacing the batteries	7	Operator services	29
Battery life and range	7	Extra	
Introduction		Call duration	30
Screen in idle mode	8	Alarm clock	30
Understanding the menu system	8	Setting the “Do Not Disturb” mode	32
How to navigate in the menus	8	Sounds	
Basic principles	9	Handset ring tones	33
In-call features	10	Group ring tones	33
Editing system	11	Handset ring tone volume	34
SMS		Settings	34
Send new SMS	12	Base station	
Read SMS	13	Enable registration	36
SMS settings	15	Line settings	36
Handset		Service codes settings	38
Babysit mode	17	FAQ	40
Registering/unregistering an additional handset	17	Troubleshooting	
Renaming the handset	18	Declaration of conformity	
Setting the date and time	18	Index	
Setting the display contrast	19		
Setting screen saver	19		

Menu structure

By using the “pilot key”  on the side of the handset, you can browse  through the menus



SMS

Send new SMS

- Send SMS

Read SMS

- View SMS
- View number
- Reply
- Forward
- Send again
- Delete SMS
- Copy to phonebook
- Call

SMS Settings

- SMS mode
- SMS center



Handset

Babysit mode

Registration

- Register handset
- Un-register handset
- Base selection

Rename handset

Date & time

Display contrast

Screen saver



Intercom



Phonebook

View

- Call
- Change number
- Change name
- Select group
- Change sub-address
- Delete
- Send SMS

Add new



Call log

View

Delete all

Call log settings



Operator services



Extra

Call duration

Alarm clock

- Activation
- Set day
- Set time
- Settings

Do not disturb mode



Sounds

Handset ring tones

Group ring tones

Handset ring tone volume

Settings



Base station

Enable registration

Line settings

- Dial mode
- Recall type
- Choose country/oper.
- First ring

Service codes settings

Conformity, Environment and Safety

Safety information : This equipment is not designed to make emergency calls when the power fails. An alternative has to be made available to allow emergency calls.

Conformity : Hereby, PHILIPS, declares that DECT 311XX is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC (see page 42).

This product can only be connected to the analogue telephone network of Singapore.

Power requirements : This product requires an electrical supply of 220-240 volts, alternating monophased power, excluding IT installations defined in standard EN 60-950.

In case of a power failure, the communication can be lost.

Warning ! The electrical network is classified as dangerous according to criteria in the standard EN 60-950. The only way to power down this product is to unplug the power supply from the electrical outlet. Ensure the electrical outlet is located close to the apparatus and is always easily accessible.

Telephone connection : The voltage on the network is classified as TNV-3 (Telecommunication Network Voltages, as defined in the standard EN 60-950).

Safety precautions : Do not allow the handset to come into contact with water. Do not open the handset or the base station. You could be exposed to high voltages. Do not allow the charging contacts or the battery to come into contact with conductive materials.

Environmental care : Please remember to observe the local regulations regarding the disposal of your packaging materials, exhausted batteries and old phone and where possible promote their recycling.

Using GAP standard compliance : The GAP standard guarantees that all DECT™GAP handsets and base stations comply with a minimum operating standard irrespective of their make. Your DECT 311 handset and base station are GAP compliant, which means the minimum guaranteed functions are : register a handset, take the line, receive a call and dial. The advanced features may not be available if you use another handset than an DECT 311 with your base station.

Unpacking DECT 311/DECT3112

The DECT 311 package contains :

NiMH 2HR
AAA600 mAh
rechargeable
Batteries



A base station



A handset



A user guide



A guarantee



A power supply



A line cord




In the DECT 3112 pack you will find one more additional handset and its charger & power supply, together with additional NiMH 2HR AAA 600 mAh rechargeable batteries.

Installing the phone

Installing the base station

To properly install the base station, connect the line cord and the power cable. Plug the cord and the cable into the wall. Situate your product close enough to the telephone and mains power sockets so that the cables will reach. If you have a broadband DSL Internet installation please make sure you have one DSL filter plugged directly on each line socket used in the house and check the modem and the phone are plugged in the correct filter slot (one specific for each).

Warning ! Always use the cables provided with the product.




Do not insert anything in this opening

Connect the power supply

Connect the telephone line cord

Installing and replacing the batteries



Batteries should not be disposed of with general household waste

Insert the batteries as indicated and slide the battery cover back into place.

Allow the handset to charge for 24 hours to reach full charge.

Optimal battery life is reached after 3 cycles of complete charge & discharge.

In case you need to change the batteries, only use the approved type :2HR AAA NiMH 600 mAh.

Note:The base station must always be plugged into the mains when charging or when in use. Always use rechargeable batteries.

Warning ! The electrical network is classified as dangerous according to criteria in the standard EN 60-950. The only way to power down this product is to unplug the power supply from the electrical outlet. Ensure the electrical outlet is located close to the apparatus and is always easily accessible

Battery life and range

Battery life in standby mode	Battery life in communication	Indoor range	Outdoor range
Up to 200 hours	Up to 15 hours	Up to 50 meters	Up to 300 meters






Introduction



Philips screen saver

After 2 minutes of inactivity, the screen saver is displayed :
You can deactivate it (See p.19)








The screen in idle mode



In idle mode, the DECT 311 display shows various information :

- the date & time, the name of the handset and the instructions to access the menu.
- Missed calls , new SMS  or operator voice mailbox message , if any.
- "Do Not Disturb" mode , and the alarm clock , if activated.

To activate/deactivate these functions press  or 









Understanding the menu system

- To access the carousel menu from idle screen, press  on the side of the handset.
- The carousel represents a loop of icons that gives access to the different first level menus.
- Scroll up or down  to reach the desired menu. Press  to enter that menu.
- The sub-menus are listed and represented by little squares at the bottom of the display.
- To reach one particular sub-menu (option) use the "pilot key"  and press  to enter it.
- A  shows the selected sub-menu (option).
- The  shows the sub-menu (option) your are browsing.

Certain menus are directly accessible via a dedicated key (Example : SMS  or Intercom )

Example of navigation in the menus

To set the handset melody volume

-  Press to enter the carousel menu
-  Scroll to **Sounds** and select 
-  Scroll to **Handset ring tone vol.** and select 
- The current level is heard,  to hear other levels
-  Browse through the levels and select one 

Basic principles

To make or to answer a call



Pre dialling
Dial the number

Or



Direct dialling
Press the key



Make the call



Dial the number



Answer a call
When ringing

Take the line

To call from the phonebook



Scroll down to directly reach the list of names




Choose a name in the list



Make the call



or press to select **Call** in the options



To store a name from predial



Dial the number



Press to enter the options



Scroll to **Store** and select



Enter the name and press **OK**



To store an SMS



Dial the number



Press to enter the options




Scroll to **Send SMS** and select



Edit the text and press **OK**



Scroll to **Store** and select



To redial from call log



Scroll up to directly reach **Call log**



Choose an entry in the list




Make the call or select **Call** in the options



In call features

During an external call, some other options are available.

Press  to enter **Options**.

To mute the handset microphone



Press to enter **Options**



Press to select **Mute** (The caller can no longer hear you)



Press again to resume the conversation (**End mute**)



Intercom (only if DECT 3.1.2)

During an external call, you can use the intercom in-call option to call another handset and for example transfer the call to this handset.



Press to enter **Options**



Scroll to **Intercom** (The caller can no longer hear you)

If there is only one additional handset it rings automatically, otherwise select a handset from the list.



Press to select **Transfer** when the second handset has taken the line. The call is then ended on your handset.



Other options are available (**Switch & Conference call**), See p.21.

To switch the handset loudspeaker ON/OFF

Press  to activate/deactivate the handset loudspeaker

Warning: Handsfree activation could suddenly increase the volume in the earpiece to a very high level. Make sure the handset is not too close to your ear.

To increase/decrease the handset earpiece/loudspeaker volume during a call



Scroll up to increase the volume when on line





Scroll down to decrease the volume when on line

There are 5 volume levels available. The last setting is stored for the next calls.

Caller Line Identification and Call waiting

If you subscribe to Call waiting, a beep in the earpiece informs you of a second incoming call. The name or number of the second caller may be displayed if you also subscribe to Caller Line Identification service.




To answer that second call, use  +  (according to your network, the code may be different). Please contact your network provider for more details.


Editing system


Case mode

By default, the first letter of a sentence is in upper case. Use  to change the case mode:

- all characters in upper case (AB)
- all letters in lower case (ab)
- First letter in upper case and the rest of the text in lower case (Ab)

Punctuation and mathematical marks are available through  and  while other special characters are available on .

Scroll  to move the cursor left or right.

Press  to delete a character ; a long press deletes the whole text.

The standard multi-tap system

This system allows you to enter the text character by character, pressing the corresponding key as many times as necessary to reach the desired character.

To write “Peter” with multi-tap


Press  once : P

Press  twice : Pe

Press  once : Pet

Press  twice : Pete

Press  three times : Peter

Press  to validate the name.

Keypad Keys

1
2
3
4
5
6
7
8
9
0

Multi-tap Sequence

[space] | @ _ # = < > () & € £ \$ ¥ [] { }
² §
a b c 2 à ä ç å æ
d e f 3 è é Δ φ
g h i 4 ì Γ
j k l 5 Λ
m n o 6 ñ ò ö
p q r s 7 ß Π θ Σ
t u v 8 ù ü
w x y z 9 φ Ω Ξ Ψ
. 0 , / ; " ' ! ; ? ; * + - % \ ^ ~ |



SMS

- Send new SMS
- Read SMS
- SMS settings




SMS menu is accessible via the Carousel or 

Important information are available on the SMS information leaflet in the box

SMS stands for Short Message Service. To benefit from this service you must subscribe to the Caller Line Identification together with the SMS service from your network provider.

SMS can be exchanged with a phone (mobile or compatible fixed line) provided the receiver has also subscribed to the CLI & SMS services.



 **Your DECT 311 factory settings correspond to the main national operator. If you wish to send or receive SMS through another service provider you must set the corresponding numbers** (See p.15 and the SMS leaflet).


Send new SMS

To send New SMS




Press to directly reach **Send new SMS** and select 

Enter the number and press  **OK** or scroll down  to retrieve the number from the phonebook

Enter the text and press 



To store your SMS, scroll to **Store** and select 

Press to select **Send now**

Note: If you store an SMS you can later retrieve it from **Read SMS**

The sent SMS can be up to 160 characters long (including e-mail address), the special characters **Euro** and [] count for 2.

It is possible to store a variable number of SMS (depending on the length of each SMS).



Read SMS

A stored SMS is marked in the SMS list. A received SMS is marked .

To read SMS/View number

sms

Press to directly reach **Send new SMS**



Scroll to **Read SMS** and select




Browse the SMS list and select



Press to select **Read SMS**



or scroll to **View number** and select



To reply

sms

Press to directly reach **Send new SMS**



Scroll to **Read SMS** and select



Browse the SMS list and select



Scroll to **Reply** and select



Enter the text and press **OK**



Press to select **Send now**



To forward

sms

Press to directly reach **Send new SMS**



Scroll to **Read SMS** and select



Browse the SMS list and select



Scroll to **Forward** and select




Enter the number and press **OK**



You can modify the text if necessary or select



Press to select **Send now**





To send again

sms

Press to directly reach **Send new SMS**




Scroll to **Read SMS** and select **↵**



Browse the SMS list and select **↵**



Scroll to **Send again** and select **↵**



To delete SMS

sms

Press to directly reach **Send new SMS**



Scroll to **Read SMS** and select **↵**



Browse the SMS list and select **↵**



Scroll to **Delete SMS** and select **↵**



Press to confirm **↵** **OK**



To copy a number to the phonebook

sms

Press to directly reach **Send new SMS**



Scroll to **Read SMS** and select **↵**



Browse the SMS list and select **↵**



Scroll to **Copy to phonebook** and select **↵**



Enter the name and press **↵** **OK**



To call

sms

Press to directly reach **Send new SMS**



Scroll to **Read SMS** and select **↵**




Browse the SMS list and select **↵**



Scroll to **Call** and select **↵**



Or make the call





SMS settings

To set the SMS mode

If there are 2 SMS-enabled phones on your telephone line, you will have to deactivate the SMS feature on 1 of the devices.

sms

Press to directly reach **Send new SMS**



Scroll to **SMS Settings** and select **➔**



Press to select **Mode**



Press to select **ON** or scroll to **OFF** and select **➔**

SMS Settings

Mode



To choose by default an SMS centre

sms

Press to directly reach **Send new SMS**



Scroll to **SMS Settings** and select **➔**



Scroll to **SMS centre** and select **➔**

Choose an SMS centre and select **➔**



Press to select **Choose by default**

SMS centre 1

Choose by default



To set the SMS centre numbers

sms

Press to directly reach **Send new SMS**



Scroll to **SMS Settings** and select **➔**



Scroll to **SMS centre** and select **➔**

Choose an SMS centre and select **➔**



Scroll to **Edit incoming number** and select **➔**



Enter the number and press **➔ OK**



Scroll to **Edit outgoing number** and select **➔**



Enter the number and press **➔ OK**

Edit incoming number

➔ OK

Edit outgoing number

➔ OK



Handset

- Babysit mode
- Registration
- Rename handset
- Date & time
- Display contrast
- Screen saver

Babysit mode (only DECT3112)

To activate/deactivate the babysit mode



Press to enter the carousel menu



Scroll to **Handset** and select



Press to select **Babysit mode**



Press to select **ON** or scroll to **OFF** and select



Note:An intercom is necessary to monitor the room (See p.22). You can still answer/make a call with the handset.

Registration

Up to 4 handsets can be registered to a base station. A handset can be registered to 4 base stations.

Warning !: if you wish to associate non Philips handset, make sure that this handset is GAP compliant, otherwise it will not operate properly.

- 1- Unplug and plug back in the mains lead to put the base in registration mode
 - 2- With the additional handset press to start the registration
 - 3- Enter the 4-digit RC code written on the sticker placed under the base station
- If successful the additional handset is named & numbered (example: **Philips2**)

To un-register a handset

To un-register a handset



Press to enter the carousel menu



Scroll to **Handset** and select



Scroll to **Registration** and select



Scroll to **Un-register handset** and select

Choose the handset in the list and press **OK**

Enter the RC code (4-digit code) and press **OK**



Note: Should you have your handset serviced, please make sure it is un-registered from the base before taking it back to it to the repair centre.



To select a base station



Press to enter the carousel menu



Scroll to **Handset** and select




Scroll to **Registration** and select



Scroll to **Un-register handset** and select

Choose the handset in the list and press **OK**

Enter the RC code (4-digit code) and press **OK**



Rename handset

To rename a handset



Press to enter the carousel menu



Scroll to **Handset** and select



Scroll to **Rename handset** and select



Long press to erase the current name

Enter the name and press **OK**



Date & time

To set the date & time



Press to enter the carousel menu



Scroll to **Handset** and select



Scroll to **Date & time** and select



Select **Set date**

Enter the current date press **OK**



Scroll to **Set time** and select

Enter the current time press **OK**



Warning ! If your phone is connected to an ISDN line through an adapter, the date & time settings may change after each call. Please check the date & time settings in your ISDN system. Please contact your network provider. See FAQ.p.39.



Display contrast

To set the display contrast



Press to enter the carousel menu



Scroll to **Handset** and select



Scroll to **Display contrast** and select



Browse through the levels and select



Screen-saver

After 2 minutes of inactivity, the screen saver is displayed (see p.8).
You can deactivate it.

To activate or deactivate the screen-saver



Press to enter the carousel menu




Scroll to **Handset** and select



Scroll to **Screen-saver** and select



Press to select **ON** or scroll to **OFF** and select





Intercom




Intercom menu is accessible via the Carousel or 

This feature allows you to make free internal calls, transfer internal calls from one handset to another or use the conference option (DECT 3112 only). It also enables you to use the babysit feature (room monitoring).

Internal call



Press to call the other handset (s)

To call a selected handset press handset number (for example )



Hang up

Note: If the handset does not belong to the Philips DECT 311 range, this function may not be available.

Fast call transfer when on line

During a call you can transfer the call without waiting for the other handset to pick up. All the handsets will then ring.



Press to call the other handset



Hang up

Note: The person on hold hears music.

A press on  allows you to switch between the 2 calls (**Switch**).

Call transfer to a specific handset when on line

During a call you can transfer the call to a specific handset.



Press + handset number (for example  to call the selected handset)



Hang up

Note: The person on hold hears music.

A press on  allows you to switch between the 2 calls (**Switch**).



Call transfer via the in-call options

During a call you can transfer the call via the in-call options.



Press to enter the options (with handset 1)



Scroll to **Intercom** and select

If there is only one additional handset, it rings automatically. Otherwise :

Select from the handsets list the handset you want to call and select

The called handset rings (handset 2).The external call is put on hold.

If there is no answer from the called handset you can resume the call on the first handset.



Take the line with handset 2. Or press

Both internal callers can talk.



Press to select **Transfer** (with handset 1)



Scroll to reach **Switch** and come back to the external caller



The conference call via the in-call options

Conference call allows one external call to be shared with two handsets (in intercom).

The 3 people can share the conversation. No operator subscription is needed.



Press to enter the options (with handset 1)



Scroll to **Intercom** and select

If there is only one additional handset, it rings automatically. Otherwise :

Select from the handsets list, the handset you want to call and select


The called handset rings (handset 2).The external call is put on hold.

If there is no answer from the called handset you can resume the call on the first handset.



Take the line with handset 2

Both internal callers can talk.



Scroll to the **Conference call** option and select (with handset 1)

The 3 people can share the conversation.



Initiate the babysit/Room monitoring

To use the babysit mode feature you need to activate it (see p.16) and to initiate an intercom. Place the handset in the baby's room and you will hear the noise on your additional handset.



Press to enter the carousel menu



Scroll to **Intercom** and select


If there is only one additional handset, it rings automatically. Otherwise :

Select from the handsets list the handset you want to call and select

The called handset rings

Take the line on the called handset

The room monitoring can start





Phonebook

- View
- Add new



Phonebook menu is accessible via the Carousel or

50 names and numbers can be stored in the phonebook (shared with all handsets).

The phonebook contains all the information related to the callers, especially the group settings. The names & numbers are shared with all the handsets registered to your base.

Group settings

There are 3 groups (group A, group B & group C). When ringing, the ringer helps you identify the caller's group (See p. 32) and the screen shows the caller's name.

A subscription to the Caller Line Identification service is needed.

Add new

The names are stored in alphabetical order.

To add a name and number



Press to enter the carousel menu



Scroll to **Phonebook** and select



Scroll to **Add new** and select



Enter the number and press **OK**

Enter the name and press **OK**



To store a name and number from predial

Once the number is dialled select **Store** in the options

Enter the name and press **OK**

View

To quickly reach a name in the phonebook, press the first letter of the name (browse if several names begin by the same letter).



To call



Scroll down to directly reach the list of names



Browse through the list of names and select a name



Make the call



Or press to reach the options



And press again to select **Call**



To change a number



Scroll down to directly reach the list of names



Browse through the list of names and select a name




Scroll to **Change number** and select



Press to erase current number



Enter the new number and press **OK**



Note: it is possible to erase the current number with . You can simply change any digit by moving the cursor to reach the digit and press .

To change a name



Scroll down to directly reach the list of names



Browse through the list of names and select a name




Scroll to **Change name** and select



Press to erase the current name



Enter the new name and press **OK**



Note: it is possible to erase the current name with . You can simply change any letter by moving the cursor to reach the letter and press .



To define a group for a name and a number (See p. 23)



Scroll down to directly reach the list of names



Browse through the list of names and select **→** a name



Scroll to **Select group** and select **→**



Browse through the groups (A, B, C) and select **→**



To delete a name and number



Scroll down to directly reach the list of names



Browse through the list of names and select **→** a name



Scroll to **Delete** and select **→**



Press to confirm **→** **OK**



To send an SMS from the phonebook



Scroll down to directly reach the list of names



Browse through the list of names and select **→** a name



Scroll to **Send SMS** and select **→**



Enter the text and press **→**



Press to select **Send now**



Note: Once in the list of names, a press on  enables you to directly edit your SMS text.



Call log

- View
- Delete all
- Call log settings



Call log menu is accessible via the Carousel or

The call log can store up to 20 entries.

- Unanswered call

- Outgoing calls

- Answered calls

- Messages (voice mailbox)

The call log shows the list of incoming & outgoing calls.

If you have subscribed to the Caller Line Identification (CLI), the name (or number) of the callers, will be displayed. The date & time of the call is also shown.

If you have no subscription the display shows “Unknown caller” as well as the date & time of the call.

View


To view the call log



Scroll up to directly reach the calls list



Browse through the list and read the information



To call/redial



Scroll up to directly reach the calls list



Browse through the list



Press to select an entry



Press to call



Or press to select **Call** in the options





To view the number



Scroll up to directly reach the calls list



Browse through the list



Press to select an entry



Scroll to **View number** and select

Gregory Mills

View number

□□□□

To store



Scroll up to directly reach the calls list



Browse through the list



Press to select an entry



Scroll to **Store** and select

Gregory Mills

Store

□□●□□



Enter the name or number and press **OK**

The name and number are stored in the phonebook.

To delete



Scroll up to directly reach the calls list



Browse through the list



Press to select an entry



Scroll to **Delete** and select

Gregory Mills

Delete

□□□●□



Press to confirm **OK**



To send an SMS



Scroll up to directly reach the calls list



Browse through the list



Press to select an entry



Scroll to **Send SMS** and select



Edit the text and press



Press to select **Send Now**

Note: Once in the list of names, a press on enables you to directly edit your SMS text.

To delete all

To delete all the call log



Press to access the carousel



Scroll to **Call log** and select



Scroll to **Delete all** and select



Press to confirm **OK**

Call log settings

To set the call log



Press to access the carousel



Scroll to **Call log** and select



Scroll to **Call log settings** and select



Press to select **Incoming calls** or scroll to **Outgoing calls**



Browse the various options and select



Operator services

This feature allows you to activate or deactivate operator services.

Codes need to be set in the phone (See p.37). Contact your network operator for more details.

Example of services : Call forward

To activate call forward



Press to enter the carousel menu



Scroll to **Operator services** and select

Operator Services



Press to select **Call forward**

Call forward

●○○○○○○○○



Enter the number to which the calls are to be forwarded and press **OK**

The number is automatically chained to the call forward prefix and the system dials



Hang up

From now on the calls will be redirected to the assigned phone number.

To deactivate call forward



Press to select **View**

Mon 13 May 04 08:00
Call forwarded



Press to select **Cancel**

View



Hang up



Extra

- Call duration
- Alarm clock
- "Do not disturb"

Call duration

To view the time



Press to enter the carousel menu



Scroll to **Extra** and select




Press to select **Call duration**

The total time of communications is displayed



Press to **Reset** the counter



The alarm clock

To activate/deactivate the alarm clock

A long press on activates/deactivates the alarm clock with your own settings.

To set the alarm clock



Press to enter the carousel menu



Scroll to **Extra** and select




Scroll to **Alarm clock** and select



Scroll to **Set day** and select a day



Scroll to **Set time**, enter the time and press **OK**



When the alarm rings, press any key to stop it.

The snooze is then activated (will ring every 5 mn). To definitely stop it, press



To set the alarm ringer type



Press to enter the carousel menu



Scroll to **Extra** and select



Scroll to **Alarm clock** and select



Scroll to **Settings** and select



Press to select **Ring tones** and select

The current ringer is heard



Browse through the list and select

Alarm Clock Settings

Ring tones



To set the alarm ringer volume



Press to enter the carousel menu



Scroll to **Extra** and select



Scroll to **Alarm clock** and select



Scroll to **Settings** and select



Scroll to **Ring tone Volume** and select

The current volume is heard



Browse through the levels and select

Alarm Clock Settings

Ring tone volume






“Do not disturb” mode

This feature allows you to screen calls after a certain time in the evening when you do not want to be disturbed. Enter the time and select the group(s) allowed to call you. If the caller does not belong to an allowed group the handset will remain silent, while he will hear ringing. The operator voice mailbox (if any) will answer the call. A subscription to Caller Line Identification service is needed.

To activate/deactivate “Do not disturb” mode


A long press on  activates/deactivates the “Do not disturb” mode with your own settings.

To set the “Do not disturb” mode



Press to enter the carousel menu



Scroll to **Extra** and select 




Scroll to **Do not disturb** and select 




Scroll to **Set day**, enter the day or period of time





Scroll to **Start time**, enter the time and press  **OK**



Scroll to **Stop time**, enter the time and press  **OK**



Scroll to **Allowed caller choice**, activate the callers group’s allowed to call you and select 



Warning ! Only allowed callers will be able to reach you during the selected day & time.

Note: You can select up to 4 groups. If no group is selected but the feature is activated, then nobody will be able to reach you.



Sounds

- Handset ring tones
- Group ring tones
- Handset ring tone volume
- Settings

Handset ring tones

To set the external ring tone



Press to enter the carousel



Scroll to **Sounds** and select 



Press to select **Handset ring tones**



Press to select **External ring tone**



Browse through the list to hear the ring tones



Press to select your ring tone

Handset ring tones

External ring tone



To set the internal ring tone

You can set the melody heard when receiving an internal call.



Press to enter the carousel



Scroll to **Sounds** and select 



Press to select **Handset ring tones**



Scroll to **Internal ring tone** and select 



Browse through the list to hear the melodies



Press to select your melody

Handset ring tones

Internal ring tone





Group ring tones

To set the group ring tone

There are 3 groups of callers (See p.23). You can associate 1 ring tone to a group.



Press to enter the carousel



Scroll to **Sounds** and select




Scroll to **Group ring tones** and select



Press to select a group (A, B or C)



Browse through the list of melodies and select



Handset ring tone volume

To set the ring tone volume



Press to enter the carousel



Scroll to **Sounds** and select




Scroll to **Handset ring tone vol.** and select



The current level is heard
Browse through the levels to hear them



Press to select the appropriate volume



Settings

To set the earpiece tone



Press to enter the carousel



Scroll to **Sounds** and select



Scroll to **Settings** and select




Press to select **Earpiece tone**



Browse through the options



And select the appropriate setting





To set the key & feedback tone



Press to enter the carousel



Scroll to **Sounds** and select




Scroll to **Settings** and select



Scroll to **Key & feedback tones** and select



Press to select **ON** or scroll to **OFF** and select



To set the notification beep



Press to enter the carousel



Scroll to **Sounds** and select




Scroll to **Settings** and select



Scroll to **Notification beep** and select



Press to select **ON** or scroll to **OFF** and select



To activate/deactivate the music on hold

The feature allows the caller to hear music when the call is put on hold when transferring a call from one handset to the other.



Press to enter the carousel



Scroll to **Sounds** and select



Scroll to **Settings** and select



Scroll to **Music on hold** and select



Press to select **ON** or scroll to **OFF** and select





Base station

- Enable registration
- Line settings
- Service codes settings

Enable registration

This feature allows you to register a DECT peripheral without keypad. Some DECT peripherals, such as repeaters, do not have keypad. A special menu-operated procedure is used to register such peripherals to the base station. Also use the peripheral instructions to register it to the base.

To register a DECT peripheral



Press to enter the carousel menu



Scroll to **Base station** and select




Press to select **Enable registration**



Enter the peripheral code and press **OK**

Follow the instructions in the peripheral manual



Line settings

To change the dial mode



Press to enter the carousel menu



Scroll to **Base station** and select



Scroll to **Line settings** and select



Press to select **Dial mode**



Press to select **Tone** or scroll to **Pulse** and select




Note: This setting allows you to select pulse dialling (also called “Loop disconnect”) and used in countries without DTMF tone dialling capability or using old PABX.



To change the recall type


- Press to enter the carousel menu
- Scroll to **Base station** and select
- Scroll to **Line settings** and select
- Scroll to **Recall type** and select
- Press to select **Short flash** or scroll to **Long flash** and select



Note: This setting is useful when using operator services. The use of some services accessed with R+1, R+2 and +3 (call waiting, call forward...) will depend on the flash setting (short/long) according to your installation type (ISDN, Public, PABX).

To change the configuration

- Press to enter the carousel menu
- Scroll to **Base station** and select
- Scroll to **Line settings** and select
- Scroll to **Choose country/oper.** and select
- Browse through the countries and select the appropriate one




Note: Useful if the Caller Line Identification service does not work whereas you subscribed to that service.

To prevent the phone from ringing when receiving an SMS, the first ring is deactivated. You can activate it.

To activate/deactivate the first ring

- Press to enter the carousel menu
- Scroll to **Base station** and select
- Scroll to **Line settings** and select
- Scroll to **First ring** and select
- Press to select **ON** or scroll to **OFF** and select





Service codes settings

When you subscribe to extra services with your operator you may need to set some codes in your phone.

The default codes are codes used by the main national operator.

If you subscribed to another operator you may need to change the codes.

Contact your network operator for more information on the services.

To change a service code



Press to enter the carousel menu



Scroll to **Base station** and select




Scroll to **Service code settings** and select



Browse the list of services and select



Enter the new code and press **OK**



I have no dialling tone after having installed my phone. How do I solve this problem?

Check that you have connected your phone using the supplied line cable and not the one from any previous phone (they are often wired differently).

Check that you have fully charged the handset according to the instructions given for the phone.

Check that the aerial icon (radio link with the base station) is displayed. If the handset is not registered you may need to register it (refer to the user guide).

Can the handset be left on the base all the time?

Yes there is no "memory effect". The handset can be left on the base station for all current models using NiMh batteries.

Will my phone lose all recorded data (phonebooks entries) in the case of a general power cut?

No it will not. The data recorded in your phone is not deleted in the case of a general power failure or when you unplug your base station or when you replace the batteries.

I have set up the date & time on my phone and the information given after a call is not correct. Why?

If you have a ISDN phone installation, these parameters (date & time) may be transferred directly through the ISDN to the phone. If you did not set-up the ISDN correctly this can explain why the information transmitted is not correct. Set-up the date & time directly on the ISDN phone installation or, if this is not possible, call the Operator/dealer who provided and installed the ISDN.

What is CLI and how do I make it work?

CLI stands for Caller Line Identification and it is a special service that you may subscribe to from your network operator. Once you have subscribed to the service, a CLI enabled phone will display the callers number (unless withheld) as the phone rings so that you may decide whether or not to take the call.

The CLI service does not work on my Philips phone on my digital phone installation (ISDN, ADSL). How do I solve this problem?

Our products are designed to work on an analogue network. If you plugged your PHILIPS phone into a digital installation, the CLI may not be displayed upon incoming calls. Digital phone installations (ISDN) are not always compatible with analogue phones as far as operator services are concerned.

You may find the information regarding compatibility in the user guide of your ISDN. If not, please contact the ISDN manufacturer to check if the device is designed to display CLI on analogue phones. ISDN over 2 or 3 years old are generally not compatible with analogue phones for the CLI Service.

Note that the filters used with some ADSL lines can filter out part of the CLI signal and prevent the phone from displaying CLI correctly. It is possible to purchase better ADSL filters that do not cause this problem.

What is CNIP (Caller Name Identification)?

As with the CLI service this new feature is dependent on the Network and it has to be activated by your Operator (by subscription). It will allow you to have the name of the caller displayed upon an incoming call. This service may not be available from all Operators yet. We advise you to check with your Operator. NB. If the name of the caller is registered in your phonebook upon an incoming call it will be the name you have registered which will be displayed and not the one provided by the Operator. The data in your phonebook will have priority over the Operator's data in this particular case. The CNIP uses the same technology as for the CLI. Therefore the limits of this service are identical (please refer to the questions related to CLI if the service is not working properly). Remember that it only works with alphanumeric display.

Which are the conditions required to be able to send an SMS ?

You must first have a subscription to Caller Display (CLI) service from your network operator as well as an SMS service subscription from the appropriate provider.

Is it possible to write, read send or receive an SMS when the other handset is in communication (DECT 3112 only)?

No it is not possible.

What happens if I send an SMS to a fixed line with no SMS phone ?

The correspondent could receive a vocal message (SMS provider dependent).

Is it possible to send an SMS to a fixed line in another country ?




This feature depends on your provider. Please contact your provider for more details.

How can I get the SMS centre number ?

One SMS centre number at least is pre-programmed in your DECT 311. However, should you need to store another number, other numbers can be set into the phone from the menu **SMS/SMS Settings/SMS centre**. Please check the incoming and outgoing centre numbers with the SMS provider or from the enclosed addendum to your phone user manual.


When using my SMS-enabled Philips phone with another SMS-enabled phone on the same line, can it cause any problems ?


Yes, this will prevent the phones from receiving SMS. You need to deactivate the SMS feature on one of the phones. Your DECT 311 has a feature which enables you to turn the SMS feature off. Go to menu **SMS/SMS Settings/Mode/OFF**

PROBLEMS	CAUSES	SOLUTIONS
The  does not scroll when the handset is placed on the base	<ul style="list-style-type: none"> - Bad battery contact - Dirty contact - Battery is full 	<ul style="list-style-type: none"> - Move the handset slightly - Clean the contact with a cloth moistened with alcohol - No need to charge
No dialling tone	<ul style="list-style-type: none"> - No power - Batteries are too low - You are too far from the base station 	<ul style="list-style-type: none"> - Check the connections. Reset the phone : unplug and plug back in the mains - Charge the batteries at least 24 hours - Move closer to the base station - Always use the cables provided
No ringer	<ul style="list-style-type: none"> - The ringer is deactivated - The Do not Disturb mode is ON 	<ul style="list-style-type: none"> - Set the ringer (page 33) - Deactivate it (page 32)
The  does not appear	<ul style="list-style-type: none"> - No mains power - The handset is too far from the base station 	<ul style="list-style-type: none"> - Check connections - Move closer to the base station
The  is blinking	<ul style="list-style-type: none"> - Handset not registered to the base station 	<ul style="list-style-type: none"> - Register the handset to the base (page 17)
<ul style="list-style-type: none"> - Crackling on the line 	<ul style="list-style-type: none"> - You are too far from the base station - The base station is too close to electrical appliances, reinforced concrete walls or metal door-frames 	<ul style="list-style-type: none"> - Move closer to the base station - Move the base station to find a better place (the higher the better)
The handset displays 'not available' <ul style="list-style-type: none"> - when attempting to add another handset to the base station - when using a handset 	<ul style="list-style-type: none"> - The procedure to add a handset has failed, try again - Maximum number of handsets has been reached - Base station is already busy with another handset (ie : phonebook) 	<ul style="list-style-type: none"> - Disconnect and connect the base station power supply. Follow the procedure to register a handset (page 17) - Un-register a handset - Wait until it is available
Noise interference on your radio or television	The DECT 3.11 base station or mains power pack are too close to electrical appliances	Move the power pack or base station as far as possible
Caller Line Identification (CLI) service does not work	- The service is not activated	- Check your subscription with your network operator

PROBLEMS	CAUSES	SOLUTIONS
A phonebook entry cannot be memorised	The phonebook is full	Delete an entry to free memory
No new SMS are received	SMS memory is full	Delete old SMS
No SMS can be sent or received	<ul style="list-style-type: none"> - The outgoing or incoming SMSC number is not set or is wrong - SMS mode is OFF - You have no subscription - Another SMS-enabled phone is also on your line - There is a problem of compatibility between operators 	<ul style="list-style-type: none"> - Contact your operator to get the correct SMSC's numbers - Activate SMS mode (page 15) - Contact your provider for more information - Deactivate the SMS mode on one of the device. - Contact your provider for more information
No caller Id/ poor audio quality/Poor connection quality with broadband DSL internet	<ul style="list-style-type: none"> - DSL filter(s)/splitter missing or insufficient number of filters - Modem &/or phone plugged in the wrong DSL filter slot - Defective DSL filter 	<ul style="list-style-type: none"> - Make sure you have one DSL filter plugged directly on each line socket used in the house - Check the modem and the phone are plugged in the correct filter slot (one specific for each) - The filter(s) can be defective. Replace it/them and make another test

Philips has marked the battery and packaging with standard symbols designed to promote the recycling and appropriate disposal of your eventual waste.

 A financial contribution has been paid to the associated national recovery & recycling system.

 The labelled packaging material is recyclable.

DECT™ is a Trade Mark of ETSI registered for the benefit of the implementers of the DECT technology.

Declaration of conformity

We
Philips Consumer Electronics
Route d'Angers
72081 Le Mans Cedex 9
France

Declare that the products DECT 311XX are in compliance with the Annex III of the R&TTE-Directive 1999/5/EC and then with the following essential requirements :

Article 3.1.a (protection of the health & the safety of the user) : EN 60950-1 (10/2001)

Article 3.1.b (protection requirements with respect to electromagnetic compatibility : ETSI EN 301 489-6 VI.2.1 (08/2002) & ETSI EN 301 489-1 VI.4.1 (08/2002)

Article 3.2 (effective use of the radio spectrum) EN 301 406 (2003)

The presumption of conformity with essential requirements regarding Council Directive 1999/5/EC is ensured.

Date : 10/05/2004
Le Mans

Quality Manager
Home Communication

A handwritten signature in black ink, consisting of a stylized 'M' followed by a horizontal line and an arrow pointing to the right.

A

Add new (phonebook) 22
Alarm clock 29

B

Babysit 16, 21
Base 3
Base installation 7

Batteries 7

C

Call duration 29
Call log settings 27
Call forward 28
Change name (phonebook) 23
Change number (phonebook) 23
Choose country/operator 36
Conformity 6
Copy to phonebook (name) 14

D

Date and time 17
Declaration of conformity 42
Define groups 24
Delete all (call log) 27
Delete call log entry 26
Delete name (phonebook) 24
Delete SMS 14

Delivery report 12
Dial mode 35

Display contrast 18
Do not disturb 31

E

Earpiece tone 33
Edition mode 11
Enable registration (DECT peripheral) 35

F

FAQ 38
First ring 37
Forward SMS 13

G

GAP 6
Groups 33

H

Handset 2
Handset melody 32

I

Idle mode 8
Intercom 10, 19, 20

K

Key and feedback tone 34
Keypad lock 2

L

Line settings 35
Loudspeaker (handset) 10

M

Make call 9, 14, 23, 25
Menu structure 5
Music on hold 34
Mute 10

N

Navigation in menus 8
Notification beep 34

O

Operator services 28

Q

Quick start guide 1

R

Read SMS 13
Recall type 36
Redial 9
Rename handset 17
Reply 13
Register handset 16
Ring tone 32
Ringer type (alarm) 30
Ringer volume (alarm) 30

S

Screen-saver 8, 18
Send again SMS 14
Send new SMS 12
Send SMS (phonebook) 24
Send SMS (call log) 27
Service code settings 37
SMS centre 15
SMS centre (default) 15
SMS mode 15
Store (name & number) 9
Store (SMS) 9
Store from call log 26
Symbols 3

T

Table of contents 4
Troubleshooting 40

U

Unpacking DECT 311 6
Un-register handset 16

V

View call log 25
View number 26
Volume (earpiece) 10
Volume (ring tone) 33

Index

© 2004
Philips Consumer Electronics
Home Communication
All rights reserved
Printed in Hungary
www.philips.com



SG 3111 285 23301