

Always there to help you

Register your product and get support at
www.philips.com/welcome



DA1200



User manual

PHILIPS

Contents

1 Important	2
Safety	2

2 Your DAB+ digital radio	3
Introduction	3
What's in the box	3
Overview	3

3 Get started	4
Connect power	4
Turn on	4
Adjust volume	5
Connect the earphones	5

4 Listen to DAB radio	5
Switch to DAB mode	5
Store DAB radio stations automatically	5
Store DAB radio stations manually	6
Select a preset DAB radio station	6
Display DAB information	6
Use DAB menu	6

5 Listen to FM radio	8
Switch to FM mode	8
Tune to a radio station manually	8
Tune to a radio station automatically	8
Store FM radio stations	8
Select a preset FM radio station	8
Display RDS information	8
Use FM menu	9

6 Synchronize the clock	9
--------------------------------	----------

7 Upgrade the software	10
Register your product	10
Check the current software version	10
Perform the upgrade	10

8 Product information	11
Tuner (FM/DAB)	11
General information	11
RDS program types	11

9 Troubleshooting	12
--------------------------	-----------

10 Notice	12
Compliance	12
Care of the environment	12
Copyright	13

11 About DAB	13
---------------------	-----------

1 Important

Safety

- Never lubricate any part of this unit
- Never place this unit on other electrical equipment.
- Never expose this device to direct sunlight, naked flames, or heat.
- Only use attachments/accessories specified by the manufacturer.
- Refer all servicing to qualified service personnel. Servicing is required when the digital radio has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the digital radio, the digital radio has been exposed to rain or moisture, does not operate normally, or has been dropped.
- The unit shall not be exposed to dripping or splashing.
- Do not place any sources of danger on the unit (e.g. liquid filled objects, lighted candles).
- Where the mains plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.

Hearing safety



Listen at a moderate volume.

- Using headphones at a high volume can impair your hearing. This product can produce sounds in decibel ranges that may cause hearing loss for a normal person, even for exposure less than a minute. The

higher decibel ranges are offered for those that may have already experienced some hearing loss.

- Sound can be deceiving. Over time your hearing 'comfort level' adapts to higher volumes of sound. So after prolonged listening, what sounds 'normal' can actually be loud and harmful to your hearing. To guard against this, set your volume to a safe level before your hearing adapts and leave it there.

To establish a safe volume level:

- Set your volume control at a low setting.
- Slowly increase the sound until you can hear it comfortably and clearly, without distortion.

Listen for reasonable periods of time:

- Prolonged exposure to sound, even at normally 'safe' levels, can also cause hearing loss.
- Be sure to use your equipment reasonably and take appropriate breaks.

Be sure to observe the following guidelines when using your headphones.

- Listen at reasonable volumes for reasonable periods of time.
- Be careful not to adjust the volume as your hearing adapts.
- Do not turn up the volume so high that you can't hear what's around you.
- You should use caution or temporarily discontinue use in potentially hazardous situations. Do not use headphones while operating a motorized vehicle, cycling, skateboarding, etc.; it may create a traffic hazard and is illegal in many areas.



Note

- The type plate is located on the back of the product.

2 Your DAB+ digital radio

Congratulations on your purchase, and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

Introduction

With this digital radio, you can listen to


- FM radio (RDS radio included), and
- DAB radio (DAB+ radio included).

What's in the box

Check and identify the contents of your package:

- Digital radio
- AC power adaptor
- USB cable
- Earphones
- User manual

Overview



- ① Earphones socket.
- ② **Display panel**
 - Display current information.
- ③ **INFO**
 - Display DAB/RDS information
- ④ /
 - Connect to the AC power adaptor through a USB cable for power and battery charge.
 - Connect to PC for software upgrade.
- ⑤ **MENU**
 - Access DAB/FM menu.
- ⑥ /
 - Adjust volume.
 - /
 - Select a menu item.
 - Press repeatedly to tune to a radio station at a specific frequency.
 - Press and hold to activate the automatic tuning to a radio station with strong signals.

OK

 - Confirm an option.
 - Press to activate the automatic tuning to the next radio station with strong signals.
- ⑦ **DAB/FM**
 - Switch the source between FM radio and DAB radio.
- ⑧ **PRESET**
 - Press to access the list of stored radio stations.
 - Press and hold to access the menu for storing a radio station.
- ⑨ **Power switch**
 - Turn on or off the digital radio.

3 Get started

Always follow the instructions in this chapter in sequence.

If you contact Philips, you will be asked for the model number and serial number of this product. The model number and serial number are on the back of the product. Write the numbers here:

- Model No. _____
- Serial No. _____





Connect power




Caution


- Risk of product damage! Make sure that the power supply voltage matches with the voltage printed on the back of the product.
- Risk of electric shock! When you unplug the AC power adaptor; always pull the plug from the socket. Never pull the USB cable.
- Before connecting the AC power adaptor; make sure that you have completed all other connections.
- When you unplug the USB cable from the digital radio or adaptor, disconnect the adaptor from the power supply first.
- The battery contains chemical substances, so it should be disposed of properly.

This digital radio can be powered by AC mains or build-in battery.

- 1 Uncover the  /  socket on the left of the unit.
- 2 Connect the USB cable to
 - the  /  socket, and
 - the AC power adaptor.



- 3 Connect the AC power adaptor to the power supply.




↳ The digital radio begins to charge.



Note

- To use the build-in battery as power supply, make sure that its power is sufficient. If not, follow steps mentioned above to charge your digital radio.

Turn on



Slide the power switch to **ON**.


- ↳ **[Welcome to Digital Radio]** (welcome to use this digital radio) is displayed.
- ↳ The digital radio switches to the last selected source.
- To turn it off, slide the power switch to **OFF**.

Adjust volume

Press ▲ / ▼ repeatedly.

- ▲ : Increase the volume.
- ▼ : Decrease the volume.

Connect the earphones

- Before tuning to a radio station, connect the supplied earphones to the  socket on the top of the product.
- For optimal reception, fully extend the cable of your earphones and adjust the position of your digital radio.

Note

- To avoid interference, position your digital radio as far as possible from TV, VCR, or any other radiation source.

4 Listen to DAB radio

Switch to DAB mode


Press **DAB/FM** repeatedly until **[DAB Mode]** (DAB mode) is displayed.

Store DAB radio stations automatically

For the first time use

When the digital radio is switched to DAB mode for the first time, or no DAB station is stored, the digital radio automatically stores DAB radio stations.

- 1 Press **DAB/FM** repeatedly to switch to DAB mode.
↳ The scan starts.



- A progress bar on the bottom: indicates the progress of the search.
- A number on the middle right: indicates the total number of stations that has been stored.

- 2 The scan is complete.
↳ If stations are stored, the first stored station is broadcast automatically.
↳ If no DAB station is stored, **[No DAB Station]** (no DAB station) is displayed.

Re-scan DAB radio stations

To keep the list of DAB stations up-to-date, perform full scan regularly.

- 1 Press **MENU** to access the DAB menu.
- 2 Press **◀/▶** repeatedly until **[Full scan]** (full scan) is displayed.
- 3 Press **OK** to confirm.
↳ The scan goes on until all available DAB radio stations are stored, and then the first available station is broadcast.

Store DAB radio stations manually

Note

- You can store up to 10 DAB radio stations.

- 1 Tune to a DAB radio station.
- 2 Press and hold **PRESET** until **[Preset Store]** (store as a preset station) is displayed.
- 3 Press **◀/▶** repeatedly to select a sequence number.
- 4 Press **OK** to confirm.
- 5 Repeat steps 1 to 4 to store more DAB stations.

Note

- To overwrite a preset station, store another station with its sequence number.

Select a preset DAB radio station

- 1 Press **PRESET**.
↳ **[Preset Recall]** (recall the list of preset stations) is displayed.
- 2 Press **◀/▶** repeatedly to select a preset DAB radio station.
- 3 Press **OK** to confirm.

Note

- If no button is pressed within 15 seconds when you scroll through the preset station list, the radio tunes to last selected station.

Display DAB information

- 1 Tune to a DAB radio station.
- 2 Press **INFO** repeatedly to scroll through the following information (if available):
 - Dynamic Label Segment (DLS)
 - Signal strength
 - Program Type (PTY)
 - Ensemble name
 - Channel and frequency
 - Signal error rate
 - Bit rate and audio status
 - Time

Use DAB menu

- 1 Press **MENU** to access the DAB menu.
↳ **[Station list]** (station list) is displayed.
- 2 Press **◀/▶** repeatedly to select a menu item.
- 3 Press **OK** to confirm the option.

- 4 Repeat steps 2 and 3 if sub-options are available.
- **[Station list]** (station list): display the list of all stored DAB radio stations.
 - **[Full scan]** (full scan): scan all available DAB radio stations.
 - **[Manual tune]** (manual tune): tune to a specific channel/frequency manually and add it to the station list.
 - **[DRC]** (DRC): Dynamic range compression adds or removes a degree of compensation for the differences in the dynamic range between radio stations.
 - **[DRC high]** (DRC high): set DRC in high level.
 - **[DRC low]** (DRC low): set DRC in low level.
 - **[DRC off]** (DRC off): turn off DRC.



Note

- Before you perform the software upgrade, make sure that the latest software is available on your PC and the digital radio is correctly connected to your PC through the USB cable.
- If no button is pressed within 15 seconds, the product exits the menu.



Note

- DRC only works when the broadcaster enables it for a specific station.
-
- **[Station order]** (station order): select an ordering pattern for the list of stored stations.
 - **[Alphanumeric]** (alphanumeric): list stations in alphanumeric order.
 - **[Ensemble]** (ensemble): list groups of stations that are broadcast together on the same ensemble.
 - **[System]** (system): adjust system settings.
 - **[Backlight]** (backlight): select **[On]** to keep the backlight on, or select a duration for the backlight.
 - **[Language]** (language): select a language for displayed menus.
 - **[Factory Reset]** (factory reset): reset all settings to factory default.
 - **[Software Upgrade]** (software upgrade): upgrade the software when available.
 - **[SW version]** (software version): display the version information of current software.

5 Listen to FM radio

Switch to FM mode

Press **DAB/FM** repeatedly until **[FM Mode]** (FM mode) is displayed.

Tune to a radio station manually

Press **◀/▶** repeatedly until the target frequency is displayed.

Tune to a radio station automatically

Press **OK**, or press and hold **◀/▶** for more than two seconds.

- ↳ **[Scanning]** (scanning) is displayed until a station with strong signals is detected and broadcast.

Store FM radio stations

Note

- You can store up to 10 FM radio stations.

- 1 Tune to an FM radio station.
- 2 Press and hold **PRESET** until **[Preset Store]** (store as a preset station) is displayed.
- 3 Press **◀/▶** repeatedly to select a sequence number.
- 4 Press **OK** to confirm.
 - ↳ The frequency of the preset radio station is displayed behind the sequence number.

- 5 Repeat steps 1-4 to store more FM stations.

Tip

- To overwrite a preset station, store another station with its sequence number.

Select a preset FM radio station

- 1 Press **PRESET**.
 - ↳ **[Preset Recall]** (recall the list of preset stations) is displayed.
- 2 Press **◀/▶** repeatedly to select a preset FM radio station.
- 3 Press **OK** to confirm.

Note

- If no button is pressed within 15 seconds when you scroll through the preset station list, the radio tunes to the last selected station.

Display RDS information

Radio Data System (RDS) is a service that allows FM stations to transmit additional information. When you tune to an FM radio station that transmits RDS signals, the station name is displayed.

- 1 Tune to an RDS station.
- 2 Press **INFO** repeatedly to scroll through the following information (if available):
 - Radio text
 - Program type such as **[NEWS]** (news), **[SPORT]** (sport), **[POP M]** (pop music)...
 - Station name
 - Mono/stereo

Use FM menu

- 1 Press **MENU** to access the menu.
↳ **[Scan setting]** (scan settings) is displayed.
 - 2 Press ◀/▶ repeatedly to select a menu item.
 - 3 Press **OK** to confirm the option.
 - 4 Repeat steps 2 and 3 if sub-options are available.
- **[Scan setting]** (scan setting)
 - **[All stations]** (all stations): scan all FM radio stations.
 - **[Strong stations only]** (strong stations only): scan stations with strong signals only.
 - **[Audio setting]** (audio setting)
 - **[Stereo allowed]** (stereo allowed): select stereo broadcast.
 - **[Forced mono]** (forced mono): select mono broadcast.
 - **[System]** (system)
 - **[Backlight]** (backlight): select **[On]** to keep the backlight on, or select a duration for the backlight.
 - **[Language]** (language): select a language for displayed menus.
 - **[Factory Reset]** (factory reset): reset all settings to factory default.
 - **[Software Upgrade]** (software upgrade): upgrade the software when available.
 - **[SW version]** (software version): display the version information of current software.

Note

- Before you perform the software upgrade, make sure that the latest software is available on your PC and the digital radio is correctly connected to your PC through the USB cable.
- If no button is pressed within 15 seconds, the product exits the menu.

6 Synchronize the clock

The digital radio can automatically synchronize its clock with a DAB or RDS radio station that transmits time signals.

Note

- The time accuracy depends on the DAB or RDS radio station.

7 Upgrade the software

Note

- Before you perform the upgrade, make sure that the latest software is available on your PC and the digital radio is correctly connected to your PC through the USB cable.
- Power supply must not be interrupted during the upgrade.
- If the upgrade fails, turn off the radio first, turn it on again, and then redo the upgrade.

Check the current software version

Follow the steps to check the version of current software on your product.

- 1 Press **DAB/FM** to switch to radio mode.
- 2 Press **MENU** to access the menu.
- 3 Press **◀/▶** to select [**System**] (system), and then press **OK**.
- 4 Press **◀/▶** to select [**SW version**] (software version), and then press **OK**.
↳ The version of current software scrolls on the display panel

Register your product

- 1 Go to www.philips.com/welcome.
- 2 Click the link of "**Register my product**" (the exact wording of this link name may vary in different languages).
- 3 Log in with your account on the prompt Web page.
 - If you have no account for Club Philips, create one first on this Web page.
- 4 Search your product with "**DA1200/05**" as the keyword.
- 5 Click the link of search result to access the Web page for registering your product.
- 6 Fill in necessary information about this product to complete the registration.
↳ With the registration, you can get information about software update and product support at this Web page or via your mailbox that is registered as the account for Club Philips.

Perform the upgrade

- 1 Go to www.philips.com/welcome.
- 2 Log in with your account for Club Philips.
↳ Support information about your registered product is displayed.
- 3 Click the link of "**Firmware Upgrade Readme File**" (the exact wording of this link name may vary in different languages).
- 4 Read and understand the instructions on software upgrade.
- 5 Follow the instructions to download the upgrade packet and complete the upgrade.

8 Product information

Note

- Product information is subject to change without prior notice.

Tuner (FM/DAB)

Tuning range	FM: 87.5 - 108 MHz DAB: 174.928 - 239.200 MHz (Band III)
Tuning grid (FM)	50 kHz
Sensitivity	
- Mono, 26 dB S/N ratio	< 22 dBu
- Stereo, 46 dB S/N ratio	< 45 dBu
Search selectivity	
-All stations	30 dBf
-Strong station	35 dBf
Total harmonic distortion	< 2%
Signal-to-noise ratio	> 55 dB

General information

AC power adaptor	PHILIPS
- Brand name	S005SB0500050
- Model	100-240 V~; 50/60
- Input	Hz; 150 mA
- Output	5 V == 0.5 A
Operation power consumption	2.5 W
Headphone output power	3 mW x 2 (16 Ohm)
Dimensions (H x W x D)	172 x 92 x 72 mm
Net weight	0.067 kg

RDS program types

NO TYPE	No RDS programme type
NEWS	News services
AFFAIRS	Politics and current affairs
INFO	Special information programs
SPORT	Sports
EDUCATE	Education and advanced training
DRAMA	Radio plays and literature
CULTURE	Culture, religion and society
SCIENCE	Science
VARIED	Entertainment programs
POP M	Pop music
ROCK M	Rock music
MOR M	Light music
LIGHT M	Light classical music
CLASSICS	Classical music
OTHER M	Special music programs
WEATHER	Weather
FINANCE	Finance
CHILDREN	Children's programs
SOCIAL	Social Affairs
RELIGION	Religion
PHONE IN	Phone In
TRAVEL	Travel
LEISURE	Leisure
JAZZ	Jazz Music
COUNTRY	Country Music
NATION M	National Music
OLDIES	Oldies Music
FOLK M	Folk Music
DOCUMENT	Documentary
TES	Alarm Test
ALARM	Alarm

9 Troubleshooting



Warning

- Never remove the casing of this product.

To keep the warranty valid, never try to repair the product yourself.

If you encounter problems when using this product, check the following points before requesting service. If the problem remains unsolved, go to the Philips Web page (www.philips.com/support). When you contact Philips, make sure that the product is nearby and the model number and serial number are available.

No power

- When you use the build-in battery as power supply, make sure that its power is sufficient.
- When you use AC power adaptor as power supply, make sure that the USB cable is properly connected to both the digital radio and the power adaptor, and there is power at the AC outlet.

No sound

- Fully insert your earphones.
- Adjust the volume.

No response from the unit

- Make sure that the power is available.
- Turn off the product, and then turn it on again.

Poor radio reception

- Due to the interference from other electrics or building obstacles, the signals become weak. Move to a place free of interference.
- Make sure that the earphone cable is fully extended.

10 Notice

Any changes or modifications made to this device that are not expressly approved by Philips Consumer Lifestyle may void the user's authority to operate the equipment.

Compliance



This product complies with the radio interference requirements of the European Community.

Care of the environment



Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.



When this crossed-out wheeled bin symbol is attached to a product it means that the product is covered by the European Directive 2002/96/EC. Please inform yourself about the local separate collection system for electrical and electronic products.


Please act according to your local rules and do not dispose of your old products with your normal household waste.

Correct disposal of your old product helps to prevent potential negative consequences for the environment and human health.



Your product contains batteries covered by the European Directive 2006/66/EC, which cannot be disposed with normal household waste. Please inform yourself about the local rules on separate collection of batteries because correct disposal helps to prevent negative consequences for the environmental and human health.

Always bring your product to a professional to remove the built-in battery.



Environmental information

All unnecessary packaging has been omitted. We have tried to make the packaging easy to separate into three materials: cardboard (box), polystyrene foam (buffer) and polyethylene (bags, protective foam sheet.)

Your system consists of materials which can be recycled and reused if disassembled by a specialized company. Please observe the local regulations regarding the disposal of packaging materials, exhausted batteries and old equipment.

Copyright

2012 © Koninklijke Philips Electronics N.V.
Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V or their respective owners. Philips reserves the right to change products at any time without being obliged to adjust earlier supplies accordingly.

11 About DAB

What is Digital Audio Broadcasting (DAB)?

DAB digital radio is a new way of broadcasting radio via a network of terrestrial transmitters. It provides listeners with more choice and information delivered in crystal clear, crackle-free sound quality.

- The technology allows the receiver to lock on to the strongest signal it can find.
- With DAB digital stations there are no frequencies to remember; and sets are tuned by station name, so there is no returning on the move.

What is DAB+?

DAB+ is based on the original DAB standard but uses a more efficient audio codec. Whereas DAB uses MPEG Audio Layer II (better known as MP2), DAB+ uses HE-AAC v2 (better known as MP4 or AAC+). This allows equivalent or better subjective audio quality to be broadcast at lower bit rates. The increased efficiency offers benefits for Governments and Regulators (even better spectrum efficiency), broadcasters (lower costs per station) and consumers (a wider choice of stations). DAB+ is designed to provide the same functionality as the original DAB radio services including services following (e.g. to the same service on another DAB ensemble or its FM simulcast), traffic announcements and PAD multimedia data (e.g. dynamic labels such as title artist information or news headlines; complementary graphics and images etc.)

What is a multiplex?

Digital radio operation is made up of a single block of frequencies called a multiplex. Each multiplex works within a frequency spectrum, such as Band III for DAB broadcasts.

DAB BROADCASTERS AND DLS

Each DAB broadcaster (or multiplex operator) also provides text and audio data services. Some programs are supported by Dynamic Label Segments (DLS). This is data which you can read as scrolling text on your DAB radio display. Some stations transmit the latest news, travel, and weather; what's on now and next, website addresses and phone numbers.



Tip

- For more information about digital radio coverage and services, go to www.drdb.org.



Specifications are subject to change without notice
© 2012 Koninklijke Philips Electronics N.V.
All rights reserved.

DA1200_05_UM_V1.0

