

PHILIPS

Television

6909 Series

User Manual

32PHG6909/78
43PFG6909/78

Content

1 Home Screen	4	8.5 Remove a Device	19
1.1 Introduction	4	8.6 Turn Bluetooth on or off	19
1.2 Dashboard and Settings	4	9 Connect your Google TV	20
1.3 Basic Mode and Google TV Mode	4	9.1 Network and Internet	20
1.4 Open the Home Screen	5	9.2 Google Account	21
2 Setting Up	6	10 Apps	22
2.1 Read the Safety Instructions	6	10.1 About Apps	22
2.2 TV Stand and Wall Mounting	6	10.2 Google play	22
2.3 Tips on Placement	6	10.3 Start or Stop an App	23
2.4 Power Cable	6	10.4 Manage Apps	23
2.5 Antenna Cable	7	11 Sources	24
3 Remote Control	8	11.1 Switch to a device	24
3.1 Key Overview	8	12 Settings	25
3.2 Voice Search	9	12.1 TV options	25
3.3 IR Sensor	10	12.2 Picture Settings	25
3.4 Batteries and Cleaning	10	12.3 Sound Settings	27
4 Switching On and Off	11	12.4 System	27
5 Channel Installation	12	12.5 About	28
5.1 First Time to Install Channels	12	12.6 Advanced Options	30
5.2 Cable or Antenna Installation	12	13 Videos, Photos, Music	31
5.3 Update Channels	12	13.1 From a USB Connection	31
5.4 Add Favorite	12	13.2 Play your Videos	31
5.5 Remove Favorite	12	13.3 View your Photos	31
5.6 Hide Channels	12	13.4 Play your Music	32
5.7 REC option	13	14 TV guide	33
5.8 Time shift option	13	14.1 What You Need	33
6 Channels	14	14.2 TV Guide Data	33
6.1 About Channels and Switch Channels	14	15 Smartphones and Tablets	34
6.2 Channel Lists	14	15.1 Chromecast built-in	34
6.3 Favorite Channels	14	16 Netflix	35
6.4 Parental Controls	14	17 Amazon Prime Video	36
7 Connect Devices	16	18 Specifications	37
7.1 About Connections	16	18.1 Power	37
7.2 Home Theater System - HTS	17	18.2 Operating System	37
7.3 Video Device	17	18.3 Reception	37
7.4 Audio Device	18	18.4 Display Type	37
7.5 USB Flash Drive	18	18.5 Display Input Resolution	37
7.6 AV IN	18		
8 Bluetooth®	19		
8.1 What You Need	19		
8.2 Pairing a Device	19		
8.3 Select a Device	19		
8.4 Rename a Device	19		

18.6 Connectivity	37
18.7 Sound	37
18.8 Multimedia	38
19 Help and Support	39
19.1 Register your TV	39
19.2 Troubleshooting	39
19.3 Online Help	41
19.4 Support and Repair	41
20 Safety and Care	42
20.1 Safety	42
20.2 Screen Care	43
21 Terms of Use	44
22 Copyrights	45
22.1 Google TV	45
22.2 HDMI	45
22.3 HEVC Advance	45
22.4 Dolby Audio	45
22.5 DTVi	45
22.6 Other Trademarks	46
23 Disclaimer	47
Index	48

Home Screen

1.1

Introduction

To enjoy the benefits of your Google TV, connect the TV to the Internet. Press **HOME** on your remote control to get your **Home screen**. Like on your Android smartphone or tablet, the Home screen is the center of your TV. From the Home screen you can decide what to watch by browsing entertainment options from app and live TV.

The Home screen is organized in rows to let you discover great content from your favorite apps. You can also add additional rows or find new apps to get more content. Apps may populate their recommendation (if available) with their own choices as an individual row on the home screen.

Highlights on your home screen

With multiple tabs like **Home**, **Apps**, **Library** and **Search**, you can discover movies and shows from your services and popular apps. Sign in to your Google Account to get personalized recommendations from your streaming services based on what you have watched and what interests you. You can also trigger Google search with voice or text input in the **Search** tab.

Apps

The **Apps** tab of the Home screen contains all installed Apps that come with the TV and the Apps you have installed from Google Play™ Store. You can also install and add more apps as favorites from the **Apps** tab.

Navigation

Decide what to watch next with easy-to-use navigation. Browse your personalized recommendations, pick up where you left off, or quickly find a certain app using the new tab system.

Discover personalized recommendations

Browse shows and movies that you will love on all your favorite media services. Sign in to your Google Account to get started.

Get recommendations across Google

Your services are saved to your Google Account so you can get better recommendations across Google.

See also www.support.google.com/googletv

1.2

Dashboard and Settings

Dashboard

The Dashboard is a side panel in Google TV that provides access to Settings, Inputs, notifications and more.

The Dashboard can be accessed in two ways as follows:

- 1 - Navigating to the profile icon in the upper right of the home screen.
- 2 - Pressing the **DASHBOARD**/ key on the remote control.

The dashboard contains the following features.

- **Settings**: to access all setting menus for adjusting the TV settings.
- **Clock and screensaver**: to indicate the system clock and to activate screen saver immediately.
- **Inputs**: to launch the input source list for switching to any of the connected devices.
- **Picture**: quick link to adjust picture settings.
- **NO NOTIFICATIONS**: to provide you messages about the Google TV system; press **Clear all** to dismiss all notifications.

Adjust settings

You can access the **Settings** menu via the dashboard in the top-right corner. Alternatively, you can access the **Settings** menu directly from the remote control by pressing the **DASHBOARD** /  key and selecting **Settings**.

1.3

Basic Mode and Google TV Mode

Feature differences

You can set your Google TV to **Basic Mode** or **Full Mode**.

Basic Mode contains only Live TV and External devices (e.g. HDMI) features. Google TV Mode requires you to log in with your Google account and Internet connection. With Google TV Mode, you have all Basic Mode features and more of Google's personalized services. For example, movies and TV shows from your favorite streaming apps, personalized recommendations, and Google Assistant to search and control your TV with your voice.

Home screen differences

The Home screen in Basic Mode has only two rows with no tabs. The first **Home** row contains **Inputs** and **Dashboard** icons to control the TV's features. The second **App** row

contains all pre-installed Apps. The **Dashboard** in Basic Mode does not include personal profiles and can only perform setting changes and display system notifications.

The Home screen in Full Mode has multiple tabs, including **Home**, **Apps**, **Library** and **Search**. Each tab contains rows of apps, movies and shows from your services and popular apps. You can get personalized recommendations from your streaming services based on what you have watched and what interests you. You can also trigger Google search with voice or text input in the **Search** tab.

1.4

Open the Home Screen

To open the Home screen and open an item:

- 1 - Press **HOME**/.
- 2 - Select an item and press **OK** to open or start it.
- 3 - Press **Back** /  continuously or press **HOME**/ to go back to the Home screen.

2. Setting Up

2.1

Read the Safety

Please read the safety instructions before you use the TV.

2.2

TV Stand and Wall Mounting

TV Stand

You can find the instructions for mounting the TV stand in the Quick Start Guide that came with the TV. If you lose this guide, you can download it from www.philips.com/TVsupport.


Use the model number of the TV to look for the **Quick Start Guide** to download.

Wall Mounting

Your TV is also prepared for the wall mount bracket (sold separately).

The wall mount size may vary depending on the different types of back cases; refer to the **Quick Start Guide** in your product package to see which size is for your TV.

Use the following wall mount dimensions when purchasing the wall mount.



32PHG6909/78

200x200, M4 (min.: 9.5 mm, max: 10.5 mm)

ST4 (min.: 9.5 mm, max: 10.5 mm)

43PFG6909/78

200x200, M4 (min.: 9.5 mm, max: 10.5 mm)

ST4 (min.: 9.5 mm, max: 10.5 mm)

Caution


Wall mounting the TV requires special skills and should only be performed by qualified personnel. The TV wall mounting should meet safety standards according to the TV's weight. Also read the safety precautions before positioning the TV.

TP Vision Europe B.V. bears no responsibility for improper mounting or any mounting that results in accident or injury.

2.3

Tips on Placement

- Position the TV where light does not shine directly on the screen.
- The ideal distance to watch TV is 2 to 5 times its diagonal screen size. When seated, your eyes should be level with the center of the screen.
- When wall mounted, position the TV up to 6 inches away from the wall.




Note:

Please keep the TV away from dust-producing sources such as stoves. It is suggested to clean the dust regularly to avoid getting dust into the TV.

2.4

Power Cable

- Make sure the power cable is securely inserted in the connector.
- Make sure that the power plug, in the wall socket, is accessible at all times.
- When you unplug the power cable, always pull the plug, never pull the cable.



Power


Although this TV has a very low standby power consumption, unplug the power cable to save energy if you do not use the TV for a long period of time.

2.5

Antenna Cable

Insert the antenna plug firmly into the **Antenna** socket at the side of the TV.

You can connect your own antenna or an antenna signal from an antenna distribution system. Use an IEC Coax 75 Ohm RF antenna connector.




Remote Control

3.1

Key Overview

RC-1



1 - Power (Standby/On) (⏻)

To switch the TV on or back to Standby.
Press long to shut down.

2 - VOICE microphone

3 - Ambilight*

To select one of the Ambilight styles.

* The Ambilight setting is only for models that support the Ambilight function.

** 6909Series is not compatible with Ambilight function.

4 - SOURCES (↗)

To open the Sources menu.

5 - NETFLIX

To launch the Netflix App with the TV switched on or from standby.

- If you have a Netflix subscription, you can enjoy Netflix on this TV. Your TV must be connected to the Internet.
- To open Netflix, press the **NETFLIX** key to open the Netflix App. You can open Netflix immediately from a TV in standby.

6 - Prime Video

To launch the Amazon Prime Video App.

7 - YouTube

To launch the YouTube app.

8 - Apps (⋮)

To launch the **Your apps** page to display the list of Apps that are pre-installed or installed by the user.

RC-2



1 - OK button

To confirm a selection or setting. /To open the TV menu with typical TV functions (In TV mode)

2 - Back (←)

To return to the previous menu.

3 - MENU

To open the TV Menu with typical TV functions (In TV mode).
Open the settings menu (Non-shart mode)

4 - Color keys

Follow the on-screen instructions to select more options or operations.

5 - Navigation keys

To navigate up, down, left or right.

6 - Google Assistant™ (🗨️)

To launch Google Assistant™.

7 - Home (🏠)

To open the Home menu. Long press to launch the Dashboard on the side of the screen.

8 - Playback (hidden keys, available when the 123 ⏮ is pressed) ⏮ / ⏸ / ⏭ / ⏹

- Play ⏮, to play back.
- Pause ⏸, to pause playback
- Rewind ⏮, to go back quickly
- Fast forward ⏭, to forward quickly

RC-3



1 - TV/ EXIT

Access the last outgoing source.

2 - Volume + / -

Press + or - to adjust the volume level.

3 - Number keys (hidden keys, available by pressing the 123 ▢▶)

To select a channel directly.

4 - 123 ▢▶

To turn the hidden function keys on or off and switch the keys between different sets of operations.

5 - Channel + / - (≡)

Move down or up to switch to the next or previous channel in the channel list. Press the middle of the key to open the channel list.

6 - Mute (🔇)

Press to mute the sound or to restore it.

7 - DASHBOARD (⚙️)

To launch Dashboard on the side of the screen to access Settings, Inputs, notifications and more.

8 - TV GUIDE

Program Guide

9 - OPTIONS

Display program information

10- CC

Closed Captions

Pair Your Remote Control to the TV

This remote control uses both Bluetooth® and IR (infrared) to send its commands to the TV.

- You can use this remote control via IR (infrared) for most operations.
- To use advanced operation like voice search and remote control keyboard, you need to pair (link) the TV with the remote control.

When you start the initial TV installation, the TV invites you to press the **Home (🏠) + Back (⬅️)** key to pair with the remote control. It is best to complete the pairing when you first install the TV.

Note:

1 - Once the remote control has entered pairing mode successfully, the white LED indicator ring around the microphone on the front side of the remote control starts blinking.

2 - The remote control must be kept close to the TV (within 3 feet) during pairing in order to ensure success.

3 - If the TV does not launch the voice control field when you press **Google Assistant™ (🗣️)**, pairing was unsuccessful.

4 - It is advisable to wait until the set has fully started up and launched all background processes before pairing mode is entered as the toast message containing further instructions may appear too late, thereby negatively impacting the pairing procedure.

Pairing again

If the pairing with the remote control was lost, you can pair the TV with the remote control again.

You can press the **Home (🏠) + Back (⬅️)** key or long press the **PAIR (🔗)** key (for about 3 seconds) for pairing.

3.2

Voice Search

You can search for videos, music or anything else on the Internet by simply using your voice. You can speak into the microphone on the remote control.

You need to pair the remote control to the TV before use voice search.

To use Voice...

1 - Press **Google Assistant™ (🗣️)** on remote control, the white light on the remote control lights up and the search field opens, the microphone is active.

2 - Speak out what you are looking for with clear pronunciation. You can speak for 10 seconds before the microphone switches off. It might take some time for the results to appear.

3 - In the list of search results, you can select the item you want.

3.3

IR Sensor

The TV can receive commands from a remote control that uses IR (infrared) to send commands. If you use such a remote control, always make sure you point the remote control at the infrared sensor on the front of the TV.

Warning

Do not put any objects in front of IR sensor of the TV as it may block the IR signal.

3.4

Batteries and Cleaning

Replace batteries

Refer to the **Quick Start Guide** in your product package for detailed information about the remote control batteries.

If the TV does not react to a button being pressed on the remote control, the batteries might be dead.

To replace the batteries, open the battery compartment on the back of the remote control.

1 - Slide the battery door in the direction shown by the arrow.

2 - Replace the old batteries with new batteries. Make sure the + and the - ends of the batteries line up correctly.

3 - Reposition the battery door and slide it back until it clicks.

- Remove the batteries if you are not using the remote control for a long time.
- Safely dispose of your old batteries according to the end of use directions.

Cleaning

Your remote control is treated with a scratch-resistant coating.

To clean the remote control, use a soft damp cloth. Never use substances such as alcohol, chemicals or household cleaners on the remote control.

Switching On and Off


Make sure the TV is connected to the mains AC power. The indicator light at the bottom of the TV lights up.

Switch on

Press **Power** on the remote control to turn the TV on. You can also press the small joystick button on the bottom of the TV to turn the TV on in case you can't find the remote control or its batteries are dead.

Switch to standby

To turn the TV to standby, press **Power**/ on the remote control. You can also press the small joystick button on the bottom of the TV.



In standby mode, the TV is still connected to the mains power but consumes very little energy.

To turn off the TV completely, disconnect the power plug.

When disconnecting the power plug, always pull the power plug, never the cord. Ensure that you have full access to the power plug, power cord and outlet socket at all times.

Channel Installation

5.1

First Time to Install Channels

Install channels during the first TV installation

On the first TV installation, you can follow on-screen instructions to set the menu language, network connection, sign in Google account, select your country and complete other basic settings for the TV. Moreover, you can also install channels during the first TV installation.

To install channels during the first TV installation:

- 1 - The first TV installation starts from Welcome screen with language setting options, follow on-screen instruction to complete multiple TV settings until the channel installation part.
- 2 - Select **Antenna, Cable, Cable + Antenna** or **Next Step** to install channels.
- 3 - Follow on-screen instructions to complete one of the channel installation types as your selection. You can complete other types of channel installations later under **Settings > Channels & Inputs > Channels**.

For more details about channel installation, refer to the various installation instruction sections.

5.2

Cable or Antenna Installation

Cable Installation

Please note that before installing channels, you should first change the **Channel Installation Mode** to the one you want to install. For the Cable channel installation, you need to change **Channel Installation Mode** to **Cable** first and then start the installation.

Note: Cable channel installation is for the selected country only. (Philippines is not included.)

Press [] key, select **settings > Channels & Inputs > Channels > Channels Scan**, press [OK] key to enter.

Auto Scan

Select **Auto Scan**, press [OK] key to enter.

- 1- Select **Cable + Antenna**, and press [OK] key, then the machine starts auto scanning.
- 2- Select **Cable > Analog**, and press [OK] key, then the machine starts auto scanning.
- 3- Select **Antenna > Digital / Analog / Digital + Analog**, and press [OK] key, then the machine starts auto scanning.

Manual Scan

Select **Manual Scan** press [OK] key to enter.

- 1- Select **Digital** and press [OK] key, then set **Channel Number, Frequency(KHz), BandWidth(M)**. Select **Start Scan**, and press [OK] key, the machine starts scanning.
- 2- Select **Analog**, and press [OK] key, then set **Scan Type, Program, Audio System, Color System**, Select **Frequency**, and press [OK] key, then select **Start Scan**, and press [OK] key, the machine starts scanning.

5.3

Update Channels

Manual Channel Update

You can always start a channel update yourself.

To start a channel update manually:

- 1 - Press **Settings > Channels & Inputs > Channels > Channels Scan > Manual Scan Digital / Analog** press OK
- 2 - Follow the instructions on the screen to complete manual channel updates
- 3 - Press **Back(←)**, repeatedly if necessary, to close the menu.

5.4

Add Favorite

Press **MENU > TV options > Add Favorite > Favorites 1-4**, and press OK

5.5

Remove Favorites

Press **MENU > TV options > Remove Favorites > Favorites 1-4**, and press OK

5.6

Hide Channels

Press **MENU > TV options > Channel Options > Hide channels > Select the Channel you want to set, and press OK**

REC option

In DTV mode, press **[OK]** key, select **Channels > Start Recording**. Press **[OK]** key to select recording time, and the machine start recording. In the process of recording, select **Channels > ■ REC**, then press **[OK]** to save and exit recording.

Press **[OK]** key, then select **Channels > Recorded Programs**. Select the file that you want to play, and press **[OK]** key. Select **Play recording**, then press **[OK]** key to play it.

While playing, press **[OK]** key to display toolbar. Select the menu option which you want, and press **[OK]** key to perform the operation. You can press **[←]** key to exit playing.

Note: Only the memorizer with FAT32 file system supports the recording function. Memorizer with other file systems need to be formatted; Before formatting memorizer, please back up useful data because the content of memorizer can not recover after formatting

Time Shift option

In DTV mode, press **[OK]** key, and select **Channels > Start TimeShift**, then press **[OK]** key to turn on the time shift function. Press **[←]** key to stop and exit time-shift.

When user pauses program for a short time, time-shift function can suspend and cache the playing program to U disk. When user resumes playing, the program can continue to be played.

In the process of the time shift, press **[OK]** key, and select **Play controls** to display toolbar. Select the menu option which you want, and press **[OK]** key to perform the operation.

Channels

6.1

About Channels and Switch Channels

To watch TV channels

- Press **SOURCES** /  and select any TV source.
- Press **Home** > **Live TV** and press **OK**.
- Press **Channel +** or **Channel -** to switch channels.
- If you know the channel number, type in the number with the number buttons. Press **OK** after you entered the number to change channels.

To change to a channel from a channel list

- While watching a TV channel, press  to open the channel lists.
- The channel list can have several pages with channels. To view the next or previous page, follow the on-screen instruction.
- To close the channel lists without changing channels, press **Back**.

6.2

Channel Lists

About Channel Lists

After a channel installation, all channels appear on the channel list. Channels are shown with their name if this information is available.

With a channel list selected, press **Navigation buttons** up or down to select a channel, then press **OK** to watch the selected channel.

Open a Channel List

Next to the list with all channels, you can select a filtered list or you can select one of the favorite lists you created.

To open the current channel list / :

- 1 - While watching TV, press  to open the current channel list. Follow the on-screen instruction.
- 2 - Press **Back** to close the channel list.

6.3

Favorite Channels

About favorite Channels

In a favorite channel list, you can collect the channels you like.

You can create 4 different lists of favorite channels to easily change between channels.

press  open a channel List with a Favorites List selected, press the Navigation buttons up or down to select a channel, channel, then press **OK** to watch the selected channel.

6.4

Parental Controls

Settings>System>Television>Settings>Lock

enter parental controls

Channel Blocked

To prevent children from watching a channel, you can lock a channel. To watch a locked channel, you must enter the 4 digit PIN code first. You cannot lock programs from connected devices.

To lock or unlock a channel:

- 1 - Press **MENU** > **TV options** > **Channel Options** > **Parental Controls** and press **OK**.
- 2 - Enter your PIN code if necessary. (Initial password 1234)
- 3 - Select **off/on** to turn parental controls on or off.
- 4 - Select **Channels lock** and press **OK**.
- 5 - Press **Navigation buttons** up or down to select the channel you want to lock or unlock, and press **OK**.
- 6 - A locked channel is marked with a lock icon.
- 7 - Press **Back**, repeatedly if necessary, to close the menu.

Program Restrictions

To prevent children from watching a program that may not be suitable for them, you can set a rating.

Digital channels can have their programs rated. When the rating of a program is equal to or higher than the rating you have set, the program will be locked. To watch a locked program, you must enter the PIN code first.

To set a rating:

- 1 - Press **MENU > TV Options > Channel Options > Parental Controls** and press **OK**.
- 2 - Enter your PIN code if necessary.
- 3 - Select **Ratings** and press **OK**.
- 4 - Select **High restrictions/medium restrictions/Low restrictions/Custom** and press **OK**.
- 5 - Set the restrictions for your children.
- 6 - Press **Back**, repeatedly if necessary, to close the menu.

To turn off the parental rating, select **None**. However, in some countries you must set a rating.

For some broadcasters/operators, the TV only locks programs with a higher rating. The parental rating is set for all channels.

Inputs Blocked

To prevent from using connected devices, you can lock an input source. To connect a locked input source, you must enter the 4 digit PIN code first.

To lock or unlock an input source:

- 1 - Press **MENU > TV Options > channel options > Parental Controls** and press **OK**.
- 2 - Enter your PIN code if necessary.
- 3 - Select **Source lock** and press **OK**.
- 4 - Press **Navigation buttons** up or down to select the source you want to lock or unlock, and press **OK**.
- 5 - A locked source is marked with a lock icon.
- 6 - Press **Back**, repeatedly if necessary, to close the menu.

Change PIN

Set new or reset PIN code. The PIN code is used to lock or unlock channels or programs.

- 1 - Press **MENU > TV Options > Channel Options > Parental Controls** and press **OK**.
- 2 - Enter your PIN code if necessary.
- 3 - Select **Change PIN** and press **OK**.
- 4 - Enter your Current PIN.
- 5 - Enter the new PIN code.
- 6 - Press **Back**, repeatedly if necessary, to close the menu.

Connect Devices

7.1

About Connections

Connectivity Guide

Always connect a device to the TV with the highest quality connection available. Also, use good quality cables to ensure a good transfer of picture and sound.

When you connect a device, the TV recognizes its type and gives each device a correct type name. You can change the type name if you wish. If a correct type name for a device is set, the TV automatically switches to the ideal TV settings when you switch to this device in the Sources menu.

Antenna port


If you have a Set-top box (a digital receiver) or Recorder, connect the antenna cables to run the antenna signal through the Set-top box and/or Recorder first before it enters the TV. In this way, the antenna and the Set-top box can send possible additional channels to the Recorder to record.

HDMI ports

HDMI Quality

An HDMI connection has the best picture and sound quality. One HDMI cable combines video and audio signals. Use an HDMI cable for High Definition (HD) TV signals.

For best signal quality transfer, use a High speed HDMI cable and do not use an HDMI cable longer than 5 m.



Copy protection


HDCP (High-bandwidth Digital Content Protection) is a copy protection signal that prevents copying content from a DVD disc or Blu-ray Disc. Also referred to as DRM (Digital Rights Management).

HDMI eARC

Only **HDMI 1** on the TV supports **HDMI eARC** (Audio Return Channel).


If the device, typically a Home Theater System (HTS), soundbar or AV receiver, also has the HDMI eARC connection, connect it to **HDMI 1** on this TV. With the HDMI eARC connection, you do not need to connect the extra audio cable that sends the sound of the TV picture to the HTS. The HDMI eARC connection combines both signals.

You can use any HDMI connection on this TV to connect to the HTS, but eARC is only available for 1 device/connection at a time.



HDMI CEC

Connect HDMI CEC-compatible devices to your TV, you can operate them with the TV remote control.



HDMI CEC (Consumer Electronic Control) must be turned on the TV and the connected device.

Turn on CEC

Allow the TV to control the HDMI device.

Settings > Channels & Inputs > External Inputs > HDMI CEC Settings > CEC Control.

Device Auto Power Off

Turn off the HDMI devices with the TV.

Settings > Channels & Inputs > External Inputs > HDMI CEC Settings > Device Auto Power Off .

Tv Auto Power On

Power on the TV with HDMI devices.

Settings > Channels & Inputs > External Inputs > HDMI CEC Settings > Tv Auto Power On.

Note:

- HDMI CEC might not work with devices from other brands.
- The HDMI CEC functionality has different names on different brands. Some examples are: Anynet, Aquos Link, Bravia Theater Sync, Kuro Link, Simplink and Viera Link. Not all brands are fully compatible with EasyLink. Example HDMI CEC branding names are property of their respective owners.

7.2

Home Theater System - HTS

Connect with HDMI eARC


Use an HDMI cable to connect a Home Theater System (HTS) to the TV. You can connect a Philips Soundbar or an HTS with a built-in disc player.

HDMI eARC

If your Home Theater System has an HDMI eARC connection, you can use HDMI eARC connection on the TV to connect. With HDMI eARC, you do not need to connect

the extra audio cable. The HDMI eARC connection combines both signals.

Since HDMI 1 on the TV can offer the Audio Return Channel (eARC) signal, the TV can only send the eARC signal to this HDMI connection.



Audio to video synchronization (sync)

If the sound does not match the video on screen, you can set a delay on most Home Theater Systems with a disc player to match the sound with the video.


7.3

Video Device

HDMI

Use a **High speed HDMI** cable to connect with best picture and sound quality.

For best signal quality transfer, use a high-speed HDMI cable. Do not use an HDMI cable longer than 16 feet (5 meters). You can connect devices supporting HDR to any of the HDMI connectors.




Audio Device

Digital Audio Out - Optical


Audio Out - Optical is a high quality sound connection.

This optical connection can carry 5.1 audio channels. If your device, typically a Home Theater System (HTS), has no HDMI ARC connection, you can use this connection with the Audio In - Optical connection on the HTS. The Audio Out - Optical connection sends the sound from the TV to the HTS.



Headphones


You can connect a set of headphones to the connection on the back of the TV. The connection is a mini-jack 3.5mm. You can adjust the volume of the headphones separately.



USB Flash Drive

You can view photos or play your music and videos from a connected USB flash drive.

Insert a USB flash drive in one of the **USB** connections on the TV while the TV is switched on.




To view the files from the USB flash drive, press **Home** and click on the MediaPlayer app icon to start the app.

To stop watching the USB flash drive content, press **EXIT** or select another activity. Exit the MediaPlayer app before you disconnect the flash drive.

MINI AV-IN

It is used for audio and video transmission between the set-top box and the TV. The connection method is to use a dedicated AV cable.



- Ⓨ Yellow (video signal cable)
- Ⓦ White (audio left channel signal connection cable)
- Ⓡ Red (audio right channel signal connection cable)

Bluetooth®

8.1

What You Need

You can connect a wireless device with Bluetooth® to this TV – a wireless speaker or headphones.

To enable the TV audio on a wireless speaker, you must pair the wireless speaker with the TV. The TV can only play the sound on one speaker at a time.

Attention

Before you purchase a wireless Bluetooth® speaker system, find out more about the newest models and look for a device with a low latency rating. Ask your dealer for advice.

Disclaimer:

Due to the transmission limitations of Bluetooth® wireless technology, a slight sound delay might occur when you hear audio from your Bluetooth® headphone or Bluetooth® speakers.

When this occur, you might see the character moving his or her mouth but there is a slight delay in spoken dialogue accompany it – commonly known as lip Sync error.

8.2

Pairing a Device

Position the wireless speaker within 15 feet of the TV. Read the user manual of the device for specific information on pairing and on wireless range. Make sure the Bluetooth® setting on TV is switched on.

Once a wireless speaker is paired, you can select it to play the TV sound. When a device is paired, you do not need to pair it again unless you remove the device.

To pair a Bluetooth® device with the TV:

- 1 - Switch on the Bluetooth® device and place it within range of the TV.
- 2 - Press **Settings > Remotes & Accessories** and press **OK**.
- 3 - Select **Pair accessory** and press **OK**. Follow the instructions on screen. You will pair the device with the TV and the TV will store the connection. You might need to unpair a paired device first if the maximum number of paired devices was reached.
- 4 - Press **Back**, repeatedly if necessary, to close the menu.

Note:

Only one Bluetooth® sound output can be paired at a

time. If you would like to pair another Bluetooth® speaker or headphones, just un-pair the current one first.

8.3

Select a Device

To select a wireless device:

- 1 - Press **Settings > Remotes & Accessories** and press **OK**.
- 2 - In the list, select the wireless device and press **OK**.
- 3 - Select connect and press ok
- 4 - Press **Back**, repeatedly if necessary, to close the menu.

8.4

Rename a Device

To rename a wireless device:

- 1 - Press **Settings > Remotes & Accessories** and press **OK**.
- 2 - In the list, select the wireless device and press **OK**.
- 3 - Select **Rename** and press **OK**.
- 4 - Enter a new name for the device.
- 5 - Press **Back**, repeatedly if necessary, to close the menu.

8.5

Remove a Device

You can connect or disconnect a wireless Bluetooth® device. You can also remove a wireless Bluetooth® device. If you remove a Bluetooth® device, the device will be unpaired.

To remove or disconnect a wireless device:

- 1 - Press **Settings > Remotes & Accessories** and press **OK**.
- 2 - In the list, select the wireless device and press **OK**.
- 3 - Select **Forget** and press **OK**.
- 4 - Press **Back**, repeatedly if necessary, to close the menu.

8.6

Turn Bluetooth® on or off

- 1 - Press **Settings > Remotes & Accessories > Bluetooth®** and press **OK**.

Connect your Google TV

9.1

Network and Internet

Home Network

To enjoy the full capabilities of your Philips Google TV, your TV must be connected to the Internet.

Connect the TV to a home network with a high-speed Internet connection. You can connect your TV wirelessly or wired to your network router.

Connect to Network

Wireless Connection

What You Need

To connect the TV to the Internet wirelessly, you need a Wi-Fi router with a connection to the Internet.

Use a high-speed (broadband) Internet connection.



Turn Wi-Fi On or Off

Settings > Network & Internet > Wi-Fi.

Make the Connection

Settings > Network & Internet > Wi-Fi.

- 1 - In the list of found networks, select on your wireless network. If your network is not in the list because the network name is hidden (you switched off the SSID broadcast of the router), select **Add new network** to enter the network name yourself.
- 2 - Follow the on-screen instruction.
- 3 - A message will be shown when the connection is successful.

Problems

Wireless network not found or distorted

- Microwave ovens, DECT phones or other Wi-Fi 802.11b/g/n devices in your proximity might disturb the wireless network.
- Make sure that the firewalls in your network allow access to the TV's wireless connection.
- If the wireless network does not work properly in your home, try the wired network installation.

Internet does not work

- If the connection to the router is OK, check the router connection to the Internet.

The PC and Internet connection are slow

- Look in your wireless router's user manual for information on indoor range, transfer rate and other factors of signal quality.
- Use a high-speed (broadband) Internet connection for your router.


DHCP

- If the connection fails, you can check the DHCP (Dynamic Host Configuration Protocol) setting of the router. DHCP should be turned on.

Wired Connection

What You Need

To connect the TV to the Internet, you need a network router with an Internet connection. Use a high-speed (broadband) Internet connection.



Make the Connection

- 1 - Connect the router to the TV with a network cable (Ethernet cable**).
- 2 - Make sure that the router is turned on.
- 3 - The TV constantly searches for the network connection.
- 4 - A message will be shown when the connection is successful.

If the connection fails, you can check the DHCP setting of

the router. DHCP should be turned on.

**To fulfill EMC regulations, use a shielded FTP Cat. 5E Ethernet cable.

9.2

Google Account

Sign in to Google Account

To enjoy the full capabilities of your Philips Google TV, you can sign in to Google with your Google Account.

By signing in, you can play your favorite games across your phone, tablet and TV. You will also get customized video and music recommendations on your TV Home screen, as well as access to YouTube, Google Play and other apps.

Sign in to Google Account in Basic Mode

If you did not sign in to your Google account during the first TV installation, your TV is working with Basic Mode. You can sign in to your Google account to switch your TV to Full Mode at any time. Use your existing Google account to sign in to your TV. A Google Account consists of an email address and a password. If you don't have a Google Account yet, use your computer or tablet to create one (accounts.google.com).

To sign in after the TV installation:

- 1 - Select **Settings > Set up Google TV** and press **OK**.
- 2 - Alternatively, press **Home** to go back to the Home screen, select the **Set up Google TV** and press **OK**.
- 3 - With the on-screen keyboard, enter your email address and press **OK**.
- 4 - Enter your password and press **OK** to sign in.

Google Account Settings

You can set or view several Google account-specific settings or information. You can manage **Your Services**, **Content Preferences**, **Autoplay Trailers**, **Hidden Purchases and Rentals**, **Payments and Purchases**. Customize your **Google Assistant**, set to **Apps-Only Mode** or **Remove** this Google account.

To open these settings...

- 1 - Sign in to Your Google Account.
- 2 - Select **Settings > Accounts & Sign-in** and press **OK**.
- 3 - Explore the different Google account settings.
- 4 - Press **Back** ← if necessary, to close the menu.

Apps

10.1

About Apps

You can find your favorite Apps on the **Your apps** row on the Home menu.

Like apps on your smartphone or tablet, the apps on your TV offer specific functions for an enriched TV experience. Apps like YouTube, games, video stores.

Apps can come from the Google Play™ Store. To get you started, some practical apps are pre-installed on your TV.

To install apps from the Google Play™ Store, the TV must be connected to the Internet. You must sign in with a Google Account to use the Google Play apps and Google Play™ Store. Select the app you want to install and select the **Install** button to start the installation. Once the app installation is done, you can select the **Open** button to open the app or **Uninstall** button to uninstall the app.

10.2

Google play

Movies and TV

With the **Google TV** app, you can rent or buy movies and TV shows to watch on TV.

What You Need

- your TV must be connected to the Internet
- you must sign in with your Google Account on the TV
- add a credit card to your Google Account to purchase movies and TV shows

To rent or buy a movie or TV show:

- 1 - Go to **Settings > Apps > See all apps > Show system apps** and select **Google Play Movies & TV > Open**.
- 2 - Select a movie or TV show and press **OK**.
- 3 - Select the purchase you want and press **OK**. You will be taken through the purchase procedure.

To watch a rented or purchased movie or TV show:

- 1 - Go to **Settings > Apps > See all apps > Show System Apps** and select **Google TV**.
- 2 - Select the movie or TV show from your library in the app, select the title and press **OK**.
- 3 - You can use the **Stop, Pause, Rewind** or **Fast forward** buttons on the remote control.
- 4 - To stop the Movies & TV app, press **Back** repeatedly or press **EXIT**.

Find more information at
www.support.google.com/googletv

Music

With **YouTube Music**, you can play your favorite music on TV.

You can buy new music on your computer or mobile device. Or, on your TV, you can sign up for All Access, the Google Play Music subscription. Alternatively, you can play the music you already own, stored on your computer.

What You Need

- your TV must be connected to the Internet
- you must sign in with your Google Account on the TV
- add a credit card to your Google Account to add a music subscription

To start YouTube Music:

- 1 - Go to **Settings > apps > See all apps >** and select **YouTube Music**.
- 2 - Select the music you want and press **OK**.
- 3 - To stop the Music app, press **Back** repeatedly or press **EXIT**.

Find more information at
www.support.google.com/googletv
 or support.google.com/youtubemusic

Games

With Google Play Games, you can play games on TV. Online or offline.

You can see what your friends are playing currently or you can join the game and compete. You can track your achievements or start wherever you left off.

What You Need

- your TV must be connected to the Internet
- you must sign in with your Google Account on the TV
- add a credit card to your Google Account to purchase new games

Start the Google Play Games app to select and install new game apps on your TV. Some games are free of charge. A message appears if a particular game needs a gamepad to play the game.

To start or stop a Google Play Game:

- 1 - Go to **Settings > Apps > See All Apps > Show System Apps** and select **Google Play Games**.
- 2 - Select a game to play or select a new game to install and press **OK**.
- 3 - When done, press **Back** repeatedly or press **EXIT** or stop the app with its dedicated exit/stop button.

Google Play Store

From the Google Play Store you can download and install new apps. Some apps are free of charge.

What You Need

- your TV must be connected to the Internet
- you must sign in with your Google Account on the TV
- add a credit card to your Google Account to purchase apps

To install a new app:

- 1 - Go to **Settings > Apps > See all apps > Show system apps** and select **Google Play Store** and press **OK**.
- 2 - Select the app you want to install and press **OK**.
- 3 - To close the **Google Play Store**, press **Back** repeatedly or press **EXIT**.

Payments

To make a payment on Google Play on TV, you must add a form of payment - a credit card (outside the United States) - to your Google Account. When you purchase a movie or TV show, you will be charged on this credit card.

To add a credit card:

- 1 - On your computer, go to accounts.google.com and sign in with the Google Account you will use with Google Play on TV.
- 2 - Go to wallet.google.com to add a card to your Google Account.
- 3 - Enter your credit card data and accept the terms and conditions.

10.3

Start or Stop an App

You can start an app from the Home screen.

To start an app:

- 1 - Press **Home** (🏠).
- 2 - Move to the **Your Apps** row, select the app you want and press **OK**.
- 3 - Alternatively, you can go to **Settings > Apps > See all apps** or **Show system apps** to select an app to open.
- 4 - To stop an app, press **Back** or press **EXIT** or stop the app with its dedicated exit/stop button.

10.4

Manage Apps

Settings > Apps.

If you stop an app and return to the Home menu, the app is not really stopped. The app is still running in the background to be readily available when you start it again. To run fluently, most apps need to save some data in the cache memory of the TV. It might be good to stop an app completely or clear the cache data of a particular app to optimize the overall performance of apps and to keep memory usage low on your TV. Also, it is best to uninstall apps that you are not using anymore.

Sources

11.1

Switch to a device

From the list of Sources, you can switch to any of the connected devices. You can switch to a tuner to watch TV or play the files from a connected USB flash drive. You can switch to your connected devices to watch programs on that device, a digital receiver or a Blu-ray Disc player.

To switch to a connected device:

- 1 - Press **SOURCES**  to open the Sources menu.
- 2 - Select one of the items in the source list and press **OK**. The TV will show the program or content of the device.

One Touch Play

With the TV in standby, you can turn on a disc player with your TV remote control.

To turn on both disc player and TV from standby and start playing the disc immediately, press **Play** on the TV remote control. The device must be connected with an HDMI cable and both TV and device must have HDMI CEC switched on.

Settings

12.1

TV options

Press **MENU** to select one of the menus below, then press **OK**.

Picture

Select one of the preset picture styles for ideal picture viewing.

Screen

Select one of the preset picture formats which fits the screen.

Sound

Select a preset sound style for the ideal sound experience.

Signal Type

Select the type of antenna

Closed Captions

Switch **Closed Caption On** or **Off** with this option.

Add Favorite

Add your favorite programs

Remove Favorite

Remove favorite programs

Audio Language

Select audio Language

Settings

View settings menu.

Channel Options

Select Channel Options

Open Favorite

Turn on your favorite show

12.2

Picture Settings

Picture Mode

Select a style

Settings > Display & Sound > Picture > Picture Mode.

For easy picture adjustment, you can select a preset picture style.

- Standard - Most energy-conscious setting
- Vivid - Ideal for daylight viewing
- Sport - Ideal for sport
- Movie - Ideal for watching movies with original studio effect
- Game - Ideal for playing games
- ECO - Ideal for saving energy
- Dynamic - Select Dynamic mode
- Gentle - Select Gentle mode
- Presonal - Select Custom mode

When TV receives HDR10 signal, select a picture style below:

- Standard(HDR10)
- Vivid(HDR10)
- Sport(HDR10)
- Movie(HDR10)
- Game(HDR10)
- ECO (HDR10)

When the TV receives an HLG (Hybrid Log Gamma) signal, select which picture style to use:

- Standard(HLG)
- Vivid(HLG)
- Sport(HLG)
- Movie(HLG)
- Game(HLG)
- ECO (HLG)

Other Picture Settings

Settings > Display & Sound > Picture and press OK.

WCG

Select WCG mode

Screen Brightness

Adjust the video screen brightness intensity.

Advanced Settings

Set the advanced picture settings.

- **Color Temperature**

Set the picture to a preset color temperature or adjust the setting yourself.

- **Noise Reduction**

Digital Noise Reduction, with image noise reduction filters to reduce image noise.

- **Picture Reset**

Reset the current picture settings to default.

- **HDMI PC/AV mode**

Select HDMI PC/AV mode
(video, PC, Auto)

- **Dynamic Contrast**

Open or close Dynamic Contrast

Picture Format

If the picture is not filling the whole screen, if black bars are showing on the top or bottom or at both sides, you can adjust the picture to fill the screen completely.

To select one of the basic settings to fill the screen:

Settings > Display & Sound > Screen > Aspect Ratio .

Auto

Automatically zooms in the picture to fit the screen with original aspect ratio. No content lost visible.

16:9

Stretches the picture to a 16:9 format.

4:3

Display the classic 4:3 format.

Original

Provide maximum detail for PC.

Sound Settings

Sound Style

Settings > Display & Sound > Sound > Sound mode.

For easy sound adjustment, you can select a preset setting with sound style.

- Standard - Most neutral sound setting
- Cinema - Ideal for watching
- Music - Ideal for listening to music
- News - Ideal for speech
- Personal - Custom Sound mode

Other Sound Settings

Settings > Display & Sound > Sound and press OK.

Surround Mode

Set the surround mode.

Sound Only

The TV screen is off, leaving only sound.

Advanced Settings

Set the sound Settings they want.

Sound Reset

Settings > Display & Sound > Sound > Advanced Settings > Sound Reset, and press OK

Reset the current sound settings to default.

Speakers and optical

If you want to set the TV to play the sound on the connected audio system, and make sure the connected audio system is turned on.

Settings > Display & Sound > Audio output > Output Device > SPDIF/Optical

System

Accessibility Settings

Settings > System > Accessibility.

With Audio description switched on, the TV is ready to be used by those who are deaf, hard of hearing, blind or partially-sighted.

Captions

Settings > System > Accessibility > Captions.

Change the settings to display captions.

High contrast text

Settings > System > Accessibility > High contrast text.

Turn on/off or set the level of the text contrast.

Text to Speech

Settings > System > Accessibility > Text to speech.

To enable and set up the text-to-speech function.

Accessibility shortcut

Settings > System > Accessibility > Accessibility shortcut.

To enable/disable the shortcut to Accessibility settings. When the shortcut is on, you can press both the back and down buttons for 3 seconds to start an accessibility feature.

Talk Back

Settings > System > Accessibility > Talk Back > Enable press OK.

Switch Access

Settings > System > Accessibility > Switch Access > Enable press OK.

Date and Time

Settings > System > Date & Time.

Automatic date & time

Settings > System > Date & Time > Automatic date & time.

Set to use network-provided time or turn off Automatic Date & Time.

Set date

Settings > System > Date & Time > Set date.

Set current date.

Set time

Settings > System > Date & time > Set time.

Set current time.

Set time zone

Settings > System > Date & Time > Set time zone.

Set current time zone.

Use 24-hour format

Settings > System > Date & Time > Use 24-hour format.

Set to use 24-hour format to display the time.

Language

Change the language of the TV menu and messages

Settings > System > Language.

Select the language to display the TV menu and messages.

Keyboard

Settings for the connected keyboard

Settings > System > Keyboard.

Connect the USB keyboard to one of the USB connections on this TV. When the TV detects the keyboard for the first time, you can select your keyboard lay-out and test your selection.

Storage

Internal shared storage

You can see how much storage space - the internal TV memory - you are using for your apps, videos, music, etc. You can see how much free space you still have available for installing new apps. Check your storage if apps start to run slow or in case of app trouble.

Select **Settings > System > Storage** to see how much storage you are using.

Ambient mode

Settings for Ambient mode

Settings > System > Ambient mode.

Ambient mode is the screen saver to avoid displaying still images for a longer period of time. You can set the photo source, display weather or time information, and adjust the slideshow speed.

12.5

About

System Update

Update Software

Update from Internet

If the TV is connected to the Internet, you may receive a message to update the TV software. You need a high-speed (broadband) Internet connection. If you receive this message, we recommend you carry out the update.

- 1 - Press **Settings > System > About > System update** and press **OK**.
- 2 - Follow the instructions on screen.

Status

Display TV status information

Settings > System > About > Status.

To display the TV status about IP address, Device MAC address, Bluetooth address, Serial number, etc.

Legal Information

Open Source Licenses

To view the open-source licenses:

- 1 - Select **Settings > System > About > Legal Information > Open Source Licenses** or press **MENU > TV Options > Channel options > Open Source Licenses**.
- 2 - View open-source license information.
- 3 - Press **Back** if necessary, to close the menu.

Other Legal Information

Display other legal information

Settings > System > About > Legal Information > Google Legal / System WebView Licenses / Consumer Information.

To display other legal information about Google, System WebView licenses and Consumer Information.

System Information

View information about the current TV system

Settings > System > About > Model / Android TV OS version / Android TV OS Security Patch Level / Kernel version / Android TV OS build / Netflix ESN.

This will show the information about the current system software version and the Netflix Electronic Serial Number (ESN).

Power and Energy

Set the Power on behavior

Settings > System > Power & Energy > Power On behavior.

Set the TV to stay on the **Google TV** home screen or on **Last used Input** when power on the TV.

Set Energy saver

Settings > System > Power & Energy > when inactive

Set the time to turn off the TV display automatically to save energy. You can set the time to **15 minutes, 20 minutes, 30 minutes, 1 hour, 4 hours, 8 hours, 12 hours, 24 hours, or Never.**

Television

Sleep timer

Settings > System > Television > Sleep Timer.

TV switches to standby mode automatically after a preset time.

Settings Exit Timer

Settings > System > Television > Settings Exit Timer.

Set the Exit timer mode

Wake On Network

Settings > System > Television > Settings > Power > Wake on Network / Wake on Chromecast / Fast awake

Note: If you turn on **Wake On Network** function, the maximum power consumption of the machine in standby mode does not exceed 1W.

Rcu Firmware Update

Settings > System > Television > RCU Firmware Update

Update the remote control firmware

System Sounds

Settings for system sound

Settings > System > System Sounds.

Enable or disable the system sounds.

Retail Mode

Retail Mode

Settings > System > Television > Environment > Home/Shop

Switch retail mode on or off. If you set the retail mode to on. You can set the retail message type and demo.

Restart

Settings > System > Restart

Note:

- Disconnect the external USB hard disc before rebooting.
- Wait for few seconds, the TV restarts automatically.

This will remove unnecessary data and information in the memory.

If your TV runs low performance when using Apps, such as the video and audio are not synchronized or the App is running slow, reboot your TV for better performance.

12.6

Advanced Options

Set audio preference language

Audio Language

MENU > TV Options > Audio Language .

Set the audio settings based on the channel audio.

Digital TV channels can broadcast audio with several spoken languages for a program. You can set a preferred audio language. If audio in one of these languages is available, the TV will switch to this audio. This is only available with digital channels.

Videos, Photos, Music

13.1

From a USB Connection

You can view your photos or play your music and videos from a connected USB flash drive.

With the TV turned on, plug in a USB flash drive to one of the USB connections.

- 1 - Press **Home**() , select **Media Player** from the Apps list and press **OK**.
- 2 - Use **Navigation buttons** to select the file type.
- 3 - Follow the on-screen instructions to play the files.

13.2

Play your Videos

Play a video

- 1 - Press **Home**, select **Media Player** from the Apps list and press **OK**.
- 2 - Use **Navigation buttons** to select **KingSton USB drive**.
- 3 - Select one of the videos, and press **OK** to play.

During the video playback...

- Press **OPTIONS** to show the options.

Play, Pause

Press **OK** to play or pause the video.

Rewind 

Play/Pause  / 

Fast Forward 

Next 

Repeat All 

Audio Track 

Subtitle 

Text Encoding 

Previous 

13.3

View your Photos

View Photos

View a photo

- 1 - Press **Home**, select **Media Player** from the Apps list and press **OK**.
- 2 - Use **Navigation buttons** to select **KingSton USB drive**.
- 3 - Select one of the photos, and press **OK**.

During the photos playback

- 1 - Press "OK" to show the options

(**Single View** / **Previous** / **Next** / **Rotate** / **Zoom** / **Virtual Keyboard**)

OK : Slide Show / Single View

 : Previous/Next

 : Rotate

 (Red) : Zoom In

 (Green) : Zoom Out

Play your Music

Play music

- 1 - Press **Home**, select **Media Player** from the Apps list and press **OK**.
- 2 - Use **Navigation buttons** to select **KingSton USB drive**.
- 3 - Select one of the audio, and press **OK** to play.

Rewind ◀◀

Play/Pause ⏸ / ▶

Fast Forward ▶▶

Next ▶▶

Repeat All 🔄

Previous ◀◀

TV GUIDE

14.1

What You Need

With the TV Guide you can view a list of the current and scheduled TV programs of your channels. Depending on where the TV guide information (data) is coming from, analog and digital channels or only digital channels are shown. Not all channels offer TV Guide information.

The TV can collect TV Guide information for the channels that are installed on the TV. The TV cannot collect the TV Guide information for channels viewed from a digital receiver or decoder.

14.2

TV Guide Data (in DTV mode)

MENU > Navigation keys up > Channels > Program Guide.

The TV Guide receives information (data) from broadcasters. In some regions and for some channels, TV Guide information might not be available. The TV can collect TV Guide information for the channels that are installed on the TV. The TV cannot collect the TV Guide information from channels viewed from a digital receiver or decoder.

Smartphones and Tablets

Chromecast built-in

What You Need

If an app on your mobile device has Chromecast built-in, you can cast the app on this TV. On the mobile app, look for the Google Cast icon. You can use your mobile device to control what's on TV. Chromecast built-in works on Android and iOS.

Your mobile device must be connected to the same Wi-Fi home network as your TV.

Chromecast-enabled apps

New Chromecast-enabled apps become available every day. You can already try it with YouTube, Chrome, Netflix, Photowall ... or Big Web Quiz for Chromecast. See also www.google.com/chromecast/built-in.

Some Google Play products and features aren't available in all countries.

Find more information at www.support.google.com/chromecastbuiltin.

Cast from Apps to TV

To cast an app to the TV screen:

- 1 - On your smartphone or tablet, open an app that supports Google Cast.
- 2 - Tap the Google Cast icon.
- 3 - Select the TV you would like to cast to.
- 4 - Press play on your smartphone or tablet. What you selected should start playing on TV.

Netflix

If you have a Netflix subscription, you can enjoy Netflix on this TV. Your TV must be connected to the Internet. In your region, Netflix might only come available with future software updates.

To open Netflix, press **NETFLIX** on the remote control to open the Netflix App. You can open Netflix immediately from a TV in standby.

www.netflix.com

Amazon Prime Video

With Amazon Prime membership, you gain access to thousands of popular movies and TV show, including exclusive Prime Originals.

Press the **prime video** button on your remote control or the app icon to open the Amazon Prime Video app. Your TV must be connected to the Internet to use the app. For more information about Amazon Prime Video, please visit www.primevideo.com.

Specifications

Power

Product specifications are subject to change without notice. For more specifications for this product, see www.philips.com/TVsupport.

Power

- Mains power: AC 100-240V
- Ambient temperature: 5°C to 35°C

When testing the standby power consumption:

- Wake-On-Lan (WoWLAN) must be turned off.
- Wait at least 10 minutes to enter a stable state before the power consumption testing for standby mode.

Operating System

Android OS:

Android 11

Reception

- Antenna input: 75 ohm coaxial (F-type)
- Tuner bands: Hyperband, UHF, VHF
- ISDB-T
- Video playback : NTSC, PAL (Country dependent)
- Digital video playback: MPEG2 SD/HD (ISO/IEC 13818-2), MPEG4 SD/HD (ISO/IEC 14496-10)
- Digital audio playback (ISO/IEC 13818-3)

Display Type

Diagonal screen size

- 80 cm/32 inch
- 108 cm/43 inch

Display resolution

- 32PHG6909/78:1366 x 768
- 43PFG6909/78:1920 x 1080

Display Input Resolution

Supported Video only resolution

Resolution — Refresh rate

- 480i - 60 Hz
- 576i - 50 Hz
- 1080i - 50 Hz, 60 Hz

Supported Computer/Video resolution

Resolution — Refresh rate

- 640 x 480 - 60 Hz
- 576p - 50Hz
- 720p - 50 Hz, 60 Hz
- 1920 x 1080p 50 Hz, 60 Hz

Connectivity

TV Side

- MINI AV-IN
- USB 1 - USB 2.0
- USB 2 - USB 2.0
- HDMI 1 in - eARC
- HDMI 2
- Antenna (75 ohm)
- Earphone

TV Rear

- Audio out - Optical out
- Network LAN - RJ45

Sound

- Output power (RMS): 43" 8+8W/32" 6+6W
- Dolby Audio
- Surround Sound

Multimedia

Connections

- USB 2.0
- Ethernet LAN RJ-45
- Wi-Fi 802.11ac, Dual Band
- Bluetooth® 5.0

Supported USB file systems

- NTFS, FAT 32

Playback formats

- Containers: TS, MP4, M4V, MKV, AV
- Video Codecs:
 - AVI, MKV, HEVC, H.264/MPEG-4, MPEG1, MPEG2, MPEG4, VP9, HEVC (H.265), AV1
- Audio Codecs: MP3, WAV, AAC, FLAC.
- Subtitles:
 - Formats: SRT, SMI, SSA, SUB, ASS, TXT
 - Character encodings: UTF-8(Unicode), UTF-16, Simplified Chinese, Central Europe, Cyrillic, Western Europe, Greek, Turkish, Hebrew, Korean
- Maximum Supported Data Rate:
 - MPEG-4 AVC (H.264) is supported up to High Profile @ L5.1. 30Mbps
 - H.265 (HEVC) is supported up to Main Main 10 Profile up to Level 5.1 40Mbps
- Image Codecs: JPEG, GIF, PNG, BMP

Help and Support

19.1

Register your TV

Go to www.philips.com/TVsupport to register your TV and enjoy a range of benefits, including full support (including downloads), privileged access to information about new products, exclusive offers and discounts, the chance to win prizes and even special surveys about new releases.

19.2

Troubleshooting

Switch On and Remote Control

The TV does not switch on

- Disconnect the power cable from the power outlet. Wait for one minute then reconnect it.
- Make sure that the power cable is securely connected.

Creaking sound at startup or switch off

When you turn the TV on, off or to standby, you hear a creaking sound from the TV chassis. The creaking sound is due to the normal expansion and contraction of the TV as it cools and warms up. This does not affect performance.

TV does not respond to the remote control

The TV requires some time to start up. During this time, the TV does not respond to the remote control or TV controls. This is normal behavior.

If the TV continues to be unresponsive to the remote control, you can check if the remote control is working by means of a mobile phone camera. Put the phone in camera mode and point the remote control to the camera lens. If you press any button on the remote control and you notice the infra-red LED flicker through the camera, the remote control is working. The TV needs to be checked.

If you do not notice the flickering, the remote control might be broken or its batteries are low.

This method of checking the remote control is not possible with remote controls which are wirelessly paired with the TV.

Channels

No digital channels found during the installation

See the technical specifications to make sure that your TV supports digital channels in your country. Make sure that all cables are properly connected and that the correct network is selected.

Previously installed channels are not in the channel list

Make sure that the correct channel list is selected.

Picture

No picture/distorted picture

- Make sure that the antenna is properly connected to the TV.
- Make sure that the correct device is selected as the display source.
- Make sure that the external device or source is properly connected.

Sound but no picture

- Change to other video sources and then change back to current source, then do picture style restore in Picture settings or do Factory reset in General settings option.

Poor antenna reception

- Make sure that the antenna is properly connected to the TV.
- Loud speakers, unearthed audio devices, neon lights, high buildings and other large objects can influence reception quality. If possible, try to improve the reception quality by changing the antenna direction or moving devices away from the TV.
- If reception on only one channel is poor, fine-tune this channel with Manual Installation.

Poor picture from a device

- Make sure that the device is connected properly. Make sure the device's output video setting is the highest possible resolution if applicable.
- Restore picture style or change to other picture styles.

Picture settings change after a while

Make sure that **Retail mode** is set to **Off**. You can change and save settings in this mode.

A commercial banner appears

Make sure that **Retail mode** is set to **Off**. Select **Settings > System > Television > Environment > home**.

Picture does not fit the screen

- Change to a different picture format.
- Change **Display mode** to **Automatic**.

Picture position is incorrect

- Picture signals from some devices may not fit the

screen correctly. Check the signal output of the connected device.

- Change **Display mode** to **Automatic**.

Computer picture is not stable

- Make sure that your PC uses the supported resolution and refresh rate.
- Make sure HDMI video source is not supported HDR content.

Sound

No sound or poor sound quality

If no audio signal is detected, the TV automatically switches the audio output off — this does not indicate malfunction.

- Make sure that the sound settings are correctly set.
- Make sure that all cables are properly connected.
- Make sure that the volume is not muted or set to zero.
- Make sure that the TV audio output is connected to the audio input on the Home Theater System. Sound should be heard from the HTS speakers.
- Some devices may require you to manually enable HDMI audio output. If HDMI audio is already enabled, but you still do not hear audio, try changing the digital audio format of the device to PCM (Pulse Code Modulation). Refer to the documentation accompanying your device for instructions.

HDMI and USB

HDMI

- Note that HDCP (High-bandwidth Digital Content Protection) support can delay the time taken for a TV to display content from an HDMI device.
- If the TV does not recognize the HDMI device and no picture is displayed, switch the source from one device to another and back again.
- If the picture and sound of a device connected to HDMI is distorted, connect the device to another HDMI port on TV and power reboot your source device.
- If there are intermittent sound disruptions, make sure that output settings from the HDMI device are correct.
- If you use an HDMI-to-DVI adaptor or HDMI-to-DVI cable, make sure that an additional audio cable is connected to AUDIO IN (mini-jack only), if available.

HDMI EasyLink does not work

- Make sure that your HDMI devices are HDMI-CEC compatible. EasyLink features only work with devices that are HDMI-CEC compatible.

No volume icon shown

- When an HDMI-CEC audio device is connected and you use the TV Remote Control to adjust the volume level from the device, this behavior is normal.

Photos, videos and music from a USB device do not show

- Make sure that the USB storage device is set to Mass Storage Class compliant, as described in the storage device's documentation.
- Make sure that the USB storage device is compatible with the TV.
- Make sure that the audio and picture file formats are supported by the TV.

Choppy playback of USB files

- The transfer performance of the USB storage device may limit the data transfer rate to the TV which causes poor playback.

Network

Wi-Fi network not found or distorted

- Microwave ovens, DECT phones or other Wi-Fi 802.11b/g/n devices in your proximity might disturb the wireless network.
- Make sure that the firewalls in your network allow access to the TV's wireless connection.
- If the wireless network does not work properly in your home, try the wired network installation.

Internet does not work

- If the connection to the router is OK, check the router connection to the Internet.

The PC and Internet connection are slow

- Look in your wireless router's user manual for information on indoor range, transfer rate and other factors of signal quality.
- Use a high-speed (broadband) Internet connection for your router.

DHCP

- If the connection fails, you can check the DHCP (Dynamic Host Configuration Protocol) setting of the router. DHCP should be turned on.

Bluetooth®

Unable to pair

- Make sure the device is in pairing mode. Read the user manual of the device.
- Keep the wireless speaker as close to the TV as possible.
- Trying to pair several devices with the TV at the same time may not work.

Bluetooth® lost connection

- Always position the wireless speaker within a range of 15 feet from the TV.

Bluetooth® Audio and Video synchronization

- Before you purchase a wireless Bluetooth® speaker, inform yourself about its Audio to Video synchronization quality, commonly called 'lip sync.' Not all Bluetooth® devices perform correctly. Ask your dealer for advice.

Wrong Menu Language

Change the language back to your language

- 1 - Go to **Settings > System > Language** and press **OK**.
- 2 - Select the language you want and press **OK**.
- 3 - Press **Back**, repeatedly if necessary, to close the menu.

19.3

Online Help

Go to www.philips.com/TVsupport to resolve any Philips TV problem and consult our online support. You can select your language and enter your product model number.

On the support site you can find your country's telephone number to contact us as well as answers to frequently asked questions (FAQs). In some countries, you can chat with one of our collaborators and ask your question directly or send a question by email. You can download new TV software or the manual to read on your computer.

19.4

Support and Repair

For support and repair, call the Consumer Care hotline in your country. Our service engineers will take care of a repair, if necessary.

You can find the telephone number in the printed documentation that came with the TV.
Or consult our website www.philips.com/TVsupport and select your country, if needed.

TV model number and serial number

You might be asked to provide the TV product model number and serial number. Find these numbers on the packaging label or on the type label on the back or bottom of the TV.

Warning

Do not attempt to repair the TV yourself. This may cause severe injury, irreparable damage to your TV or void your warranty.

Safety and Care

20.1

Safety

Important

Read and understand all safety instructions before you use the TV. If damage is caused by failure to follow instructions, the warranty does not apply.

Risk of Electric Shock or Fire

- Never expose the TV to rain or water. Never place liquid containers, such as vases, near the TV. If liquids are spilled on or into the TV, disconnect the TV from the power outlet immediately. Contact Philips TV Consumer Care to have the TV checked before use.
- Never expose the TV, remote control or batteries to excessive heat. Never place them near burning candles, naked flames or other heat sources, including direct sunlight.
- Never insert objects into the ventilation slots or other openings on the TV.
- Never place heavy objects on the power cord.
- Avoid force coming onto power plugs. Loose power plugs can cause arcing or fire. Ensure that no strain is exerted on the power cord when you swivel the TV screen.
- To disconnect the TV from the mains power, the power plug of the TV must be disconnected. When disconnecting the power, always pull the power plug, never the cord. Ensure that you have full access to the power plug, power cord and outlet socket at all times.

Risk of Injury or Damage to the TV

- Two people are required to lift and carry a TV that weighs more than 25 kg or 55 lbs.
- If you mount the TV on a stand, only use the supplied stand. Secure the stand to the TV tightly. Place the TV on a flat, level surface that can support the weight of the TV and the stand.
- When wall mounted, ensure that the wall mount can safely bear the weight of the TV set. TP Vision bears no responsibility for improper wall mounting that results in accident, injury or damage.
- Parts of this product are made of glass. Handle with care to avoid injury or damage.

Risk of damage to the TV!

Before you connect the TV to the power outlet, ensure that the power voltage matches the value printed on the back of the TV. Never connect the TV to the power outlet if the voltage is different.

Stability Hazards

A television set may fall, causing serious personal injury or death. Many injuries, particularly to children, can be avoided by taking simple precautions such as:

- ALWAYS ensure the television set is not overhanging the edge of the supporting furniture.
- ALWAYS use cabinets or stands or mounting methods recommended by the manufacturer of the television.
- ALWAYS use furniture that can safely support the television.
- ALWAYS educate children about the dangers of climbing on furniture to reach the television or its controls.
- ALWAYS route cords and cables connected to the television so that they cannot be tripped over, pulled or grabbed.
- NEVER place a television in an unstable location.
- NEVER place the television on tall furniture (for example, cupboards or bookcases) without anchoring both the furniture and television to a suitable support.
- NEVER place the television on cloth or other materials that may be located between the television and supporting furniture.
- NEVER place items that might tempt children to climb, such as toys and remote controls, on the top of the television or furniture on which the television is placed.

If the existing television is going to be retained and relocated, the same considerations as above should be applied.

Risk of Batteries

- Do not ingest the battery. Chemical burn hazard.
- The remote control may contain a coin/button cell battery. If the coin/button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.
- Keep new and used batteries away from children.
- If the battery compartment does not close securely, stop using the product and keep it away from children.
- If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.
- Risk of fire or explosion if the battery is replaced by an incorrect type.
- Replacement of a battery with an incorrect type that can defeat a safeguard (e.g. in the case of some lithium battery types).
- Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can

result in an explosion.

- Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.
- A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

Risk of Overheating

Never install the TV in a confined space. Always leave a space of at least 10 cm or 4 in around the TV for ventilation. Ensure curtains or other objects never cover the ventilation slots on the TV.

Lightning Storms

Disconnect the TV from the power outlet and antenna before lightning storms. During lightning storms, never touch any part of the TV, power cord or antenna cable.

Risk of Hearing Damage

Avoid using earphones or headphones at high volumes or for prolonged periods of time.

Low Temperatures

If the TV is transported in temperatures below 5°C or 41°F, unpack the TV and wait until the TV temperature reaches room temperature before connecting the TV to the power outlet.

Humidity

In rare occasions, depending on temperature and humidity, minor condensation can occur on the inside of the TV glass front (on some models). To prevent this, do not expose the TV to direct sunlight, heat or extreme humidity. If condensation occurs, it will disappear spontaneously while the TV is playing for a few hours. The condensation moisture will not harm the TV or cause malfunction.

20.2

Screen Care

- Never touch, push, rub or strike the screen with any object.
- Unplug the TV before cleaning.
- Clean the TV and frame with a soft damp cloth and wipe gently. Avoid touching the Ambilight* LEDs on the backside of the TV. Never use substances such as alcohol, chemicals or household cleaners on the TV.
- To avoid deformations and color fading, wipe off water drops as quickly as possible.
- Avoid stationary images as much as possible. Stationary images are images that remain onscreen for extended periods of time. Stationary images include onscreen menus, black bars, time displays, etc. If you must use stationary images, reduce screen contrast and brightness to avoid screen damage.

* Ambilight LED is only for models which support Ambilight function.

Terms of Use

2024 © TP Vision Europe B.V. All rights reserved.

This product was brought to the market by TP Vision Europe B.V. or one of its affiliates, hereinafter referred to as TP Vision, which is the manufacturer of the product. TP Vision is the warrantor in relation to the TV with which this booklet was packaged. Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V or their respective owners. TP Vision reserves the right to change products at any time without being obliged to adjust earlier supplies accordingly.

The written material packaged with the TV and the manual stored in the memory of the TV or downloaded from the Philips website www.philips.com/TVsupport are believed to be adequate for the intended use of the system.

The material in this manual is believed adequate for the intended use of the system. If the product, or its individual modules or procedures, are used for purposes other than those specified herein, confirmation of their validity and suitability must be obtained. TP Vision warrants that the material itself does not infringe any United States patents. No further warranty is expressed or implied. TP Vision cannot be held responsible neither for any errors in the content of this document nor for any problems as a result of the content in this document. Errors reported to Philips will be adapted and published on the Philips support website as soon as possible.

Terms of warranty - Risk of injury, damage to TV or void of warranty!

Never attempt to repair the TV yourself. Use the TV and accessories only as intended by the manufacturer. The caution sign printed on the back of the TV indicates risk of electric shock. Never remove the TV cover. Always contact Philips TV Customer Care for service or repairs. Find the telephone number in the printed documentation that came with the TV. Or consult our website www.philips.com/TVsupport and select your country if needed. Any operation expressly prohibited in this manual, or any adjustments and assembly procedures not recommended or authorized in this manual, shall void the warranty.

Pixel characteristics

This TV product has a high number of color pixels. Although it has effective pixels of 99.999% or more, black dots or bright points of light (red, green or blue) may appear constantly on the screen. This is a structural property of the display (within common industry standards) and is not a malfunction. Therefore, please

note that this is not subject to repair, exchange or refund within and/or out of the warranty period.

Backlight characteristics

All Philips TVs have undergone stringent tests and checks before shipment to you. You can rest assured that we place utmost importance on the quality of our TVs so you don't suffer any viewing displeasure while watching your TV. However, please note that backlight bleeding (the 'Mura effect') and/or background light unevenness that can only be observed in dark images or in a very dark and dim room are considered to be within normal TV specifications. Such occurrences do not represent deterioration nor should be regarded as a defect of the TV. Hence, we regret that claims of this nature for warranty cover, free-of-charge service, replacements or refunds cannot be accepted within and/or outside of the warranty period.

TP Vision is committed to developing, producing and marketing products that cause no adverse health effects. TP Vision confirms that, as long as its products are handled properly for their intended use, they are safe to use according to scientific evidence available today. TP Vision plays an active role in the development of international safety standards, enabling TP Vision to anticipate further developments in standardization for early integration in its products.

22.

Copyrights

22.1

Google TV

Google TV is the name of this device's software experience and a trademark of Google LLC. Google, YouTube and other marks are trademarks of Google LLC.



22.2

HDMI

The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI Trade Dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.



22.3

HEVC Advance

Covered by one or more claims of the HEVC patents listed at patentlist.accessadvance.com. Future proof with advanced HEVC decoding.



22.4

Dolby Audio

Manufactured under license from Dolby Laboratories. Dolby, Dolby Audio, and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.



22.5

DTV_i

The DTV_i brand and logo are registered marks of Pontifical Catholic University of Rio de Janeiro (PUC-Rio) and the Federal University of Paraíba (UFPB).



Other Trademarks

All other registered and unregistered trademarks are the property of their respective owners.

Disclaimer

Disclaimer regarding services and/or software offered by third parties

Services and/or software offered by third parties may be changed, suspended or terminated without prior notice. TP Vision does not bear any responsibility in these sorts of situations.

Index

A		R	
Accessibility settings	27	Register your product	39
Ambient Mode	29	Repair	41
Antenna	7	REC option	13
Apps	22	S	
Audio Language	30	Safety Instructions	42
B		Set PIN Code	15
Bluetooth®	19	Software, Update	28
Bluetooth®, Devices	19	Sound settings	27
Bluetooth®, Remove device	19	Storage	28
Bluetooth®, Select device	19	Switching On	11
C		T	
Channel	14	Troubleshooting	39
Channel Install, Cable	12	TV guide	33
Channel List	14	TV Guide Data	33
Channel List sorting	14	TV, standby	11
Channel List, open	14	Time shift option	13
Channel, Installation	12	W	
Channel, Manual channel update	12	Wifi	20
Channel, TV guide	33	Wired connection	20
Channel, Update	12	Wireless connection	20
Connectivity Guide	16		
Consumer Care	41		
Contact Philips	41		
I			
Input blocked	14		
K			
Keyboard	28		
L			
Lock channel	14		
M			
Media	31		
Media files, from a USB drive	31		
N			
Network connection	20		
Network, Wired	20		
Network, Wireless	20		
O			
Online support	41		
P			
Parental Controls	14		
Photos, Videos and Music	31		
Picture Setting	25		
Problems, Channel	39		
Problems, Connection, Internet	40		
Problems, Connection, Wi-Fi	40		
Problems, HDMI Connection	40		
Problems, Picture	39		
Problems, Remote control	39		
Problems, Sound	40		
Problems, USB Connection	40		
Problems, Wrong menu language	41		



All registered and unregistered trademarks are property of their respective owners.
Specifications are subject to change without notice.

Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license.

This product has been manufactured and is sold under the responsibility of TP Vision Europe B.V., and TP Vision Europe B.V. is the warrantor in relation to this product.

2024© TP Vision Europe B.V. All rights reserved.

www.philips.com/welcome