



Introduction

Congratulations on your purchase and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

Important

Read this user manual carefully before you use the appliance and save it for future reference.

Danger

- Never immerse the iron in water.

Warning

- Check if the voltage indicated on the type plate corresponds to the local mains voltage before you connect the appliance.
- Do not use the appliance if the plug, the mains cord or the appliance itself shows visible damage, or if the appliance has been dropped.
- If the mains cord is damaged, you must have it replaced by Philips, a service centre authorised by Philips or similarly qualified persons in order to avoid a hazard.
- Never leave the appliance unattended when it is connected to the mains.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not let the mains cord come into contact with the hot soleplate of the iron.

Caution

- Only connect the appliance to an earthed wall socket.
- Check the mains cord regularly for possible damage.
- Always place and use the iron on a stable, level and horizontal surface.
- The soleplate of the iron can become extremely hot and may cause burns if touched.
- When you have finished ironing, when you clean the appliance and also when you leave the iron even for a short while: put the iron on its heel and remove the mains plug from the wall socket.
- The appliance is intended for household use only.

Electromagnetic fields (EMF)

This Philips appliance complies with all standards regarding electromagnetic fields (EMF). If handled properly and according to the instructions in this user manual, the appliance is safe to use based on scientific evidence available today.

General description (Fig. 1)

- A** Temperature dial
- B** Temperature light
- C** Mains cord
- D** Heel
- E** Type plate
- F** Soleplate

Before first use

- 1 Remove any sticker or protective foil from the soleplate.
- 2 Let the iron heat up to maximum temperature and pass the iron over a piece of damp cloth for several minutes to remove any residues from the soleplate.

Using the appliance

Setting the temperature

- 1 Put the iron on its heel.
 - 2 To set the required ironing temperature, turn the temperature dial to the appropriate position (Fig. 2).
- Check the laundry care label for the required ironing temperature:
 - Synthetic fabrics (e.g. acrylic, viscose, polyamide, polyester)
 - Silk
 - Wool
 - Cotton, linen

If you do not know what kind or kinds of fabric an article is made of, determine the right ironing temperature by

ironing a part that is not visible when you wear or use the article.

Silk, woollen and synthetic materials: iron the reverse side of the fabric to prevent shiny patches.

Start ironing the articles that require the lowest ironing temperature, such as those made of synthetic fibres.

- 3 Put the mains plug in an earthed wall socket.

Ironing

Note: The iron may give off some smoke when you use it for the first time. This stops after a short while.

- 1 Put the iron on its heel.
- 2 Put the mains plug in an earthed wall socket.
- 3 Set the recommended ironing temperature (see section 'Setting the temperature' above) (Fig. 2).
- 4 Let the iron heat up until the temperature light first goes out and then goes on again (Fig. 3).

Note: The temperature light goes on from time to time during ironing.

- 5 Start ironing.

Tip: Ironing is easier and takes less time if you moisten the article first.

Cleaning

- 1 Put the iron on its heel.
- 2 Remove the mains plug from the wall socket and let the iron cool down for at least 30 minutes.
- 3 Wipe the soleplate with a damp cloth and a non-abrasive (liquid) cleaning agent.

To keep the soleplate smooth, avoid hard contact with metal objects. Never use a scouring pad, vinegar or other chemicals to clean the soleplate.

- 4 Clean the upper part of the iron with a damp cloth.

Storage

- 1 Put the iron on its heel.
- 2 Remove the mains plug from the wall socket and let the iron cool down for at least 30 minutes.
- 3 Wind the mains cord round the cord storage facility (Fig. 4).
- 4 Store the iron on its heel in a safe and dry place (Fig. 5).

Environment

- Do not throw away the appliance away with the normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you help to preserve the environment (Fig. 6).

Guarantee & service

If you need service or information or if you have a problem, please visit the Philips website at www.philips.com or contact the Philips Consumer Care Centre in your country (you find its phone number in the worldwide guarantee leaflet). If there is no Consumer Care Centre in your country, go to your local Philips dealer.

Troubleshooting

This chapter summarises the most common problems you could encounter with the appliance. If you are unable to solve the problem with the information below, contact the Consumer Care Centre in your country.

Problem	Possible cause	Solution
The iron is plugged in but the soleplate is cold.	There is a connection problem.	Check the mains cord, the plug and the wall socket.
	The temperature dial is set to MIN.	Set the temperature dial to the required position (see section 'Setting the temperature' in chapter 'Using the appliance').

TIẾNG VIỆT

Giới thiệu

Chúc mừng bạn đã mua được sản phẩm Philips mới và chào mừng bạn đến với Philips! Để có được lợi ích đầy đủ từ sự hỗ trợ do Philips cung cấp, hãy đăng ký sản phẩm tại www.philips.com/welcome.

Lưu ý

Hãy đọc kỹ hướng dẫn sử dụng này trước khi sử dụng thiết bị và cất giữ để tiện tham khảo sau này.

Nguy hiểm

- Không được nhúng bàn ủi trong nước.

Cảnh báo

- Trước khi cắm điện, kiểm tra xem điện áp ghi trên bàn ủi có tương ứng với hiệu điện thế nguồn hay không.
- Không sử dụng thiết bị này nếu phích cắm, dây điện hoặc chính bản thân thiết bị có biểu hiện hư hỏng biểu hiện ra bên ngoài, hoặc nếu bàn ủi đã bị rơi.
- Nếu dây điện bị hư hỏng, bạn nên thay dây điện tại trung tâm bảo hành của Philips, trung tâm bảo hành do Philips ủy quyền hoặc những nơi có khả năng và trình độ tương đương để tránh gây nguy hiểm.
- Phải luôn để mắt đến thiết bị khi đã cắm điện.
- Thiết bị này không dành cho người dùng (bao gồm cả trẻ em) có sức khỏe kém, khả năng giác quan hoặc có dấu hiệu tâm thần, hoặc thiếu kinh nghiệm và kiến thức, trừ khi họ được giám sát hoặc hướng dẫn sử dụng thiết bị bởi người có trách nhiệm đảm bảo an toàn cho họ.
- Trẻ em phải được giám sát để đảm bảo rằng chúng không chơi đùa với thiết bị này.
- Không để dây điện nguồn tiếp xúc với mặt đế bàn ủi khi còn nóng.

Chú ý

- Chỉ nối lò chiên vào ổ cắm điện có dây tiếp đất.
- Kiểm tra dây điện nguồn thường xuyên về những hư hỏng có thể xảy ra.
- Luôn đặt và sử dụng bàn ủi trên bề mặt phẳng, nằm ngang và chắc chắn.
- Mặt bàn ủi rất nóng và có thể gây bỏng nếu chạm vào.
- Khi ủi xong, khi lau chùi và cả khi không ủi thậm chí chỉ trong chốc lát: đặt đứng bàn ủi và rút phích cắm ra khỏi ổ điện.
- Thiết bị này được thiết kế chỉ để dùng trong gia đình.

Từ trường điện (EMF)

Thiết bị Philips này tuân thủ tất cả các tiêu chuẩn liên quan đến các từ trường điện (EMF). Nếu được sử dụng đúng và tuân thủ các hướng dẫn trong sách hướng dẫn này, theo các bằng chứng khoa học hiện nay, việc sử dụng thiết bị này là an toàn.

Mô tả tổng quát (Hình 1)

- A** Nút điều chỉnh nhiệt độ
- B** Đèn báo nhiệt độ
- C** Dây điện nguồn
- D** Chân dựng đứng
- E** Loại đế ủi
- F** Đế bàn ủi

Trước khi sử dụng lần đầu

- Loại bỏ tất cả các nhãn hoặc lớp bảo vệ dính trên mặt đế bàn ủi.
- Đặt bàn ủi nóng lên đến nhiệt độ tối đa và là bàn ủi trên một miếng vải ẩm trong vài phút để loại bỏ những cấu bẩn khỏi mặt đế bàn ủi.

Cách sử dụng máy

Điều chỉnh nhiệt độ

- Dựng đứng bàn ủi
 - Để chọn nhiệt độ ủi yêu cầu, xoay nút điều chỉnh nhiệt độ đến vị trí tương ứng (Hình 2).
- Kiểm tra nhãn ghi chất liệu vải để biết nhiệt độ ủi yêu cầu:
 - Vải tổng hợp (ví dụ: acrylic, sợi vitcô, polyamit, vải pôliexte)
 - ● Tơ lụa
 - ●● Len
 - ●●● Bông, lanh

Nếu bạn không biết một món đồ được làm bằng (những) loại vải nào, hãy chọn nhiệt độ ủi thích hợp bằng cách ủi thử một vùng không bị nhìn thấy khi bạn mặc vào hoặc sử dụng món đồ đó.

Đối với vải tơ lụa, vải len và vải tổng hợp: hãy ủi mặt trái để vải không bị bóng.

Hãy ủi trước các loại quần áo thích hợp với nhiệt độ ủi thấp nhất, ví dụ như các loại quần áo làm từ sợi tổng hợp.

3 Cắm điện vào ổ cắm có tiếp đất.

Ủi

Lưu ý: Khi sử dụng lần đầu tiên, bàn ủi sẽ thải ra một ít khói. Hiện tượng này sẽ kết thúc sau một lúc sử dụng.

- Dựng đứng bàn ủi
- Cắm điện vào ổ cắm có tiếp đất.
- Chọn nhiệt độ ủi như được đề xuất (xem mục 'Điều chỉnh nhiệt độ' ở trên) (Hình 2).
- Hãy để bàn ủi nóng lên cho tới khi đèn báo nhiệt độ tắt và sau đó sáng trở lại (Hình 3).

Lưu ý: Đèn báo nhiệt độ sẽ thỉnh thoảng bật sáng trong khi ủi.

5 Bắt đầu ủi.

Mẹo: Việc ủi sẽ dễ dàng hơn và tốn ít thời gian hơn nếu bạn làm ấm quần áo trước.

Vệ sinh máy

- Dựng đứng bàn ủi
- Rút dây cắm bàn ủi ra khỏi ổ điện và để bàn ủi nguội xuống trong thời gian tối thiểu là 30 phút.
- Lau sạch mặt đế bàn ủi bằng một miếng vải ẩm với một chất làm sạch không ăn mòn (dạng lỏng).

Để giữ cho mặt bàn ủi được trơn nhẵn, bạn nên tránh để va chạm mạnh với các đồ vật bằng kim loại. Không bao giờ dùng các miếng xốp cọ rửa, giũa hoặc các hoá chất khác để làm sạch mặt bàn ủi.

- Lau chùi phần trên của bàn ủi bằng một miếng vải ẩm.

Cất giữ

- Dựng đứng bàn ủi
- Rút dây cắm bàn ủi ra khỏi ổ điện và để bàn ủi nguội xuống trong thời gian tối thiểu là 30 phút.
- Quấn dây điện vòng quanh chân đế (Hình 4).
- Đặt bàn ủi đứng để bảo quản và đặt ở một nơi khô ráo an toàn (Hình 5).

Môi trường

- Không vứt thiết bị cùng chung với rác thải gia đình thông thường khi ngừng sử dụng nó mà hãy đem thiết bị đến điểm thu gom chính thức để tái chế. Làm như vậy sẽ giúp bảo vệ môi trường (Hình 6).

Bảo hành & dịch vụ

Nếu bạn cần biết dịch vụ, thông tin hay gặp trực trực, vui lòng vào website của Philips tại www.philips.com hoặc liên hệ với Trung Tâm Chăm Sóc Khách Hàng của Philips ở nước bạn (bạn sẽ tìm thấy số điện thoại của Trung tâm trong tờ bảo hành khắp thế giới). Nếu không có Trung Tâm Chăm Sóc Khách Hàng tại quốc gia của bạn, hãy liên hệ với đại lý Philips tại địa phương bạn.

Cách khắc phục sự cố

Chương này tóm tắt các sự cố thường gặp phải với thiết bị này. Nếu bạn không thể giải quyết được vấn đề sau khi tham khảo thông tin dưới đây, hãy liên hệ với Trung Tâm Chăm Sóc Khách Hàng của Philips tại nước bạn.

Vấn đề	Nguyên nhân có thể	Giải pháp
Bàn ủi đã được cắm điện nhưng mặt bàn ủi không nóng.	Có vấn đề về dây nối hay phích cắm điện.	Kiểm tra dây điện, phích cắm và ổ cắm.
	Nút điều chỉnh nhiệt độ được đặt ở vị trí MIN (tối thiểu).	Vặn nút điều chỉnh nhiệt độ sang vị trí được đề xuất (xem mục 'Điều chỉnh nhiệt độ' trong chương 'Sử dụng thiết bị').