

Register your product and get support at  
[www.philips.com/welcome](http://www.philips.com/welcome)



**PHILIPS**

## Introduction

Congratulations on your purchase and welcome to Philips! To fully benefit from the support that Philips offers, register your product at [www.philips.com/welcome](http://www.philips.com/welcome).

## Important

Read this important information carefully before you use the appliance and save it for future reference.

### Danger

- Never vacuum up water or any other liquid, flammable substances or hot ashes.

### Warning

- Check if the voltage indicated on the appliance corresponds to the local mains voltage before you connect the appliance.
- Do not use the appliance if the plug, the mains cord or the appliance itself is damaged.
- If the mains cord is damaged, you must have it replaced by Philips, a service centre authorised by Philips or similarly qualified persons in order to avoid a hazard.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

- The plug must be removed from the socket-outlet before cleaning or maintaining the appliance.
- Do not point the hose, the tube or any other accessory at the eyes or ears nor put it in your mouth.

## **Caution**

- Never use the appliance without the motor protection filter (located in the dustbag compartment). This could damage the motor and shorten the life of the appliance.
- Only use Philips s-bag<sup>®</sup> disposable synthetic dustbags or the reusable dustbag. Using other types or brands of dustbags might cause damage to the vacuum cleaner.
- Specific types only: Always replace the batteries of the remote control with batteries of the correct type.
- Specific types only: Remove the batteries of the remote control if you are not going to use the appliance for one month or more.
- To guarantee optimal dust retention and performance of the vacuum cleaner, always replace the filters with original Philips filters of the correct type (see chapter 'Ordering accessories').
- Maximum noise level:  $L_c = 84 \text{ dB(A)}$

## **Electromagnetic fields (EMF)**

---

This Philips appliance complies with all applicable standards and regulations regarding exposure to electromagnetic fields.

## Ordering accessories

To buy accessories or spare parts (such as dustbags, filters and additional nozzles), visit [www.shop.philips.com/service](http://www.shop.philips.com/service) or go to your Philips dealer. You can also contact the Philips Consumer Care Centre in your country (see the worldwide guarantee leaflet for contact details).

## Recycling

- This symbol means that this product shall not be disposed of with normal household waste (2012/19/EU) (Fig. 1).
- This symbol means that this product contains batteries which shall not be disposed of with normal household waste (2006/66/EC) (Fig. 2).
- Follow your country's rules for the separate collection of electrical and electronic products and batteries. Correct disposal helps prevent negative consequences for the environment and human health.
- To remove disposable batteries, see the instructions for placing and/or removing batteries in the user manual.

## Guarantee and support

If you need information or support, please visit [www.philips.com/support](http://www.philips.com/support) or read the separate worldwide guarantee leaflet.

## Troubleshooting

This chapter summarises the most common problems you could encounter with the appliance. If you are unable to solve the problem with the information below, visit [www.philips.com/support](http://www.philips.com/support) for a list of frequently asked questions or contact the Consumer Care Centre in your country.

Problem	Possible cause	Solution
The suction power is insufficient.	The dustbag is full.	Empty the reusable dustbag or replace the disposable dustbag.
	The filters are dirty.	Clean or replace the filters.

Problem	Possible cause	Solution
	The suction power is set to a low setting.	Increase the suction power with the regulator on the appliance or on the handgrip.
	The nozzle, tube or hose is blocked up.	To remove the obstruction, disconnect the blocked-up item and connect it (as far as possible) the other way around. Switch on the vacuum cleaner to force the air through the blocked-up item in opposite direction.
When I use my vacuum cleaner I sometimes feel electric shocks.	Your vacuum cleaner builds up static electricity. The lower the air humidity, the more static electricity the appliance builds up.	Discharge the appliance by frequently holding the tube against other metal objects in the room (for example the legs of a table or chair, a radiator etc.). You can also raise the air humidity level in the room.
Specific types only: The infrared remote control does not function.	The batteries do not make full contact or have not been inserted properly.	Remove the lid of the battery compartment and insert the batteries correctly. Make sure the - and + poles point in the right direction.
	The batteries are empty.	Replace the batteries. You can continue to vacuum but you cannot use the remote control to increase or decrease the suction power or to switch off the appliance. To switch off the appliance, press the on/off button on the appliance.

# TÜRKÇE

## Giriş

Ürünümüzü satın aldığınız için teşekkür ederiz. Philips'e hoş geldiniz! Philips'in sunduğu destekten faydalanabilmek için lütfen ürününüzü şu adresten kaydedin: [www.philips.com/welcome](http://www.philips.com/welcome).

## Önemli

Cihazı kullanmadan önce bu önemli bilgileri dikkatlice okuyun ve gelecekte başvurmak üzere saklayın.

### Tehlike

- Hiçbir zaman su veya başka bir sıvıyı, yanıcı maddeleri veya sıcak külleri süpürmeyin.

### Uyarı

- Cihazı prize takmadan önce, üstünde yazılı olan gerilimin, evinizdeki şebeke gerilimiyle aynı olup olmadığını kontrol edin.
- Cihazın fişi, kordonu veya kendisi hasarlıysa kesinlikle kullanmayın.
- Cihazın elektrik kablosu hasarlıysa, bir tehlike oluşturmasını önlemek için mutlaka Philips'in yetki verdiği bir servis merkezi veya benzer şekilde yetkilendirilmiş kişiler tarafından değiştirilmesini sağlayın.
- Bu cihazın 8 yaşın üzerindeki çocuklar ve fiziksel, motor ya da zihinsel becerileri gelişmemiş veya bilgi ve tecrübe açısından eksik kişiler tarafından kullanımı sadece bu kişilerin nezaretinden sorumlu kişilerin bulunması veya cihazın güvenli kullanım talimatlarının bu kişilere sağlanması ve olası tehlikelerin anlatılması durumunda mümkündür.

Çocuklar cihazla oynamamalıdır. Temizlik ve kullanıcı bakımı herhangi bir gözetim olmadan çocuklar tarafından yapılmamalıdır.

- Cihazı temizlemeden veya cihazın bakımını yapmadan önce fişi prizden çekilmelidir.
- Hortumu, boruyu veya diğer herhangi bir aksesuarı gözlerinize veya kulaklarınıza tutmayın ya da ağızınıza sokmayın.

### **Dikkat**

- Motor koruma filtresi (toz torbası bölmesindedir) olmadan cihazı kesinlikle kullanmayın. Bu, motorun zarar görmesine ve cihazın kullanım ömrünün azalmasına neden olabilir.
- Sadece Philips s-bag® tek kullanımlık sentetik toz torbalarını veya tekrar kullanılabilir toz torbalarını kullanın. Diğer toz torbası türleri veya markaları, elektrikli süpürgeye zarar verebilir.
- Sadece belirli modellerde: Uzaktan kumandanın pillerini mutlaka doğru tipteki pillerle değiştirin.
- Sadece belirli modellerde: Cihazı bir ay veya daha uzun süre kullanmayacaksanız uzaktan kumandanın pillerini çıkarın.
- Elektrikli süpürge için optimum toz tutma ve performans sağlaması için, filtreleri her zaman doğru tipteki orijinal Philips filtreleri ile değiştirin (bkz. 'Aksesuar siparişi' bölümü).
- Maksimum gürültü düzeyi:  $L_c = 84 \text{ dB(A)}$

## Elektromanyetik alanlar (EMF)

Bu Philips cihazı, elektromanyetik alanlara maruz kalmaya ilişkin geçerli tüm standartlara ve düzenlemelere uygundur.

### Aksesuarların sipariş edilmesi

Aksesuar veya yedek parça (toz torbaları, filtreler ve ek başlıklar gibi) satın almak için [www.shop.philips.com/service](http://www.shop.philips.com/service) adresini ziyaret edin ya da Philips bayinize gidin. Aynı zamanda ülkenizdeki Philips Müşteri Hizmet Merkezi ile iletişim kurabilirsiniz (iletişim bilgileri için dünya çapında garanti kitapçığına başvurun).

### Geri dönüşüm

- Bu simge, ürünün normal evsel atıklarla birlikte atılmaması gerektiği anlamına gelir (2012/19/EU) (Şek. 1).
- Bu simge, ürünün normal evsel atıklarla birlikte atılmaması gereken piller içerdiği anlamına gelir (2006/66/EC) (Şek. 2).
- Elektrikli ve elektronik ürünlerin ve pillerin ayrı olarak toplanmasına ilişkin ülkenizde geçerli olan kurallara uyun. Bu işlemin doğru şekilde yapılması çevreyi ve insan sağlığını olumsuz etkileyecek sonuçların önlenmesine yardımcı olur.
- Tek kullanımlık pilleri çıkarmak için kullanım kılavuzunda bulunan, pillerin yerleştirilmesi ve/veya çıkarılmasına ilişkin talimatlara bakın.

### Garanti ve destek

Bilgi veya desteğe ihtiyaç duyarsanız lütfen [www.philips.com/support](http://www.philips.com/support) adresini ziyaret edin veya dünya çapında garanti kitapçığını okuyun.

### Sorun giderme

Bu bölüm, cihazda en sık karşılaşılabileceğiniz sorunları özetlemektedir. Sorunu aşağıdaki bilgilerle çözemiyorsanız sık sorulan sorular listesi için [www.philips.com/support](http://www.philips.com/support) adresini ziyaret edin veya ülkenizdeki Müşteri Destek Merkezi ile iletişim kurun.



Sorun	Nedeni	Çözüm
Emiş gücü yetersiz.	Toz torbası dolu olabilir.	Tekrar kullanılabilir toz torbasını boşaltın veya tek kullanımlık toz torbasını değiştirin.
	Filtreler kirli olabilir.	Filtreleri temizleyin ya da değiştirin.
	Emiş gücü düşük ayarda olabilir.	Emme gücünü cihazdaki veya saptaki regülatörle artırın.
	Başlık, boru veya hortum tıkanmış olabilir.	Herhangi bir tıkanma söz konusu olduğunda, tıkanan aparatı çıkartarak ters taraftan (mümkün olduğunca uzak) takın. Elektrikli süpürgeyi açarak tıkanmış parçaya ters yönden hava gönderin.
Elektrikli süpürgeyi kullanırken bazen elektrik çarpmış gibi hissediyorum.	Elektrikli süpürgeinizde statik elektrik birikmiştir. Havadaki nem ne kadar düşük olursa, cihazlarda biriken statik elektrik o kadar yüksek olur.	Boruyu sık sık odadaki diğer metal nesnelere değdirerek cihaz yükünü boşaltın (örneğin, masanın veya sandalyenin ayakları, radyatör vb.). Odadaki havanın nem seviyesini de artırabilirsiniz.
Sadece belirli modellerde: Kızılötesi uzaktan kumanda çalışmıyor.	Piller tam olarak temas etmiyor veya düzgün şekilde takılmamış.	Pil yuvasının kapağını kaldırın ve pilleri düzgün şekilde takın. - ve + kutupların doğru yönde yerleştirilmiş olduğundan emin olun.
	Piller bitmiştir.	Pilleri değiştirin. Elektrikli süpürgeyi kullanmaya devam edebilirsiniz, ancak emiş gücünü artırmak veya azaltmak için ya da cihazı kapatmak için uzaktan kumandayı kullanamazsınız. Cihazı kapatmak için cihaz üzerindeki açma/kapama düğmesine basın.



[www.philips.com](http://www.philips.com)



100% recycled paper

4222.003.4213.1