

ENGLISH

Introduction

Congratulations on your purchase and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

General description

- 1 Cover of pusher
- 2 Pusher
- 3 Feeding tube
- 4 Lid
- 5 Filter
- 6 Juice collector with spout (drip stop function)
- 7 Integrated pulp container
- 8 Driving shaft
- 9 Locking arm
- 10 Motor unit
- 11 Control knob
- 12 Cord storage compartment
- 13 Berry funnel (spec types only)
- 14 Juice jug lid with integrated foam separator
- 15 Juice jug

Important

Read this important information carefully before you use the appliance and save it for future reference.

Danger

- Never immerse the motor unit in water or any other liquid, nor rinse it under the tap.
- Warning**
 - If the supply cord is damaged, it must be replaced by Philips, its service agent or similarly qualified persons in order to avoid a hazard.
 - Always disconnect the appliance from the mains if you leave it unattended or before you assemble, disassemble or clean it.
 - Do not use the appliance if the sieve or the lid is damaged in any way or shows visible cracks and contact the nearest Philips service center.
 - This appliance is intended for normal household use only. It is not intended for use in environments such as staff kitchens of shops, offices, farms or other work environments. Nor is it intended to be used by clients in hotels, motels, bed and breakfasts and other residential environments.
 - This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
 - Children should be supervised not to play with the appliance.
 - Do not use the appliance if the plug, the mains cord or other components are damaged.
 - Never reach into the feeding tube with your fingers or an object while the appliance is operating. Only use the pusher for this purpose. Do not insert other items than fruits, vegetables or the pusher into the feeding tube.
 - Do not touch the small cutting blades in the base of the sieve. They are very sharp.
 - Always place and use the appliance on a dry, stable and level surface.
 - To ensure that the appliance stands stably, keep the surface on which the appliance stands and the bottom of the appliance clean.
 - Do not eat the pulp or use for preparing dishes.
 - Check if the voltage indicated on the base of the appliance corresponds to the local mains voltage before you connect the appliance.
 - Never let the appliance operate unattended.

Caution

- Before you disassemble the appliance and before you clean it, set the control knob to off position and remove the plug from the wall socket. Then lower the locking arm to unlocked position.
- Only lower the locking arm to unlocked position after you have switched off the appliance and the sieve has stopped rotating.
- Always unplug the appliance after use.
- Do not hold the appliance by the locking arm when you carry it.
- Always unwind the power cord completely from the cord storage area before use.
- Never use any accessories or parts from other manufacturers or that Philips does not specifically recommend. If you use such accessories or parts, your guarantee becomes invalid.
- Make sure all parts are correctly assembled before you switch on the appliance.
- Only use the appliance when the locking arm is in locked position.

Electromagnetic fields (EMF)

This Philips appliance complies with all applicable standards and regulations regarding exposure to electromagnetic fields.

Drip Stop

After you have processed all ingredients and the juice flow has stopped, turn the spout clockwise by about 120° to activate the drip stop function.

Ordering accessories

To buy accessories or spare parts, visit www.shop.philips.com/service or go to your Philips dealer. You can also contact the Philips Consumer Care Centre in your country (see the worldwide guarantee leaflet for contact details).

Recycling

- Do not throw away the product with the normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you help to preserve the environment.
- Follow your country's rules for the separate collection of electrical and electronic products. Correct disposal helps prevent negative consequences for the environment and human health.

Guarantee and support

If you need information or support, please visit www.philips.com/support or read the separate worldwide guarantee leaflet.

한국어

소개

필립스 제품을 구입해 주셔서 감사합니다! 필립스가 드리는 지원 혜택을 받으실 수 있도록 www.philips.co.kr에서 제품을 등록하십시오.

제품정보

- 1 누름봉 뚜껑
- 2 누름봉
- 3 재료 투입구
- 4 뚜껑
- 5 필터
- 6 충출구가 있는 주스 받이(누수 방지 기능)
- 7 내장형 과육 용기
- 8 구동축
- 9 잡금 손잡이
- 10 본체
- 11 속도 조절기
- 12 코드 보관함
- 13 갈대기형 주입구(특정 모델만 해당)
- 14 거품 분리기가 있는 주스 용기 뚜껑
- 15 주스 용기

중요 사항

본 제품을 사용하기 전에 이 중요 정보를 주의 깊게 읽고 나중에 참조할 수 있도록 잘 보관하십시오.

위험

- 절대 본체를 물 또는 다른 액체에 담그거나 행구지 마십시오.
- 경고**
 - 전원 코드가 손상된 경우 안전을 위해 필립스, 서비스 기사 또는 전문 기술자에게 의뢰하여 교체하십시오.
 - 제품을 사용하지 않고 자리를 비우거나 제품을 조립, 분리 및 청소하기 전에는 반드시 전원 코드를 뽑으십시오.
 - 거품망이나 뚜껑이 손상되었거나 금이 간 경우 제품을 사용하지 마시고 가까운 필립스 서비스 센터에 문의하십시오.
 - 본 제품은 일반 가정용품입니다. 본 제품은 매장의 직원 휴게실, 시무실, 농장 또는 기타 작업 환경에서 사용하기 위한 것이 아닙니다. 또한 호텔, 모텔, 민박 및 기타 숙박 시설의 투숙객을 위한 위치도 아닙니다.
 - 신체적인 감각 및 인지능력이 떨어지거나 경험과 지식이 풍부하지 않은 성인 및 어린이는 혼자 제품을 사용하지 말고 제품 사용과 관련하여 안전에 책임질 수 있도록 자지사향을 충분히 숙지한 사람의 도움을 받으십시오.
 - 아이들이 제품을 가지고 놀지 못하도록 지도해 주십시오.
 - 플러그, 전원 코드 또는 기타 부품이 손상된 경우에는 제품을 사용하지 마십시오.
 - 제품이 작동 중일 때는 절대로 재료 투입구에 손이나 다른 물건을 넣지 마십시오. 필요한 경우에는 누름봉을 사용하십시오. 재료 투입구에 과일, 야채 또는 누름봉 이외의 물체를 넣지 마십시오.
 - 거품망 바닥의 작은 칼날을 만지지 마십시오. 매우 날카롭습니다.
 - 제품을 항상 물기나 없고 안정적이며 수평인 곳에 놓고 사용하십시오.
 - 제품이 안정적으로 유지될 수 있도록 제품이 옮겨져 있는 표면과 제품의 바닥을 깨끗한 상태로 유지하십시오.
 - 과육 치꺼기를 먹거나 음식을 만드는 데 사용하지 마십시오.
 - 제품을 벽 콘센트에 연결하기 전에 제품 하단에 표시되어 있는 전원이 사용 지역의 전압과 일치하는지 확인하십시오.
 - 제품이 작동 중일 때는 자리를 비우지 마십시오.

주의

- 제품을 분리하거나 세척하기 전에 먼저 속도 조절기를 꺼짐 위치에 맞추고 벽면 콘센트에서 전원 플러그를 뽑으십시오. 그런 다음 잡금 손잡이를 내려 열림 상태로 만드십시오.
- 제품 전원을 끄고 거품망이 더는 회전하지 않을 때만 잡금 손잡이를 내려 열림 상태로 만드십시오.
- 사용 후에는 반드시 제품의 전원 코드를 뽑으십시오.
- 제품을 깔끔 때는 잡금 손잡이를 잡고 끌어지지 마십시오.
- 사용하기 전에 항상 코드 보관함에서 전원 코드를 완전히 풀십시오.
- 다른 제품 압착제에서 만졌거나 필립스에서 권장하지 않은 제품 액세서리나 또는 부품은 절대 사용하지 마십시오. 이러한 액세서리나 부품을 사용했을 경우에는 품질 보증이 무효화됩니다.
- 전원을 켜기 전에 모든 부품이 올바르게 장착되어 있는지 확인하십시오.
- 잡금 손잡이가 잠금 상태에 있을 때에만 제품을 사용하십시오.

EMF(전자기장)

이 제품은 EMF(전자기장)와 관련된 모든 기준 및 규정을 준수합니다.

드립 증지

재료를 모두 끊어 더는 과즙이 나오지 않으면 드립을 중지하기 위해 주스 축출구를 시계 방향으로 약 120°를 돌립니다.

액세서리 주문

액세서리나 교체 부품을 구입하려면 웹사이트 (www.shop.philips.com/service) 또는 필립스 대리점장을 방문하십시오. 해당 지역의 필립스 고객 상담실에 문의하셔도 됩니다. 자체 한 연락처는 제품 보증서를 참조하십시오.

제작물

- 수명이 다 된 제품은 일반 가정용 쓰레기와 함께 버리지 마시고 지정된 재활용품 수거 장소에 버리십시오. 이를 통해 환경 보호에 동참하실 수 있습니다.
- 해당 국가의 전기/전자 제품 분리 수거 규칙에 따라 버리십시오. 물비른 제품 폐기기를 통해 환경 및 인류의 건강을 유해한 영향으로부터 보호할 수 있습니다.

보증 및 지원

보다 자세한 정보나 지원이 필요한 경우에는 필립스 웹 사이트 (www.philips.com/support)를 방문하시거나 제품 보증서를 참조하십시오.

제조번호 부여기준 : 본 제품의 제조번호는 4자리.5자리.6자리.9자리로 표기될 수 있습니다. (1) **4자리일 경우** : 앞의 두 자리는 연도를, 뒤의 두 자리는 생산된 주를 의미합니다. 예 0632 → 2006년 32번 주 생산 (2) **5자리일 경우** : 앞의 두 자리는 연도를, 다음 두 자리는 생산된 주를, 마지막 자리는 생산된 월을 의미합니다. 예 061245 → 2006년 12월 45일 (3) **6자리일 경우** : 앞의 두 자리는 연도를, 다음 두 자리는 생산된 주를, 마지막 자리는 생산된 월을 의미합니다. 예 061125 → 2006년 11월 25일 (4) **7자리일 경우** : 앞의 한 자리는 제조국을, 다음 두 자리는 연도를, 다음 두 자리는 생산된 주를, 다음 한 자리는 공장의 생산라인을, 마지막 3자리는 그 주에서 생산된 제품번호를 의미합니다. 예 05042001 → 네덜란드에서 2007년 40번 주 01년 생산라인에서 첫 번째 생산 (5) **기타제조번호**에 대한 문의사항은 (02)709-1200 으로 연락바랍니다.

BAHASA MELAYU

Pengenalan

Tahniah atas pembelian anda, dan selamat datang ke Philips! Untuk mendapat manfaat sepenuhnya daripada sokongan yang ditawarkan oleh Philips, daftarkan produk anda di www.philips.com/welcome.

Perihal umum

- 1 Penutup penolak
- 2 Penolak
- 3 Tiub suapan
- 4 Tudung
- 5 Penuras
- 6 Pengumpul jus dengan muncung (fungsi penghenti titisan)
- 7 Bekas pulpa bersepada
- 8 Aci pemacu
- 9 Lengan pengunci
- 10 Unit motor
- 11 Tombol kawalan
- 12 Petak simpanan kord
- 13 Corong beri (jenis tertentu sahaja)
- 14 Tudung jag jus dengan pemisah busa bersepada
- 15 Jag jus

Penting

Baca maklumat penting ini dengan teliti sebelum anda menggunakan perkakas dan simpan ia untuk rujukan masa depan.

Bahaya

- Jangan sekali-kali tenggelamkan unit motor ke dalam air atau cecair lain atau membilas unit di bawah paip.

Amaran

- Jika kord sesalur rosak, kord mestilah digantikan oleh Philips, ejen servis atau pihak yang berkelayakan yang serupa untuk mengelakkan bahaya.

General description

- 1 Cover of pusher
- 2 Pusher
- 3 Feeding tube
- 4 Lid
- 5 Filter
- 6 Juice collector with spout (drip stop function)
- 7 Integrated pulp container
- 8 Driving shaft
- 9 Locking arm
- 10 Motor unit
- 11 Control knob
- 12 Cord storage compartment
- 13 Berry funnel (spec types only)
- 14 Juice jug lid with integrated foam separator
- 15 Juice jug

Important

Read this important information carefully before you use the appliance and save it for future reference.

Danger

- Never immerse the motor unit in water or any other liquid, nor rinse it under the tap.
- Warning**
 - If the supply cord is damaged, it must be replaced by Philips, its service agent or similarly qualified persons in order to avoid a hazard.
 - Always disconnect the appliance from the mains if you leave it unattended or before you assemble, disassemble or clean it.
 - Do not use the appliance if the sieve or the lid is damaged in any way or shows visible cracks and contact the nearest Philips service center.
 - This appliance is intended for normal household use only. It is not intended for use in environments such as staff kitchens of shops, offices, farms or other work environments. Nor is it intended to be used by clients in hotels, motels, bed and breakfasts and other residential environments.
 - This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
 - Children should be supervised not to play with the appliance.
 - Do not use the appliance if the plug, the mains cord or other components are damaged.
 - Never reach into the feeding tube with your fingers or an object while the appliance is operating. Only use the pusher for this purpose. Do not insert other items than fruits, vegetables or the pusher into the feeding tube.
 - Do not touch the small cutting blades in the base of the sieve. They are very sharp.
 - Always place and use the appliance on a dry, stable and level surface.
 - To ensure that the appliance stands stably, keep the surface on which the appliance stands and the bottom of the appliance clean.
 - Do not eat the pulp or use for preparing dishes.
 - Check if the voltage indicated on the base of the appliance corresponds to the local mains voltage before you connect the appliance.
 - Never let the appliance operate unattended.

Caution

- Before you disassemble the appliance and before you clean it, set the control knob to off position and remove the plug from the wall socket. Then lower the locking arm to unlocked position.
- Only lower the locking arm to unlocked position after you have switched off the appliance and the sieve has stopped rotating.
- Always unplug the appliance after use.
- Do not hold the appliance by the locking arm when you carry it.
- Always unwind the power cord completely from the cord storage area before use.
- Never use any accessories or parts from other manufacturers or that Philips does not specifically recommend. If you use such accessories or parts, your guarantee becomes invalid.
- Make sure all parts are correctly assembled before you switch on the appliance.
- Only use the appliance when the locking arm is in locked position.

Electromagnetic fields (EMF)

This Philips appliance complies with all applicable standards and regulations regarding exposure to electromagnetic fields.

Drip Stop

After you have processed all ingredients and the juice flow has stopped, turn the spout clockwise by about 120° to activate the drip stop function.

Ordering accessories

To buy accessories or spare parts, visit www.shop.philips.com/service or go to your Philips dealer. You can also contact the Philips Consumer Care Centre in your country (see the worldwide guarantee leaflet for contact details).

Recycling

- Do not throw away the product with the normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you help to preserve the environment.
- Follow your country's rules for the separate collection of electrical and electronic products. Correct disposal helps prevent negative consequences for the environment and human health.

Guarantee and support

If you need information or support, please visit www.philips.com/support or read the separate worldwide guarantee leaflet.

- Tanggalkan perkakas daripada bekalan kuasa jika perkakas dibiarkan tanpa pengawasan dan sebelum memasang, menanggalkan bahagian atau membership perkakas.

- Jangan gunakan perkakas jika penyaring atau tudung rosak atau kelihan retak. Hubungi pusat servis Philips yang berdekatkan.

- Perkakas ini dimaksudkan untuk penggunaan biasa di rumah sajahan. Perkakas tidak dimaksudkan untuk digunakan dalam persekitaran seperti dapur kakitangan di kedai, pejabat, ladang atau persekitaran kerja yang lain. Perkakas juga tidak dimaksudkan untuk digunakan oleh klien di hotel, motel, inap sarapan dan persekitaran kediangan lain.

- Perkakas ini tidak dimaksudkan untuk digunakan oleh orang (termasuk kanak-kanak) yang kurang upaya dari segi fizikal, deria atau mental atau kurang berpengalaman dan pengetahuan, melainkan mereka telah diberikan pengawasan atau arahan berkenaan penggunaan perkakas ini oleh orang yang bertanggungjawab atas keselamatan mereka.

- Kanak-kanak perlu diawasi agar mereka tidak bermain dengan perkakas ini.

- Jangan gunakan perkakas jika palam, kord utama atau komponen lain sinduh rosak.

- Jangan sekali-kali masukkan jari anda atau objek lain ke dalam lubang suapan untuk mengambil perkakas sedang berjalan. Hanya gunakan penolak untuk tujuan ini. Jangan masukkan item selain buah-buahan, sayuran atau penolak ke dalam lubang suapan.

- Jangan sentuh pisau pemotong kecil pada tapak penyaring. Pisau sangat tajam.

- Letakkan dan gunakan perkakas pada permukaan yang kering, stabil dan rata.

- Untuk memastikan kedudukan perkakas stabil, pastikan tempat perkakas diletakkan dan bahagian bawah perkakas bers