



PHILIPS

PHILIPS

VisaPure

ADVANCED

REVITALISING
MASSAGE



www.philips.com

>75% recycled paper

4222.100.5486.1 (11/15)

Introduction

The Revitalising Massage head is designed together with experts in Japanese massage. The customised DualMotion program gently stimulates the skin to encourage the blood flow and relax the muscles. By encouraging the blood flow, more oxygen and nutrients are available in the skin, making your skin look radiant, revitalised and giving it a healthy glow!

Note: Please read all instructions for VisaPure Advanced before using the Revitalising Massage head.

Important

Caution

- The Revitalising Massage head is intended to massage the cheeks.
- Do not use the Revitalised Massage head if it is damaged or broken to avoid injuries.
- Do not put the Revitalised Massage head in the dishwasher.

Revitalising Massage

- The Revitalising Massage head is suitable for all skin types. We advise you to use it 2-3 times a week. Before you massage the skin, we advise you to first cleanse your face with VisaPure Advanced.

The 3 minutes Revitalising massage program

- It consists of 2 treatment periods of 1 1/2 minute. The Revitalising Massage head is intended to treat the right and left cheek. The cheek zones include the chin, the area between the nose and upper lip and the areas between the eyes and ears.

Note: Each treatment period has a specific rotation direction optimised for the skin zone treated.

- Do not use the Revitalising Massage head on the sensitive area around the eyes.

Using the Revitalising Massage head

- You can use the Revitalising Massage head on dry skin or after applying cream or oil to your skin.
- 1 Push the Revitalising Massage head onto the connection pin until it locks into position with a click (Fig. 1).
 - 2 Press the on/off button to switch on the appliance and choose your preferred setting.
- Note: When you attach a different head the appliance recognises it. You hear a beep and the intensity setting indications flash alternately (Fig. 2).
- 3 Place the Revitalising Massage head on your right cheek. Gently move the head across your skin, from the nose towards the ear and repeat this movement (Fig. 3).
 - Do not push the head too hard onto the skin to make sure the treatment remains comfortable
 - 4 After 1 1/2 minute, the appliance pauses briefly to let you know that you have to move it to the other cheek (Fig. 4).
- 5 When the program is finished, clean the Revitalising Massage head with water and mild soap.

Revitalising Massage Head replacement

We advise you to replace the Revitalising Massage Head after 1 year, or earlier if it is damaged. Replacement heads are available from www.shop.philips.com or from the shop where you purchased your Philips VisaPure Advanced.

Úvod

Nástavec Osviežujúca masáž je navrhnutý v spolupráci s odborníkmi na japonskú masáž. Prispôsobený program DualMotion jemne stimuluje pokožku, čím podporuje prietok krvi a uvoľňuje svaly. Podporou krvného prietoku sa do pokožky môže dostať viac kyslíka a výživných látok, vďaka čomu vyzerá pokožka rozžiarene, sviežo a zdravo!

Poznámka: Pred použitím nástavca Osviežujúca masáž si prečítajte všetky pokyny pre kefku VisaPure Advanced.

Dôležité

Výstraha

Nástavec Osviežujúca masáž je určený na masáž líci.

- Nástavec Osviežujúca masáž nepoužívajte, ak je poškodený alebo zlomený, aby nedošlo k poraneniam.

Nástavec Osviežujúca masáž nevkladajte do umývačky riadu.

Osviežujúca masáž

Nástavec Osviežujúca masáž je vhodný pre všetky typy pokožky.

Odporúčame vám, aby ste ho používali 2- až 3-krát do týždňa. Pred masážou pokožky vám odporúčame si najskôr vyčistiť tvár pomocou kefky VisaPure Advanced.

3-minútový program Osviežujúca masáž

Skladá sa z dvoch fáz ošetroania po 1 a 1/2 minúte. Nástavec Osviežujúca masáž je určený na ošetroenie pravého a ľavého líca. Do zón líci patrí brada, oblasť medzi nosom a hornou perou a oblasti medzi očami a ušami.

Poznámka: Každá fáza ošetronia má špecifický smer otáčania optimalizovaný pre ošetrovanú zónu pokožky.

Nástavec Osviežujúca masáž nepoužívajte na citlivú pokožku okolo očí.

- Používanie nástavca Osviežujúca masáž

Nástavec Osviežujúca masáž používajte na suchej pokožke alebo po aplikovaní krému alebo oleja na pokožku.

- 1 Nástavec Osviežujúca masáž zatlačte na prípojný kolík, až kým sa s cvaknutím (Obr. 1) nezostane v správnej polohe.

- 2 Stlačením vypínača zapnite zariadenie a vyberte si uprednostňované nastavenie.

Poznámka: Keď pripojíte iný nástavec, zariadenie ho rozpozná. Budete počuť pípnutie a indikátory nastavenia intenzity budú striedavo (Obr. 2) blikať.

- 3 Nástavec Osviežujúca masáž si priložte na pravé líce. Nástavcom jemne pohybujte po pokožke od nosa k uchu a tento pohyb (Obr. 3) opakujte.

Nezatláčajte nástavec na pokožku veľmi silno, aby bolo ošetroenie príjemné.

- 4 Po 1 a 1/2 minúte zariadenie na chvíľu zastane, čím signalizuje, že ho máte presunúť na druhé líce (Obr. 4).

- 5 Po dokončení programu vyčistite nástavec Osviežujúca masáž vodou a jemným mydlom.

Výmena nástavca Osviežujúca masáž

Nástavec Osviežujúca masáž odporúčame vymeniť po jednom roku, prípadne skôr, ak je poškodený. Náhradné nástavce sú k dispozícii na našej webovej lokalite www.shop.philips.com alebo v predajni, v ktorej ste zakúpili kefkú VisaPure Advanced od spoločnosti Philips.