



Quick start
Mise en service rapide
Inicio rápido
Schnellstart
Snelstart
Avvivo rápido



Thanks for buying **Philips AJ3540 clock radio**.
Our **Quick Start** guides you through just some of the features on the set. Please read our instruction booklet to really rise & shine!



ENGLISH

Quick start as easy as ABC!

Step A

Power and switch on the radio

1. Remove the battery door to insert a **9 volts 6F22** type battery (not included) for clock memory backup.
2. Plug to the wall outlet.
3. Adjust **OFF/ON/AUTO/BUZZ** to **ON** to switch on the radio.

Step B

Setting the Clock & Alarm times

1. Hold down **SET TIME/ALARM OFF** or **SET ALARM 1** or **SET ALARM 2**.
2. Use **TIME SET ▲** or **▼** to adjust minute and/or hour.
3. Release **SET TIME/ALARM OFF**, or **SET ALARM 1** or **SET ALARM 2**, and **TIME SET ▲** or **▼** when you reach the correct setting.
4. Repeat steps 1-3 for each of the clock or alarm settings.

Step C

Setting the Alarm mode

1. Adjust **AL1/AL2/AL1+2** to **AL1** (alarm 1), or **AL2** (alarm 2), or **AL1+2** (alarm 1+ alarm 2).
2. Select your choice of alarm mode by adjusting **OFF/ON/AUTO/BUZZ** to **AUTO** or **BUZZ**.

3 ways to switch off the alarm

Either press:

- **SET TIME/ALARM SET**
- **REPEAT ALARM**
- Or adjust **OFF/ON/AUTO/BUZZ** to **OFF**.

Special feature: SLEEP

This set has a built-in timer, which enables the set to be automatically switched off during radio playback after a set period of time.

1. Set **OFF/ON/AUTO/BUZZ** switch to **OFF** position.
2. Set your sleep time by pressing on the **SLEEP** button. Keep your finger on the button and the display will begin to count down from 0:59 to 0:00 minute.
→ To cancel sleep, press **SET TIME/ALARM OFF**.

FRANÇAIS

Mise en Service Rapide c'est simple comme bonjour!

Etape A

Alimentation et activer la radio

1. Retirez le couvercle de logement de la pile afin d'y introduire une pile de type **9 volt 6F22G** (non-incluse) pour mémoire de secours de l'horloge.
2. Branchez sur le secteur.
3. Ajustez l'interrupteur **OFF/ON/AUTO/BUZZ** à **ON** pour mettre en marche le radio.

Etape B

Réglage de l'horloge et de l'alarme.

1. Maintenez enfoncée la touche **SET TIME/ALARM OFF**, ou **SET ALARM 1** ou **SET ALARM 2**.
2. Utilisez les touches **TIME SET ▲** ou **▼** pour ajuster les minutes et/ou les heures.
3. Relâchez les touches **SET TIME/ALARM OFF**, ou **SET ALARM 1** ou **SET ALARM 2**, et **TIME SET ▲** ou **▼** lorsque vous atteindrez le réglage désiré.
4. Répétez les instructions 1 - 3 pour chaque réglage de l'horloge ou de l'alarme.

Etape C

Pour sélectionner le mode de l'alarme

1. Réglez **AL1/AL2/AL1+2** sur **AL1** (alarme 1) ou **AL2** (alarme 2), ou encore sur **AL1+2** (alarme 1 + alarme 2)
2. Sélectionnez le mode d'alarme en réglant le commutateur **OFF/ON/AUTO/BUZZ** sur **AUTO** ou **BUZZ**.

3 façons d'éteindre

Appuyez rapidement sur l'un des touches:

- **SET TIME/ALARM SET**
- **REPEAT ALARM**
- Mettez **OFF/ON/AUTO/BUZZ** en position **OFF**.

Caractéristique Spécial: mise en veille (SLEEP)

Cet appareil est équipé d'une minuterie intégrée qui permet d'arrêter l'appareil automatiquement en mode radio au bout d'une période donnée pré-réglée.

1. Réglez le commutateur **OFF/ON/AUTO/BUZZ** sur **OFF**.
2. Réglez le délai avant l'arrêt programmé à l'aide de la touche **SLEEP**. Maintenez la touche enfoncée pour que l'afficheur commence à décompter de 0:59 minutes à 0:00 minute.
→ Pour annuler l'arrêt programmé, appuyez sur **SET TIME/ALARM OFF**.