


Supplied Accessories: 1 x headphones HE250 1 x remote control, AY3162 1 x AA battery, etc.



Printed in China Ym-kb-0546

1 Push the open button to slide on the CD lid. 2 Insert a disc, printed side up, by pressing gently on the disc's center so that it fits onto the hub.

2 SELECTING DIFFERENT PLAY OPTIONS - MODE (remote control only) You can select and change the various play modes before or during playback.

1 OPEN 2 Press FM to switch the radio on. 3 Press PROG to activate programming. 4 LOCK/UNLOCK 5 PLAY 6 VOLUME +/-

1 45V DC jack for AC/DC adapter power supply 2 ESP selects between the battery power-save mode and Electronic Skip Protection (ESP).

POWER SUPPLY Batteries (supplied or optionally available) You can use the following batteries with this CD-player: alkaline batteries type AA (LR6, UM6) or AAA (LR03, UM4).

PLAYING A CD 1 Push the open button to slide on the CD lid. 2 Insert a disc, printed side up, by pressing gently on the disc's center so that it fits onto the hub.

2 SELECTING DIFFERENT PLAY OPTIONS - MODE (remote control only) You can select and change the various play modes before or during playback.

Switching radio on/off Press FM to switch the radio on. Display shows FRD10 icon briefly followed by frequency and preset number.

Remote control AY3803 (see figure 2) 1 VOL +/- adjusts the volume 2 MODE selects playback options.

POWER SUPPLY Average playing time of batteries under normal conditions Battery type Audio CD Power Save MP3-CD

PLAYING A CD 7 Press again to stop the CD player. 8 Remove the disc, hold it by its edge and press the hub gently while tilting the disc.

DISPLAY INFORMATION (WMA/MP3 tracks only) On the remote control, press and hold MODE 3 seconds to activate the display option mode.

3 Press PROG again to confirm. 4 Repeat steps: the preset number and frequency of the preset station.

Using the remote control The remote control allows you to command all the functions on the player.

POWER SUPPLY Average playing time of batteries under normal conditions Battery type Audio CD Power Save MP3-CD

SELECTING A TRACK/ALBUM AND SEARCHING Selecting and searching on all discs Selecting a track 1 Press << or >> once or several times to skip to the previous or subsequent track.

ESP / POWERSAVING MODE With a conventional portable CD-player you might have experienced that the music stopped a moment when you were jogging.

WARNING: Under no circumstances should you try to repair the unit yourself as this will invalidate the warranty.

Do not touch the lens (A) of the CD player. Do not expose the unit, batteries or CDs to humidity, rain, sand or excessive heat.

ENVIRONMENTAL INFORMATION All redundant packing material has been omitted. We have done our utmost to make the packaging easily separable into two materials: cardboard (box) and polyethylene (bags, protective foam sheet).

PROGRAMMING TRACK NUMBERS (remote control only) You can select up to 50 tracks and store them in the memory in a desired sequence.

RESUME & HOLD (main set only, audio CD only) RESUME - continuing from where you have stopped You can store the last position played.

The CD skips tracks The CD is damaged or dirty. Replace or clean the CD. SHUFFLE/PROG active: Switch off whichever is on.

Accessoires fournis : 1 x écouteurs HE250 1 x télécommande AY3803 1 x clapet de compartiment piles AA

ALIMENTATION ELECTRIQUE Piles (fournies ou disponibles en option) Avec ce lecteur, vous pouvez utiliser des piles alcalines du type AA (LR6, UM6) ou AAA (LR03, UM4).

LECTURE D'UN DISQUE 1 Appuyez sur le bouton-gâchette pour ouvrir le couvercle du CD. 2 Introduisez un disque, face imprimée vers le haut, en appuyant doucement sur le milieu du disque afin de le faire entrer dans le lecteur.

SELECTION DE DIFFERENTES POSSIBILITES DE LECTURE (seulement pour les pistes MP3/WMA) Sur la télécommande, appuyez sur MODE de façon répétée pour sélectionner un mode de lecture.

Appuyez de nouveau sur PROG pour confirmer. Affichage: indique le numéro de préréglage, la bande de fréquence et la fréquence.

Télécommande AY3803 (voir figure 2) 1 prise casque 3,5 mm 2 VOL +/- règle le volume 3 MODE sélectionne les différentes possibilités de lecture.

ALIMENTATION ELECTRIQUE Durée moyenne d'utilisation des piles dans des conditions normales Type de piles Économie d'énergie

LECTURE D'UN DISQUE 7 Appuyez une nouvelle fois sur pour étirer l'appareil. 8 Pour enlever le disque, tirez-le par ses bords et appuyez doucement sur l'axe tout en soulevant le disque.

INFORMATIONS A AFFICHAGE (seulement pour les pistes MP3/WMA) Sur la télécommande, appuyez et maintenez sur MODE pendant 3 secondes.

3 Appuyez de nouveau sur PROG pour confirmer. Affichage: indique le numéro de préréglage, la bande de fréquence et la fréquence.

Utilisation de la télécommande La télécommande vous permet de commander toutes les fonctions du lecteur.

ALIMENTATION ELECTRIQUE Durée moyenne d'utilisation des piles dans des conditions normales Type de piles Économie d'énergie

LECTURE D'UN DISQUE 7 Appuyez une nouvelle fois sur pour étirer l'appareil. 8 Pour enlever le disque, tirez-le par ses bords et appuyez doucement sur l'axe tout en soulevant le disque.

ESP / MODÉ D'ÉCONOMIE D'ÉNERGIE Les lecteurs de CD portables classiques sautent souvent des parties du CD quand ils sont sautés, à cause de vibrations.

AVERTISSEMENT : N'essayez en aucun cas de réparer l'appareil vous-même, sous peine d'invalider la garantie.

Ne touchez jamais la lentille (A) du lecteur de CD. N'équipez jamais l'appareil, les piles ou le CD à l'humidité, à la pluie ou à une chaleur excessive.

INFORMATIONS RELATIVES A L'ENVIRONNEMENT Informations relatives à l'environnement Les matériaux d'emballage superflus ont été supprimés.

A PROPOS DE MP3/WMA La technologie de compression musicale MP3 (MPEG Audio Layer 3) et le logiciel Windows Media Audio (réduit les données digitales d'un CD audio de façon significative tout en gardant un son similaire à celui du CD original).

RESUME - reprend à l'endroit où vous avez arrêté Le CD est endommagé ou contaminé. Remplacez ou nettoyez le CD. SHUFFLE/PROG active: Switch off whichever is on.

Le CD saute des plages Le CD est endommagé ou contaminé. Remplacez ou nettoyez le CD. SHUFFLE/PROG active: Switch off whichever is on.