

Portable DVD Player

Use manual
Manuel d'utilisation
Manual de usuario

Need Help? Call us!
Philips requires you to read to help you use your equipment safely. For more information, call us at 1-888-PHILIPS before you consider returning the product to us.
1-888-PHILIPS (744-5177)
or visit us on the web at www.1-888-phillips.com

About DVD

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer or sold with the apparatus. When a cart is used, use caution when moving the cart/appliances combination to avoid injury from tip-over.

PHILIPS

PHILIPS CONSUMER ELECTRONICS COMPANY
Marietta, GA 30006-0026
Meet Philips at the Internet
<http://www.usa.support.philips.com>
or call
1-888-PHILIPS (744-5177)

CLASS 1 LASER PRODUCT

Be responsible. Respect copyrights.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.
©2006 Koninklijke Philips Electronics N.V. All rights reserved.

Printed in China WKS293

AC Polarized Plug

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer or sold with the apparatus. When a cart is used, use caution when moving the cart/appliances combination to avoid injury from tip-over.

PHILIPS

PHILIPS CONSUMER ELECTRONICS COMPANY
Marietta, GA 30006-0026
Meet Philips at the Internet
<http://www.usa.support.philips.com>
or call
1-888-PHILIPS (744-5177)

CLASS 1 LASER PRODUCT

Be responsible. Respect copyrights.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.
©2006 Koninklijke Philips Electronics N.V. All rights reserved.

Printed in China WKS293

Canada

English

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus as set out in the Radio Interference Regulations of the Canadian Department of Communications.

Français

Cet appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de Classe B prescrites dans le Règlement sur le Brouillage Radioélectrique édicté par le Ministère des Communications du Canada.

1. Lea estas instrucciones.
2. Conserve estas instrucciones.
3. Lea todos los avisos.
4. Sigá todas las instrucciones.
5. No utilice este aparato cerca del agua.
6. Para limpiar el aparato utilice sólo un trapo seco.
7. No tape las aperturas de ventilación. Proceda a su instalación de acuerdo con las instrucciones del fabricante.
8. No instale el equipo cerca de fuentes de calor. Como radiadores, calentadores, estufas o cualquier otro aparato (incluyendo los amplificadores) generador de calor.
9. No anule la seguridad de la clavija de corriente (ya sea de tipo polarizado o con toma de tierra). Las clavijas polarizadas tienen dos patillas, una más ancha que la otra. Las que disponen de toma de tierra tienen dos patillas y una tercera que es de conexión a tierra. Tanto la patilla más ancha como la toma de tierra han sido incorporadas a la clavija para su seguridad personal. Si la clavija sustramada con el equipo no es compatible con su toma de corriente, consulte a un electricista para sustituir la toma de corriente obsoleta.
10. Proteja debidamente el cable interconexión que pueda pisarse o incluso perforarse, especialmente en la parte más próxima a la clavija y en el punto de salida del equipo.
11. Utilice exclusivamente aquellos dispositivos/accesorios recomendados por el fabricante.

12. Coloque el equipo exclusivamente sobre aquellos carros, bases, trípodes, soportes o mesas especificados por el comerciante o vendidos con el equipo. Cuando utilice un carro, tenga cuidado al desplazar el conjunto carro/equipo para evitar posibles daños por vuelco.
13. Desenchufe el aparato durante tormentas eléctricas o cuando no vaya a ser utilizado durante un largo tiempo.
14. Confíe el mantenimiento y las reparaciones a personal técnico especializado. El equipo deberá repararse siempre que haya resultado dañado de alguna manera, como por ejemplo por daños en el cable o en la clavija, por derame de líquido sobre el equipo, por objetos que hubieran podido introducirse en su interior, por exposición del equipo a la lluvia o a ambientes húmedos, cuando el equipo no funciona con normalidad o cuando hubiera sufrido algún tipo de caída.
15. Uso de las pilas - ADVERTENCIA: Para prevenir lesiones o daños a terceros ocasionar lesiones físicas, daños a su propiedad o dañar la unidad.
• Instale todas las pilas correctamente, + y - como está marcado en la unidad.
• No mezcle las pilas (vías con nuevas o de carbono y alcalinas, etc.).
• Extraiga las pilas cuando no vaya a usar la unidad durante largo tiempo.
16. El aparato no debe exponerse a goteros ni salpicaduras.
17. No coloque nada que pueda ser peligroso sobre el aparato (por ejemplo, objetos llenos de líquido, velas encendidas).
18. Ese producto puede contener el plomo y mercurio. La eliminación de este material puede estar regulada debido a consideraciones medioambientales. Para obtener información sobre la eliminación o reciclaje de material, póngase en contacto con las autoridades locales (o con la Electronic Industries Alliance : [www. eia.org](http://www.eia.org)).

PHILIPS

PHILIPS CONSUMER ELECTRONICS COMPANY
Marietta, GA 30006-0026
Meet Philips at the Internet
<http://www.usa.support.philips.com>
or call
1-888-PHILIPS (744-5177)

CLASS 1 LASER PRODUCT

Be responsible. Respect copyrights.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.
©2006 Koninklijke Philips Electronics N.V. All rights reserved.

Printed in China WKS293

The set complies with the FCC-Rules, Part 15 and with 21 CFR 104.10. Operation is subject to the following two conditions:
1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Dispositif conforme aux normes FCC, Partie 15 et 21 CFR 104.10. Fonctionnement soumis aux deux conditions suivantes:
1. Cet appareil ne doit pas provoquer d'interférences nuisibles, et
2. Cet appareil doit accepter toute interférence reçue, y compris les interférences susceptibles de provoquer un fonctionnement peu satisfaisant.

El aparato cumple las normas FCC, Parte 15 y 21 CFR 104.10. Funcionamiento sujeto a las siguientes condiciones:
1. Este aparato debe evitar cualquier interferencia perjudicial, incluyendo las interferencias que pueden provocar un funcionamiento insatisfactorio.

Dispositif conforme aux normes CE, Partie 15 et 21 CFR 104.10. Fonctionnement soumis aux deux conditions suivantes:
1. Cet appareil ne doit pas provoquer d'interférences nuisibles, et
2. Cet appareil doit accepter toute interférence reçue, y compris les interférences susceptibles de provoquer un fonctionnement peu satisfaisant.

El aparato cumple las normas CE, Parte 15 y 21 CFR 104.10. Funcionamiento sujeto a las siguientes condiciones:
1. Este aparato debe evitar cualquier interferencia perjudicial, incluyendo las interferencias que pueden provocar un funcionamiento insatisfactorio.

PHILIPS

PHILIPS CONSUMER ELECTRONICS COMPANY
Marietta, GA 30006-0026
Meet Philips at the Internet
<http://www.usa.support.philips.com>
or call
1-888-PHILIPS (744-5177)

CLASS 1 LASER PRODUCT

Be responsible. Respect copyrights.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.
©2006 Koninklijke Philips Electronics N.V. All rights reserved.

Printed in China WKS293

DISPOSAL OF YOUR OLD PRODUCT

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.

When this crossed-out wheeled bin symbol is attached to a product it means the product is covered by the European Directive 2002/96/EC on Waste Electrical and Electronic Equipment (WEEE). Please inform yourself about the local separate collection system for electrical and electronic products.

Please act according to your local rules and do not dispose of your old products with your household waste. Please contact your local authorities for more information.

Slowly increase the sound until you can hear it comfortably and clearly, without disturbing your neighbours.

Hearing Safety

Listen at a moderate volume:

- Using headphones at a high volume can impair your hearing. This product can produce sound in decibel ranges that may cause hearing loss for a normal person, even for exposures less than a minute. The higher decibel ranges are offered for those that may have already experienced some hearing loss.
- Sound can be distressing. Over time your hearing "comfort level" adapts to the volume of sound. After prolonged listening, what sounds "normal" can actually be loud and harmful to your hearing. To guard against this, set your volume control to a level that you can hear comfortably and clearly without disturbing your neighbours.
- To establish a safe volume level:
 - Set your volume control to a low setting.
 - Slowly increase the sound until you can hear it comfortably and clearly, without disturbing your neighbours.
 - Prolonged exposure to sound, even at normally "safe" levels, can also cause damage to your hearing.
 - Be sure to use your equipment reasonably and take appropriate breaks.
 - Be aware to observe the following volume and hearing safety warnings:
 - Listen responsibly to the audio reproduction of music.
 - Be careful not to adjust the volume as you are using adapters.
 - Do not turn up the volume so high that you can't hear what's around you.
 - You should use caution or temporarily discontinue use in potentially hazardous situations.
 - Do not use headphones or temporarily a motorized vehicle, cycling, skateboarding, etc.; it may create a traffic hazard and is illegal in many areas.

INFORMATION SUR LE DROIT D'AUTEUR

Tous les copies d'une œuvre protégée par un droit d'auteur, ou incluant les programmes informatiques, les enregistrements d'images de son, peut être une contrefaçon d'un droit d'auteur et constituer un délit. Cet appareil ne doit pas être utilisé à cet effet.

Microsoft et les logos Windows sont des marques, déposées ou non, de Microsoft Corporation aux États-Unis et/ou dans d'autres pays.

MISE AU REBUT DE VOTRE ANCIEN PRODUIT

Votre produit est conçu et fabriqué à l'aide de matériaux et composants de haute qualité, recyclables et réutilisables.

Quand ce symbole de poubelle barrée sur un produit indique que ce dernier est couvert par la directive européenne 2002/96/CE. Veuillez vous renseigner sur les systèmes locaux de collecte des produits électroniques aux normes CE.

Agissez conformément à vos règles locales et ne jetez pas vos vieux produits avec vos déchets ménagers. Veuillez contacter les autorités locales pour plus d'informations.

DESECHO DEL PRODUCTO ANTIGUO

El producto se ha diseñado y fabricado con materiales y componentes de alta calidad, que se pueden reciclar y volver a utilizar.

Cuando este símbolo de contenedor de ruedas tachado se muestra en un producto indica que éste cumple la directiva europea 2002/96/CE. Consulte información sobre la recogida selectiva local de productos electrónicos y electrónicos.

Cumpla con la normativa local y no deseches los productos antiguos con los desechos domésticos. El desecho correcto del producto antiguo evitará o reducirá las consecuencias negativas para el medioambiente y la salud humana.

PHILIPS

PHILIPS CONSUMER ELECTRONICS COMPANY
Marietta, GA 30006-0026
Meet Philips at the Internet
<http://www.usa.support.philips.com>
or call
1-888-PHILIPS (744-5177)

CLASS 1 LASER PRODUCT

Be responsible. Respect copyrights.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.
©2006 Koninklijke Philips Electronics N.V. All rights reserved.

Printed in China WKS293

IMPORTANT SAFETY INSTRUCTIONS

- Read these instructions.
- Keep these instructions.
- Heed all warnings.
- Follow all instructions.
- Do not use this apparatus near water.
- Clean only with dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer or sold with the apparatus. When a cart is used, use caution when moving the cart/appliances combination to avoid injury from tip-over.

PHILIPS

PHILIPS CONSUMER ELECTRONICS COMPANY
Marietta, GA 30006-0026
Meet Philips at the Internet
<http://www.usa.support.philips.com>
or call
1-888-PHILIPS (744-5177)

CLASS 1 LASER PRODUCT

Be responsible. Respect copyrights.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.
©2006 Koninklijke Philips Electronics N.V. All rights reserved.

Printed in China WKS293

IMPORTANT SAFETY INSTRUCTIONS

- Read these instructions.
- Keep these instructions.
- Heed all warnings.
- Follow all instructions.
- Do not use this apparatus near water.
- Clean only with dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer or sold with the apparatus. When a cart is used, use caution when moving the cart/appliances combination to avoid injury from tip-over.

PHILIPS

PHILIPS CONSUMER ELECTRONICS COMPANY
Marietta, GA 30006-0026
Meet Philips at the Internet
<http://www.usa.support.philips.com>
or call
1-888-PHILIPS (744-5177)

CLASS 1 LASER PRODUCT

Be responsible. Respect copyrights.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.
©2006 Koninklijke Philips Electronics N.V. All rights reserved.

Printed in China WKS293

INSTRUCCIONES IMPORTANTES DE SEGURIDAD

- Lea estas instrucciones.
- Conserve estas instrucciones.
- Lea todos los avisos.
- Siga todas las instrucciones.
- No utilice este aparato cerca del agua.
- Para limpiar el aparato utilice sólo un trapo seco.
- No tape las aperturas de ventilación. Proceda a su instalación de acuerdo con las instrucciones del fabricante.
- No instale el equipo cerca de fuentes de calor.
 Como radiadores, calentadores, estufas o cualquier otro aparato (incluyendo los amplificadores) generador de calor.
9. No anule la seguridad de la clavija de corriente (ya sea de tipo polarizado o con toma de tierra). Las clavijas polarizadas tienen dos patillas, una más ancha que la otra. Las que disponen de toma de tierra tienen dos patillas y una tercera que es de conexión a tierra. Tanto la patilla más ancha como la toma de tierra han sido incorporadas a la clavija para su seguridad personal. Si la clavija sustramada con el equipo no es compatible con su toma de corriente, consulte a un electricista para sustituir la toma de corriente obsoleta.
10. Proteja debidamente el cable interconexión que pueda pisarse o incluso perforarse, especialmente en la parte más próxima a la clavija y en el punto de salida del equipo.
11. Utilice exclusivamente aquellos dispositivos/accesorios recomendados por el fabricante.
- Coloque el equipo exclusivamente sobre aquellos carros, bases, trípodes, soportes o mesas especificados por el comerciante o vendidos con el equipo. Cuando utilice un carro, tenga cuidado al desplazar el conjunto carro/equipo para evitar posibles daños por vuelco.
13. Desenchufe el aparato durante tormentas eléctricas o cuando no vaya a ser utilizado durante un largo tiempo.
14. Confíe el mantenimiento y las reparaciones a personal técnico especializado. El equipo deberá repararse siempre que haya resultado dañado de alguna manera, como por ejemplo por daños en el cable o en la clavija, por derame de líquido sobre el equipo, por objetos que hubieran podido introducirse en su interior, por exposición del equipo a la lluvia o a ambientes húmedos, cuando el equipo no funciona con normalidad o cuando hubiera sufrido algún tipo de caída.
15. Uso de las pilas - ADVERTENCIA: Para prevenir lesiones o daños a terceros ocasionar lesiones físicas, daños a su propiedad o dañar la unidad.
• Instale todas las pilas correctamente, + y - como está marcado en la unidad.
• No mezcle las pilas (vías con nuevas o de carbono y alcalinas, etc.).
• Extraiga las pilas cuando no vaya a usar la unidad durante largo tiempo.
16. El aparato no debe exponerse a goteros ni salpicaduras.
17. No coloque nada que pueda ser peligroso sobre el aparato (por ejemplo, objetos llenos de líquido, velas encendidas).
18. Ese producto puede contener el plomo y mercurio. La eliminación de este material puede estar regulada debido a consideraciones medioambientales. Para obtener información sobre la eliminación o reciclaje de material, póngase en contacto con las autoridades locales (o con la Electronic Industries Alliance : [www. eia.org](http://www.eia.org)).

PHILIPS

PHILIPS CONSUMER ELECTRONICS COMPANY
Marietta, GA 30006-0026
Meet Philips at the Internet
<http://www.usa.support.philips.com>
or call
1-888-PHILIPS (744-5177)

CLASS 1 LASER PRODUCT

Be responsible. Respect copyrights.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.
©2006 Koninklijke Philips Electronics N.V. All rights reserved.

Printed in China WKS293

INSTRUCCIONES IMPORTANTES DE SEGURIDAD

- Lea estas instrucciones.
- Conserve estas instrucciones.
- Lea todos los avisos.
- Siga todas las instrucciones.
- No utilice este aparato cerca del agua.
- Para limpiar el aparato utilice sólo un trapo seco.
- No tape las aperturas de ventilación. Proceda a su instalación de acuerdo con las instrucciones del fabricante.
- No instale el equipo cerca de fuentes de calor.
 Como radiadores, calentadores, estufas o cualquier otro aparato (incluyendo los amplificadores) generador de calor.
9. No anule la seguridad de la clavija de corriente (ya sea de tipo polarizado o con toma de tierra). Las clavijas polarizadas tienen dos patillas, una más ancha que la otra. Las que disponen de toma de tierra tienen dos patillas y una tercera que es de conexión a tierra. Tanto la patilla más ancha como la toma de tierra han sido incorporadas a la clavija para su seguridad personal. Si la clavija sustramada con el equipo no es compatible con su toma de corriente, consulte a un electricista para sustituir la toma de corriente obsoleta.
10. Proteja debidamente el cable interconexión que pueda pisarse o incluso perforarse, especialmente en la parte más próxima a la clavija y en el punto de salida del equipo.
11. Utilice exclusivamente aquellos dispositivos/accesorios recomendados por el fabricante.
- Coloque el equipo exclusivamente sobre aquellos carros, bases, trípodes, soportes o mesas especificados por el comerciante o vendidos con el equipo. Cuando utilice un carro, tenga cuidado al desplazar el conjunto carro/equipo para evitar posibles daños por vuelco.
13. Desenchufe el aparato durante tormentas eléctricas o cuando no vaya a ser utilizado durante un largo tiempo.
14. Confíe el mantenimiento y las reparaciones a personal técnico especializado. El equipo deberá repararse siempre que haya resultado dañado de alguna manera, como por ejemplo por daños en el cable o en la clavija, por derame de líquido sobre el equipo, por objetos que hubieran podido introducirse en su interior, por exposición del equipo a la lluvia o a ambientes húmedos, cuando el equipo no funciona con normalidad o cuando hubiera sufrido algún tipo de caída.
15. Uso de las pilas - ADVERTENCIA: Para prevenir lesiones o daños a terceros ocasionar lesiones físicas, daños a su propiedad o dañar la unidad.
• Instale todas las pilas correctamente, + y - como está marcado en la unidad.
• No mezcle las pilas (vías con nuevas o de carbono y alcalinas, etc.).
• Extraiga las pilas cuando no vaya a usar la unidad durante largo tiempo.
16. El aparato no debe exponerse a goteros ni salpicaduras.
17. No coloque nada que pueda ser peligroso sobre el aparato (por ejemplo, objetos llenos de líquido, velas encendidas).
18. Ese producto puede contener el plomo y mercurio. La eliminación de este material puede estar regulada debido a consideraciones medioambientales. Para obtener información sobre la eliminación o reciclaje de material, póngase en contacto con las autoridades locales (o con la Electronic Industries Alliance : [www. eia.org](http://www.eia.org)).

PHILIPS

PHILIPS CONSUMER ELECTRONICS COMPANY
Marietta, GA 30006-0026
Meet Philips at the Internet
<http://www.usa.support.philips.com>
or call
1-888-PHILIPS (744-5177)

CLASS 1 LASER PRODUCT

Be responsible. Respect copyrights.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.
©2006 Koninklijke Philips Electronics N.V. All rights reserved.

Printed in China WKS293

CONSIGNES DE SÉCURITÉ IMPORTANTES

- Lisez ces instructions.
- Conservez ces instructions.
- Respectez les avertissements.
- Suivez toutes les instructions.
- N'utilisez pas cet appareil à proximité d'une source d'eau.
- Nettoyez l'appareil uniquement avec un chiffon sec.
- N'obstruez aucun orifice de ventilation. Installez l'appareil selon les instructions du fabricant.
- N'installez pas l'appareil près d'une source de chaleur comme par exemple des radiateurs, bouches de chaleur, cuisinières, ou autres appareils (même des amplificateurs) dégageant de la chaleur.
- Ne détruisez pas la prise incorporée dans la prise de terre ou prise polarisée fournie. Une prise polarisée est dotée de deux lames dont une plus large que l'autre. Une prise de terre est dotée de deux fiches semblables et une troisième, plus large, qui assure la mise à la terre pour votre sécurité. Si la prise fournie ne convient pas à la prise murale dont vous disposez, consultez un électricien pour remplacer et adapter votre prise murale.
- Protégez le cordon d'alimentation du produit de manière à ce qu'il ne se pinche particulièrement aux endroits des prises mâles et femelles, et au point de raccordement sur l'appareil lui-même.
- Utilisez uniquement des accessoires ou options recommandés par le fabricant.

PHILIPS

PHILIPS CONSUMER ELECTRONICS COMPANY
Marietta, GA 30006-0026
Meet Philips at the Internet
<http://www.usa.support.philips.com>
or call
1-888-PHILIPS (744-5177)

CLASS 1 LASER PRODUCT

Be responsible. Respect copyrights.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.
©2006 Koninklijke Philips Electronics N.V. All rights reserved.

Printed in China WKS293

CONSIGNES DE SÉCURITÉ IMPORTANTES

- Lisez ces instructions.
- Conservez ces instructions.
- Respectez les avertissements.
- Suivez toutes les instructions.
- N'utilisez pas cet appareil à proximité d'une source d'eau.
- Nettoyez l'appareil uniquement avec un chiffon sec.
- N'obstruez aucun orifice de ventilation. Installez l'appareil selon les instructions du fabricant.
- N'installez pas l'appareil près d'une source de chaleur comme par exemple des radiateurs, bouches de chaleur, cuisinières, ou autres appareils (même des amplificateurs) dégageant de la chaleur.
- Ne détruisez pas la prise incorporée dans la prise de terre ou prise polarisée fournie. Une prise polarisée est dotée de deux lames dont une plus large que l'autre. Une prise de terre est dotée de deux fiches semblables et une troisième, plus large, qui assure la mise à la terre pour votre sécurité. Si la prise fournie ne convient pas à la prise murale dont vous disposez, consultez un électricien pour remplacer et adapter votre prise murale.
- Protégez le cordon d'alimentation du produit de manière à ce qu'il ne se pinche particulièrement aux endroits des prises mâles et femelles, et au point de raccordement sur l'appareil lui-même.
- Utilisez uniquement des accessoires ou options recommandés par le fabricant.

PHILIPS

PHILIPS CONSUMER ELECTRONICS COMPANY
Marietta, GA 30006-0026
Meet Philips at the Internet
<http://www.usa.support.philips.com>
or call
1-888-PHILIPS (744-5177)

CLASS 1 LASER PRODUCT

Be responsible. Respect copyrights.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.
©2006 Koninklijke Philips Electronics N.V. All rights reserved.

Printed in China WKS293

CONSIGNES DE SÉCURITÉ IMPORTANTES

- Lisez ces instructions.
- Conservez ces instructions.
- Respectez les avertissements.
- Suivez toutes les instructions.
- N'utilisez pas cet appareil à proximité d'une source d'eau.
- Nettoyez l'appareil uniquement avec un chiffon sec.
- N'obstruez aucun orifice de ventilation. Installez l'appareil selon les instructions du fabricant.
- N'installez pas l'appareil près d'une source de chaleur comme par exemple des radiateurs, bouches de chaleur, cuisinières, ou autres appareils (même des amplificateurs) dégageant de la chaleur.
- Ne détruisez pas la prise incorporée dans la prise de terre ou prise polarisée fournie. Une prise polarisée est dotée de deux lames dont une plus large que l'autre. Une prise de terre est dotée de deux fiches semblables et une troisième, plus large, qui assure la mise à la terre pour votre sécurité. Si la prise fournie ne convient pas à la prise murale dont vous disposez, consultez un électricien pour remplacer et adapter votre prise murale.
- Protégez le cordon d'alimentation du produit de manière à ce qu'il ne se pinche particulièrement aux endroits des prises mâles et femelles, et au point de raccordement sur l'appareil lui-même.
- Utilisez uniquement des accessoires ou options recommandés par le fabricant.

PHILIPS

PHILIPS CONSUMER ELECTRONICS COMPANY
Marietta, GA 30006-0026
Meet Philips at the Internet
<http://www.usa.support.philips.com>
or call
1-888-PHILIPS (744-5177)

CLASS 1 LASER PRODUCT

Be responsible. Respect copyrights.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.
©2006 Koninklijke Philips Electronics N.V. All rights reserved.

Printed in China WKS293

CONSIGNES DE SÉCURITÉ IMPORTANTES

- Lisez ces instructions.
- Conservez ces instructions.
- Respectez les avertissements.
- Suivez toutes les instructions.
- N'utilisez pas cet appareil à proximité d'une source d'eau.
- Nettoyez l'appareil uniquement avec un chiffon sec.
- N'obstruez aucun orifice de ventilation. Installez l'appareil selon les instructions du fabricant.
- N'installez pas l'appareil près d'une source de chaleur comme par exemple des radiateurs, bouches de chaleur, cuisinières, ou autres appareils (même des amplificateurs) dégageant de la chaleur.
- Ne détruisez pas la prise incorporée dans la prise de terre ou prise polarisée fournie. Une prise polarisée est dotée de deux lames dont une plus large que l'autre. Une prise de terre est dotée de deux fiches semblables et une troisième, plus large, qui assure la mise à la terre pour votre sécurité. Si la prise fournie ne convient pas à la prise murale dont vous disposez, consultez un électricien pour remplacer et adapter votre prise murale.
- Protégez le cordon d'alimentation du produit de manière à ce qu'il ne se pinche particulièrement aux endroits des prises mâles et femelles, et au point de raccordement sur l'appareil lui-même.
- Utilisez uniquement des accessoires ou options recommandés par le fabricant.

PHILIPS

PHILIPS CONSUMER ELECTRONICS COMPANY
Marietta, GA 30006-0026
Meet Philips at the Internet
<http://www.usa.support.philips.com>
or call
1-888-PHILIPS (744-5177)

CLASS 1 LASER PRODUCT

Be responsible. Respect copyrights.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.
©2006 Koninklijke Philips Electronics N.V. All rights reserved.

Printed in China WKS293

English FUNCTIONAL OVERVIEW

Main unit controls (see figure 1)

- MENU Display MENU page
- OSD Screen Display on/off
- OK Confirm selection
- II Pause playback
- Start / resume playback
- Press twice to stop playback
- For previous (◀) or next (▶) chapters, tracks or titles
- Search backward (◀) or search forward (▶)
- MONITOR Selection display
 - ▶ To adjust the brightness with ◀ ▶
 - ▶ To adjust the color with ◀ ▶
 - ▶ To adjust the screen of 16:9 or 4:3 with ◀ ▶
- AV IN/OUT - AV OUT (AUX)

Front of player (see figure 1)

- POWER/CHG Power and charging indicator
- IR Remote sensor

English FUNCTIONAL OVERVIEW

Left of player (see figure 1)

- OPEN Open disc door to insert or remove disc
- ON POWER OFF Switch the player on / off

Right of player (see figure 1)

- VOLUME Volume control
- PHONE 1 & 2 Headphones jack
- AV OUT Audio/Video output jack
- AV IN Audio/Video input jack
- COAXIAL Digital audio output jack
- DC IN 5V Power supply socket

Remote controls (see figure 2)

- ▶ ◀ ◂ ◃ ▶ ◂ ◃ ▶ ◂ ◃ ▶ Left / down / left / right cursor
- OK Confirms selection
- VOL / + Volume control
 - ▶ For previous (◀) or next (▶) chapters, tracks or titles
 - ▶ Starts / resumes playback
 - ▶ Press twice to stop playback
 - ▶ Search backward (◀) or search forward (▶)
- OSD On-Screen Display on / off
- Slow motion
- AUDIO Audio language selector
- COAXIAL To repeat or skip a sequence in a title
- PLAY MODE Selects play order options
- 0-9 Numeric keypad
- MUTE Audio language volume
- REPEAT Repeat chapter / title / disc
- RETURN For VCD menu page
- ANGLE Selects DVD camera angle
- SUBTITLE Subtitle language selector
- LANGUAGE Language selector
- MENU Displays MENU page
- SETUP Enters SETUP menu
- Infr. Red port
- BATTERY COMPARTMENT

GENERAL INFORMATION

Power Sources

- This unit operates on a supplied AC adapter, car adapter, or a rechargeable battery pack.
- Make sure that the input voltage of the AC adapter is in line with the local voltage. Otherwise, the AC adapter and unit may be damaged.
- Do not touch the AC adapter with wet hands to prevent electric shock.
- When connecting with car power (cigarette lighter) adapter, be sure the input voltage of the adapter is identical with or close to the voltage of the AC adapter from the outlet or remove the battery pack when the unit is not used for long periods of time.
- Hold the plug to disconnect the AC adapter. Do not pull the power cord.

Safety and maintenance

- Do not disassemble the unit for laser rays are dangerous to eyes.
- Any service should be done by qualified service personnel.
- Unplug the AC adapter from the power if liquid or objects get inside the unit.
- Take care not to drop the unit or subject it to strong shocks, which may cause malfunction.
- Do not expose to excessive heat caused by heating equipment or direct sunlight.
- This product is not waterproof. Do not allow your player to be submerged in water. Water entering the player may cause major damage.
- Do not use any cleaning agents containing alcohol, ammonia, benzene, or abrasives as they may harm the player.
- Apparatus shall not be exposed to dripping or splashing. Do not place any sources of danger on the apparatus (e.g. liquid filled objects/lighted candles)
- Do not touch the lens!

Environmental information

We have reduced the packaging to its minimum and made it easy to separate into materials: cardboard, PS, PE and PET.

Your set consists of material which can be recycled if disassembled by a specialized company. Please observe the local regulations to dispose of packaging, exhausted batteries and old equipment.

Copyright information

"DVD," "CD," "Certified," and associated logos are trademarks of DivX, Inc. and are used under license.

All other brand and product names are trademarks of their respective companies or organizations.

Unauthorized duplication of any recordings downloaded from the internet or made on CDs / VCDs / DVDs is a violation of copyright laws and international treaties.

The making of unauthorized copies of copyrighted material, including computer programs, files, spreadsheets and sound recordings, may be an infringement of copyrights and constitute a criminal offense. This equipment should not be used for such purposes.

GENERAL INFORMATION

Handling discs

- Do not attach paper or tape to the disc.
- Keep the disc away from direct sunlight or heat sources.
- Store the disc in a disc case after playback.
- To clean, wipe the disc outwardly from the center with a soft, lint-free clean cloth.

On handling the LCD screen

The LCD is manufactured using high precision technology. You may, however, see tiny black points that continuously appear on the LCD. This is a normal result of the manufacturing process and does not indicate a malfunction.

Environmental information

We have reduced the packaging to its minimum and made it easy to separate into materials: cardboard, PS, PE and PET.

Your set consists of material which can be recycled if disassembled by a specialized company. Please observe the local regulations to dispose of packaging, exhausted batteries and old equipment.

Copyright information

"DVD," "CD," "Certified," and associated logos are trademarks of DivX, Inc. and are used under license.

All other brand and product names are trademarks of their respective companies or organizations.

Unauthorized duplication of any recordings downloaded from the internet or made on CDs / VCDs / DVDs is a violation of copyright laws and international treaties.

The making of unauthorized copies of copyrighted material, including computer programs, files, spreadsheets and sound recordings, may be an infringement of copyrights and constitute a criminal offense. This equipment should not be used for such purposes.

GENERAL INFORMATION

Preparations

Power supply

Using the AC / DC adapter

Connect the supplied adapter to the set and the main power supply (as shown).

TIP

To avoid damage to the player, switch off before plugging or unplugging the AC adapter.

Using the car adapter

Connect the supplied car adapter to the set and the car cigarette lighter outlet.

TIP

- It is normal for the battery pack to become warm during charging.
- It is shown on the screen when battery power is running low.
- When connecting with car power (cigarette lighter) adapter, be sure the input voltage of the adaptor is identical with car voltage.

Powering your remote control

- Open the battery compartment.
- Remove the protective plastic tab (first time users only).
- Insert 1 lithium 3V battery, type CR2025, then close the compartment.

Batteries contain chemical substances, so they should be disposed of properly.

Incorrect use of batteries can cause electrolyte leakage and will corrode the compartment or cause the batteries to burst.

Remove the batteries if the set is not to be used for a long time.

GENERAL INFORMATION

Preparations

Switching on for OSD language setup

English is the default language of your player on screen display. You may choose to use English, French, Spanish, German, Simplified Chinese or Traditional Chinese for your player on screen display.

Countries OSD Language Options

European	English, French,
----------	------------------

