

Question?
Contact
Philips



Quick start guide **English**
Lynvejledning **Dansk**
Schnellstartanleitung **Deutsch**
Guía de configuración rápida **Español**
Guide de démarrage rapide **Français**
Guida di avvio rapido **Italiano**
Snelstartgids **Nederlands**
Snabbstartguide **Svenska**
Короткий посібник **Українська**

Stručný návod k rychlému použití **Čeština**
Οδηγός γρήγορης έναρξης **Ελληνικά**
Pikaopas **Suomi**
Rövid územbe helyezési útmutató **Magyar**
Skrócona instrukcja obsługi **Polski**
Manual de Inicio Rápido **Português**
Краткое руководство **Русский**
Stručná úvodná príručka **Slovensky**

PHILIPS

Before using your product, read all accompanying safety information.

6X1.5V R14/UM2/C CELL

AC-MAINS

To play with the device, you can use either alkaline battery (R14) or AC power.

CD

MODE
PROG

USB

MODE
PROG

Program tracks

- 1 In CD or USB mode, press ■ to stop playback.
- 2 Press **PROG** to activate program mode.
- 3 For MP3/WMA tracks, press ▲/▼ to select an album.
- 4 Press ◀▶ to select a track number, then press **PROG** to confirm.
- 5 Repeat steps 3-4 to program more tracks.
- 6 Press ▶▶ to play the programmed tracks.
- 7 To cancel the program, press ■ twice.

Specifikace

Jmenovitý výstupní výkon	2 x 1 W RMS
Kmitočtová charakteristika	63-14 000 Hz, -3 dB
Odstup signál/šum	>57 dBA
Celkové harmonické zkreslení	<1 %
Vstup Audio-in	650 mV RMS
Rozsah ladění	FM: 87.5-108 MHz
Impedance reproduktoru	8 ohmů
Napájení	- Elektrická síť 220-240V~, 50/60 Hz
	- Baterie 9V, 6 x 1,5 V, článek R14/UM2/C CELL
Spotřeba elektrické energie při provozu	15 W
Spotřeba energie v pohotovostním režimu	<0,5 W
Rozměry - hlavní jednotka (Š x V x H)	261 x 123 x 245 mm
Hmotnost - hlavní jednotka	1,1 kg

DBB

ON • OFF

FM/USB/CD

Audio-in

OFF

To get the detailed instructions for use, visit www.philips.com/support.

English

Before using your product, read all accompanying safety information.

To play with the device, you can use either alkaline battery (R14) or AC power.

Program tracks

- 1 In CD or USB mode, press ■ to stop playback.
- 2 Press **PROG** to activate program mode.
- 3 For MP3/WMA tracks, press ▲/▼ to select an album.
- 4 Press ◀▶ to select a track number, then press **PROG** to confirm.
- 5 Repeat steps 3-4 to program more tracks.
- 6 Press ▶▶ to play the programmed tracks.
- 7 To cancel the program, press ■ twice.

Specifications

Rated Output Power	2 x 1 W RMS
Frequency Response	63 -14000 Hz, -3 dB
Signal to Noise Ratio	>57 dBA
Total Harmonic Distortion	<1 %
Audio-in Input	650 mV RMS
Tuning Range	FM: 87.5 - 108MHz
Speaker Impedance	8 ohm
Power supply	- AC Power 220 - 240V, 50/60 Hz
	- Battery 9V, 6 x 1,5 V R14/UM2
Operation Power Consumption	15 W
Standby Power Consumption	< 0,5 W
Dimensions - Main Unit (W x H x D)	261 x 123 x 245 mm
Weight - Main Unit	1,1 kg

Dansk

Før du bruger produktet, skal du læse alle medfølgende sikkerhedsoplysninger.

Du kan bruge enten alkaline-batterier (R14) eller vekselstrøm til afspilning med enheden.

Programmering af numre

- I CD- eller USB-tilstand skal du trykke på ■ for at stoppe afspilning.
- Tryk på **PROG** for at aktivere programmeringsstanden.
- MP3/WMA-spor: Tryk på ▲/▼ for at vælge et album.
- Tryk på ◀▶ for at vælge et spornummer, og tryk derefter på **PROG** for at bekræfte.
- Gentag trin 3-4 for at programmere flere numre.
- Tryk på ▶▶ for at afspille de programmerede spor.
- Tryk på ■ to gange for at annullere programmet.

Du kan finde en detaljeret brugervejledning på www.philips.com/support.

Specifikationer

Vurderet effekt	2 x 1 W RMS
Frekvensgang	63 -14000 Hz, -3 dB
Signal/støjforhold	>57 dBA
Samlet harmonisk forvrængning	<1 %
Lydinput	650 mV RMS
Indstillingsområde	FM: 87,5 - 108 MHz
Højttalerimpedans	8 ohm
Strømforsyning	- Vekselstrøm 220 - 240 V, 50/60 Hz
	- Batteri 9 V, 6 x 1,5 V R14/UM2
Strømforbrug ved drift	15 W
Strømforbrug ved standby	< 0,5 W
Mål - Hovedenhed (B x H x D)	261 x 123 x 245 mm
Vægt - Hovedenhed	1,1 kg



