PHILIPS

Speakers

BT64

BT64A
BT64B
BT64R
BT64W

User manual

Register your product and get support at
www.philips.com/welcome

General information

Warnings

- Only use attachments or accessories specified by manufacturer.
- The battery shall not be exposed to excessive heat such as sunshine, fire etc.
- Only for indoor use.

Care and safety information
Avoid high temperatures, moisture, water and dust

- Apparatus should not be exposed to dripping or splashing of liquid.
- Do not place any source of danger on the speaker (e.g.liquid filled objects lighted candles).
- Do not install near heat sources.

Do not block any ventilation opening

- Place the apparatus in a location with adequate ventilation to prevent internal heat build up.
- Allow at least 10cm (4 inches) of free space all around the apparatus for adequate ventilation.

Care of the cabinet

- Use a soft cloth slightly moistened to clean the cabinet.
- Do not use a solution containing alcohol, spirits, ammonia or abrasives to clean the cabinets.

Accessories

Item	3.5mm to stereo cable	User manual	USB cable
Quantity	1	1	1

Top & Back panel

Top panel operation

A. Switch operation

		1 ⏻	2. ▶II☎	3. —	4. +
BT mode.	short press	function	a. play or pause song b. accept or reject an incoming call	Prev Song/Track*	Next Song/Track*
	long press	Power on/off	Disconnect BT connection	Volume decreases	Volume increases, when it reaches higher volume it will make sound
AUX mode.	short press	function			
	long press	Power on/off		Volume decreases	Volume increases, when it reaches higher volume it will make sound
FM mode.	short press	function		Back Stored radio/Track*	Next Stored radio/Track*
	long press	Power on/off	FM channels and save	Volume decreases	Volume increases, when it reaches higher volume it will make sound
TF mode.	short press	function	play or pause song	Prev Song/Track*	Next Song/Track*
	long press	Power on/off		Volume decreases	Volume increases, when it reaches higher volume it will make sound

B. LED

- a. red LED: charging
- b. blue LED: bluetooth mode
- c. green LED: AUX mode.
- d. blue and green LED alternate: FM mode.
- e. light blue LED: mircro SD/ TF card mode.

C. Back panel

- 5. [MICRO USB]socket for charging the unit.
- 6. [AUX] : 3.5mm AUX socket.
- 7. [MICRO SD Card / TF Card]

* In case of laptop BT connection, this will work with windows media player.

Over view of the speaker

1. ⏻ - Power on/off and Source selection.
- Turn the speaker on or off with long press.
- Select source by short pressing Bluetooth/ micro SD card (TF card)/ FM/ Line in (FM/ line in is available only when stereo cable is connected.

2. ▶II☎
- Play/ Pause
- Answer or reject an incoming call
- End the current call
- Disconnect Bluetooth connection
- Search FM channel and save

3. "—"
- Volume decrease -long press
- Previous song/channel-short press

4. "+"
- Volume increase -long press
- Next song/channel-short press
5. DC in- Recharging the built in battery.
6. Line in- Connect an external audio device and for use in FM as antenna.
7. Micro SD card (TF card).

Get started

- Place the speaker on a flat surface.
- Charge the built in battery
  Notes for charging
  a) Before use, fully charge the built in battery.
  b) The micro USB socket is for charging only.
  c) Rechargeable battery has a limited number of charge cycles.
- Battery life and number of charge cycle vary by use & settings.
- Connect the USB cable between DC in socket on the speaker and USB Socket of a computer.

Bluetooth pairing

- To turn on the speaker long press "⏻" -speaker enters in Bluetooth mode blue LED will quickly flash.
- Turn on Bluetooth device like mobile, computer and search the Bluetooth name "PHILIPS BT64"
- Press pair in the device to connect with the speaker , when enter pairing mode it will give out a "Beep" sound while it will give out double "Beep" sound after pairing successfully.
- Blue light will stop flashing. (Normally no need to provide password, if need just put " 0000" as the password.)
- After pairing successfully, the device will connect with speaker automatically next time.
- Long press "▶II☎" for 3 seconds to disconnect current device, speaker enters in pairing mode.

Audio in

Connect a stereo cable (audio input cable) on both ends to
- Audio in socket of speaker
- The headphone socket on the external device
Short press "⏻" to choose FM mode/Audio in mode.Without Audio cable, speaker cannot go into line in mode.

FM

Connect and audio stereo cable (Audio cable) and press" ⏻" speaker will go in FM mode and LED will flash blue & green alternatively.
Long press "▶II☎", speaker will go in search mode & save all FM channels from 87.5 to 108Hz ."-" or "+" with short press will select desired channel.
Without Audio cable, speaker cannot go into FM mode.

Micro SD card (TF card)

When inserting micro SD card (TF card), short press " ⏻" to choose micro SD/ TF card mode,with LED color changing to light blue.
Without micro SD/ TF card, speaker cannot go into micro SD/ TF card mode.

Handfree phone call function

Blue light will flash when there is an incoming call, the speaker will also come out with 'Beep' sound, press button " ▶II☎" to anwer the phone call.
to decrease or increase volume by pressing "-"/ "+", press "▶II☎" to disconnect.

Low power

When it comes to low power, the speaker will come out with "Beep" sound, at the same time volume will be decreased to keep perfect playback, pls charge in time, the speaker will shutdown for no power.
If you are not using the speaker for long time, ensure that it is being fully charged once every month in order to protect the battery.

Warranty

This Philips 2.0 multimedia speakers system is warranted against any defect due to defective materials or workmanship for 12 months from the date of purchase, should a defect develop during the period of warranty, **Gibson Innovations India Private Limited** undertake to repair the apparatus FREE OF CHARGE through the dealer from whom it has been purchased or at any of the Philips Authorised Service Centres.

The warranty is not valid in case :

1. Proof of purchase is not accompanied with nty card.
2. The warranty card is not completed immediately after purchase.
3. The apparatus is not used according to this manual.
4. Defects are caused by improper or reckless use.
5. Any repairs are done by persons other than Philips Authorised service centre.
6. Any modifications or alteration of any nature are made in the apparatus.
7. The serial number is tampered with.
8. Defects due to causes beyond control like lightning, abnormal voltage, acts of God or while in transit to the purchaser's residence.

All consumables and parts susceptible to normal wear and tear are not covered under warranty.

Week/S.No.: _____ Bill No. _____

Date of purchase _____

Dealer's name: _____

Dealers stamp: _____

Customer's name and address: _____

Model No.: _____

Dealer's signature: _____

Gibson Innovations India Private Limited 4th Floor, Block-1, Vatika Business Park, Sector 49, Sohna Road, Gurgaon-122018, Haryana, India

---

Product specifications*

Amplifier

Rated output power	3W RMS
Signal to Noise Ratio	>55dB
Audio input	600mV
Frequency Response	70Hz~20KHz

Speaker

Speaker Impedance	4 ohm
Speaker Driver	1.5 inch/40mm
Sensitivity	80 dBm

Bluetooth

Bluetooth version	V 4.0
Bluetooth profile	V2.1+EDR
Bluetooth freg	2.4GHz~248GHz
Bluetooth range	Upto 10M (freespaee)

General Introduction

Power supply	5V ⎓ 1A
Built in Battery	Li-polymer battery
Dimension main unit (LxWxH)mm	110x32x56mm
Weight	145g

Connectivity	FM,mirco SD (TF-Card), line-in, Bluetooth
Micro SD(TF card)	up to 32GB

*Specification subject to change without prior notice.
Measured under specific conditions.

PHILIPS

Question?
Contact
Philips

Always there to help you
Visit us at www.india.philips.com
Contact at: 1860 180 1111, 1800 102 2929
Or customercare.india@philips.com