Important safety instructions

Know these safety symbols

CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS ARE INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

The caution marking is located on the rear or bottom of the cabinet.

The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the apparatus's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the apparatus.

The symbol for CLASS II (double insulated) electrical apparatus. This apparatus has been designed in such a way that it does not require a safety connection to electrical earth.

WARNING!
To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture and objects filled with liquids, such as vases, should not be placed on objects filled with liquids, such as vases, shall be placed on the apparatus.

CAUTION!
To prevent electric shock, match wide blade of plug to wide slot, fully insert.

PHILIPS *For fastest support visit us online for chat and self service options at www.philips.com/support*

CHILD SAFETY:
PROPER TELEVISION PLACEMENT MATTERS
THE CONSUMER ELECTRONICS INDUSTRY CARES

- Manufacturers, retailers and the rest of the consumer electronics industry are committed to making home entertainment safe and enjoyable.
- All televisions should comply with recognized safety standards—new and old—must be supported on proper stands or installed according to the manufacturer's recommendations. Televisions that are inappropriately placed on unsuitable surfaces, such as dressers, desks, bookcases, shelves, carts, etc., may fall over, resulting in injury.

TUNE IN TO SAFETY

- **ALWAYS** follow the manufacturer's recommendations for the safe placement of your television.
- **ALWAYS** read and follow all instructions for proper use of your television.
- **NEVER** allow children to climb on or play on the television or the furniture on which the television is placed.
- **NEVER** place your television on furniture that can easily be used as steps, such as a chest of drawers.
- **ALWAYS** install the television where it cannot be pushed, pulled over or tipped easily.
- **ALWAYS** route cords and cables connected to the television so that they cannot be tripped over, pulled or grabbed.

WALL OR CEILING MOUNT YOUR TELEVISION

- **ALWAYS** contact your retailer about professional installation if you have any questions about how to mount your television safely.
- **ALWAYS** use a mount that has been recommended by the television manufacturer and has a safety certification by an independent laboratory. (such as UL, CSA, ETL).
- **ALWAYS** follow all instructions supplied by the television and mount manufacturers.
- **ALWAYS** make sure that the wall or ceiling where you are mounting the television is appropriate. Some mounts are not designed to be mounted to walls and ceilings with steel studs or older block construction. If you are unsure, contact a professional installer.
- Televisions can be heavy. A minimum of two people is required for a wall or ceiling mount installation.

MOVING AN OLDER TELEVISION TO A NEW PLACE IN YOUR HOME

- Many new television buyers move their older CRT televisions into a secondary location in the home, such as a bedroom or playroom. Special care should be made in the placement of older CRT televisions.
- **ALWAYS** place your older CRT television on furniture that is sturdy and appropriate for the size of the television.
- **NEVER** place your older CRT television on a dresser where children may be tempted to use the drawers to climb.
- **ALWAYS** make sure your older CRT television does not hang over the edge of your furniture.

Consumer Technology

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments / accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart / apparatus combination to avoid injury from tip-over.
13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Note to the CATV system installer:
This reminder is provided to call the CATV system installer's attention to Article 820 of the NEC. ANSI/NFPA 70 and Section 54 of the CEC, Part I that provide guidelines for proper grounding and, in particular, specify that the Cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as practical.

Example of antenna grounding as per NEC - National Electric Code



If an outside antenna or cable system is connected to the product, be sure the antenna or cable system is grounded so as to provide some protection against voltage surges and built-up static charges. Article 810 of the NEC, ANSI/NFPA 70, provides in Section 810-20 information with respect to proper grounding of the mast and supporting structure, grounding of the lead in wire to an antenna-discharge unit, size of grounding conductors, location of antenna-discharge unit, connection to grounding electrodes, and requirements for the grounding electrode.

Wall mount bracket kit

Brand	Model #	Screw dimension
32PFL6573/F7	SANUS	AST16	M4 x 1.378 " (35 mm)

- Your TV meets the VESA standard for wall mounting. Consult with your local dealer for a wall mount bracket which is compatible with your TV model.
- The recommended wall mount bracket kit (sold separately) allows the mounting of your TV in the wall.
- For detailed information on installing the wall mount, refer to the wall mount bracket guide.
- Funai Corporation is not responsible for any damage to the product or injury to yourself or others if you elect to install the TV wall mount bracket by yourself. Please call 1-833-978-3323.
- The wall mount bracket must be installed to wood.

Funai Corporation is not liable for any accidents or injuries incurred while installing this product, including but not limited to those noted below:

- Install the wall mount bracket on a sturdy vertical wall.
- Any additional accessories or devices the TV and wall mount bracket may be attached to, ceiling or drywall etc.
- Do not use screws that are longer or shorter than their specified length. If screws too long are used this may cause mechanical or electrical damage inside the TV set. If screws too short are used this may cause the TV set to fall.
- Do not fasten the screws by excessive force. This may damage the product or cause the product to fall, leading to an injury.
- There are reasons use 2 people to mount the TV onto a wall mounting bracket.
- Do not mount the TV onto the wall mounting bracket while your TV is plugged in or turned on. It may result in an electrical shock injury.

When installing the unit on the wall, allow this much space.

Top:	11.8 " (30 cm)
Left and right side:	5.9 " (15 cm)
Bottom:	3.9 " (10 cm)

Notice

Trademarks are the property of Koninklijke Philips N.V. or their respective owners. Funai Corporation reserves the right to change products at any time without being obliged to adjust earlier supplies accordingly.
The material in document is believed adequate for the intended use of the system. If the product or its individual modules or procedures are used for purposes other than those specified herein, confirmation of their validity and suitability must be obtained.
Funai Corporation warrants that the material itself does not infringe any United States patents.
No further warranty is expressed or implied.
Funai Corporation cannot be held responsible neither for any errors in document, nor for the consequences of any errors in the material contained in document. Errors reported to Funai Corporation will be adapted and published on the Funai Corporation support website as soon as possible.

Pixel characteristics
This LCD product has a high number of color pixels. Although it has effective pixels of 99.999% or more, black dots or bright points of light (red, green or blue) may appear constantly on the screen. This is a structural property of the display (within common industry standards) and is not a malfunction.

Warranty
Replacements are user serviceable. Do not open or remove covers to the inside of the product. Repairs may only be done by service centers and official repair shops. Failure to do so shall void any warranty, stated or implied. Any operation expressly prohibited in document, any adjustments or assembly procedures not recommended or authorized in document shall void the warranty.

Federal communications commission notice
This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules.
These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio or television technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Declaration of conformity:
Trade name: Funai Corporation, Inc.
Responsible party: Funai Corporation, Inc.
Model: 32PFL6573/F7
Address: 13485 Jamboree Road, Santa Fe Springs, CA 90670, USA
Telephone number: 1 833 978 3323

Modifications
The apparatus must not generate or use radio frequency energy. Changes or modifications to this apparatus may cause harmful interference.
Any changes or modifications not expressly approved by Funai Corporation.
The user could lose the authority to operate this apparatus if an unauthorized change or modification is made.

Cables
Connections to this device must be made with shielded cables with metallic RFI/EMI connector hoods to maintain compliance with FCC rules and regulations.

Canadian notice
LAN-CSS-3(B)-160608-3(B)
Analog and digital television receiving apparatus, Canada BETS-7-NTMR-3.

The following FCC/IC statements applies to the wireless LAN adapter included in this product.
FCC caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.
This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

FCC/IC RF Exposure Compliance
This equipment complies with FCC/IC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines and RSS-102 of the IC radio frequency (RF) Exposure rules. This equipment should be installed and operated keeping the radiator at least 20 cm or more away from your body.
This device complies with Part 15 of FCC Rules and Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of this device.

5150-5250 MHz band is restricted to indoor operations only.
High-power radars are allocated as primary users (i.e.priority users) of the bands 5250-5350 MHz and 5650-5850 MHz and that these radars could cause interference and/or damage to LE-LAN devices.

Compliance with FCC requirement 15.407(c) and IC requirement RSS-210 A9.4(4)
Data transmission is always initiated by software, which is the passed down through the MAC, through the digital and analog baseband, and finally to the RF chip. Several special packets are initiated by the MAC. These are the only ways the digital baseband portion will turn on the RF transmitter, which it will then turn off after the packets have been sent. i.e. the system cannot send RF on only while one of the aforementioned packets is being transmitted. In other words, this device automatically discontinue transmission in case of either absence of information to transmit or operational failure.

Positioning the TV

- Before you lift and move the heavy , 2 people are required to carry and handle a large screen TV.
- Make sure to hold the upper and bottom frames of the unit when moving the unit.
- Install the unit in a horizontal and stable position.
- Do not install the unit in direct sunlight or in a place subject to strong vibrations.
- Depending on the environment, the temperature of the units may increase slightly. This is not a malfunction.
- Ventilate well when using in a temperate environment, avoid a place of rapid temperature changes.
- This unit should not be used in a tropical environment as it has not been evaluated under such conditions.
- No objects should be placed directly on or under this unit, especially lighted candles or naked flames.
- Depending on your external devices, noise or disturbance of the picture and / or sound may be generated if the unit is placed too close to them. In such cases, please ensure enough space between the external devices and your unit.
- Do not insert the AC power cord into the power socket outlet before all the other connections are made.
- Ensure that you always have easy access to the AC power cord and outlet to disconnect the TV from the AC outlet.
- Keep the AC power cord and connected cables to prevent damage to connectors, especially the TV tuner.
- Be sure to unplug the AC power plug from the AC outlet before moving or cleaning the TV.
- When moving the TV and then setting it down, please be careful not to pinch the AC power cord under the unit.

Regulatory notices
WARNING: To prevent injury, this apparatus must be securely attached to the floor/wall in accordance with the installation instructions.
Tipping, shaking or rocking the unit may cause injury or death.

Stability Hazard
A television set may fall, causing serious personal injury or death. Never place a television set in an unstable location. Many injuries, particularly to children, can be avoided by taking simple precautions such as:

- Always use cabinets, stands or mounting methods recommended by the manufacturer of the television set.
- Always use furniture that can safely support the television set.
- Always ensure the television set is not overhanging the edge of the supporting furniture.
- Always educate children about the dangers of climbing on furniture to reach the television set or its controls.
- Certainly wire the cords and cables connected to television set that cannot be routed, pulled and climbed.
- Not placing the television set on unstable places.
- Not placing the television set on tall furniture (for example, cupboards or bookcases) without anchoring both the furniture and the television set to a suitable support.
- Not placing the television set on cloth or other materials that may be located between the television set and supporting furniture.
- Not placing anything such as toys or cortfists that tempts children on a TV or on the furniture that holds the TV.

If the existing television set is going to be retained and relocated, the same considerations as above should be applied.
Do not use this TV if the ambient temperature is capable of being tilted by a child and an adult leaning, pulling, standing or climbing on it. A falling unit can cause serious injury or even death. In order to avoid interruption of ventilation, do not cover the TV with items such as newspapers, table cloths, back cabinet, sofa, etc., and the vents of this unit should not be covered with anything such as a tablecloth, curtain, newspaper, etc. Make sure that there is sufficient space around the TV for air circulation. Failure to allow for adequate air flow can result in an overheating and possibly damage. To completely turn off the unit, you must unplug the AC power plug from the AC power outlet. Disconnect the AC power plug to shut the unit off when trouble is found or not in use. The AC plug shall remain readily available.

Never use a gas duster on this TV.
The gas trapped inside of this unit may cause ignition and explosion.

Environmental care

The packaging of this product is intended to be recycled.
Contact your local authorities for information about how to recycle the packaging.
For product recycling information, please visit: **www.recycle.philips.com**

End of life directives
Your new TV contains many components to produce environmental-friendly products in most local areas. Your new TV contains materials which can be recycled and reused. At the end of its life, specialized companies can dismantle the discarded TV to concentrate the reusable materials and to minimize the amount of materials to be disposed of. Please ensure you dispose of your old TV according to local regulations.

Batteries supplied
CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
WARNING: Batteries (battery pack or batteries installed) should not be exposed to excessive heat such as sunshine, fire or the like.

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (ni-cad, ni-mh, etc.) batteries.

Disposal of used batteries
The batteries supplied do not contain the heavy metals mercury and cadmium, however in certain localities, disposing batteries with household waste is not permitted. Please ensure you dispose of batteries according to local regulations.

Preparing to move / ship the unit
Please pack the unit properly by following the diagram on the carton (as noted below).

- To avoid damage to the screen, do not pack the stand on the same side as the TV screen, refer to the illustration.

Copyright
All other registered and unregistered trademarks are the property of their respective owners.

The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.

Manufactured under license from Dolby Laboratories. Dolby, Dolby Audio, and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.

Portions of this software are copyright © **The FreeType Project (www.freetype.org).**

The American Academy of Pediatrics discourages television viewing for children younger than two years of age.
Some features may require an always-on broadband internet connection. Internet service and / or a minimum bandwidth. Internet services vary by location.

License
Funai Corporation, Inc. hereby offers to deliver, upon request, a copy of the complete corresponding source code for the copy righted open source software used in this TV where such offer is required by the relevant license but is requested by the respective licenses. This offer is valid up to three years after the product purchase to anyone in receipt of this information. To request source code please call 1-833-978-3323 or write to Funai Service Corporation 205 Kensington Old Research, 2425 Spiegel Drive, Groveport, OH 43125, USA. Funai Corporation, Inc. disclaims any and all warranties and representations with respect to such software and treated source code including quality, reliability, usability, and accuracy and further disclaims all implied warranties including without limitation any implied warranties of merchantability, or fitness for a particular purpose. Funai Corporation, Inc. shall not be liable to make any updates, modifications, adaptations, enhancements or new releases, technical support or assistance with respect to it. Funai Corporation, Inc. disclaims any and all liability arising out of or in connection with the use of this software and/or source code.

This product has been manufactured by and is sold under the responsibility of Funai Corporation, Inc., and Funai Corporation, Inc. is the warrantor in relation to this product.

Limited warranty

LIMITED WARRANTY ONE (1) YEAR

WARRANTY COVERAGE:
This warranty obligation is limited to the terms as set forth below.

WHO IS COVERED:
This limited warranty is issued to the original purchaser or the person receiving the product as a gift against defects in materials and workmanship as based on the date of original purchase ("Warranty Period") from an authorized dealer. A valid proof of purchase bill showing the product name and the purchase date from an authorized retailer is considered such proof.

WHAT IS COVERED:
This warranty covers new products if a defect in material or workmanship occurs and a valid claim is received within the Warranty Period. At its option, Funai Corporation will (1) repair the product at no charge, using new or refurbished replacement parts, or (2) exchange the product with a product that is new or which has been manufactured from new or serviceable used parts and is at least functionally equivalent or most comparable to the original product in current inventory, or (3) refund the original purchase price of the product.
Replacement products or parts provided under this warranty are covered against defects in materials and workmanship from the date of the replacement or repair for ninety (90) days or the remainder of the original product's warranty, whichever provides longer coverage for you. When a product or part is exchanged, any replacement item becomes your property and the replaced item becomes Funai Corporation's property. When a refund is given, your product becomes company property.
Note: Any product sold and identified as refurbished or renewed carries a ninety (90) day Limited warranty.
Replacement product can only be sent if all warranty requirements are met. Failure to follow all requirements can result in delay.
WHAT IS NOT COVERED - EXCLUSIONS AND LIMITATIONS:
This limited warranty is only applicable to hardware Funai Corporation products that can be identified by the trademark, trade name, or logo affixed to it. This Limited warranty does not apply to any hardware product or any software, even if packaged or sold with the product. Funai Corporation manufacturers or publishers may provide a separate warranty for their own products packaged with the bundled product.
The company is not liable for any damage to or loss of any programs, data, or other information stored on any media contained within the product, or any non-Funai product or part not covered by this warranty. Recovery or reinstallation of programs, data or other information is not covered under this Limited warranty.
This warranty does not apply (a) to damage caused by accident, abuse, misuse, neglect, misapplication, or non-supplied product, (b) to damage occurring during shipment of the product, (c) to damage resulting from attempted repair by anyone other than a dealer, service center, or retail store authorized to perform warranty repairs for the product, (d) to damage caused by unauthorized attachments or equipment, (e) to damage or loss of any program, data, or removable storage media, (f) to damage caused by improper installation or failure to follow installation instructions, (g) to damage caused by power line surges, lightning damage, retained images or screen markings resulting from viewing fixed images displayed for extended periods of time that are not part of normal viewing of the television unless you enable a screen saver and use it whenever you are not watching digital content, (h) to damage occurring during shipment of the product (claims must be submitted to the shipping company), (i) to damage resulting from use of the product in other than the United States, including without limitation failure to use electrical systems with proper voltage and current capacity, (j) to damage resulting from acts of nature, such as lightning, (k) to damage resulting from improper ventilation of the product or failure to follow the ventilation instructions, (l) to cosmetic damage, including but not limited to scratches, dents, and broken plastic on ports, (m) to damage caused by servicing (including upgrades and expansions) performed by anyone who is not a representative of Funai Corporation or a dealer, service center, or retail store authorized to perform warranty repairs for the product, (n) to a product or part that has been modified without written company permission, or (o) if any serial number has been removed or defaced, in each instance listed above (collectively, "Exclusions"). This warranty also excludes refurbished product sold "AS IS" by some retailers.
This Limited warranty does not cover:

- Shipping charges to return defective product.
- Labor charges for installation or setup of the product, adjustment of customer controls on the product, and installation or repair of antenna / signal source systems outside of the product.
- Product claimed to be defective/replacement because of improper installation or maintenance, connection to improper voltage supply, power line surge, lightning damage, retained images or screen markings resulting from viewing fixed images displayed for extended periods of time that are not part of normal viewing of the television unless you enable a screen saver and use it whenever you are not watching digital content, or damage from mishandled shipments or transit accidents when returning product.
- A product that requires modification or adaptation to enable it to operate in any country other than the country for which it was designed, manufactured, approved and/or authorized, or repair of products damaged by these modifications.
- Product used for commercial or institutional purposes (including but not limited to rental purposes).
- Product lost in shipment and no signature verification receipt can be provided.
- Failure to operate per documentation.

TO OBTAIN ASSISTANCE...
Contact the customer care center at: 1 833 978 3323
Chat with us at: https://tinyurl.com/y2e29sxq

THE REMEDY SET FORTH HEREIN IS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY FOR THE CONSUMER. WITH THE ISSUING COMPANY NOT LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY.
Some states do not allow the exclusions or limitation of incidental or consequential damages, or allow limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you.

This warranty gives you specific legal rights. You may have other rights which vary from state / province to state / province.

Funai Service Corporation
2425 Spiegel Drive, Groveport, OH 43125, USA

Printed in China

PHILIPS

ROKU TV

6573 series
Quick Start Guide

Register your product:
www.philips.com/my-tv

- Early access to exclusive offers and more!
- Keep track of your product warranty coverage
- Get easy access to product support

Scan to register

User Manual:
www.philips.com/support

For a detailed manual, please visit our support page and enter your TV model number to download.

Scan to download

Call us:
1-833-978-3323

To obtain assistance, contact Philips customer care center, in the U.S.A., Canada, Puerto Rico, or the U.S. Virgin Islands

Scan to call

Chat with us:
https://tinyurl.com/y2e29sxq

Scan to chat

What's in the box

TV | TV remote with batteries | Quick start guide | AV cable

ST4 x 0.787" (20 mm) Screws | TV stands

1 What you need (not included)

- **Phillips screw driver**
- **Wireless router** (needed to connect your TV to the Internet)
- **Internet connection** (needed for streaming)
- **Computer, tablet, or smartphone** (needed for setup)
- **Roku account** (needed to access entertainment across thousands of streaming channels)

For additional support, please see online owner's manual at *www.philips.com/support*
Key things to know: A paid subscription or other payments may be required for some streaming channel content.
Channel availability is subject to change and varies by country.

2 Mount base onto TV



If you plan to wall mount your TV, refer to "Wall mount bracket kit" in "Important safety instructions" page of this Quick start guide for recommended wall mount bracket kit.

3-1 Connections



Caution
Disconnect the AC power cord before connecting devices.

3-2 Controls

1 Press to turn the TV on/select connected device
Press and hold to turn the TV off

2 Remote control sensor

3 Press and hold about 10 seconds for factory reset.



*Power button is located at the bottom side of the TV

Caution
A factory reset clears the majority of data from your Roku TV and resets it to a factory default state. After you complete a factory reset, you might need to set up and configure your Roku TV again including Guided Setup and activation process, sign in to streaming channels, perform a television channel scan and configure parental control settings.

4 Using the remote

How to install the batteries in the remote
Open the battery cover by firmly sliding down. Insert 2 AAA (1.5 V) batteries matching the polarity indicated inside battery compartment of the remote.

1 **Power**
Turn TV on and off

2 **Back**
Return to previous screen

3 **OK**
Select an option from a menu

4 **Instant replay**
Replay the last few seconds of streaming video

5 **RWD scan**
Rewind streaming video, scroll left one page at a time

6 **Home**
Return to Roku Home screen

7 **Directional keypad (D-Pad)**
Move up or down. The left arrow will bring up the antenna TV channel list or Smart Guide.
The left and right arrow are used for Live TV Pause to select scenes.

8 **Sleep**
Set the sleep timer

9 **Options**
Access to picture settings, move streaming channel icons and more

10 **FWD scan**
Fast forward streaming video, scroll right one page at a time. This button is also used to fast forward paused live TV using Live TV Pause.

11 **Play / Pause**
Start or pause playback. This button is also used to activate and use the Live TV Pause feature when a 16 GB USB drive is attached to the TV.

12 **Featured channel shortcut**
Lets you directly access featured channels

13 **Volume / Mute**
Increase / Decrease volume and mutes the TV sound

* The ✱ gives you easy access to picture settings, display options and more. Try it on every screen.

5 Plug in and turn on TV

Connect the AC power cord to the AC outlet. Press the power button on the TV's remote control.

6 Follow the on-screen instructions

1. **Once your Roku TV powers on, follow the on-screen instructions. Your Roku TV will walk you through initial setup and help connect to your preferred wireless network.**
2. **Your TV will automatically detect wireless networks in your area. Have your network name and password handy and follow the easy on-screen instructions.**
If you are not ready to connect your TV to a wireless network, you can still use it as a regular TV by selecting "Connect to the Internet later".
3. **Once connected your TV will automatically update with the latest software. This can take a few minutes to update.**

Once you complete guided setup, your TV will automatically update with the latest software. Your new Philips Roku TV automatically receives regular software updates in the background when it's connected to the Internet. This allows it to give you a better experience over time.

7 Activate your smart TV

You need a Roku account to activate your Roku TV and to access entertainment across thousands of streaming channels.

Your Roku account
Follow the on-screen instructions on your Roku TV. You will need to activate your Roku TV using your smartphone, tablet, or computer to link to a Roku account. See more information below.

- Roku accounts are free, and while a valid credit card number is not required to create your account, providing your credit card information makes renting and purchasing entertainment from the Roku Channel Store fast and convenient.
- If you choose to provide a payment method, you will be able to seamlessly rent content, download channels and subscribe to services without having to enter your credit card information each time.
- A unique PIN can be added to the account to prevent unauthorized purchases.

Tip
Roku does not charge for activation support — beware of scams.

Caution
Funai Corporation, Inc. does not warrant access to the portal or to any of the services, content, software and advertising. Funai Corporation, Inc. may, in its sole discretion, add or remove access to any specific services, content, software and advertising at any time. Although Funai Corporation, Inc. will strive to provide a good selection of services, content or software, Funai Corporation, Inc. does not warrant continued access to any specific services, and content or software.

8 Connect antenna or cable (optional)

With the tuner built-in you can connect your TV to antenna or cable (free cable only, does not work with cable TV using a set-top box) and enjoy over-the-air entertainment.

1. **When the setup wizard is complete, select the Live TV tile from the home screen.**
2. **Follow the on-screen instructions.**
3. **Whenever you want to watch local broadcast TV, select this tile.**

- User interface may vary.

Tip
While in the live TV input, you can use your remote to access additional features.
- **D-Pad left: Pressing this key brings up the smart guide, a list of antenna TV channels.**
- **Play / Pause: Pause live TV for up to 90 minutes when a 16 GB USB drive is connected.**
- **RWD scan and FWD scan: Allows you to fast forward and rewind while using the Live TV pause feature.**
- **D-Pad left and right: Allows you to scroll through the paused Live TV and select scenes.**

- Live TV Pause can pause content received on the antenna TV input for up to 90 minutes and requires a 16 GB or larger USB drive and a valid Roku account. All data on the USB drive will be deleted prior to use.

70-32PFL6-Q5GZ1

Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license.
Roku, Roku TV, the Roku logo, and the purple d-pad design are trademarks of Roku, Inc. All other trademarks and logos herein are the property of their respective owners.