PHILIPS

Corded phone

M20

User Manual

Register your product and get support at:
www.philips.com/support

Contents

1 Important safety instructions 2

2 Your phone 2
- What is in the box 2
- Overview of the phone 3

3 Get started 4
- 1. Connect the base station 4
- 2. Install the handset 4
- 3. Set the date and time 4

4 Calls 5
- Make a call 5
- Normal call 5
- Redial a call 5
- Call from the call log 5
- Query incoming calls 5
- Turn the speaker on or off 5

5 Settings 6
- Adjust the volume 6
- Set the brightness 6
- Temporary time setting 6

6 Technical data 7
- Screen dimensions 7
- General specification and features 7
- Weight and dimensions 7

7 Frequently asked questions 7
- No dialing tone 7
- No voice from the receiver or no voice transmission 7
- The caller ID does not display 7

1 Important safety instructions

This product shall be used under the conditions of not interfering with legal radio stations and being protected from interference.

To avoid damage or malfunction

Warning:

- Avoid high temperature (60°C), humid or corrosive environments.

NCC warning:

- This product shall be used under the indoor conditions of not interfering with legal radio stations and being protected from interference.
- Please use the product appropriately to reduce the influence of electromagnetic waves.

2 Your phone

What is in the box

Base station



Handset



Coil cord



Line cord



User Manual

Guarantee

Overview of the phone



1 Handset

2 Outgoing call log
- It shows the outgoing call log.

3 Incoming call log
- It shows the incoming call log.

4 Brightness
- It adjusts the brightness of the screen in on-hook condition.

5 Recall
- It is used for recall in off-hook condition.

6 Speaker (🔊)
- Make and receive calls through the speaker.

7 Redial

8 Callback

9 Call transfer

10 Pause

11 Delete
- It deletes a call log when you query incoming or outgoing call logs. Press and hold for 3s to delete all incoming or outgoing call logs.
- It deletes a digit when you dial a number.

12 Volume

13 Settings

14 Up/Down

15 LCD screen

16 Cable socket

3 Get started

1. Connect the base station

Connect each end of the line cord to:

- ☎ telephone socket on the top of the base station
- telephone socket on the wall



2. Install the handset

Connect each end of the coil cord to:

- telephone socket at the bottom of the handset
- telephone socket at the left side of the base station.



3. Set the date and time

- Press [SETTING]. The screen displays "SEt 1 dAtE". Press [SETTING] again to confirm. After entering the date/time settings screen, the year digit starts to blink. Press [▲▼] to set the year and then press [SETTING] to set the day/hour/minute.
- Pick up the handset to confirm the setting.

Remarks

- After the time and date are set, the LCD screen automatically displays the corresponding week.

4 Calls

Make a call

You can make a call in these ways:

- Normal call
- Call from the redial list
- Call from the call log

Normal call

1. Pick up the handset or press .
2. Dial the phone number.
   - To erase a digit, press .

Redial a call

1. Pick up the handset.
2. Press REDIAL. The most recent outgoing call is dialed.

Call from the call log

1. Press to enter the incoming call log.
2. Press to select a record on the list.
3. The screen displays the incoming call number, date, and time.
4. Press CALLBACK or again to call back.

1. Press to enter the outgoing call log.
2. Press to query the latest outgoing call number and time.
3. Press CALLBACK or again to call back.

Query incoming calls

1. Press to enter the incoming call log.
2. Press to select a record on the list.
3. The screen displays the incoming call number, date, and time.

Turn the speaker on or off

Press .

5 Settings

Adjust the volume

Adjust the speaker volume

You can set the speaker volume in the following ways:

1. Press [speaker] to enter the speaker mode.
2. Press [volume] to adjust the speaker volume. The speaker volume is set to high upon factory delivery.

Set the brightness

There are five brightness levels for selection.

1. In the on-hook condition, press [☼] to adjust the screen of the LCD screen. Press this button continuously to display different brightness. The brightness is set to level 3 upon factory delivery.
2. Pick up the handset to confirm the setting.

Temporary time setting

1. Press [SETTING] to enter the setting mode.
2. Press [▲▼] to select "SEt 4 FLASH".
3. Press [SETTING] again to enter the temporary time setting menu.
4. "FLASH 600" is displayed.
5. Press [▲▼] to set the time.
6. Pick up the handset to confirm the setting.

6 Technical data

Screen dimensions

- Screen size: 3.3 inches

General specification and features

- Speaker phone
- Callback and redial
- Call transfer or three-way calling with the transfer button in cooperation with switches

Weight and dimensions

- Base station and handset: 539.0 grams
- 77.0 × 218.0 × 179.0 mm (H × W × D)

7 Frequently asked questions

No dialing tone

- Make sure your phone is properly connected to the line cord.

No voice from the receiver or no voice transmission

- Make sure the handset is properly connected to the base through the coil cord.

The caller ID does not display

- The service is not activated. Check with your service provider.
- The caller's information is withheld or unavailable.

2021 © MMD Hong Kong Holding Limited. All rights reserved. Specifications are subject to change without notice.

Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license. This product has been manufactured by and is sold under the responsibility of MMD Hong Kong Holding Limited or one of its affiliates, and MMD Hong Kong Holding Limited is the warrantor in relation to this product.

M20B_90_UM_V1.0