



**[NOTE]**

Put an 'Energy Guide Label' on the front cabinet directly.  
Do not put it on PE protect.