

GCX Mounting Assembly Installation Guide

Fixed VHM Arm Extension




The purpose of these instructions is to:


Describe attachment of VHM Arm Extension.

Attachment of Adjustable Stop

1. Adjust Adjustable stop at desired location in Channel and tighten as shown.



2. Guide Arm Extension into Channel as shown.



3. Guide VHM onto Arm Extension as shown.

