



Philips Sensiflex
Sonicare Brush heads

• 4-pack

HX2014



Sensiflex replacement brushes

Sonicare toothbrush replacement head

Sensiflex replacement brushes. Replace the brush head of your Philips Sonicare electric toothbrush every 6 months for optimal performance.

Double Cleaning Action

- Cleans visible teeth surfaces
- Naturally whiter teeth

Gentle on gums, tough on plaque

- Gum Protection system

PHILIPS

Specifications

Cleaning performance

- Brush heads: 4



Issue date 2013-05-09

Version: 6.1.1

12 NC: 0000 000 00000

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com