

# Always here to help you

Register your product and get support at  
[www.philips.com/welcome](http://www.philips.com/welcome)



HX9383  
HX9343  
HX9333

**Sonicare DiamondClean**

## Quick start guide

Kurzanleitung

Guide de mise en route

Guida di avvio rapido

Snelstartgids



**Please read chapter 'Important' in the user manual before you use the appliance.**

Lesen Sie bitte in der Bedienungsanleitung das Kapitel "Wichtig", bevor Sie das Gerät verwenden.

Veuillez lire le chapitre « Important » du mode d'emploi avant d'utiliser l'appareil.


Leggete il capitolo 'Importante' nel manuale per l'utente prima di iniziare a utilizzare l'apparecchio.

Lees hoofdstuk 'Belangrijk' in de gebruiksaanwijzing voordat u het apparaat gebruikt.



# PHILIPS

# CONTENT / INHALT / SOMMAIRE / SOMMARIO / INHOUD



## A

Brush head  
 Bürstenkopf  
 Tête de brosse  
 Testina  
 Opzetborstel

## B

Handle  
 Handstück  
 Manche  
 Impugnatura  
 Handvat

## C

Charger glass  
 Glas des Ladegeräts  
 Verre de charge  
 Bicchiere per ricarica  
 Oplaadglas

## D

Charging stand  
 Ladegerät  
 Base de recharge  
 Supporto di ricarica  
 Oplaadstandaard


## E

Charging base  
 Ladestation  
 Station de recharge  
 Base di ricarica  
 Oplaadstation

## F

Charging travel case  
 Box für Reiseladegerät  
 Coffret - chargeur de voyage  
 Custodia da viaggio  
 Oplaadreisetui

**BEFORE FIRST USE / VOR DEM ERSTEN GEBRAUCH /  
AVANT LA PREMIÈRE UTILISATION / PRIMO UTILIZZO /  
VOOR HET EERSTE GEBRUIK**



Refer to your user manual for additional instructions.





Nur bestimmte Gerätetypen Vor dem ersten Gebrauch Weitere  
Informationen finden Sie in der Bedienungsanleitung.

Reportez-vous au mode d'emploi pour de plus amples instructions.







Per ulteriori informazioni, consultate il manuale dell'utente.

Raadpleeg uw gebruiksaanwijzing voor extra instructies.


**USING / DAS GERÄT VERWENDEN / UTILISATION /  
UTILIZZO / GEBRUIK**



**TRAVELING WITH YOUR SONICARE / REISEN MIT IHRER  
SONICARE / VOYAGER AVEC VOTRE SONICARE /  
IN VIAGGIO CON IL VOSTRO SONICARE / REIZEN  
MET UW SONICARE**



**REPLACEMENT BRUSH HEADS / ERSATZBÜRSTENKÖPFE /  
TÊTES DE BROSE DE RECHANGE / TESTINE DI RICAMBIO  
PER SPAZZOLINO / VERVANGENDE OPZETBORSTELS**



Replace brush head every 3 months for optimal results.

Um optimale Ergebnisse zu erzielen, tauschen Sie den Bürstenkopf nach 3 Monaten aus.

Pour un résultat optimal, remplacez la tête de brosse tous les 3 mois.

Per ottenere ottimi risultati, sostituite la testina ogni 3 mesi.

Vervang de opzetborstel om de 3 maanden voor optimale resultaten.



4235.020.4914.2

[www.philips.com/Sonicare](http://www.philips.com/Sonicare)