



Philips Sonicare ProResults  
Standard sonic toothbrush  
heads

3-pack

*ProResults*

HX6013

## All-around Clean

Larger surface area and contoured bristles thoroughly clean and massage teeth and gums.

### **Thorough clean feeling in your mouth**

- Angled, radial-trimmed bristles expand the area covered
- Contoured bristles fit the natural shape of your teeth
- Brush head design maximises sonic motion

### **Designed to optimise performance**

- Reminder bristles ensure you are getting an effective clean

### **A brush head that fits multiple handles**

- Snap-on brush head

**PHILIPS**  
**sonicare**

sense and simplicity

# Specifications

## Ease of use

- Suitable for these models: FlexCare+, FlexCare, HealthyWhite, HydroClean, EasyClean, DiamondClean

## Technical specifications

- Operating time: For optimal results, a new brush head is recommended every three months.
- Replacement: Reminder Bristles fade when a

replacement is needed.

## Weight and dimensions

- Dimensions brush head packaging: 21.6 h x 7.0 w x 2.2 d cm
- Weight brush head packaging: 0.056 kg

## Items Included

- Hygienic travel cap: 3 pcs

# Highlights

## Snap-on brush head



Easy brush head placement and handle cleaning

## Angled radial-trimmed bristles



The curved surface area created by angled, radial-trimmed bristles helps maintain contact with the surfaces of the teeth and gums as the brush head pivots, covering a larger surface area without increasing the size of the brush head.

## Contoured bristles

Bristles are trimmed in a contoured pattern to fit the natural shape of teeth. The peaks and valleys along the length of the brush head are ergonomically designed to follow teeth topography and fit between teeth so you're less likely to miss places when you brush.

## Maximise cleaning performance



Thoughtful design and precision engineering ensure that when this brush head is combined with the sonic motion and flexible brushing modes, you get a thorough clean.

## Reminder bristles

Reminder bristles let you know when to replace the brush head. After three months of normal use bristles exhibit fatigue, and brush heads are less effective. Replace your brush head every 3 months.



Issue date 2011-07-09

Version: 2.1.1

12 NC: 0000 000 00000

© 2011 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips  
Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)