

Philips
Warm Sensual Massager
for sharing
HF8410

# Explore together

### Warm intimate massager to get you both in the mood

This Warm Sensual Massager is ideal to get you both in the mood. Take time to caress and excite your partner using the combination of the vibrating massages. Relax, enjoy and let the journey begin...

### Pre-warm to comfortable body temperature

- Can be easily pre-warmed before use
- Multiple vibration modes for arousing variety
- Five vibration settings and five intensity levels

#### Shaped for intimate use

• Specially shaped to fit naturally with your body

#### Waterproof

• Use the massager in the shower

#### Lubricant compatible

• Can be used with water or silicone based lubricants



## Specifications

#### **Design and finishing**

- Materials: Soft touch top coat
- Colour(s): Purple

#### **Technical specifications**

- Battery type: NiMH
- Voltage: 100–240 V
- Charging: Cordless rechargeable
  Charging time: 24 hour(s)
- Charging time: 24 hour
   Frequency: 50–60 Hz
- Water resistant: Waterproof, can be used in bath/ shower

#### Vibration

- Frequency (max): 95 Hz
- Number of intensities: 5
- Number of modes: 4
  Sound level (average): 32 dB
- Sound level (average): 32 df
  Sound level (max): 43 dB

#### Weight

- Charging case: 114 g
- Intimate massager: 74 g

#### HF8410/01

## Highlights

#### Sensual shape for both



The massager feels comfortable to hold in many ways; in your palm, between your fingers, or with your fingertips. The massager is specially shaped to fit as naturally in your hand as it does to specific curves and parts of the body, while letting you maintain skin contact with your partner. You can turn the concave part away from the palm, for instance, to stroke the penis, or wrap your hand around the concave surface to titillate the clitoris with the rounded tips.

#### **Pre-warming function**



You can choose to gently pre-warm the sensual massager to a comfortable body temperature. To use it, place the massager on the charger and press the pre-warming button. It takes five minutes for the massager to warm up. The warming along with the pleasure your touch gives, lets your partner also feel an arousing warmth from the massager's surface.

#### Soft, sensual material



Made of a soft, sensual material, the sensual massager feels comfortable and sexy against your skin. Incorporate the massager into foreplay or use during sex. Using its natural fit in the hand to experiment together for excitement and stimulation, maintaining touch between partners.



Issue date 2012-04-20

Version: 4.0.1 Sr

© 2012 Koninklijke Philips Electronics N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com