

PHILIPS

Sonicare Brush
heads

Sensiflex

4-pack

HX2014



Sensiflex replacement brushes

Sonicare toothbrush replacement head

Sensiflex replacement brushes. Replace the brush head of your Philips Sonicare electric toothbrush every 6 months for optimal performance.

Double Cleaning Action

- Cleans visible teeth surfaces
- Naturally whiter teeth

Gentle on gums, tough on plaque

- Gum Protection system

Specifications

Cleaning performance

Brush heads: 4

