



In-between Clean

The unique brush head design helps dislodge plaque and food particles in between teeth.

Thorough clean feeling in your mouth

· Brush head design maximises sonic motion

Designed to optimise performance

· Reminder bristles ensure you are getting an effective clean

Delivers a better clean in-between

• Hydroguides help dislodge plaque and food particles

A brush head that fits multiple handles

· Snap-on brush head

Highlights

Snap-on brush head



Easy brush head placement and handle cleaning

Hydroguides

HydroGuides work with our patented sonic technology to direct toothpaste and water between teeth to help you clean those tight spaces. While they don't replace flossing, they can help give you a better clean between teeth.

Maximise cleaning performance



Thoughtful design and precision engineering ensure that when these Philips Sonicare replacement brushes are combined with the sonic motion and flexible brushing modes, you get a thorough clean.

Reminder bristles



Reminder bristles let you know when to replace the brush head. After three months of normal use bristles exhibit fatigue, and brush heads are less effective. Replace your brush head every 3 months.

Specifications

Weight and dimensions

Dimensions brush head packaging: 21.6 h x 7.0 w x 2.2 d cm

Weight brush head packaging: 0.056 kg

Technical specifications

Operating time: For optimal results, a new brush head is recommended every three months.

Replacement: Reminder Bristles fade when a replacement is needed.

Items Included

Hygienic travel cap: 1 pcs

Ease of use

Suitable for these models: FlexCare+, FlexCare, HealthyWhite, HydroClean, EasyClean, DiamondClean

© 2019 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

Issue date 2019-07-18 Version: 3.0.1

12 NC: 0000 000 00000

www.philips.com

