



## Replacement brush head

## for Sonicare Advance 4000 series toothbrushes

Replace your brush head every 6 months for optimal performance.

Extra-soft bristles

Precision cleaning in hard-to-reach areas

Longer neck and smaller brush headIdeal for smaller mouths, special cleaning needs & children

Replacement brush for Sonicare Advance 4000 Series

Brush head

HX4011/10

© 2019 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners. Version: 3.1.1

Issue date 2019-07-17

12 NC: 0000 000 00000

www.philips.com

