

Philips
Address recorder

SCD605/00



Help your child

find her/his way back to you

Help your child find her way back to you

- Record child's name and your phone number or address
- Recessed, one-touch 'Address' replay button

Easy and comfortable to wear

- Attach to clothes or bag to make sure it's always with you

Reliability and piece of mind

- Ensures your child cannot record over your message

Totally safe to play with

- Complies with all relevant toy and safety standards

PHILIPS

Specifications

Technical specifications

- Complies with: EU and USA Toy regulation

Audio recording

- Recording time: up to 20 s

Accessories

- Included accessories: Battery
- User manual

Power

- Battery type: GP76A
- Number of batteries: 4
- Operating time on battery: 50 hour(s)
- Removable/replaceable

Highlights

Record vital information

If your child has wandered off and needs help to find you, it's reassuring to know that he or she has vital contact information at the touch of a button.

Digital recording of info

Digital voice recording provides a quick, secure and easy way to record the essential contact details that may save valuable time if you should ever inadvertently lose sight of your child.

Easy to attach to your child's clothes

To make sure it is always with you but out of the way.

Protected against accidental over-recording

Requiring a sharp pencil to be inserted into a small hole to activate recording, it's virtually impossible for your child to erase, change or record over your digital message of essential contact information.

Complies with toy standard

The products that comply with the toy standard have been thoroughly tested to ensure they meet these norms and are totally safe.



Issue date 2020-11-18

Version: 2.1.1

12 NC: 0000 000 00000

© 2020 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com