

Philips  
Address recorder



SCD605/00

## Help your child

find her/his way back to you

### **Help your child to find her way back to you**

- Record child's name and your phone number or address
- Recessed, one-touch 'Address' replay button

### **Easy and comfortable to wear**

- Attach to clothes or bag, to make sure it's always with you

### **Reliability and piece of mind**

- Ensures your child can not over-record your message

### **Totally safe to play with**

- Complies with all relevant toy and safety standards

# PHILIPS

# Specifications

## Technical specifications

- Complies with: EU & USA Toy regulation

## Audio recording

- Recording time: upto 20 s

## Accessories

- Included accessories: Battery
- User manual

## Power

- Battery type: GP76A
- Number of batteries: 4
- Operating time on battery: 50 hour(s)
- Removable/replaceable

# Highlights

## Record vital information

If your child has wandered off and needs help to find you, it's reassuring to know that he or she has vital contact information at the touch of a button.

## Digital recording of info

Digital voice recording provides a quick, secure and easy way to record the essential contact details that may save valuable time if you should ever inadvertently lose sight of your child.

## Easy to attach to your child's clothes

To make sure it is always with you but out of the way.

## Protected against accidental over-recording

Requiring a sharp pencil to be inserted into a small hole to activate recording, it's virtually impossible for your child to erase, change or over-record your digital message of essential contact information.

## Complies with toys standard

The products that comply to the toys standard have been thoroughly tested to ensure they meet these norms and are totally safe.

