

回收

- 弃置产品时，请不要将其与一般生活垃圾堆放在一起；应将其交给官方指定的回收中心。这样做有利于环保。

保修与服务

如果您需要服务或信息，或者有任何疑问，请访问飞利浦网站：

www.philips.com/support。

您也可与您所在国家/地区的飞利浦客户服务中心联系（可从全球保修卡中找到其电话号码）。如果您所在的国家/地区没有飞利浦客户服务中心，请与当地的飞利浦经销商联系。

故障种类和处理方法

1 吸力不足。

A 集尘桶可能已满。清空集尘桶。

B 过滤网可能脏了。清洁或更换过滤网。

C 吸力可能被设置在较低的档位。使用调节器增强产品或手柄的吸力。

D 吸嘴、硬管或软管可能被阻塞。要清除阻塞物，请将阻塞的部分拆下，并将它反向连接（尽可能离远一些）。打开吸尘器的电源，强迫气流反方向通过阻塞的部位。

2 有时，在使用吸尘器时会有触电的感觉。

A 您的真空吸尘器会积聚静电。空气湿度越低，产品积聚的静电就越多。经常握住硬管使其与房间中的其它金属物体接触（例如桌椅脚或电炉等）对产品进行放电。您也可以增加房间的空气湿度（例如将装有水的碗放在电炉上或附近）。

PHILIPS

产品 : 飞利浦家用真空卧式吸尘器
型号 : FC6826
额定电压 : 220V~
额定频率 : 50Hz
额定输入功率: 1600 W
生产日期 : 请见产品本体
产地 : 中国苏州

飞利浦（中国）投资有限公司
上海市天目西路218号1602-1605
全国顾客服务热线: 4008 800 008

本产品根据国标 GB4706.1-2005, GB4706.7-2014, GB4343.1-2009及GB17625.1-2012制造

PHILIPS

产品 : 飞利浦家用真空卧式吸尘器
型号 : FC5823
额定电压 : 220V~
额定频率 : 50Hz
额定输入功率: 1600 W
生产日期 : 请见产品本体
产地 : 中国苏州

飞利浦（中国）投资有限公司
上海市天目西路218号1602-1605
全国顾客服务热线: 4008 800 008

本产品根据国标 GB4706.1-2005, GB4706.7-2014, GB4343.1-2009及GB17625.1-2012制造

PHILIPS

产品 : 飞利浦家用真空卧式吸尘器
型号 : FC5822
额定电压 : 220V~
额定频率 : 50Hz
额定输入功率: 1400 W
生产日期 : 请见产品本体
产地 : 中国苏州

飞利浦（中国）投资有限公司
上海市天目西路218号1602-1605
全国顾客服务热线: 4008 800 008

本产品根据国标 GB4706.1-2005, GB4706.7-2014, GB4343.1-2009及GB17625.1-2012制造

PHILIPS

产品 : 飞利浦家用真空卧式吸尘器
型号 : FC5820
额定电压 : 220V~
额定频率 : 50Hz
额定输入功率: 1400 W
生产日期 : 请见产品本体
产地 : 中国江苏苏州

飞利浦（中国）投资有限公司
上海市天目西路218号1602-1605
全国顾客服务热线: 4008 800 008

本产品根据国标 GB4706.1-2005, GB4706.7-2014, GB4343.1-2009及GB17625.1-2012制造

保留备用
发行日期 : 09/09/2015

PHILIPS

产品 : 飞利浦家用真空卧式吸尘器
型号 : FC5830
额定电压 : 220V~
额定频率 : 50Hz
额定输入功率: 1800 W
生产日期 : 请见产品本体
产地 : 中国苏州

飞利浦（中国）投资有限公司
上海市天目西路218号1602-1605
全国顾客服务热线: 4008 800 008

本产品根据国标 GB4706.1-2005, GB4706.7-2014, GB4343.1-2009及GB17625.1-2012制造

PHILIPS

产品 : 飞利浦家用真空卧式吸尘器
型号 : FC5828
额定电压 : 220V~
额定频率 : 50Hz
额定输入功率: 1600 W
生产日期 : 请见产品本体
产地 : 中国苏州

飞利浦（中国）投资有限公司
上海市天目西路218号1602-1605
全国顾客服务热线: 4008 800 008

本产品根据国标 GB4706.1-2005, GB4706.7-2014, GB4343.1-2009及GB17625.1-2012制造



www.philips.com

100% recycled paper
100% 循环再造纸

4222.003.3663.5

Register your product and get support at /
在以下网址注册您的产品并获得支持
www.philips.com/welcome

ENGLISH	2
简体中文	4



PHILIPS

Introduction

Congratulations on your purchase and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

Important

Read this important information carefully before you use the appliance and save it for future reference.

Danger

- Never vacuum up water or any other liquid, flammable substances or hot ashes.

Warning

- Check if the voltage indicated on the appliance corresponds to the local mains voltage before you connect the appliance.
- Do not use the appliance if the plug, the mains cord or the appliance itself is damaged.
- If the mains cord is damaged, you must have it replaced by Philips, a service centre authorised by Philips or similarly qualified persons in order to avoid a hazard.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Keep the appliance and its cord out of the reach of children.
- Do not point the hose, the tube or any other accessory at the eyes or ears nor put it in your mouth.

Caution

- Never use the appliance without any of the filters. This could damage the motor and shorten the life of the appliance.
- Always clean all parts as shown in the user manual. Do not clean any parts with water and/or cleaning agents if this is not particularly shown in the user manual.
- If you clean a washable filter with water, make sure it is completely dry before you put it back into the appliance. Do not dry the filter in direct sunlight, on the radiator or in the tumble dryer. Replace a washable filter if it can no longer be cleaned properly or if it is damaged.
- To guarantee optimal dust retention and performance of the vacuum cleaner, always replace the filters with original Philips filters of the correct type (see chapter 'Ordering accessories').
- Maximum noise level: Lc = 84 dB(A)

Electromagnetic fields (EMF)

This Philips appliance complies with all standards regarding electromagnetic fields (EMF).

Ordering accessories

To purchase accessories (such as filters and additional nozzles) for this appliance, please visit our online shop at www.shop.philips.com/service. If the online shop is not available in your country, go to your Philips dealer or a Philips service centre. If you have any difficulties obtaining accessories for your appliance, please contact the Philips Consumer Care Centre in your country. You find its contact details in the worldwide guarantee leaflet.

Recycling

- Do not throw away the product with the normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you help to preserve the environment.

Guarantee and service

If you need service or information or if you have a problem, please visit the Philips website at www.philips.com/support or contact the Philips Consumer Care Centre in your country. You find its phone number in the worldwide guarantee leaflet. If there is no Consumer Care Centre in your country, go to your local Philips dealer.

Troubleshooting**1 The suction power is insufficient.**

- A The dust container may be full. Empty the dust container.
- B The filters may be dirty. Clean or replace the filters.
- C The suction power may be set to a low setting. Increase the suction power with the regulator on the appliance or on the handgrip.
- D The nozzle, tube or hose may be blocked up. To remove the obstruction, disconnect the blocked-up item and connect it (as far as possible) the other way around. Switch on the vacuum cleaner to force the air through the blocked-up item in opposite direction.

2 When I use my vacuum cleaner I sometimes feel electric shocks.

- A Your vacuum cleaner builds up static electricity. The lower the air humidity, the more static electricity the appliance builds up. Discharge the appliance by frequently holding the tube against other metal objects in the room (for example the legs of a table or chair, a radiator etc.). You can also raise the air humidity level in the room (for example by placing bowls filled with water on or near radiators).

简介

感谢您的惠顾，欢迎光临飞利浦！为了您能充分享受飞利浦所提供的支持，请在 www.philips.com/welcome 上注册您的产品。

注意事项

使用产品之前，请仔细阅读本重要信息，并妥善保管以供日后参考。

危险

- 切勿吸入水或其它液体、易燃物质或热灰。

警告

- 在将产品连接电源之前，请先检查产品所标电压与当地的供电电压是否相符。
- 如果插头、电源线或产品本身受损，请勿使用本产品。
- 如果电源软线损坏，为避免危险，必须由制造厂或其维修部或类似的专职人员来更换。
- 肢体不健全、精神有障碍及缺乏相关经验和知识的人（包括儿童）必须在监护人的监督及指导下使用。
- 将产品及其线缆放在儿童接触不到的地方。
- 切勿将软管、硬管或任何其它附件指向眼睛或耳朵，也不要放在口中。

注意

- 切勿在没有任何滤网的情况下使用本产品。这会损坏马达并缩短产品的使用寿命。
- 务必按照用户手册中的说明清洁所有部件。请勿使用水和/或清洁剂清洁任何部件（如果用户手册中未特别说明）。
- 如果用水清洁可水洗滤网，确保其完全干燥，然后再放回产品中。切勿在阳光直射处、暖气管上或转筒式干燥机中干燥滤网。如果无法再正常清洁水洗滤网或其已损坏，请加以更换。
- 为保证吸尘器的最佳吸尘效果和性能，请务必用正确型号的原装飞利浦过滤网来替换滤网（请参阅“订购附件”一章）。
- 最大噪音强度：Lc = 84 dB(A)

电磁场 (EMF)

本飞利浦产品符合与电磁场 (EMF) 相关的所有标准。

订购附件

要购买本产品的附件（例如滤网和其它吸嘴），请访问我们的在线商城 www.shop.philips.com/service。如果您的国家/地区没有在线商城，请联系您的飞利浦经销商或飞利浦服务中心。如果您在购买产品的附件时遇到困难，请联系您所在国家/地区的飞利浦客户服务中心。可在全球保修卡中找到其详细联系信息。