

PHILIPS

Emulsifying DISC

CP6665



Emulsifying tool

Check the specifications for compatibility

The perfect tool for whipping, whisking or emulsifying eggs or whipped cream. For best volume increase and fluffiness, use the low speed setting. Creating delicious desserts or mayonnaise has never been easier!

Ease of using Philips spare parts

- Easily renew your product with original Philips parts

Highlights

Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.

Specifications

Replaceable part

Fits Product type: HR7627, HR7776

