

PHILIPS

Chopping knife

CP9717



to replace your current chopping knife

This is the knife for the compact chopper accessory to chop herbs, nuts, cheese, chocolate and onions.

Ease of using Philips spare parts

- Easily renew your product with original Philips parts

Highlights

Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.

Specifications

Replaceable part

Fits product types:: HR1640/Ox, HR1641/Ox, HR1642/Ox, HR1643/Ox, HR1644/Ox, HR1645/Ox, HR1646/Ox, HR1647/Ox

