PHILIPSToaster

Pure Essentials Collection

2 slot

3 function

White



HD2686/30



Have it your way, exactly your way

Toasts any type of bread you like

State-of-the art toaster HD2686/30 that enables you to prepare the kind of toast you want, thanks to the extra long, extra wide slots. The eight digital browning settings give you full control so you get the crispy toasted bread you like.

Toast any type of bread

- Extralong slots to fit all kinds of bread
- Extrawide and extradeep slot(s) to fit your bread
- · Evenly toasts thick or thin slices

Exactly the way you like

- Bun warming rack to warm buns and croissants
- · Defrost and toast frozen bread at any browning level
- · Reheat setting warms or further browns just toasted bread

In the easiest way

- Cancel button to stop toasting at any time
- ${}^{\textstyle \cdot}{}$ High lift feature to safely take out small pieces of bread
- $\boldsymbol{\cdot}$ The outside of the toaster stays cool and safe to touch
- · Removable crumb tray for easy cleaning

Toaster HD2686/30

Highlights

Extrawide and extradeep slot(s)

Extrawide and extradeep slot(s) to fit your bread.

Bun warming rack



Bun warming rack to warm buns and croissants.

Specifications

General specifications

Multiple toast settings: 8 Automatic safety shut-off

Technical specifications

Power: 1500 W

Slot size (L x W x H): 152X30X130 mm

Cord length: 0.85 m Voltage: 220-240 V Frequency: 50/60 Hz

Design specifications

Materials: Housing: metal/plastic (PC/ABS),

chrome plated top

Color(s): White, metal and red

© 2019 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

Issue date 2019-03-10 Version: 6.3.1

12 NC: 0000 000 00000

www.philips.com

