

PHILIPS

Potato masher

CP9745



to replace your current potato masher

With the masher accessory for the Philips hand blender you can mash potatoes silky smooth. Also other vegetables can be mashed or pureed.

Ease of using Philips spare parts

- Easily renew your product with original Philips parts

Highlights

Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.

Specifications

Replaceable part

Fits product types:: HR1640/0x, HR1641/0x, HR1642/0x, HR1643/0x, HR1644/0x, HR1646/0x, HR1647/0x, HR1670/9x, HR1671/9x, HR1672/9x, HR1673/9x, HR1674/9x, HR1675/9x, HR1676/9x, HR1677/9x

